

M10RDI

Intel Atom Mini ITX Motherboard
with Intel ICH10R Chipset

User's Manual

1st Ed – 11 January 2013

FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

Copyright Notice

Copyright 2013 Gigabyte Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

Disclaimer

Gigabyte Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Gigabyte Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Gigabyte Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Life Support Policy

Gigabyte Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Gigabyte Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

A Message to the Customer

Gigabyte Customer Services

Each and every Gigabyte's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Gigabyte device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Gigabyte has come to be known.

M10RDI

Your satisfaction is our primary concern. Here is a guide to Gigabyte's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.gigabyte.tw/>

If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Gigabyte's products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from Gigabyte's engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products. Please do not hesitate to call or e-mail us.

Product Warranty

Gigabyte warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase. This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Gigabyte, or which have been subject to misuse, abuse, accident or improper installation. Gigabyte assumes no liability under the terms of this warranty as a consequence of such events. Because of Gigabyte's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If any of Gigabyte's products is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details. If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, Gigabyte's products model name, hardware & BIOS revision number, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your good return more quickly.
4. Carefully pack the defective product, a complete Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Content

1. Getting Started	9
1.1 Safety Precautions	9
1.2 Packing List	9
1.3 Document Amendment History	10
1.4 System Specifications	12
1.5 Architecture Overview – Block Diagram	14
2. Hardware Configuration	15
2.1 Product Overview	16
2.2 Before you Proceed	18
2.3 Motherboard Overview	19
2.3.1 Placement Direction	19
2.3.2 Screw Holes	19
2.4 Setting Jumpers & Connectors	23
2.4.1 Serial Port Setting - RS232/422/485 (JRS1, JRS2, JRS3, JRS4)	23
2.4.2 Serial Port 1 Select - RS-232/422/485 (JCOM1)	24
2.4.3 Serial Port 3 RI Pin Signal Select – Ring/+5V/+12V (JCOM3)	25
2.4.4 Power Mode Select – AT or ATX (AT_CN)	26
2.4.5 Clear CMOS (CLR_CMOS)	26
2.4.6 System Fan Connector (SYS_FAN)	27
2.4.7 Serial Port 3 Connector (COM3)	27
2.4.8 Serial Port 4 Connector (COM4)	28
2.4.9 Serial Port 5 Connector (COM5)	28
2.4.10 Serial Port 5 Select - RS-232/422/485 (JCOM5)	29
2.4.11 Serial Port 6 Connector (COM6)	29
2.4.12 LVDS Connector (LVDS)	30
2.4.13 LCD Inverter Connector (BKL_CN)	31
2.4.14 Front Panel Connector (F_PANEL)	31
2.4.15 Front Panel Audio Connector (F_AUDIO).....	32
2.4.15.1 Signal Description – Audio connector (F_AUDIO)	32
2.4.16 Audio Amplifier Connector (SPK_OUT)	33
2.4.17 SATA Power (SATAPW_1)	33
2.4.18 SATA Power (SATAPW_2)	34
6 M10RDI User's Manual	

2.4.19 USB Connector (F_USB1)	34
2.4.20 USB Connector (F_USB2)	35
2.4.21 GPIO Connector (GPIO_CNT)	35
2.4.22 Low Pin Count Connector (LPC)	36
3. BIOS Setup	37
3.1 Introduction	38
3.2 Starting Setup	38
3.3 Using Setup	39
3.4 Getting Help	40
3.5 In Case of Problems	40
3.6 BIOS setup	41
3.6.1 Main Menu	41
3.6.1.1 System Date	41
3.6.1.2 System Time	41
3.6.2 Advanced BIOS settings	42
3.6.2.1 ACPI Settings	42
3.6.2.2 S5 RTC Wake settings	43
3.6.2.3 SATA Configuration	43
3.6.2.3 SATA Configuration	44
3.6.2.4 USB Configuration	45
3.6.2.5 F81214 Second Super IO Configuration	46
3.6.2.5.1 Serial Port 1 Configuration	46
3.6.2.5.2 Serial Port 2 Configuration	47
3.6.2.6 IT8783F Super IO Configuration	48
3.6.2.6.1 Serial Port 3 Configuration	49
3.6.2.6.2 Serial Port 4 Configuration	49
3.6.2.6.3 Serial Port 5 Configuration	50
3.6.2.6.4 Serial Port 6 Configuration	50
3.6.2.7 IT8783F H/W Monitor	51
3.6.3 Advanced Chipset Features	52
3.6.3.1 Intel IGD Configuration	53
3.6.4 Boot settings	54
3.6.5 Security	55
3.6.5.1 Administrator Password	55

M10RDI	
3.6.5.2 User Password	55
3.6.6 Save & Exit	56
3.6.6.1 Save Changes and Exit	56
3.6.6.2 Discard Changes and Exit	57
3.6.6.3 Save Changes and Reset	57
3.6.6.4 Discard Changes and Reset	57
3.6.6.5 Save Changes	57
3.6.6.6 Discard Changes	57
3.6.6.7 Restore Defaults	57
3.6.6.8 Save as user defaults	57
3.6.6.9 Restore user defaults	57
3.6.6.10 Boot override	57
4. Mechanical Drawing	58

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

Always note that improper disassembling action could cause damage to the motherboard. We suggest not removing the heat sink without correct instructions in any circumstance. If you really have to do this, please contact us for further support.

1.2 Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x M10RDI Mini-ITX Motherboard
- 1 x CD-ROM contains OS drivers/QIG/User's Manual
- 1 x COM cable
- 2 x SATA cable
- 2 x SATA Power Cable
- 1 x I/O shield

M10RDI

1.3 Document Amendment History

Revision	Date	Comment
1 st	January 2013	Initial Release

This manual describes in detail the Gigabyte Technology M10RDI Single Board.

We have tried to include as much information as possible but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to interface with M10RDI series or change the standard configurations. Whilst all the necessary information is available in this manual we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors concerning this manual and want to inform us of these, please contact our Customer Service department with the relevant details.


1.4 System Specifications

System Specifications	
System	
CPU	Onboard Intel® Atom™ D2550(N2800/N2600 for Option)
BIOS	AMI 16Mb SPI BIOS
System Chipset	Intel® ICH10R
I/O Chip	ITE8783+ FINTEK F81214
System Memory	2x 204-pin DDR3 SODIMM, up to 4GB (N2600 support 1 x DDR3 SODIMM only)
Watchdog Timer	H/W Reset : 1 to 255 sec/min per step (Option)
H/W Status Monitor	Monitoring temperature, voltage, and cooling fan status. Auto throttling control when CPU overheats
TPM	Infineon TPM1.2 SLB9635 (Optional)
Expansion	1x PCI 2 x mini-PCI-E connectors
Smart Fan Control	Yes
Display	
Chipset	Cedarview Integrated graphics
Dual Display	LVDS+VGA, VGA+HDMI, HDMI+LVDS
VGA	Max resolution: 1920 x 1200
HDMI	Max resolution: 1920 x 1200
LVDS	eDP to LVDS translator, Dual channel 18/24 bit Max resolution: 1920 x 1080
LVDS Backlight	Yes, through internal LVDS Backlight Connector
Audio	
Audio Codec	Azalia Realtek ALC269
Audio Interface	Mic-In, Line-In and Line-Out, speaker out
Audio Amplifier(W)	Build-in 2W Audio amplifier on chip
Ethernet	
Chipset	2 x Realtek 8111E
Ethernet Interface	10/100/1000 Gigabit Ethernet Compatible

I/O	
MIO	2 External(COM1, RS-232/422/485; COM2, RS-232), 4 Internal (COM3&5, RS-232 with 5V/12V selected by jumper, COM4&6, RS-232), 4 SATA II, 1 HDMI, 1 VGA, 1 LVDS, 2 LAN, 1 PS/2
USB	8 USB2.0 (4 Rear , 4 internal)
Back Panel I/O Port	
Back Panel I/O Port	1 DC-in Connector (4-pin) 1 VGA Port 1 HDMI Port 2 COM Ports 4 USB 2.0 Ports 2 LAN RJ45 Ports 1 Audio I/O (3 Jacks) 1 PS/2 Mini-Din (KB/MS support by external Y-cable)
Internal I/O Connector	
Internal I/O Connector	2 USB Connectors each supports 2 USB Ports 4 COM RS-232 Connectors 4 SATA II Connectors, RAID 0,1,5,10 supported 2 SATA Power Connectors 1 Front Panel Connector 1 Front Audio Connector 1 System Fan Connector 1 GPIO Connector 1 Mini PCI-E Connector full size for mSATA (PCIe1X for Option) 1 Mini PCI-E Connector half size for PCIe slot 1 Speaker-out L/R Connector 1 LVDS Connector 1 LVDS Backlight Connector 1 LPC Connector
Power	
Power Requirement	DC 12V
Power Type	AT / ATX mode (selectable by Jumper)
Power Connector	4-pin DC-in Power Connector, 4-pin ATX 12V Power Connector
Mechanical & Environmental	
Operating Temperature	0°C to 60°C (32°F to 140°F)
Operating Humidity	0% to 90% relative humidity, non-condensing
Size	6.69" x 6.69" (170 x 170 mm)
Weight	0.77 lbs (0.35 Kg)

1.5 Architecture Overview – Block Diagram

The following block diagram shows the architecture and main components of M10RDI



2. Hardware Configuration

2.1 Product Overview

M10RDI is designed to unleash the power of the new Intel® Atom™ processor D2000 / N2000 which supports the new revolutionary two-chip layout. The Intel® Cedarview processor also provides additional flexibility and upgradeability with two slots of single channel DDR3 memory at 1066 MHz supporting up to 4GB maximum.

2. With breakthrough low-power silicon, M10RDI can be used with a passive thermal solution based on the recommended boundary conditions.1

3. M10RDI represents a fundamental shift in system design—small, yet powerful enough to enable a big Internet experience for all audiences.

2.1.1 Platform Features and Benefits

- DirectX® 10.1 let you enjoy awesome graphics performance, stunning 3D visual effect and dynamic interactivity
- Memory support, integrated DDR3 memory controller
- Operating system support:
 - Microsoft Windows XP 32/64bit
 - Microsoft Windows 7 32/64bit

2.1.2 Key Architecture Features

- Supports Intel® Atom™ processor D2000 / N2000.series
 - Supports 2 lanes in each direction for N2000 processor and 4 lanes in each direction for D2000 processor (Gen 1 2.5gbps) per lane per direction point- to- point DMI interface.
 - Compatible with high speed DDR3-1066MHz
 - TDP: 16W
- Intel® HD Audio Technology
- Integrated Display Interfaces
 - HDMI
 - VGA
 - Dual Channel LVDS
- Doubles the transfer speed of SATA, running at speed up to 3.0Gb/s
- Provides 10/100/1000 Mbps solution to your network or broadband connection without having to buy an
- Onboard audio CODEC supports uncompromising DVD audio quality, bringing a move vivid sound experience and high-quality audio without having to buy advanced sound cards.

- Main Memory

M10RDI provides 2x 204-pin DDR3 SODIMM, up to 4GB (N2600 support 1 x DDR3 SODIMM only).

*SODIMM module.


Note:

(1) Please do not change any DDR SDRAM parameter in BIOS setup to increase your system's performance without acquiring technical information in advance.

(2) Static electricity can damage the electronic components of the computer or optional boards. Before starting these procedures, ensure that you are discharged of static electricity by touching a grounded metal object briefly.

(3) The Platform requires DDR3 SODIMMs to be populated starting with the SODIMM at the far end from the processor.

Here, SODIMM2 is situated at the far end from the processor.



M10RDI

- I/O
 - One PCI slot
 - Two Mini-PCIe sockets
 - Four SATA2 ports
 - Two 10/100/1000 Mbps Ethernet Controller
 - High Definition Audio
 - USB: USB 2.0/1.1, up to 8 ports
 - Hardware Monitor
- Fan control (Voltage, Temp)

2.2 Before you Proceed

Take note of the following precautions before you install motherboard components or change any motherboard settings.



Unplug the power cord from the wall socket before touching any component.

Use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, before handling components to avoid damaging them due to static electricity.

Hold components by the edges to avoid touching the ICs on them.

Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that came with the component.

Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

2.3 Motherboard Overview

Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it. Refer to the chassis documentation before installing the motherboard.




Make sure to unplug the power cord before installing or removing the motherboard. Failure to do so can cause you physical injury and damage motherboard components.

2.3.1 Placement Direction

When installing the motherboard, make sure that you place it into the chassis in the correct orientation. The edge with external ports goes to the rear part of the chassis as indicated in the image below.

2.3.2 Screw Holes

Place four (4) screws into the holes indicated by circles to secure the motherboard to the chassis.



Place this side towards the rear of the chassis.




Do not over tighten the screws! Doing so can damage the motherboard.

M10RDI

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.


Jumpers		
Label	Function	Note
JRS1/2/3/4	Serial Port 1 Setting – RS232/422/485	3 x 1 header, pitch 2.00 mm
JCOM1	Serial Port 1 Select - RS-232/422/485	3 x 2 header, pitch 2.00 mm
JCOM3	Serial Port 3 RI Pin Signal Select – Ring/+5V/+12V	3 x 2 header, pitch 2.54 mm
JCOM5	Serial Port 5 RI Pin Signal Select – Ring/+5V/+12V	3 x 2 header, pitch 2.54 mm
AT_CN	Power Mode Select – AT or ATX	3 x 1 header, pitch 2.00 mm
CLR_CMOS	Clear CMOS	2 x 1 header, pitch 2.54 mm
Connectors		
Label	Function	Note

M10RDI

ATX_12V	ATX 4pin DC12	
SODIMM1	DIMM 1 Slot DDR3	
SODIMM2	DIMM 2 Slot DDR3	
SYS_FAN	System Fan Connector	4 x 1 wafer, pitch 2.54mm
COM1	Serial Port 1 Connector	D-sub 9-pin, male
COM2	Serial Port 2 Connector	D-sub 9-pin, male
COM3	Serial Port 3 Connector	5 x 2 wafer, pitch 2.00 mm
COM4	Serial Port 4 Connector	5 x 2 wafer, pitch 2.00 mm
COM5	Serial Port 5 Connector	5 x 2 wafer, pitch 2.00 mm
COM6	Serial Port 6 Connector	5 x 2 wafer, pitch 2.00 mm
LVDS	LVDS Connector	20 x 2 wafer, pitch 1.25mm
BKL_CN	LCD Inverter Connector	5 x 1 wafer, pitch 2.00mm
USB_LAN1	USB+LAN1	
USB_LAN2	USB+LAN2	
KB_MS	PS/2 Keyboard & Mouse Connector	
HDMI	HDMI	
VGA	VGA Connector	
Min_PCIE1	Mini PCIE Connector 1	
Min_PCIE2	Mini PCIE Connector 2 for mSATA	
AUDIO	AUDIO Line-In/Line-Out/Mic-In	
PCI1	PCI Slot	
F_AUDIO	Front Panel Audio Connector	5 x 2 wafer, pitch 2.00 mm
SPK_OUT	Audio Amplifier Connector	4 x 1 wafer, pitch 2.00 mm
SATAII 1/2/3/4	Serial ATA Connector 1/2/3/4	
SATAPW_1	SATA Power 1	4 x 1 wafer, pitch 2.54mm
SATAPW_2	SATA Power 2 (Option)	4 x 1 wafer, pitch 2.54mm
F_USB1	USB Connector 1	5 x 2 wafer, pitch 2.54 mm
F_USB2	USB Connector 2	5 x 2 wafer, pitch 2.54 mm
GPIO_CNT	GPIO Connector	6 x 2 wafer, pitch 2.00 mm
LPC	Low Pin Count Connector	7 x 2 wafer, pitch 2.00 mm
F_PANEL	Front Panel Connector	5 x 2 wafer, pitch 2.54 mm
DC_IN	DC Power-In Connector	

2.4 Setting Jumpers & Connectors

2.4.1 Serial Port 1 Setting - RS232/422/485 (JRS1, JRS2, JRS3, JRS4)




***Default**

Pin	RS-232	RS-485	RS-422
1	DCD	TXD-	TXD-
2	RXD	TXD+	TXD+
3	TXD		RXD+
4	DTR		RXD-
5	GND	GND	GND

M10RDI


2.4.2 Serial Port 1 Select – RS232/422/485(JCOM1)



*Default

Signal	PIN	PIN	Signal
RXD232	1	2	RXD1
RXD422	3	4	RXD1
RXD485	5	6	RXD1

2.4.3 Serial Port 3 RI Pin Signal Select – Ring/+5V/+12V (JCOM3)




*Default

Signal	PIN	PIN	Signal
VCC	1	2	RI3-/5V/12
NRI3-	3	4	RI3-/5V/12
+12V	5	6	RI3-/5V/12

M10RDI


2.4.4 Power Mode Select – AT or ATX(AT_CN)



*Default

Signal	PIN
NC	3
PWR_F_BTN#	2
AT_PWR_F_BT	1



2.4.5 Clear CMOS(CLR_CMOS)



*Default



Signal	PIN
-RTCRST	1
GND	2

2.4.6 System Fan Connector (SYS_FAN)

Signal	PIN
GND	1
+12V	2
FANIO2	3
PWM Input	4



2.4.7 Serial Port 3 Connector (COM3)

Signal	PIN	PIN	Signal
NC	9	10	NRI3-
NCTS3-	7	8	NRTS3-
NDSR3-	5	6	GND
NDTR3-	3	4	NTXD3-
NRXD3-	1	2	ND3-



M10RDI

2.4.8 Serial Port 4 Connectot (COM4)


Signal	PIN	PIN	Signal
NC	9	10	NR14-
NCTS4-	7	8	NRTS4-
NDSR4-	5	6	GND
NDTR4-	3	4	NTXD4-
NRXD4-	1	2	NDCD4-

2.4.9 Serial Port 5 Connector (COM5)

Signal	PIN	PIN	Signal
NC	9	10	NR15-
NCTS5-	7	8	NRTS5-
NDSR5-	5	6	GND
NDTR5-	3	4	NTXD5-
NRXD5-	1	2	NDCD5-


2.4.10 Serial Port 5 RI Pin Signal Select – Ring/+5V/+12V (JCOM5)



*Default

Signal	PIN	PIN	Signal
VCC	1	2	RI3-/5V/12
NRI3-	3	4	RI3-/5V/12
+12V	5	6	RI3-/5V/12


2.4.6.11 Serial Port 6 Connector (COM6)



Signal	PIN	PIN	Signal
NC	9	10	NRI5-
NCTS5-	7	8	NRTS5-
NDSR5-	5	6	GND
NDTR5-	3	4	NTXD5-
NRXD5-	1	2	NDCD5-


M10RDI

2.4.12 LVDS Connector (LVDS)





Signal	PIN	PIN	Signal
VCC3	1	2	VCC
VCC3	3	4	VCC
SCL1	5	6	SDA1
GND	7	8	GND
+RXO1_C	9	10	+RXO0_C
-RXO1_C	11	12	-RXO0_C
GND	13	14	GND
+RXO3_C	15	16	+RXO2_C
-RXO3_C	17	18	-RXO2_C
GND	19	20	GND
+RXE1_C	21	22	+RXE0_C
-RXE1_C	23	24	-RXE0_C
GND	25	26	GND
+RXE3_C	27	28	+RXE2_C
-RXE3_C	29	30	-RXE2_C
GND	31	32	GND
+RXECLKE_C	33	34	+RXECLKO_C
-RXECLKE_C	35	36	-RXECLKO_C
GND	37	38	GND
+12V	39	40	+12V

2.4.13 LCD Inverter Connector (BKL_CN)



Signal	PIN
+12V	5
GND	4
BKLTEN	3
BKLTCTL	2
VCC	1


2.4.14 Front Panel Connector (F_PANEL)



Signal	PIN	PIN	Signal
-INTRUDER	9	10	NC
-SYS_RST	7	8	GND
GND	5	6	PWR BTN#
SATALED-	3	4	GND
HD+	1	2	MPD+

M10RDI



2.3.15 Front Panel Audio Connector (F_AUDIO)



2.3.15.1 Signal Description – Audio connector (F_AUDIO)



Signal	Signal Description
MIC_L	Front panel microphone left channel
MIC_R	Front panel microphone right channel
-ACZ_DET	Active low when an Intel® HD Audio dongle is connected
HPOUT_R_H	Front panel headphone right channel
HPOUT_L_H	Front panel headphone left channel
SRTN1	Jack detection for front panel microphone
SRTN2	Jack detection for front panel headphone
FAUDIO_JD	Front panel jack detect

2.4.16 Audio Amplifier Connector (SPK_OUT)

Signal	PIN
OUT_L+	4
OUT_L-	3
OUT_R-	2
OUT_R+	1


2.4.17 SATA Power (SATAPW_1)


Signal	PIN
+12V	1
GND	2
GND	3
VCC	4

M10RDI



2.4.18 SATA Power (SATAPW_2)



2.4.19 USB Connector (F_USB1)





2.4.20 USB Connector (F_USB2)



Signal	PIN	PIN	Signal
USB Power	2	1	USB Power
USBP0-	4	3	USBP1-
USBP0+	6	5	USBP1+
GND	8	7	GND
GND	10	9	NC


2.4.21 GPIO Connector (GPIO_CNT)



Signal	PIN	PIN	Signal
VCC	11	12	GND
SMBCLK	9	10	SMBDATA
SOGP0_	7	8	SOGPI_4
SOGP0_	5	6	SOGPI_3
SOGP0_	3	4	SOGPI_2
SOGP0_	1	2	SOGPI_1

M10RDI

2.4.22 Low Pin Connector (LPC)



Signal	PIN	PIN	Signal
-LDRQ1	13	14	5VDUAL
GND	11	12	VCC
GND	9	10	SERIRQ
LPC_CLK	7	8	LAD3
-LFRAME	5	6	LAD2
-PFMRST	3	4	LAD1
VCC3	1	2	LAD0

3.BIOS Setup

3.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

3.2 Starting Setup

The AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing immediately after switching the system on, or

By pressing the key when the following message appears briefly at the bottom of the screen during the POST (Power On Self Test).

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

Press F1 to Continue, DEL to enter SETUP

3.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑	Move to previous item
↓	Move to next item
←	Move to the item in the left hand
→	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
PgUp key	Increase the numeric value or make changes
PgDn key	Decrease the numeric value or make changes
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Previous Values.
F3 key	Optimized defaults
F4 key	Save & Exit Setup

Navigating Through The Menu Bar

Use the left and right arrow keys to choose the menu you want to be in.

Note: Some of the navigation keys differ from one screen to another

To Display a Sub Menu

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “>” pointer marks all sub menus.

3.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the F1 key again.

3.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the CMOS settings which resets your system to its defaults.

The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both AMI and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

3.6 BIOS setup

Once you enter the AMI BIOS CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



3.6.1.1 System Date

Use the system Date option to set the system date. Manually enter the day, month and year.

3.6.1.2 System Time


Use the system time option to set the system time. Manually enter the hours, minutes and seconds.

Note: BIOS setup screens shown in this chapter are for reference only, and may not exactly match what you see on your screen. Visit the Gigabyte website (www.gigabyte.tw) to download the latest product and BIOS information.

M10RDI


3.6.2 Advanced BIOS settings

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




3.6.2.1 ACPI Settings

You can use this item to set up ACPI Configuration




Item	Options	Description
ACPI Sleep State	Suspend Disabled S1 (CPU Stop Clock), S3 (Suspend to RAM) [Default]	Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed

3.6.2.2 S5 RTC Wake settings




Item	Options	Description
Wake system with Fixed Time	Enabled Disabled[Default]	Enable or disable System wake on alarm event. When enabled, System will wake on the hr::min::sec specified.
Wake system with Dynamic Time	Enabled Disabled[Default]	Enable or disable wake on alarm event. When enabled, System will wake on the current time + Increase minutes (s)

3.6.2.3 SATA Configuration




M10RDI



Item	Options	Description
SATA Mode	Disabled IDE Mode[Default] ACHI Mode RAID Mode	Select IDE/ AHCI/ RAID Mode.
Serial-ATA Controller 0	Enabled Disabled Compatible[Default]	Enable/ Disable Serial ATA Controller 0.
Serial-ATA Controller 1	Enabled[Default] Disabled	Enable/ Disable Serial ATA Controller 1.
eSATA Port Support	Enabled Disabled[Default]	eSATA Port Support.

3.6.2.4 USB Configuration

The USB configuration menu is used to read USB configuration information and configure USB.




Item	Options	Description
Legacy USB support	Enabled [Default] Disabled Auto	Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
USB_DRIVE 1.00	Auto [Default] Floppy Forced FDD Hard Disk CD-ROM	Mass storage device emulation type. 'AUTO' enumerates devices less than 530MB as floppies. Forced FDD option can be used to force HDD formatted drive to boot as FDD (e.g. ZIP drive).

M10RDI


3.6.2.5 F81214 Second Super IO Configuration

You can use this item to set up or change the F81214 Second Super IO configuration for serial ports. Please refer to 3.6.2.5.1 and 3.6.2.5.2 for more information.




Item	Description
Serial Port 1 Configuration	Set Parameters of Serial Port 1 (COM1).
Serial Port 2 Configuration	Set Parameters of Serial Port 2 (COM2).

3.6.2.5.1 Serial Port 1 Configuration



Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).

3.6.2.5.2 Serial Port 2 Configuration




Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).

M10RDI

3.6.2.6 IT8783F Super IO Configuration


You can use this item to set up or change the IT8783F Super IO configuration for serial ports.

Please refer to 3.6.2.6.1, 3.6.2.6.2, 3.6.2.6.3 and 3.6.2.6.4 for more information.




Item	Description
Serial Port 3 Configuration	Set Parameters of Serial Port 3 (COM3)
Serial Port 4 Configuration	Set Parameters of Serial Port 4 (COM4)
Serial Port 5 Configuration	Set Parameters of Serial Port 5 (COM5)
Serial Port 6 Configuration	Set Parameters of Serial Port 6 (COM6)

3.6.2.6.1 Serial Port 3 Configuration



Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).


3.6.2.6.2 Serial Port 4 Configuration



Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).


M10RDI

3.6.2.6.3 Serial Port 5 Configuration



Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).


3.6.2.6.4 Serial Port 6 Configuration



Item	Options	Description
Serial Port	Enabled Disabled[Default]	Enable or Disable Serial Port (COM).


3.6.2.7 IT8783F H/W Monitor

The H/W Monitor shows the operating temperature, fan speeds and system voltages.




M10RDI

3.6.3 Advanced Chipset Features



Item	Options	Description
Restore AC Power Loss	Power Off[Default] Power On Last State	Specify what state to go to when power is re-applied after a power failure (G3 state).
Azalia HD Audio	Enabled[Default] Disabled	Enable / Disable Azalia HD Audio.
Onboard LAN1	Enabled[Default] Disabled	Enable or Disable the PCI Express Ports in the Chipset.
LAN PXE ROM	Enabled[Default] Disabled	Enable or Disable Boot Option for Legacy Network Devices.
Onboard LAN2	Enabled[Default] Disabled	Enable or Disable the PCI Express Ports in the Chipset.
LAN PXE ROM	Enabled[Default] Disabled	Enable or Disable Boot Option for Legacy Network Devices.
Mini PCIE1	Enabled[Default] Disabled	Enable or Disable the PCI Express Ports in the Chipset.
Mini PCIE2	Enabled[Default] Disabled	Enable or Disable the PCI Express Ports in the Chipset.
Intel IGD Configuration	Config Intel IGD Settings.	


3.6.3.1 Intel IGD Configuration



Item	Options	Description
IGFX – Boot Type	VBIOS Default[Default] CRT EFP	Select the Video Device which will be activated during POST. This has no effect if external graphics present.
Fixed Graphics Memory Size	128MB 256MB[Default]	Configure Fixed Graphics Memory Size.
LVDS Backlight PWM	0% 25% 50% 75% 100% [Default]	LVDS Backlight PWM Configuration.
Panel ID	1024x768 1ch 24bit[Default] 800x600 1ch 18bit 1024x768 1ch 18bit 1024x600 1ch 18bit 1280x800 1ch 18bit 1920x1200 2ch 24bit 640x480 1ch 18bit 800x480 1ch 18bit 1280x1024 2ch 24bit 1440x900 2ch 18bit 1600x1200 2ch 24bit 1366x768 1ch 24bit 1920x1080 2ch 24bit 1680x1050 2ch 24bit	Panel ID.

M10RDI


3.6.4 Boot settings



Item	Options	Description
Setup Prompt Timeout	1~65535	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	On [Default] Off	Select the keyboard NumLock state
Quiet Boot	Enabled Disabled [Default]	Enables or Disables Quiet Boot Option
Fast Boot	Enabled [Default] Disabled	Enables or Disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options
PCI ROM Priority	EFI Compatible ROM [Default] Legacy ROM	In case of multiple Option ROMs(Legacy and EFI Compatible),specifies what PCI Option ROM to launch.
Boot Option #1/2/3	Sets the system boot order	

3.6.5 Security

Use the Security menu to set system and user password.



3.6.5.1 Administrator Password


This setting specifies a password that must be entered to access the BIOS Setup Utility. If only the Administrator's password is set, then this only limits access to the BIOS setup program and is only asked for when entering the BIOS setup program. By default, no password is specified.

3.6.5.2 User Password

This setting specifies a password that must be entered to access the BIOS Setup Utility or to boot the system. If only the User's password is set, then this is a power on password and must be entered to boot or enter the BIOS setup program. In the BIOS setup program, the User will have Administrator rights. By default, no password is specified.


M10RDI

3.6.6 Save & Exit



3.6.6.1 Save Changes and Exit

Use the save changes and reset option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.



3.6.6.2 Discard Changes and Exit

Use the Discard changes and Exit option to exit the system without saving the changes made to the BIOS configuration setup program.

3.6.6.3 Save Changes and Reset

Any changes made to BIOS settings are stored in NVRAM. The setup program then exits and reboots the controller.

3.6.6.4 Discard Changes and Reset

Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The setup program then exits and reboots the controller.

3.6.6.5 Save Changes

Changes made to BIOS settings during this session are committed to NVRAM. The setup program remains active, allowing further changes.

3.6.6.6 Discard Changes

Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The BIOS setup continues to be active.

3.6.6.7 Restore Defaults

This option restores all BIOS settings to the factory default. This option is useful if the controller exhibits unpredictable behavior due to an incorrect or inappropriate BIOS setting.

3.6.6.8 Save as user defaults

This option saves a copy of the current BIOS settings as the User Defaults. This option is useful for preserving custom BIOS setup configurations.

3.6.6.9 Restore user defaults

This option restores all BIOS settings to the user defaults. This option is useful for restoring previously preserved custom BIOS setup configurations.

3.6.6.10 Boot override

This option lists all possible bootable devices and allows the user to override the **Boot Option Priorities** list for the current boot. If no changes have been made to the BIOS setup options, the system will continue booting to the selected device without first rebooting. If BIOS setup options have been changed and saved, a reboot will be required and the boot override selection will not be valid.

Option Priorities list for the current boot. If no changes have been made to the BIOS setup options, the system will continue booting to the selected device without first rebooting. If BIOS setup options have been changed and saved, a reboot will be required and the boot override selection will not be valid.

M10RDI

4. Mechanical Drawing

