GA-880GMA-UD2H

AM3 socket motherboard for AMD Phenom[™] II processor/AMD Athlon[™] II processor

User's Manual

Rev. 2201

(Sump) Dele <u>Jun. 7, 2010</u> Name : <u>Timmy Huang</u>	Manufacturer/Importer Syname - Tuenny Futang	EN 60335 Safety of household and similar EN 50091-1 General and Safety requirements for electrical appliances uninterruptible power systems (UPS)	EN6005 Statey requirements for makes operated 32 EN 60050 Statey for information technology equipment accurate and the state of th	The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 200585EC	CE marking (EC conformity marking)	□ DAVIDE BASS Called distuision systems: Equipment □ part 18 for revealing and/or distuision form □ part 12 sound and television signals	8 EV 5502 Linita and methods of masuumment of mals obtainance on conservatives of information technology equipment	EN 5522 Invision receives and associated explorant receives and associated explorant explorant	u En souris en internetos or mesosutement de En souri e-c announce y explanost tools and service repeatous of mis distuibuted cataloctificatio d appliancies tools and service repeatous fluorescent lange and luminaries	I inite and mathods of measurement	portable post and similar electricial EN 50082-2 Generic immunity standard Part 2 apparatus apparatus	EN 50014-1 Limits and methods of measurement EN 50002-1 Generic immunity standard Part 1: of radio distributive characteristics of Residual commercial and light industry	E EK 65013 Limits and measurement 8 EK 5624 Information Technology of initia citatamena constraintiation of evaluation technology based and associated devaluation of devaluation of devaluation of measurements	Instateal, scientist, and motical (ISM) ISEN 61000-25 Distributions in a napply preparity autod high frequency equipment electrical equipment "Voltage fluctuations"	EN SS011 Limits and methods of measurement IS EN 61000-3-2 Disturbances in supply systems caused of radio disturbance characteristics of	(reference to the specification under which conformity is declared) in accordances with 2004/10EEC EMC Directive	Motherboard GA-380GMA-UD2H	Bullenkoppel 16, 22047 Hamburg, Germany declare that the product (description of the accusate seaders) leadation to which it index1	We, Machitacturer/importer G.B.T. Technology Trading GMDH
	Date: <u>JUB. 7, 2010</u>	Signature: <u>Erte Ett</u>	Representative Person's Name: <u>ERIC LU</u>	including that may cause undesired operation.	cause harmful and (2) this device must accept any inference received,	This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not	(a), Class & Ligital Device Supplementary Information:	FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109	Conforms to the following specifications:	Model Number: GA-880GMA-UD2H	Product Name: Motherboard	hereby declares that the product	City of Industry, CA 91748 Phone/Fax No: (818) 854-9338/ (818) 854-9339	Address: 17358 Railroad Street	Responsible Party Name: G.B.T. INC. (U.S.A.)			Per FCC Part 2 Section 2.1077(a)	DECLARATION OF CONFORMITY

Copyright

© 2010 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved.

The trademarks mentioned in this manual are legally registered to their respective owners.

Disclaimer

Information in this manual is protected by copyright laws and is the property of GIGABYTE. Changes to the specifications and features in this manual may be made by GIGABYTE without prior notice. No part of this manual may be reproduced, copied, translated, transmitted, or published in any form or by any means without GIGABYTE's prior written permission.

Documentation Classifications

In order to assist in the use of this product, GIGABYTE provides the following types of documentations:

- For quick set-up of the product, read the Quick Installation Guide included with the product.
- For detailed product information, carefully read the User's Manual.
- For instructions on how to use GIGABYTE's unique features, read or download the information on/from the Support&Downloads\Motherboard\Technology Guide page on our website.

For product-related information, check on our website at: http://www.gigabyte.com

Identifying Your Motherboard Revision

The revision number on your motherboard looks like this: "REV: X.X." For example, "REV: 1.0" means the revision of the motherboard is 1.0. Check your motherboard revision before updating motherboard BIOS, drivers, or when looking for technical information.

Example:




Table of Contents

Box Conte	nts		6
Optional It	ems		6
GA-880GN	/A-UD	2H Motherboard Layout	7
GA-880GN	/A-UD	2H Motherboard Block Diagram	8
Chapter 1	Hardv	vare Installation	9
	1-1	Installation Precautions	9
	1-2	Product Specifications	10
	1-3	Installing the CPU and CPU Cooler	13
	1-3	-1 Installing the CPU	.13
	1-3	-2 Installing the CPU Cooler	.15
	1-4	Installing the Memory	16
	1-4	-1 Dual Channel Memory Configuration	.16
	1-4	-2 Installing a Memory	.17
	1-5	Installing an Expansion Card	
	1-6	Setup of the ATI Hybrid CrossFireX [™] Configuration	19
	1-7	Back Panel Connectors	20
	1-8	Internal Connectors	23
Chapter 2	BIOS	Setup	33
	2-1	Startup Screen	34
	2-2	The Main Menu	36
	2-3	MB Intelligent Tweaker(M.I.T.)	38
	2-4	Standard CMOS Features	45
	2-5	Advanced BIOS Features	47
	2-6	Integrated Peripherals	49
	2-7	Power Management Setup	52
	2-8	PnP/PCI Configurations	54
	2-9	PC Health Status	55
	2-10	Load Fail-Safe Defaults	57
	2-11	Load Optimized Defaults	57
	2-12	Set Supervisor/User Password	
	2-13	Save & Exit Setup	59
	2-14	Exit Without Saving	59

Chapter 3	Drive	s Instal	lation	61
	3-1	Installing	g Chipset Drivers	61
	3-2	Applicat	ion Software	62
	3-3	Technic	al Manuals	62
	3-4	Contact		63
	3-5	System		63
	3-6	Downloa	ad Center	64
	3-7	New Uti	lities	64
Chapter 4	Uniqu	e Featu	res	65
	4-1		Recovery2	
	4-2	•	pdate Utilities	
	4-2	1 Upd	ating the BIOS with the Q-Flash Utility	68
	4-2	2 Upd	ating the BIOS with the @BIOS Utility	71
	4-3	EasyTu	ne 6	72
	4-4	Easy Er	nergy Saver	73
	4-5	Q-Share		75
	4-6	SMART	Recovery	76
	4-7	Auto Gr	een	77
Chapter 5	Appe	dix		79
	5-1	Configu	ring SATA Hard Drive(s)	79
	5-1	1 Con	figuring AMD SB850 SATA Controller	79
	5-1	2 Mak	ing a SATA RAID/AHCI Driver Diskette	85
	5-1	3 Insta	alling the SATA RAID/AHCI Driver and Operating System	87
	5-2	Configu	ring Audio Input and Output	91
	5-2		figuring 2/4/5.1/7.1-Channel Audio	
	5-2		figuring S/PDIF In/Out	
	5-2		bling the Dolby Home Theater Function	
	5-2 5-2		figuring Microphone Recording	
	5-3		shooting	
	5-3		-	
	5-3			
	5-4		0	
	5-3	2 Trou	uently Asked Questions Ibleshooting Procedure ory Statements	100

Box Contents

- GA-880GMA-UD2H motherboard
- Motherboard driver disk
- ☑ User's Manual
- Quick Installation Guide
- ☑ One IDE cable
- Two SATA cables
- ☑ I/O Shield





- The box contents above are for reference only and the actual items shall depend on the product package you obtain.
 The box contents are subject to change without notice.
- The motherboard image is for reference only.

Optional Items

- □ Floppy disk drive cable (Part No. 12CF1-1FD001-7*R)
- 2-port USB 2.0 bracket (Part No. 12CR1-1UB030-5*R)
- □ 2-port IEEE 1394a bracket (Part No. 12CF1-1IE008-0*R)
- □ 2-port SATA power cable (Part No. 12CF1-2SERPW-0*R)
- S/PDIF In and Out cable (Part No. 12CR1-1SPINO-1*R)
- COM port cable (Part No. 12CF1-1CM001-3*R)

GA-880GMA-UD2H Motherboard Layout





- (Note 1) For optimum performance, if only one PCI Express graphics card is to be installed, be sure to install it in the PCIEX16 slot.
- (Note 2) Simultaneous output for DVI-D and HDMI is not supported.

Chapter 1 Hardware Installation

1-1 Installation Precautions

The motherboard contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Prior to installation, carefully read the user's manual and follow these procedures:

- Prior to installation, do not remove or break motherboard S/N (Serial Number) sticker or warranty sticker provided by your dealer. These stickers are required for warranty validation.
- Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components.
- When connecting hardware components to the internal connectors on the motherboard, make sure they are connected tightly and securely.
- When handling the motherboard, avoid touching any metal leads or connectors.
- It is best to wear an electrostatic discharge (ESD) wrist strap when handling electronic components such as a motherboard, CPU or memory. If you do not have an ESD wrist strap, keep your hands dry and first touch a metal object to eliminate static electricity.
- Prior to installing the motherboard, please have it on top of an antistatic pad or within an electrostatic shielding container.
- Before unplugging the power supply cable from the motherboard, make sure the power supply has been turned off.
- Before turning on the power, make sure the power supply voltage has been set according to the local voltage standard.
- Before using the product, please verify that all cables and power connectors of your hardware components are connected.
- To prevent damage to the motherboard, do not allow screws to come in contact with the motherboard circuit or its components.
- Make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
- Do not place the computer system on an uneven surface.
- Do not place the computer system in a high-temperature environment.
- Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
- If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.

1-2 Product Specifications

CPU •	Support for AM3 processors: AMD Phenom [™] II processor/ AMD Athlon [™] II processor (Go to GIGABYTE's website for the latest CPU support list.)
Whyper Transport Bus •	5200 MT/s
Chipset +	North Bridge: AMD 880G South Bridge: AMD SB850
Memory •	4 x 1.5V DDR3 DIMM sockets supporting up to 16 GB of system memory (Note 1) Dual channel memory architecture Support for DDR3 1800(O.C.)/1333/1066 MHz memory modules (Go to GIGABYTE's website for the latest supported memory speeds and memory modules.)
Onboard Graphics •	Integrated in the North Bridge: - 1 x D-Sub port - 1 x DVI-D port ^{(Note 2) (Note 3)} - 1 x HDMI port ^(Note 3)
Audio Audio	Realtek ALC892 codec High Definition Audio 2/4/5.1/7.1-channel Support for Dolby [®] Home Theater Support for S/PDIF In/Out Support for CD In
	1 x Realtek RTL8111D/E chip (10/100/1000 Mbit)
Expansion Slots	1 x PCI Express x16 slot, running at x16 (PCIEX16) (Note 4) 1 x PCI Express x16 slot, running at x4 (PCIEX4) 1 x PCI Express x1 slot (All PCI Express slots conform to PCI Express 2.0 standard.) 1 x PCI slot
Multi-Graphics	Support for ATI Hybrid CrossFireX [™] technology
Storage Interface	 South Bridge: 5 x SATA 6Gb/s connectors (SATA3_0~SATA3_4) supporting up to 5 SATA 6Gb/s devices 1 x eSATA 3Gb/s connector on the back panel supporting up to 1 SATA 3Gb/s device Support for SATA RAID 0, RAID 1, RAID 5, RAID 10, and JBOD JMicron JMB368 chip: 1 x IDE connector supporting ATA-133/100/66/33 and up to 2 IDE devices
•	iTE IT8720 chip: - 1 x floppy disk drive connector supporting up to 1 floppy disk drive

USB	South Bridge:
	- Up to 10 USB 2.0/1.1 ports (4 on the back panel, 6 via the USB brackets
	connected to the internal USB headers)
	 NEC D720200F1 chip:
	- Up to 2 USB 3.0/2.0 ports on the back panel
آ <u>ده</u> IEEE 1394	• T.I. TSB43AB23 chip:
	 Up to 2 IEEE 1394a ports (1 on the back panel, 1 via the IEEE 1394a
	bracket connected to the internal IEEE 1394a header)
	 1 x 24-pin ATX main power connector
Connectors	 1 x 8-pin ATX 12V power connector
	1 x floppy disk drive connector
	1 x IDE connector
	 5 x SATA 6Gb/s connectors
	1 x CPU fan header
	1 x system fan header
	 1 x front panel header
	 1 x front panel audio header
	1 x CD In connector
	 1 x S/PDIF In/Out header
	• 3 x USB 2.0/1.1 headers
	1 x IEEE 1394a header
	1 x serial port header
	1 x clearing CMOS jumper
Back Panel	 1 x PS/2 keyboard port or PS/2 mouse port
Connectors	 1 x D-Sub port
	 1 x DVI-D port^(Note 2) (Note 3)
	 1 x HDMI port^(Note 3)
	 1 x optical S/PDIF Out connector
	 1 x IEEE 1394a port
	 4 x USB 2.0/1.1 ports
	 1 x eSATA 3Gb/s connector
	• 2 x USB 3.0/2.0 ports
	• 1 x RJ-45 port
	6 x audio jacks (Center/Subwoofer Speaker Out/Rear Speaker Out/
	Side Speaker Out/Line In/Line Out/Microphone)
I/O Controller	iTE IT8720 chip

Hardware Monitor	• 5	System voltage detection
	• 0	CPU/System temperature detection
	• 0	CPU/System fan speed detection
	• 0	CPU overheating warning
	• 0	CPU/System fan fail warning
	• 0	CPU/System fan speed control (Note 5)
🐑 BIOS	• 2	x 8 Mbit flash
	+ L	Jse of licensed AWARD BIOS
	• 5	Support for DualBIOS™
	• F	PnP 1.0a, DMI 2.0, SM BIOS 2.4, ACPI 1.0b
Unique Features	• 5	Support for @BIOS
	• 5	Support for Q-Flash
	• 5	Support for Xpress BIOS Rescue
	• 5	Support for Download Center
	• 5	Support for Xpress Install
	• 5	Support for Xpress Recovery2
	• 5	Support for EasyTune (Note 6)
	• 5	Support for Easy Energy Saver
	• 5	Support for Smart Recovery
	• 5	Support for Auto Green
	• 5	Support for ON/OFF Charge
	• 5	Support for Q-Share
Bundled Software	• N	Iorton Internet Security (OEM version)
Operating System	• S	Support for Microsoft® Windows® 7/Vista/XP
Form Factor	• N	licro ATX Form Factor; 24.4cm x 24.4cm

- (Note 1) Due to Windows 32-bit operating system limitation, when more than 4 GB of physical memory is installed, the actual memory size displayed will be less than 4 GB.
- (Note 2) The DVI-D port does not support D-Sub connection by adapter.
- (Note 3) Simultaneous output for DVI-D and HDMI is not supported.
- (Note 4) For optimum performance, if only one PCI Express graphics card is to be installed, be sure to install it in the PCIEX16 slot.
- (Note 5) Whether the CPU/system fan speed control function is supported will depend on the CPU/system cooler you install.
- (Note 6) Available functions in EasyTune may differ by motherboard model.

1-3 Installing the CPU and CPU Cooler




Read the following guidelines before you begin to install the CPU:

- Make sure that the motherboard supports the CPU.
 (Go to GIGABYTE's website for the latest CPU support list.)
- Always turn off the computer and unplug the power cord from the power outlet before installing the CPU to prevent hardware damage.
- Locate the pin one of the CPU. The CPU cannot be inserted if oriented incorrectly. (Or you may locate the notches on both sides of the CPU and alignment keys on the CPU socket.)
- Apply an even and thin layer of thermal grease on the surface of the CPU.
- Do not turn on the computer if the CPU cooler is not installed, otherwise overheating and damage of the CPU may occur.
- Set the CPU host frequency in accordance with the CPU specifications. It is not recommended
 that the system bus frequency be set beyond hardware specifications since it does not meet the
 standard requirements for the peripherals. If you wish to set the frequency beyond the standard
 specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc.

1-3-1 Installing the CPU


A. Locate the pin one (denoted by a small triangle) of the CPU socket and the CPU.



B. Follow the steps below to correctly install the CPU into the motherboard CPU socket.



- Before installing the CPU, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the CPU.
- Do not force the CPU into the CPU socket. The CPU cannot fit in if oriented incorrectly. Adjust the CPU orientation if this occurs.







Step 2:

Align the CPU pin one (small triangle marking) with the triangle mark on the CPU socket and gently insert the CPU into the socket. Make sure that the CPU pins fit perfectly into their holes. Once the CPU is positioned into its socket, place one finger down on the middle of the CPU, lowering the locking lever and latching it into the fully locked position.

1-3-2 Installing the CPU Cooler

Follow the steps below to correctly install the CPU cooler on the CPU. (The following procedure uses the GIGABYTE cooler as the example.)



Step 1:

Apply an even and thin layer of thermal grease on the surface of the installed CPU.



Step 3:

Hook the CPU cooler clip to the mounting lug on one side of the retention frame. On the other side,push straight down on the the CPU cooler clip to hook it to the mounting lug on the retention frame.



Step 2: Place the CPU cooler on the CPU.





Turn the cam handle from the left side to the right side (as the picture above shows) to lock into place. (Refer to your CPU cooler installation manual for instructions on installing the cooler.)



Step 5:

Finally, attach the power connector of the CPU cooler to the CPU fan header (CPU_FAN) on the motherboard.

Use extreme care when removing the CPU cooler because the thermal grease/tape between the CPU cooler and CPU may adhere to the CPU. Inadequately removing the CPU cooler may damage the CPU.

1-4 Installing the Memory



Read the following guidelines before you begin to install the memory:

• Make sure that the motherboard supports the memory. It is recommended that memory of the same capacity, brand, speed, and chips be used.

(Go to GIGABYTE's website for the latest supported memory speeds and memory modules.)


- Always turn off the computer and unplug the power cord from the power outlet before installing the memory to prevent hardware damage.
- Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction.

1-4-1 Dual Channel Memory Configuration

This motherboard provides four DDR3 memory sockets and supports Dual Channel Technology. After the memory is installed, the BIOS will automatically detect the specifications and capacity of the memory. Enabling Dual Channel memory mode will double the original memory bandwidth.

The four DDR3 memory sockets are divided into two channels and each channel has two memory sockets as following:

- ▶ Channel 0: DDR3_1, DDR3_2
- ► Channel 1: DDR3_3, DDR3_4



▶ Dual Channel Memory Configurations Table

DDR3_1	DDR3_2	DDR3_3	DDR3_4
DS/SS		DS/SS	
	DS/SS		DS/SS
DS/SS	DS/SS	DS/SS	DS/SS
	DS/SS	DS/SS DS/SS	DS/SS DS/SS DS/SS

(SS=Single-Sided, DS=Double-Sided, "- -"=No Memory)

Due to CPU limitations, read the following guidelines before installing the memory in Dual Channel mode.


- 1. Dual Channel mode cannot be enabled if only one DDR3 memory module is installed.
- When enabling Dual Channel mode with two or four memory modules, it is recommended that memory of the same capacity, brand, speed, and chips be used and installed in the same colored DDR3 sockets for optimum performance.

1-4-2 Installing a Memory




Before installing a memory module, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the memory module.

DDR3 and DDR2 DIMMs are not compatible to each other or DDR DIMMs. Be sure to install DDR3 DIMMs on this motherboard.



A DDR3 memory module has a notch, so it can only fit in one direction. Follow the steps below to correctly install your memory modules in the memory sockets.



Step 1:

Note the orientation of the memory module. Spread the retaining clips at both ends of the memory socket. Place the memory module on the socket. As indicated in the picture on the left, place your fingers on the top edge of the memory, push down on the memory and insert it vertically into the memory socket.



Step 2:


The clips at both ends of the socket will snap into place when the memory module is securely inserted.

1-5 Installing an Expansion Card



Read the following guidelines before you begin to install an expansion card:

- Make sure the motherboard supports the expansion card. Carefully read the manual that came with your expansion card.
- Always turn off the computer and unplug the power cord from the power outlet before installing an expansion card to prevent hardware damage.



Follow the steps below to correctly install your expansion card in the expansion slot.

- 1. Locate an expansion slot that supports your card. Remove the metal slot cover from the chassis back panel.
- 2. Align the card with the slot, and press down on the card until it is fully seated in the slot.
- 3. Make sure the metal contacts on the card are completely inserted into the slot.
- 4. Secure the card's metal bracket to the chassis back panel with a screw.
- 5. After installing all expansion cards, replace the chassis cover(s).
- Turn on your computer. If necessary, go to BIOS Setup to make any required BIOS changes for your expansion card(s).
- 7. Install the driver provided with the expansion card in your operating system.

Example: Installing and Removing a PCI Express Graphics Card:



• Installing a Graphics Card:

Gently push down on the top edge of the card until it is fully inserted into the PCI Express slot. Make sure the card is securely seated in the slot and does not rock.



Removing the Card from the PCIEX16 Slot: Gently push back on the lever on the slot and then lift the card straight out from the slot.



Removing the Card from the PCIEX4 Slot: Press the white latch at the end of the PCI Express slot to release the card and then pull the card straight up from the slot.

1-6 Setup of the ATI Hybrid CrossFireX[™] Configuration

Combining the onboard GPU with a discrete graphics card, ATI Hybrid CrossFireX can provide significantly advanced display performance for AMD platform. Read the following instructions on configuring an ATI Hybrid CrossFireX system.

A. System Requirements

- Windows 7, Vista, or Windows XP^(Note 1) operating system
- An ATI Hybrid CrossFireX-supported motherboard and correct driver
- An ATI Hybrid CrossFireX-supported graphics card (Note 2)

B. Connecting the Graphics Cards

Step 1:

Observe the steps in "1-5 Installing an Expansion Card" and install an ATI Hybrid CrossFireX-supported graphics card on the PCI Express slot.

Step 2:

Plug the display cable into the onboard graphics port on the back panel.

C. BIOS Setup

Enter BIOS Setup to set the following items under the Advanced BIOS Features menu:

- Set Internal Graphics Mode to UMA. (Note 3)
- Set UMA Frame Buffer Size to 256MB or 512MB. (Note 3)
- Set Surround View to Disabled.
- Set Init Display First to OnChipVGA.


D. Configuring the Graphics Driver

After installing the motherboard driver in the operating system, go to the **ATI Catalyst[™] Control Center**. Select **CrossFire[™]** on the **Graphics** menu on the upper left corner and ensure the **Enable CrossFire[™]** check box is selected.



- (Note 1) For Windows XP, you must install AMD chipset driver version 8.51 or later.
- (Note 2) You do not have to install the graphics card driver if the motherboard chipset driver has been installed.
- (Note 3) To change the Internal Graphics Mode or UMA Frame Buffer Size setting in BIOS Setup, be sure to disable the CrossFire function in the operating system first.

1-7 Back Panel Connectors



USB 2.0/1.1 Port

The USB port supports the USB 2.0/1.1 specification. Use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc.

PS/2 Keyboard or PS/2 Mouse Port

Use this port to connect a PS/2 keyboard or PS/2 mouse.

O D-Sub Port

The D-Sub port supports a 15-pin D-Sub connector. Connect a monitor that supports D-Sub connection to this port.

DVI-D Port (Note 1)(Note 2)

The DVI-D port conforms to the DVI-D specification and supports a maximum resolution of 2560x1600 (the actual resolutions supported depend on the monitor being used). Connect a monitor that supports DVI-D connection to this port.

Optical S/PDIF Out Connector

This connector provides digital audio out to an external audio system that supports digital optical audio. Before using this feature, ensure that your audio system provides an optical digital audio in connector.

HDMI Port (Note 2)

The HDMI (High-Definition Multimedia Interface) provides an all-digital audio/video interface to transmit the uncompressed audio/video signals and is HDCP compliant. Connect the HDMI audio/video device to this port. The HDMI Technology can support a maximum resolution of 1920x1200 but the actual resolutions supported depend on the monitor being used.



- After installing the HDMI device, make sure the default device for sound playback is the HDMI device. (The item name may differ by operating system. The following screen is from Windows Vista.)
- Please note the HDMI audio output only supports AC3, DTS and 2-channel-LPCM formats. (AC3 and DTS require the use of an external decoder for decoding.)



In Windows Vista, select Start>Control Panel>Sound, select Realtek HDMI Output and then click Set Default.

A. Dual Display Configurations:

This motherboard provides three ports for video output: DVI-D, HDMI and D-Sub. The table below shows the supported dual display configurations.

Dual	Combination	Supported or Not
Display	DVI-D + D-Sub	Yes
	DVI-D + HDMI	No
	HDMI + D-Sub	Yes

B. Playback of HD DVD and Blu-ray Discs:

In order to get better playback quality, when playing the HD DVD or Blu-ray discs, refer to the recommended system requirements (or better) below.

- Memory: Two 1 GB DDR3 1066 memory modules with dual channel mode enabled
- BIOS Setup: At least 256 MB of UMA Frame Buffer Size (refer to Chapter 2, "BIOS Setup," "Advanced BIOS Features," for more information)
- Playback software: CyberLink PowerDVD 8.0 or later (Note: Please ensure Hardware Acceleration is enabled.)
- HDCP compliant monitor(s)

IEEE 1394a Port

The IEEE 1394 port supports the IEEE 1394a specification, featuring high speed, high bandwidth and hotplug capabilities. Use this port for an IEEE 1394a device.

eSATA 3Gb/s Port

The eSATA 3Gb/s port conforms to SATA 3Gb/s standard and is compatible with SATA 1.5Gb/s standard. Use the port to connect an external SATA device.

RJ-45 LAN Port

The Gigabit Ethernet LAN port provides Internet connection at up to 1 Gbps data rate. The following describes the states of the LAN port LEDs.



Connection/Speed LED:				
ate	Description			
ange	1 Gbps data rate			
een	100 Mbps data rate			
	10 Mbps data rate			
	nection/ ate ange een f			

Activity LED:					
State	Description				
Blinking	Data transmission or receiving is occurring				
Off	No data transmission or receiving is occurring				

(Note 1) The DVI-D port does not support D-Sub connection by adapter.

(Note 2) Simultaneous output for DVI-D and HDMI is not supported.



- When removing the cable connected to a back panel connector, first remove the cable from your device and then remove it from the motherboard.
- When removing the cable, pull it straight out from the connector. Do not rock it side to side to
 prevent an electrical short inside the cable connector.

USB 3.0/2.0 Port

The USB 3.0 port supports the USB 3.0 specification and is compatible to the USB 2.0/1.1 specification. Use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc.

Center/Subwoofer Speaker Out Jack (Orange)

Use this audio jack to connect center/subwoofer speakers in a 5.1/7.1-channel audio configuration.

• Rear Speaker Out Jack (Black)

Use this audio jack to connect rear speakers in a 7.1-channel audio configuration.

Side Speaker Out Jack (Gray)

Use this audio jack to connect side speakers in a 4/5.1/7.1-channel audio configuration.

Line In Jack (Blue)

The default line in jack. Use this audio jack for line in devices such as an optical drive, walkman, etc.

• Line Out Jack (Green)

The default line out jack. Use this audio jack for a headphone or 2-channel speaker. This jack can be used to connect front speakers in a 4/5.1/7.1-channel audio configuration.


Mic In Jack (Pink)

The default Mic in jack. Microphones must be connected to this jack.



In addition to the default speakers settings, the **@** ~ **@** audio jacks can be reconfigured to perform different functions via the audio software. Only microphones still MUST be connected to the default Mic in jack (**@**). Refer to the instructions on setting up a 2/4/5.1/7.1-channel audio configuration in Chapter 5, "Configuring 2/4/5.1/7.1-Channel Audio."

1-8 Internal Connectors



1)	ATX_12V	9)	F_AUDIO
2)	ATX	10)	CD_IN
3)	CPU_FAN	11)	SPDIF_IO
4)	SYS_FAN	12)	F_USB1/F_USB2/F_USB3
5)	FDD	13)	F_1394
6)	IDE	14)	СОМ
7)	SATA3_0/1/2/3/4	15)	CLR_CMOS
8)	F_PANEL	16)	BAT



Read the following guidelines before connecting external devices:


- · First make sure your devices are compliant with the connectors you wish to connect.
- Before installing the devices, be sure to turn off the devices and your computer. Unplug the power cord from the power outlet to prevent damage to the devices.
- After installing the device and before turning on the computer, make sure the device cable has been securely attached to the connector on the motherboard.

1/2) ATX 12V/ATX (2x4 12V Power Connector and 2x12 Main Power Connector)

With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard. Before connecting the power connector, first make sure the power supply is turned off and all devices are properly installed. The power connector possesses a foolproof design. Connect the power supply cable to the power connector in the correct orientation. The 12V power connector mainly supplies power to the CPU. If the 12V power connector is not connected, the computer will not start



To meet expansion requirements, it is recommended that a power supply that can withstand high power consumption be used (500W or greater). If a power supply is used that does not provide the required power, the result can lead to an unstable or unbootable system.





.

ATX_12V:	
Pin No.	Definition
1	GND (Only for 2x4-pin 12V)
2	GND (Only for 2x4-pin 12V)
3	GND
4	GND
5	+12V (Only for 2x4-pin 12V)
6	+12V (Only for 2x4-pin 12V)
7	+12V
8	+12V

		5)
12		•	24
		•	
	•	•	
		•	
		•	
	(-		ĥ
	(•	•	μ
		•	
		·	
	•	•	
	•		
1		•	13
)
	AT	Х	

ATX:			
Pin No.	Definition	Pin No.	Definition
1	3.3V	13	3.3V
2	3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS_ON (soft On/Off)
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	Power Good	20	-5V
9	5VSB (stand by +5V)	21	+5V
10	+12V	22	+5V
11	+12V (Only for 2x12-pin ATX)	23	+5V (Only for 2x12-pin ATX)
12	3.3V (Only for 2x12-pin ATX)	24	GND (Only for 2x12-pin ATX)

3/4) CPU_FAN/SYS_FAN (Fan Headers)

The motherboard has a 4-pin CPU fan header (CPU_FAN) and a 4-pin (SYS_FAN) system fan header. Most fan headers possess a foolproof insertion design. When connecting a fan cable, be sure to connect it in the correct orientation (the black connector wire is the ground wire). The motherboard supports CPU fan speed control, which requires the use of a CPU fan with fan speed control design. For optimum heat dissipation, it is recommended that a system fan be installed inside the chassis.

CPU_F
1 SYS_

Pin No.	Definition
1	GND
2	+12V / Speed Control
3	Sense
4	Speed Control
SYS_FAN:	
Pin No.	Definition
1	GND
2	+12V / Speed Control
3	Sense
4	Reserve


• Be sure to connect fan cables to the fan headers to prevent your CPU and system from overheating. Overheating may result in damage to the CPU or the system may hang.


FAN

 These fan headers are not configuration jumper blocks. Do not place a jumper cap on the headers.

5) FDD (Floppy Disk Drive Connector)


This connector is used to connect a floppy disk drive. The types of floppy disk drives supported are: 360 KB, 720 KB, 1.2 MB, 1.44 MB, and 2.88 MB. Before connecting a floppy disk drive, be sure to locate pin 1 of the connector and the floppy disk drive cable. The pin 1 of the cable is typically designated by a stripe of different color. For purchasing the optional floppy disk drive cable, please contact the local dealer.






6) IDE (IDE Connector)


The IDE connector supports up to two IDE devices such as hard drives and optical drives. Before attaching the IDE cable, locate the foolproof groove on the connector. If you wish to connect two IDE devices, remember to set the jumpers and the cabling according to the role of the IDE devices (for example, master or slave). (For information about configuring master/slave settings for the IDE devices, read the instructions from the device manufacturers.)





7) SATA3_0/1/2/3/4 (SATA 6Gb/s Connectors, Controlled by AMD SB850)

The SATA connectors conform to SATA 6Gb/s standard and are compaible with SATA 3Gb/s and SATA 1.5Gb/s standard. Each SATA connector supports a single SATA device. The AMD SB850 controller supports RAID 0, RAID 1, RAID 5, RAID 10, and JBOD. Refer to Chapter 5, "Configuring SATA Hard Drive(s)," for instructions on configuring a RAID array.




Please connect the L-shaped end of the SATA cable to your SATA hard drive.




- A RAID 0 or RAID 1 configuration requires at least two hard drives. If more than two hard drives are to be used, the total number of hard drives must be an even number.
- A RAID 5 configuration requires at least three hard drives. (The total number of hard drives does not have to be an even number.)
- A RAID 10 configuration requires at least four hard drives and the total number of hard drives must be an even number.

8) F_PANEL (Front Panel Header)

Connect the power switch, reset switch, speaker, chassis intrusion switch/sensor and system status indicator on the chassis to this header according to the pin assignments below. Note the positive and negative pins before connecting the cables.





• MSG/PWR (Message/Power/Sleep LED, Yellow/Purple):

System Status	LED	Connects to the power status indicator on the chassis front panel. The LED
S0	On	is on when the system is operating. The LED keeps blinking when the sys-
S1	Blinking	tem is in S1 sleep state. The LED is off when the system is in S3/S4 sleep
S3/S4/S5	Off	state or powered off (S5).

• PW (Power Switch, Red):

Connects to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch (refer to Chapter 2, "BIOS Setup," "Power Management Setup," for more information).

• SPEAK (Speaker, Orange):

Connects to the speaker on the chassis front panel. The system reports system startup status by issuing a beep code. One single short beep will be heard if no problem is detected at system startup. If a problem is detected, the BIOS may issue beeps in different patterns to indicate the problem. Refer to Chapter 5, "Troubleshooting," for information about beep codes.

 HD (Hard Drive Activity LED, Blue) Connects to the hard drive activity LED on the chassis front panel. The LED is on when the hard drive is reading or writing data.


- RES (Reset Switch, Green):
 Connects to the reset switch on the chassis front panel. Press the reset switch to restart the computer
 if the computer freezes and fails to perform a normal restart.
- CI (Chassis Intrusion Header, Gray): Connects to the chassis intrusion switch/sensor on the chassis that can detect if the chassis cover has been removed. This function requires a chassis with a chassis intrusion switch/sensor.



The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly.

9) F_AUDIO (Front Panel Audio Header)

The front panel audio header supports Intel High Definition audio (HD) and AC'97 audio. You may connect your chassis front panel audio module to this header. Make sure the wire assignments of the module connector match the pin assignments of the motherboard header. Incorrect connection between the module connector and the motherboard header will make the device unable to work or even damage it.



	F
	1
10 💿 🔊 9	
_	F
	┢
2 • • 1	┝
	┝
	L
	⊢


For HD Front Panel Audio:		
Pin No.	Definition	
1	MIC2_L	
2	GND	
3	MIC2_R	
4	-ACZ_DET	
5	LINE2_R	
6	GND	
7	FAUDIO_JD	
8	No Pin	
9	LINE2_L	
10	GND	

For AC'97 Front Panel Audio:		
Pin No.	Definition	
1	MIC	
2	GND	
3	MIC Power	
4	NC	
5	Line Out (R)	
6	NC	
7	NC	
8	No Pin	
9	Line Out (L)	
10	NC	

- The front panel audio header supports HD audio by default. If your chassis provides an AC'97 front panel audio module, refer to the instructions on how to activate AC'97 functionality via the audio software in Chapter 5, "Configuring 2/4/5.1/7.1-Channel Audio."
- Audio signals will be present on both of the front and back panel audio connections simultaneously. If you want to mute the back panel audio (only supported when using an HD front panel audio module), refer to Chapter 5, "Configuring 2/4/5.1/7.1-Channel Audio."
- Some chassis provide a front panel audio module that has separated connectors on each wire
 instead of a single plug. For information about connecting the front panel audio module that
 has different wire assignments, please contact the chassis manufacturer.

10) CD_IN (CD In Connector)

You may connect the audio cable that came with your optical drive to the header.






Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

11) SPDIF_IO (S/PDIF In/Out Header)

This header supports digital S/PDIF In/Out. Via an optional S/PDIF In and Out cable, this header can connect to an audio device that supports digital audio out and an audio system that supports digital audio in. For purchasing the optional S/PDIF In and Out cable, please contact the local dealer.






Pin No.	Definition
1	Power
2	No Pin
3	SPDIF
4	SPDIFI
5	GND
6	GND

12) F_USB1/F_USB2/F_USB3 (USB Headers)

The headers conform to USB 2.0/1.1 specification. Each USB header can provide two USB ports via an optional USB bracket. For purchasing the optional USB bracket, please contact the local dealer.




When the system is in S4/S5 mode, only the USB ports routed to the F_USB1 header can support the ON/OFF Charge function.

- Do not plug the IEEE 1394 bracket (2x5-pin) cable into the USB header.
- Prior to installing the USB bracket, be sure to turn off your computer and unplug the power cord from the power outlet to prevent damage to the USB bracket.


13) F_1394 (IEEE 1394a Header)

The header conforms to IEEE 1394a specification. The IEEE 1394a header can provide one IEEE 1394a port via an optional IEEE 1394a bracket. For purchasing the optional IEEE 1394a bracket, please contact the local dealer.

10




Pin No.	Definition
1	TPA+
2	TPA-
3	GND
4	GND
5	TPB+
6	TPB-
7	Power (12V)
8	Power (12V)
9	No Pin
10	GND



- Prior to installing the IEEE 1394a bracket, be sure to turn off your computer and unplug the power cord from the power outlet to prevent damage to the IEEE 1394a bracket.
- To connect an IEEE 1394a device, attach one end of the device cable to your computer and then attach the other end of the cable to the IEEE 1394a device. Ensure that the cable is securely connected.

14) COM (Serial Port Header)

The COM header can provide one serial port via an optional COM port cable. For purchasing the optional COM port cable, please contact the local dealer.






Pin No.	Definition
1	NDCD-
2	NSIN
3	NSOUT
4	NDTR-
5	GND
6	NDSR-
7	NRTS-
8	NCTS-
9	NRI-
10	No Pin

15) CLR_CMOS (Clearing CMOS Jumper)

Use this jumper to clear the CMOS values (e.g. date information and BIOS configurations) and reset the CMOS values to factory defaults. To clear the CMOS values, place a jumper cap on the two pins to temporarily short the two pins or use a metal object like a screwdriver to touch the two pins for a few seconds.




Ц		
	••	Open: Normal
		Short: Clear CMOS Values

- Always turn off your computer and unplug the power cord from the power outlet before clearing the CMOS values.
 - After clearing the CMOS values and before turning on your computer, be sure to remove the jumper cap from the jumper. Failure to do so may cause damage to the motherboard.
 - After system restart, go to BIOS Setup to load factory defaults (select Load Optimized Defaults) or manually configure the BIOS settings (refer to Chapter 2, "BIOS Setup," for BIOS configurations).

16) BAT (Battery)

The battery provides power to keep the values (such as BIOS configurations, date, and time information) in the CMOS when the computer is turned off. Replace the battery when the battery voltage drops to a low level, or the CMOS values may not be accurate or may be lost.





You may clear the CMOS values by removing the battery:

- 1. Turn off your computer and unplug the power cord.
- Gently remove the battery from the battery holder and wait for one minute. (Or use a metal object like a screwdriver to touch the positive and negative terminals of the battery holder, making them short for 5 seconds.)
- 3. Replace the battery.
- 4. Plug in the power cord and restart your computer.
- Always turn off your computer and unplug the power cord before replacing the battery.
- Replace the battery with an equivalent one. Danger of explosion if the battery is replaced with an incorrect model.
- Contact the place of purchase or local dealer if you are not able to replace the battery by yourself or uncertain about the battery model.
- When installing the battery, note the orientation of the positive side (+) and the negative side (-) of the battery (the positive side should face up).
- · Used batteries must be handled in accordance with local environmental regulations.

	· · · · · · · · · · · · · · · · · · ·
·	

Chapter 2 BIOS Setup

BIOS (Basic Input and Output System) records hardware parameters of the system in the CMOS on the motherboard. Its major functions include conducting the Power-On Self-Test (POST) during system startup, saving system parameters and loading operating system, etc. BIOS includes a BIOS Setup program that allows the user to modify basic system configuration settings or to activate certain system features. When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS to keep the configuration values in the CMOS.

To access the BIOS Setup program, press the <Delete> key during the POST when the power is turned on. To see more advanced BIOS Setup menu options, you can press <Ctrl> + <F1> in the main menu of the BIOS Setup program.

To upgrade the BIOS, use either the GIGABYTE Q-Flash or @BIOS utility.

- Q-Flash allows the user to quickly and easily upgrade or back up BIOS without entering the operating system.
- @BIOS is a Windows-based utility that searches and downloads the latest version of BIOS from the Internet and updates the BIOS.

For instructions on using the Q-Flash and @BIOS utilities, refer to Chapter 4, "BIOS Update Utilities."



- Because BIOS flashing is potentially risky, if you do not encounter problems using the current version of BIOS, it is recommended that you not flash the BIOS. To flash the BIOS, do it with caution. Inadequate BIOS flashing may result in system malfunction.
- BIOS will emit a beep code during the POST. Refer to Chapter 5, "Troubleshooting," for the beep codes description.
- It is recommended that you not alter the default settings (unless you need to) to prevent system
 instability or other unexpected results. Inadequately altering the settings may result in system's
 failure to boot. If this occurs, try to clear the CMOS values and reset the board to default values.
 (Refer to the "Load Optimized Defaults" section in this chapter or introductions of the battery/
 clearing CMOS jumper in Chapter 1 for how to clear the CMOS values.)

2-1 Startup Screen

The following screens may appear when the computer boots.

A. The LOGO Screen (Default)



B. The POST Screen

Motherboard Model – BIOS Version –	Award Modular BIOS v6.00PG, An Energy Star Ally Copyright (C) 1984-2010, Award Software, Inc. GA-880GMA-UD2H F3b	TRA FOLLUTION FORCERTER BUILDES DE	
	: BIOS Setup <f9>: XpressRecovery2 <f12>: Boot Me 05/27/2010-RS880P-SB850-7A66BG0KC-00</f12></f9>	nu <end>: Qflash</end>	Function Keys

SATA Mode Message:

"SATA is found running at IDE MODE!"

When the motherboard is set to its default values, the monitor will display a message during the POST, telling you the SATA controller is running at IDE mode. The message that follows asks if you want to change it to AHCI mode and enable hot plug functionality for the SATA connectors.

Press <Y> to enable AHCI mode or <N> to continue IDE mode operation and stop showing this message again.

Note: This message will appear again at next boot if you do not respond YES or NO in time.

Function Keys:

<TAB>: POST SCREEN

Press the <Tab> key to show the BIOS POST screen. To show the BIOS POST screen at system startup, refer to the instructions on the **Full Screen LOGO Show** item on page 48.

: BIOS SETUP

Press the <Delete> key to enter BIOS Setup or to access the Q-Flash utility in BIOS Setup.

<F9>: XPRESS RECOVERY2

If you have ever entered Xpress Recovery2 to back up hard drive data using the driver disk, the <F9> key can be used for subsequent access to Xpress Recovery2 during the POST. For more information, refer to Chapter 4, "Xpress Recovery2."

<F12>: BOOT MENU

Boot Menu allows you to set the first boot device without entering BIOS Setup. In Boot Menu, use the up arrow key <↑> or the down arrow key <↓> to select the first boot device, then press <Enter> to accept. To exit Boot Menu, press <Esc>. The system will directly boot from the device configured in Boot Menu. Note: The setting in Boot Menu is effective for one time only. After system restart, the device boot order will still be based on BIOS Setup settings. You can access Boot Menu again to change the first boot device setting as needed.

<END>: Q-FLASH

Press the <End> key to access the Q-Flash utility directly without having to enter BIOS Setup first.

2-2 The Main Menu

Once you enter the BIOS Setup program, the Main Menu (as shown below) appears on the screen. Use arrow keys to move among the items and press <Enter> to accept or enter a sub-menu.

(Sample BIOS Version: F3b)

_	CMOS Setup Utility-Copyright (C) 1984-2010 Award Software				
	•	MB Intelligent Tweaker(M.I.T.)			Load Fail-Safe Defaults
	►	Standard CMOS Features			Load Optimized Defaults
	►	Advanced BIOS Features			Set Supervisor Password
	►	Integrated Peripherals			Set User Password
	►	Power Management Setup			Save & Exit Setup
	►	PnP/PCI Configurations			Exit Without Saving
	►	PC Health Status			
	ESC:	Quit	↑↓→←: Select It	em	F11: Save CMOS to BIOS
	F8: Ç	2-Flash	F10: Save & Exi	t Setup	F12: Load CMOS from BIOS
	Change CPU's Clock & Voltage				

BIOS Setup Program Function Keys

	-
<↑><↓><←><-	> Move the selection bar to select an item
<enter></enter>	Execute command or enter the submenu
<esc></esc>	Main Menu: Exit the BIOS Setup program
	Submenus: Exit current submenu
<page up=""></page>	Increase the numeric value or make changes
<page down=""></page>	Decrease the numeric value or make changes
<f1></f1>	Show descriptions of the function keys
<f2></f2>	Move cursor to the Item Help block on the right (submenus only)
<f5></f5>	Restore the previous BIOS settings for the current submenus
<f6></f6>	Load the Fail-Safe BIOS default settings for the current submenus
<f7></f7>	Load the Optimized BIOS default settings for the current submenus
<f8></f8>	Access the Q-Flash utility
<f9></f9>	Display system information
<f10></f10>	Save all the changes and exit the BIOS Setup program
<f11></f11>	Save CMOS to BIOS
<f12></f12>	Load CMOS from BIOS

Main Menu Help

The on-screen description of a highlighted setup option is displayed on the bottom line of the Main Menu.

Submenu Help

While in a submenu, press <F1> to display a help screen (General Help) of function keys available for the menu. Press <Esc> to exit the help screen. Help for each item is in the Item Help block on the right side of the submenu.



- If you do not find the settings you want in the Main Menu or a submenu, press <Ctrl>+<F1> to access more advanced options.
- When the system is not stable as usual, select the Load Optimized Defaults item to set your system to its defaults.
- The BIOS Setup menus described in this chapter are for reference only and may differ by BIOS version.

■ The Functions of the <F11> and <F12> keys (For the Main Menu Only)

F11: Save CMOS to BIOS

This function allows you to save the current BIOS settings to a profile. You can create up to 8 profiles (Profile 1-8) and name each profile. First enter the profile name (to erase the default profile name, use the SPACE key) and then press <Enter> to complete.

▶ F12: Load CMOS from BIOS

If your system becomes unstable and you have loaded the BIOS default settings, you can use this function to load the BIOS settings from a profile created before, without the hassles of reconfiguring the BIOS settings. First select the profile you wish to load, then press <Enter> to complete.

MB Intelligent Tweaker(M.I.T.)

Use this menu to configure the clock, frequency and voltages of your CPU, memory, etc.

Standard CMOS Features

Use this menu to configure the system time and date, hard drive types, floppy disk drive types, and the type of errors that stop the system boot, etc.

Advanced BIOS Features

Use this menu to configure the device boot order, advanced features available on the CPU, and the primary display adapter.

Integrated Peripherals

Use this menu to configure all peripheral devices, such as IDE, SATA, USB, integrated audio, and integrated LAN, etc.

Power Management Setup

Use this menu to configure all the power-saving functions.

PnP/PCI Configurations

Use this menu to configure the system's PCI & PnP resources.

PC Health Status

Use this menu to see information about autodetected system/CPU temperature, system voltage and fan speed, etc.

Load Fail-Safe Defaults

Fail-Safe defaults are factory settings for the most stable, minimal-performance system operations.

Load Optimized Defaults

Optimized defaults are factory settings for optimal-performance system operations.

Set Supervisor Password

Change, set, or disable password. It allows you to restrict access to the system and BIOS Setup. A supervisor password allows you to make changes in BIOS Setup.

Set User Password

Change, set, or disable password. It allows you to restrict access to the system and BIOS Setup. A user password only allows you to view the BIOS settings but not to make changes.


Save & Exit Setup


Save all the changes made in the BIOS Setup program to the CMOS and exit BIOS Setup. (Pressing <F10> can also carry out this task.)

Exit Without Saving

Abandon all changes and the previous settings remain in effect. Pressing <Y> to the confirmation message will exit BIOS Setup. (Pressing <Esc> can also carry out this task.)

2-3 MB Intelligent Tweaker(M.I.T.)







- Whether the system will work stably with the overclock/overvoltage settings you made is dependent on your overall system configurations. Incorrectly doing overclock/overvoltage may result in damage to CPU, chipset, or memory and reduce the useful life of these components. This page is for advanced users only and we recommend you not to alter the default settings to prevent system instability or other unexpected results. (Inadequately altering the settings may result in system's failure to boot. If this occurs, clear the CMOS values and reset the board to default values.)
- When the System Voltage Optimized item blinks in red, it is recommended that you set the System Voltage Control item to Auto to optimize the system voltage settings.

☞ IGX Configuration

	СМС	OS Setup Utility-Copyright (C) I IGX Configura		are	
x .	Internal Graphics Mode UMA Frame Buffer Size Surround View Onboard VGA output connect VGA Core Clock control VGA Core Clock(MHz)	[UMA] [Auto] Disablec [Auto] [Auto] 560	I	Ite	m Help →
^↓-	→←: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F6: Fail-Safe Defaults		Exit F1: Dptimized Defau	General Help Its

∽ Internal Graphics Mode

Allows you to determine whether to allocate memory for the onboard graphics controller from the system memory.

- ✤ Disabled Disables the onboard graphics controller.
- WUMA Allocates memory for the onboard graphics controller from the system memory. (Default)

→ UMA Frame Buffer Size

Frame buffer size is the total amount of system memory allocated solely for the onboard graphics controller. MS-DOS, for example, will use only this memory for display. Options are: Auto (default), 128MB, 256MB, 512MB.

∽ Surround View

Enables or disables the Surround View function. This option is configurable only if **Init Display First** under **Advanced BIOS Features** is set to **PEG** and an ATI graphics card is installed. (Default: Disabled) (Default: Disabled)

∽ Onboard VGA output connect

Specifies the graphics display of the onboard graphics output from the D-SUB/DVI-D or D-SUB/HDMI.

- ➤ Auto BIOS automatically determines the primary display port for output, depending on to which port the display device is connected, D-SUB/DVI-D or D-SUB/HDMI. (Default)
- ▶ D-SUB/DVI Sets the D-SUB/DVI-D as the graphics display.
- ▶ D-SUB/HDMI Sets the D-SUB/HDMI as the graphics display.

→ VGA Core Clock control

Allows you to determine whether to manually set the VGA Core clock. (Default: Auto)

→ VGA Core Clock(MHz)

Allows you to manually set the VGA Core clock. The adjustable range is from 200 MHz to 2000 MHz. This item is configurable only if the VGA Core Clock control option is set to Manual.

CPU Clock Ratio

Allows you to alter the clock ratio for the installed CPU. The adjustable range is dependent on the CPU being used.

∽ CPU NorthBridge Freq.

Allows you to alter the North Bridge controller frequency for the installed CPU. The adjustable range is dependent on the CPU being used.

CPU Host Clock Control

Enables or disables the control of CPU host clock. Auto (default) allows the BIOS to automatically adjust the CPU host frequency. Manual allows the CPU Frequency (MHz) item below to be configurable. Note: If your system fails to boot after overclocking, please wait for 20 seconds to allow for automated system reboot, or clear the CMOS values to reset the board to default values.

→ CPU Frequency(MHz)

Allows you to manually set the CPU host frequency. The adjustable range is from 200 MHz to 500 MHz. This option is configurable only when **CPU Host Clock Control** is set to **Manual**. **Important** It is highly recommended that the CPU frequency be set in accordance with the CPU specifications.

∽ PCIE Clock(MHz)

Allows you to manually set the PCIe clock frequency. The adjustable range is from 100 MHz to 150 MHz. Auto sets the PCIe clock frequency to standard 100 MHz. (Default: Auto)

∽ PCIe Spread Spectrum

Enables or disables PCIe Spread Spectrum. (Default: Disabled)

∽ HT Link Width

Allows you to manually set the width for the HT Link between the CPU and chipset.

- ➤ Auto BIOS will automatically adjust the HT Link Width. (Default)
- ✤ 8 bit Sets HT Link Width to 8 bit.
- ▶ 16 bit Sets HT Link Width to 16 bit.

→ HT Link Frequency

Allows you to manually set the frequency for the HT Link between the CPU and chipset.

- ➤ Auto BIOS will automatically adjust the HT Link Frequency. (Default)
- ★ x1~x10
 Sets HT Link Frequency to x1~x10 (200 MHz~2.0 GHz).

∽ Set Memory Clock

Determines whether to manually set the memory clock. Auto lets BIOS automatically set the memory clock as required. Manual allows the memory clock control item below to be configurable. (Default: Auto)


Memory Clock

This option is configurable only when **Set Memory Clock** is set to **Manual**.

- ➤ X4.00 Sets Memory Clock to X4.00.
- ➤ X5.33 Sets Memory Clock to X5.33.
- ➤ X6.66 Sets Memory Clock to X6.66.
- ➤ X8.00 Sets Memory Clock to X8.00.

∽ DRAM Configuration

CMOS Setup Utility-Copyright (C) 1984-2010 Award Software DRAM Configuration					
DCTs Mode	[Unganged]				Item Help
DDR3 Timing Items	[Auto]	SPD	Auto		Menu Level 🕨
x CAS# latency					
x RAS to CAS R/W Delay					
x Row Precharge Time					
x Minimum RAS Active Time					
x 1T/2T Command Timing					
x TwTr Command Delay					
x Trfc0 for DIMM1					
x Trfc2 for DIMM2					
x Trfc1 for DIMM3					
x Trfc3 for DIMM4					
x Write Recovery Time					
x Precharge Time					
x Row Cycle Time					
x RAS to RAS Delay					
DCTs Drive Strength	DCT0	D			
ProcOdt(ohms)	[Auto]	60 [Auto]			
DQS Drive Strength	[Auto] 1	.0x [Auto]	1.0x	.	
$\uparrow \downarrow \rightarrow \leftarrow$: Move Enter: Select	+/-/PU/PD: V	/alue F1	0: Save	ESC:	
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults					
CMOS Setup Utility-Copyright (C) 1984-2010 Award Software DRAM Configuration					



→ DCTs Mode

Allows you to set memory control mode.

- >> Ganged Sets memory control mode to single dual-channel.
- >> Unganged Sets memory control mode to two single-channel. (Default)

→ DDR3 Timing Items

Manual allows all DDR3 Timing items below to be configurable. Options are: Auto (default), Manual.

→ CAS# latency

Options are: Auto (default), 4T~12T.

→ RAS to CAS R/W Delay

Options are: Auto (default), 5T~12T.

Ċ	Row Precharge Time
	Options are: Auto (default), 5T~12T.
Ċ	Minimum RAS Active Time
	Options are: Auto (default), 15T~30T.
Ţ	1T/2T Command Timing
	Options are: Auto (default), 1T, 2T.
Ċ	TwTr Command Delay
	Options are: Auto (default), 4T~7T.
Ċ	Trfc0 for DIMM1
	Options are: Auto (default), 90ns, 110ns, 160ns, 300ns, 350ns.
Ċ	Trfc2 for DIMM2
	Options are: Auto (default), 90ns, 110ns, 160ns, 300ns, 350ns.
Ċ	Trfc1 for DIMM3
	Options are: Auto (default), 90ns, 110ns, 160ns, 300ns, 350ns.
Ċ	Trfc3 for DIMM4
	Options are: Auto (default), 90ns, 110ns, 160ns, 300ns, 350ns.
Ċ	Write Recovery Time
	Options are: Auto (default), 5T~8T, 10T, 12T.
Ċ	Precharge Time
	Options are: Auto (default), 4T~7T.
Ċ	Row Cycle Time
	Options are: Auto (default), 11T~42T.
Ċ	RAS to RAS Delay
	Options are: Auto (default), 4T~7T.
D(CTs Drive Strength
Ċ	
	Options are: Auto (default), 240 ohms, 120 ohms, 60 ohms.
Ċ	DQS Drive Strength
	Options are: Auto (default), 0.75x, 1.0x, 1.25x, 1.5x.
Ċ	Data Drive Strength
	Options are: Auto (default), 0.75x, 1.0x, 1.25x, 1.5x.
Ċ	MEMCLK Drive Strength
	Options are: Auto (default), 0.75x, 1.0x, 1.25x, 1.5x.
Ċ	i i i i i i i i i i i i i i i i i i i
	Options are: Auto (default), 1.0x, 1.25x, 1.5x, 2.0x.
Ċ	CS/ODT Drive Strength
	Options are: Auto (default), 1.0x, 1.25x, 1.5x, 2.0x.
Ċ	CKE Drive Strength
	Options are: Auto (default) 1 0x 1 25x 1 5x 2 0x

Options are: Auto (default), 1.0x, 1.25x, 1.5x, 2.0x.

∽ Bank Interleaving

Enables or disables memory bank interleaving. **Enabled** allows the system to simultaneously access different banks of the memory to increase memory performance and stability. (Default: Enabled)

∽ Channel Interleave

Enables or disables memory channel interleaving. **Enabled** allows the system to simultaneously access different channels of the memory to increase memory performance and stability. (Default: Enabled)

******** System Voltage Optimized ********

∽ System Voltage Control

Determines whether to manually set the system voltages. Auto lets the BIOS automatically set the system voltages as required. Manual allows all voltage control items below to be configurable. (Default: Auto)

∽ CPU PLL Voltage Control

Allows you to set the CPU PLL voltage.

➤ Normal Supplies the CPU PLL voltage as required. (Default)

▶ 2.220V ~ 3.100V The adjustable range is from 2.220V to 3.100V.

Note: Increasing CPU voltage may result in damage to your CPU or reduce the useful life of the CPU.

C DRAM Voltage Control

Allows you to set memory voltage.

➤ Normal Supplies the memory voltage as required. (Default)

▶ 1.300V ~ 2.500V The adjustable range is from 1.300V to 2.500V.

Note: Increasing memory voltage may result in damage to the memory or reduce the useful life of the memory.

C DDR VTT Voltage Control

Allows you to set the memory VTT voltage.

➤ Normal Supplies the memory VTT voltage as required. (Default)

 \Rightarrow 0.770V ~ 1.100V The adjustable range is from 0.770V to 1.100V.

Note: Increasing memory voltage may result in damage to the memory or reduce the useful life of the memory.

∽ NB Voltage Control

Allows you to set the North Bridge voltage.

➤ Normal Supplies the North Bridge voltage as required. (Default)

▶ 0.900V ~ 1.500V The adjustable range is from 0.900V to 1.500V.

∽ NB/PCIe/PLL Voltage Ctrl

Allows you to set the North Bridge PCIe PLL voltage.

- ✤ Normal Supplies the North Bridge PCIe PLL voltage as required. (Default)
- ▶ 1.450V ~ 2.100V The adjustable range is from 1.450V to 2.100V.

→ CPU NB VID Control

Allows you to set the CPU North Bridge VID voltage. **Auto** sets the CPU North Bridge VID voltage as required. The adjustable range is dependent on the CPU being installed. (Default: Normal) Note: Increasing CPU voltage may result in damage to your CPU or reduce the useful life of the CPU.

∽ CPU Voltage Control

Allows you to set the CPU voltage. **Auto** sets the CPU voltage as required. The adjustable range is dependent on the CPU being installed. (Default: Normal)

Note: Increasing CPU voltage may result in damage to your CPU or reduce the useful life of the CPU.

∽ Normal CPU Vcore

Displays the normal operating voltage of your CPU.

2-4 Standard CMOS Features

CMOS Se	tup Utility-Copyright (C) 1984-2010 Award Soft Standard CMOS Features	ware
Date (mm:dd:yy)	Fri, Feb 22 2010	Item Help
Time (hh:mm:ss)		Menu Level 🕨
IDE Channel 0 Master	[None]	
IDE Channel 0 Slave	[None]	
IDE Channel 1 Master	[None]	
IDE Channel 1 Slave	[None]	
IDE Channel 2 Master	[None]	
IDE Channel 2 Slave	[None]	
 IDE Channel 4 Master 	[None]	
 IDE Channel 4 Slave 	[None]	
Drive A	[1.44M, 3.5"]	
Floppy 3 Mode Support	[Disabled]	
Halt On	[All, But Keyboard]	
Base Memory	640K	
Extended Memory	1022M	
$\uparrow \downarrow \rightarrow \leftarrow$: Move Enter: Select	+/-/PU/PD: Value F10: Save ES	SC: Exit F1: General Help
F5: Previous Values	F6: Fail-Safe Defaults F7	7: Optimized Defaults

∽ Date (mm:dd:yy)

Sets the system date. The date format is week (read-only), month, date and year. Select the desired field and use the up arrow or down arrow key to set the date.

∽ Time (hh:mm:ss)

Sets the system time. For example, 1 p.m. is 13:0:0. Select the desired field and use the up arrow or down arrow key to set the time.

→ IDE Channel 0, 1 Master/Slave

► IDE HDD Auto-Detection

Press <Enter> to autodetect the parameters of the IDE/SATA device on this channel.

▶ IDE Channel 0, 1 Master/Slave

Configure your IDE/SATA devices by using one of the two methods below:

- Auto Lets the BIOS automatically detect IDE/SATA devices during the POST. (Default)
- None If no IDE/SATA devices are used, set this item to **None** so the system will skip the detection of the device during the POST for faster system startup.
 - Sets the hard drive access mode. Options are: Auto (default), CHS, LBA, Large.

∽ IDE Channel 2, 4 Master/Slave

► IDE Auto-Detection

➡ Access Mode

Press <Enter> to autodetect the parameters of the IDE/SATA device on this channel.

➡ Extended IDE Drive

Configure your IDE/SATA devices by using one of the two methods below:

- Auto Lets the BIOS automatically detect IDE/SATA devices during the POST. (Default)
- None If no IDE/SATA devices are used, set this item to **None** so the system will skip the detection of the device during the POST for faster system startup.
- ➤ Access Mode Sets the hard drive access mode. Options are: Auto (default), Large.

The following fields display your hard drive specifications. If you wish to enter the parameters manually, refer to the information on the hard drive.

- Capacity Approximate capacity of the currently installed hard drive.
- Cylinder Number of cylinders.

- Landing Zone Landing zone.
- ➡ Sector Number of sectors.

つ Drive A

Allows you to select the type of floppy disk drive installed in your system. If you do not install a floppy disk drive, set this item to **None**. Options are: None, 360K/5.25", 1.2M/5.25", 720K/3.5", 1.44M/3.5", 2.88M/3.5".

☞ Floppy 3 Mode Support

Allows you to specify whether the installed floppy disk drive is 3-mode floppy disk drive, a Japanese standard floppy disk drive. Options are: Disabled (default), Drive A.

つ Halt On

Allows you to determine whether the system will stop for an error during the POST.

- ➤ All Errors Whenever the BIOS detects a non-fatal error the system boot will stop.
- ➤ No Errors The system boot will not stop for any error.
- All, But Keyboard The system boot will not stop for a keyboard error but stop for all other errors. (Default)
- ➤ All, But Diskette The system boot will not stop for a floppy disk drive error but stop for all other errors.
- All, But Disk/Key The system boot will not stop for a keyboard or a floppy disk drive error but it will stop for all other errors.

∽ Memory

These fields are read-only and are determined by the BIOS POST.

- Base Memory Also called conventional memory. Typically, 640 KB will be reserved for the MS-DOS operating system.
- >> Extended Memory The amount of extended memory.

2-5 Advanced BIOS Features

	CMOS Setup Utility-Copyright (C) 1984-2010 Award Software Advanced BIOS Features					
	IGX Configuration	[Press Enter]	Item Help			
	AMD C1E Support	[Disabled]	Menu Level			
	Virtualization	[Disabled]				
	AMD K8 Cool&Quiet control	[Auto]				
	CPU Unlock (Note)	[Disabled]				
	CPU core Control	[Auto]				
x	CPU core 0					
x	CPU core 1					
x	CPU core 2/3/4/5 (Note)					
▶	Hard Disk Boot Priority	[Press Enter]				
	First Boot Device	[Hard Disk]				
	Second Boot Device	[CDROM]				
	Third Boot Device	[Floppy]				
	Password Check	[Setup]				
	HDD S.M.A.R.T. Capability	[Disabled]				
	Away Mode	[Disabled]				
	Full Screen LOGO Show	[Enabled]				
	Backup BIOS Image to HDD	[Disabled]				
	Init Display First	[PCI Slot]				
↑	↓→←: Move Enter: Select F5: Previous Values		C: Exit F1: General Help : Optimized Defaults			

☞ IGX Configuration

The settings in this submenu are synchronous to those under the same items on the **MB Intelligent Tweaker(M.I.T.)** main menu.

→ AMD C1E Support

Enables or disables the C1E CPU power-saving function in system halt state. When enabled, the CPU core frequency and voltage will be reduced during system halt state to decrease power consumption. (Default: Disabled)

Virtualization

Virtualization allows a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple virtual systems. (Default: Disabled)

→ AMD K8 Cool&Quiet control

Auto Lets the AMD Cool'n'Quiet driver dynamically adjust the CPU clock and VID to reduce heat output from your computer and its power consumption. (Default)
 Disabled Disables this function.

→ CPU Unlock (Note)

Allows you to determine whether to unlock hidden CPU cores. (Default: Disabled)

→ CPU core Control

Allows you to determine whether to manually enable/disable CPU Core 1/2/3/4/5.

- Auto Lets the BIOS to enable all CPU cores (number of cores available depends on the CPU being used). (Default)
- ➤ Manual Allows you to individually enable/disable CPU Core 1/2/3/4/5.

∽ CPU core 0

This setting is fixed. CPU Core 0 is always enabled.

○ CPU core 1, 2/3/4/5^(Note)

Enables or disables CPU Core 1/2/3/4/5. (Default: Enabled)

(Note) This item is present only if you install a CPU that supports this feature.

∽ Hard Disk Boot Priority

Specifies the sequence of loading the operating system from the installed hard drives. Use the up or down arrow key to select a hard drive, then press the plus key <+> (or <PageUp>) or the minus key <-> (or <PageDown>) to move it up or down on the list. Press <Esc> to exit this menu when finished.

∽ First/Second/Third Boot Device

Specifies the boot order from the available devices. Use the up or down arrow key to select a device and press <Enter> to accept. Options are: Floppy, LS120, Hard Disk, CDROM, ZIP, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, Legacy LAN, Disabled.

Password Check

Specifies whether a password is required every time the system boots, or only when you enter BIOS Setup. After configuring this item, set the password(s) under the Set Supervisor/User Password item in the BIOS Main Menu.

- Setup A password is only required for entering the BIOS Setup program. (Default)
- System A password is required for booting the system and for entering the BIOS Setup program.

→ HDD S.M.A.R.T. Capability

Enables or disables the S.M.A.R.T. (Self Monitoring and Reporting Technology) capability of your hard drive. This feature allows your system to report read/write errors of the hard drive and to issue warnings when a third party hardware monitor utility is installed. (Default: Enabled)

∽ Away Mode

Enables or disables Away Mode in Windows XP Media Center operating system. Away Mode allows the system to silently perform unattended tasks while in a low-power mode that appears off. (Default: Disabled)

∽ Full Screen LOGO Show

Allows you to determine whether to display the GIGABYTE Logo at system startup. **Disabled** displays normal POST message. (Default: Enabled)

∽ Backup BIOS Image to HDD

Allows the system to copy the BIOS image file to the hard drive. If the system BIOS is corrupted, it will be recovered from this image file. (Default: Disabled)

∽ Init Display First

Specifies the first initiation of the monitor display from the installed PCI graphics card, PCI Express graphics card, or the onboard graphics.

- ▶ PCI Slot Sets the PCI graphics card as the first display. (Default)
- >> OnChipVGA Sets the onboard graphics as the first display.
- ▶ PEG Sets the PCI Express graphics card on the PCIEX16 slot as the first display.
- ▶ PEG1 Sets the PCI Express graphics card on the PCIEX4 slot as the first display.

2-6 Integrated Peripherals

	CMOS Setup Utility-Copyright (C) 1984-2010 Award Software Integrated Peripherals						
OnChip S x OnChip S OnChip S OnChip S Onboard Onboard SMART I Onboard Onboard USB Con USB Leg USB Stor	AN Function AN Boot ROM AN Audio Function 394 Function JSB 3.0 Controller	[Enabled [Native] IDE Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled [Enabled]]	DE] 	Ment	Item Help		
$\uparrow \downarrow \rightarrow \leftarrow : Mov$ F5:	e Enter: Select Previous Values	+/-/PU/PD: Value F6: Fail-Safe Defaults	F10: Save	ESC: Exit F7: Optimize	F1: General Help d Defaults		

OnChip SATA Controller (AMD SB850 South Bridge, SATA3_0~SATA3_4 and eSATA connectors)

Enables or disables the integrated SATA controller. (Default: Enabled)

OnChip SATA Type (AMD SB850 South Bridge, SATA3_0~SATA3_3 connectors) Configures the operating mode of the integrated SATA3_0~SATA3_3 connectors.

- Native IDE Allows the SATA controller to operate in Native IDE mode. (Default) Enable Native IDE mode if you wish to install operating systems that support Native mode.
- ► RAID Enables RAID for the SATA controller.
- AHCI Configures the SATA controller to AHCI mode. Advanced Host Controller Interface (AHCI) is an interface specification that allows the storage driver to enable advanced Serial ATA features such as Native Command Queuing and hot plug.

OnChip SATA Port4/5 Type (AMD SB850 South Bridge, SATA3_4 and eSATA connectors) This option is configurable only when OnChip SATA Type is set to RAID or AHCI. Configures the operating mode of the integrated SATA3_4 and eSATA connectors.

- ▶ IDE Disables RAID for the SATA controller and configures the SATA controller to PATA mode. (Default)
- ► As SATA Type The mode depends on the **OnChip SATA Type** settings.

OnChip SATA RAID5 Support (AMD SB850 South Bridge, SATA3_0~SATA3_4 and eSATA connectors)

Enables or disables RAID 5 support for the SATA controller integrated in the AMD SB850 South Bridge. This option is configurable only when **OnChip SATA Type** is set to **RAID**.

OnChip SATA3.0 Support (SATA3_0~SATA3_4 connectors) Enables or disables the SATA 6Gb/s function integrated in the Chipset. When set to Disabled, the SATA controller will operate in SATA 3Gb/s mode. (Default: Enabled)

Onboard IDE Ctrl (JMicron JMB368 Chip) Enables or disables the IDE controller integrated in the JMicron JMB368 chip. (Default: Enabled)

Onboard LAN Function

Enables or disables the onboard LAN function. (Default: Enabled) If you wish to install a 3rd party add-in network card instead of using the onboard LAN, set this item to **Disabled**.

∽ Onboard LAN Boot ROM

Allows you to decide whether to activate the boot ROM integrated with the onboard LAN chip. (Default: Disabled)

∽ SMART LAN (LAN Cable Diagnostic Function)

CMOS Set	up Utility-Copyright (C) 1 SMART LA	tware	
Start detecting at Port Part1-2 Status = Open / Length = Part3-6 Status = Open / Length = Part4-5 Status = Open / Length = Part7-8 Status = Open / Length =	= 0m = 0m	Item Help Menu Level →>	
↑↓→←: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F6: Fail-Safe Defaults	SC: Exit F1: General Help 7: Optimized Defaults	

This motherboard incorporates cable diagnostic feature designed to detect the status of the attached LAN cable. This feature will detect cabling issue and report the approximate distance to the fault or short. Refer to the following information for diagnosing your LAN cable:

∽ When No LAN Cable Is Attached...

If no LAN cable is attached to the motherboard, the **Status** fields of all four pairs of wires will show **Open** and the **Length** fields show **0m**, as shown in the figure above.

∽ When LAN Cable Is Functioning Normally...

If no cable problem is detected on the LAN cable connected to a Gigabit hub or a 10/100 Mbps hub, the following message will appear:



➤ Link Detected Displays transmission speed.

>> Cable Length Displays the approximate length of the attached LAN cable.

Note: The Gigabit hub will only operate at a speed of 10/100 Mbps in MS-DOS mode; it will operate at a normal speed of 10/100/1000 Mbps in Windows mode or when the LAN Boot ROM is activated.

∽ When a Cable Problem Occurs...

If a cable problem occurs on a specified pair of wires, the **Status** field will show **Short** and then length shown will be the approximate distance to the fault or short.

Example: Part1-2 Status = Short / Length = 2m

Explanation: A fault or short might occur at about 2m on Part 1-2.

Note: Part 4-5 and Part 7-8 are not used in a 10/100 Mbps environment, so their **Status** fields will show **Open**, and the length shown is the approximate length of the attached LAN cable.

∽ Onboard Audio Function

Enables or disables the onboard audio function. (Default: Enabled) If you wish to install a 3rd party add-in audio card instead of using the onboard audio, set this item to **Disabled**.

∽ Onboard 1394 Function

Enables or disables the onboard IEEE 1394 function. (Default: Enabled)

∽ Onboard USB 3.0 Controller (NEC USB Controller)

Enables or disables the NEC USB controller. (Default: Enabled)

→ USB Controllers

Enables or disables the integrated USB controllers. (Default: Enabled) **Disabled** will turn off all of the USB functionalities below.

☞ USB Legacy Function

Allows USB keyboard to be used in MS-DOS. (Default: Enabled)

☞ USB Storage Function

Determines whether to detect USB storage devices, including USB flash drives and USB hard drives during the POST. (Default: Enabled)

∽ Onboard Serial Port 1

Enables or disables the first serial port and specifies its base I/O address and corresponding interrupt. Options are: Auto, 2F8/IRQ3, 3F8/IRQ4(default), 3E8/IRQ4, 2E8/IRQ3, Disabled.

2-7 Power Management Setup

	CMOS Setup Utility-Copyright (C) 1984-2010 Award Software Power Management Setup						
x x x	ACPI Suspend Type Soft-Off by Power button USB Wake Up from S3 Modem Ring Resume PME Event Wake Up HPET Support ^{Name} Power On By Mouse Power On By Keyboard KB Power ON Password AC Back Function Power-On by Alarm Date (of Month) Resume Time (hh:mm:ss) ErP Support	[S3(STR)] [Instant-off] [Enabled] [Enabled] [Enabled] [Disabled] [Disabled] Enter [Soft-Off] [Disabled] Everyday 0:0:0 [Disabled]		Item Help Menu Level ≯			
	↓→←: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F1 F6: Fail-Safe Defaults	0: Save ESC: F7: O	Exit F1: General Help ptimized Defaults			

ACPI Suspend Type

Specifies the ACPI sleep state when the system enters suspend.

- S1(POS) Enables the system to enter the ACPI S1 (Power on Suspend) sleep state. In S1 sleep state, the system appears suspended and stays in a low power mode. The system can be resumed at any time.
- S3(STR) Enables the system to enter the ACPI S3 (Suspend to RAM) sleep state (default). In S3 sleep state, the system appears to be off and consumes less power than in the S1 state. When signaled by a wake-up device or event, the system resumes to its working state exactly where it was left off.

Soft-Off by Power button

Configures the way to turn off the computer in MS-DOS mode using the power button.

- > Instant-Off Press the power button and then the system will be turned off instantly. (Default)
- Delay 4 Sec. Press and hold the power button for 4 seconds to turn off the system. If the power button is pressed for less than 4 seconds, the system will enter suspend mode.

→ USB Wake Up from S3

Allows the system to be awakened from ACPI S3 sleep state by a wake-up signal from the installed USB device. (Default: Enabled)

∽ Modem Ring Resume

Allows the system to be awakened from an ACPI sleep state by a wake-up signal from a modem that supports wake-up function. (Default: Disabled)

(Note) Supported on Windows 7/Vista operating system only.

☞ PME Event Wake Up

Allows the system to be awakened from an ACPI sleep state by a wake-up signal from a PCI or PCIe device. Note: To use this function, you need an ATX power supply providing at least 1A on the +5VSB lead. (Default: Enabled)

→ HPET Support (Note)

Enables or disables High Precision Event Timer (HPET) for Windows 7/Vista operating system. (Default: Enabled)

∽ Power On By Mouse

Allows the system to be turned on by a PS/2 mouse wake-up event.

Note: To use this function, you need an ATX power supply providing at least 1A on the +5VSB lead.

- ✤ Disabled Disables this function. (Default)
- >> Double Click Double click on left button on the PS/2 mouse to turn on the system.

∽ Power On By Keyboard

Allows the system to be turned on by a PS/2 keyboard wake-up event.

Note: you need an ATX power supply providing at least 1A on the +5VSB lead.

- Disabled Disables this function. (Default)
- ➤ Any KEY Press any key on the keyboard to turn on the system.
- ▶ Keyboard 98 Press POWER button on the Windows 98 keyboard to turn on the system.

∽ KB Power ON Password

Set the password when **Power On by Keyboard** is set to **Password**. Press <Enter> on this item and set a password with up to 5 characters and then press <Enter> to accept. To turn on the system, enter the password and press <Enter>.

Note: To cancel the password, press <Enter> on this item. When prompted for the password, press <Enter> again without entering the password to clear the password settings.

AC Back Function

Determines the state of the system after the return of power from an AC power loss.

- ✤ Soft-Off The system stays off upon the return of the AC power. (Default)
- ➤ Full-On The system is turned on upon the return of the AC power.
- ➤ Memory The system returns to its last known awake state upon the return of the AC power.

→ Power-On by Alarm

Determines whether to power on the system at a desired time. (Default: Disabled) If enabled, set the date and time as following:

- >> Date (of Month): Turn on the system at a specific time on each day or on a specific day in a month.
- >> Resume Time (hh: mm: ss): Set the time at which the system will be powered on automatically.

Note: When using this function, avoid inadequate shutdown from the operating system or removal of the AC power, or the settings may not be effective.

☞ ErP Support

Determines whether to let the system consume less than 1W power in S5 (shutdown) state. (Default: Disabled)

Note: When this item is set to **Enabled**, the following four functions will become unavailable: PME event wake up, power on by mouse, power on by keyboard, and wake on LAN.

(Note) Supported on Windows 7/Vista operating system only.

2-8 PnP/PCI Configurations

CMOS S	Setup Utility-Copyright (C) 1984-2010 Av PnP/PCI Configurations	vard Software
PCII IRQ Assignment	[Auto]	Item Help Menu Level →
↑↓→←: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F10: Save F6: Fail-Safe Defaults	ESC: Exit F1: General Help F7: Optimized Defaults

∽ PCI1 IRQ Assignment

► Auto

▶ 3,4,5,7,9,10,11,12,14,15

BIOS auto-assigns IRQ to the first PCI slot. (Default) Assigns IRQ 3,4,5,7,9,10,11,12,14,15 to the first PCI slot.

2-9 PC Health Status

CMOS Setup Utility-Copyright (C) 1984-2010 Award Software PC Health Status					
Hardware Thermal Control	[Enabled]	Item Help			
Reset Case Open Status	[Disabled]	Menu Level 🕨			
Case Opened					
Vcore					
DDR3 1.5V					
+3.3V					
+12V					
Current System Temperature	38°C				
Current CPU Temperature					
Current CPU FAN Speed	1962 RPM				
Current SYSTEM FAN Speed	0 RPM				
CPU Warning Temperature	[Disabled]				
CPU FAN Fail Warning	[Disabled]				
SYSTEM FAN Fail Warning	[Disabled]				
CPU Smart FAN Control	[Enabled]				
CPU Smart FAN Mode	[Auto]				
System Smart FAN Control	[Enabled]				
↑↓→←: Move Enter: Select	+/-/PU/PD: Value F10: Save	ESC: Exit F1: General Help			
F5: Previous Values	F6: Fail-Safe Defaults	F7: Optimized Defaults			

∽ Hardware Thermal Control

Enables or disables the CPU overheating protection function. When enabled, the CPU core voltage and ratio will be reduced when the CPU is overheated. (Default: Enabled)

Reset Case Open Status

Keeps or clears the record of previous chassis intrusion status. **Enabled** clears the record of previous chassis intrusion status and the **Case Opened** field will show "No" at next boot. (Default: Disabled)

∽ Case Opened

Displays the detection status of the chassis intrusion detection device attached to the motherboard CI header. If the system chassis cover is removed, this field will show "Yes", otherwise it will show "No". To clear the chassis intrusion status record, set **Reset Case Open Status** to **Enabled**, save the settings to the CMOS, and then restart your system.

∽ Current Voltage(V) Vcore/DDR3 1.5V/+3.3V/+12V

Displays the current system voltages.

∽ Current System/CPU Temperature

Displays current system/CPU temperature.

∽ Current CPU/SYSTEM FAN Speed (RPM)

Displays current CPU/system fan speed.

∽ CPU Warning Temperature

Sets the warning threshold for CPU temperature. When CPU temperature exceeds the threshold, BIOS will emit warning sound. Options are: Disabled (default), 60°C/140°F, 70°C/158°F, 80°C/176°F, 90°C/194°F.

∽ CPU/SYSTEM FAN Fail Warning

Allows the system to emit warning sound if the CPU/system fan is not connected or fails. Check the fan condition or fan connection when this occurs. (Default: Disabled)

∽ CPU Smart FAN Control

Enables or disables the CPU fan speed control function. **Enabled** allows the CPU fan to run at different speed according to the CPU temperature. You can adjust the fan speed with EasyTune based on system requirements. If disabled, the CPU fan runs at full speed. (Default: Enabled)

∽ CPU Smart FAN Mode

Specifies how to control CPU fan speed. This item is configurable only if **CPU Smart FAN Control** is set to **Enabled**.

- Auto Lets the BIOS automatically detect the type of CPU fan installed and sets the optimal CPU fan control mode. (Default)
- ✤ Voltage Sets Voltage mode for a 3-pin CPU fan.
- ▶ PWM Sets PWM mode for a 4-pin CPU fan.

∽ System Smart FAN Control

Enables or disables the system fan speed control function. **Enabled** allows the system fan to run at different speed according to the system temperature. If disabled, system fan runs at full speed. (Default: Enabled)


2-10 Load Fail-Safe Defaults

_	CMOS Setup Utility-Copyright (C) 1984-2010 Award Software						
	►	MB Intelligent Tweaker(M.I.T.)			Load Fail-Safe Defaults		
	►	Standard CMOS Features			Load Optimized Defaults		
	►	Advanced BIOS Features			Set Supervisor Password		
	►	Integrated Peripherals			Set User Password		
	►	Power Manageme	1 15 30 6 5		ADAN		
	►	PnP/PCI Configur	Load Fail-Safe L	Defaults (Y/N)? N			
	►	PC Health Status		1			
	ESC	: Quit	↑↓→←: Select It	lem	F11: Save CMOS to BIOS		
	F8: 0	Q-Flash	F10: Save & Exi	t Setup	F12: Load CMOS from BIOS		
	Load Fail-Safe Defaults						

Press <Enter> on this item and then press the <Y> key to load the safest BIOS default settings.

In case system instability occurs, you may try to load Fail-Safe defaults, which are the safest and most stable BIOS settings for the motherboard.

2-11 Load Optimized Defaults



Press <Enter> on this item and then press the <Y> key to load the optimal BIOS default settings.

The BIOS defaults settings help the system to operate in optimum state. Always load the Optimized defaults after updating the BIOS or after clearing the CMOS values.

2-12 Set Supervisor/User Password

 CMOS Setup Utility-Copyright (C) 1984-2010 Award Software						
•	MB Intelligent Tweaker(M.I.T.)			Load Fail-Safe Defaults		
•	Standard CMOS Features			Load Optimized Defaults		
•	Advanced BIOS Features			Set Supervisor Password		
•	Integrated Peripherals			Set User Password		
•	Power Manageme	n 1				
•	PnP/PCI Configur	Password:				
►	PC Health Status		1			
ESC	: Quit	↑↓→←: Select I	tem	F11: Save CMOS to BIOS		
F8: 0	Q-Flash	F10: Save & Exi	it Setup	F12: Load CMOS from BIOS		
Change/Set/Disable Password						

Press <Enter> on this item and type the password with up to 8 characters and then press <Enter>. You will be requested to confirm the password. Type the password again and press <Enter>.

The BIOS Setup program allows you to specify two separate passwords:

Supervisor Password

When a system password is set and the **Password Check** item in **Advanced BIOS Features** is set to **Setup**, you must enter the supervisor password for entering BIOS Setup and making BIOS changes. When the **Password Check** item is set to **System**, you must enter the supervisor password (or user password) at system startup and when entering BIOS Setup.

User Password

When the **Password Check** item is set to **System**, you must enter the supervisor password (or user password) at system startup to continue system boot. In BIOS Setup, you must enter the supervisor password if you wish to make changes to BIOS settings. The user password only allows you to view the BIOS settings but not to make changes.


To clear the password, press <Enter> on the password item and when requested for the password, press <Enter> again. The message "PASSWORD DISABLED" will appear, indicating the password has been cancelled.

2-13 Save & Exit Setup

	CMOS Setup	Utility-Copyright	(C) 1984-2	2010 Award Software	
	MB Intelligent Tweaker(M.I.T.)			Load Fail-Safe Defa	ılts
	 Standard CMOS I 				ults
1	Advanced BIOS I	Save to CMOS ar	nd EXIT (Y	/N)? Y	ord
1	 Integrated Periphe]	
	Power Management Setup			Save & Exit Setup	
	 PnP/PCI Configurations 			Exit Without Saving	
	PC Health Status				
I	ESC: Quit	↑↓→←: Select It	lem	F11: Save CM	IOS to BIOS
I	F8: Q-Flash	F10: Save & Exi	t Setup	F12: Load CM	1OS from BIOS
		Save Data	to CMOS		

Press <Enter> on this item and press the <Y> key. This saves the changes to the CMOS and exits the BIOS Setup program. Press <N> or <Esc> to return to the BIOS Setup Main Menu.

2-14 Exit Without Saving



Press <Enter> on this item and press the <Y> key. This exits the BIOS Setup without saving the changes made in BIOS Setup to the CMOS. Press <N> or <Esc> to return to the BIOS Setup Main Menu.

Chapter 3 Drivers Installation



Before installing the drivers, first install the operating system.

After installing the operating system, insert the motherboard driver disk into your optical drive. The driver Autorun screen is automatically displayed which looks like that shown in the screen shot below. (If the driver Autorun screen does not appear automatically, go to My Computer, double-click the optical drive and execute the **Run**.exe program.)

3-1 Installing Chipset Drivers



After inserting the driver disk, "Xpress Install" will automatically scan your system and then list all the drivers that are recommended to install. You can click the **Install All** button and "Xpress Install" will install all the recommended drivers. Or click **Install Single Items** to manually select the drivers you wish to install.

Chipset Drivers	Install Chipset Drivers We recommend that you install the drivers listed below for your motherboard. Please click "Insta automatically.	all All" to install all the
Application Software	Xpress Install Install Single Items	
Technical Manuals	Install All	
	Easy Energy Saver	
Contact	Version:1.0	
	Size:3.65MB	
System	GIGABYTE Easy Energy Saver is a revolutionary technology that delivers unparalleled power saving click of a button. Featuring an advanced proprietary hardware and software design, the unique multi- design of GIGABYTE Easy Energy Saver allows for the most efficient switching of power phases dep workload.	gear power phase
Download	Browser Configuration Utility	
Center	Version:1.1.11.0	
	Size:3.84MB	
	This utility optimizes the internet search experience based on your country and language, and adds your system.	online games to
Auto	1	
Auto Green	Realtek HD Audio Driver	
Auto Green		
Auto Green	Realtek HD Audio Driver	
Auto Green	Realitek HD Audio Driver Version:R2.44(6065)	
Auto	Restek IG Audio Driver Version R2 44(606) Sitz 213 7008 Restek High Definition Audio Driver	
Auto	Realtek HD Audio Driver Version R2 44(6066) Size 213 70MB	



Please ignore the popup dialog box(es) (e.g. the Found New Hardware Wizard) displayed when "Xpress Install" is installing the drivers. Failure to do so may affect the driver installation.

- Some device drivers will restart your system automatically during the driver installation. After the system restart, "Xpress Install" will continue to install other drivers.
- After "Xpress Install" installs all of the drivers, a dialog box will appear asking whether to install new GIGABYTE utilities. Click Yes to automatically install the utilities. Or click No if you want to manually select the utilities to install on the Application Software page later.
- For USB 2.0 driver support under the Windows XP operating system, please install the Windows XP Service Pack 1 or later. After installing the SP1 (or later), if a question mark still exists in Universal Serial Bus Controller in Device Manager, please remove the question mark (by right-clicking your mouse and select Uninstall) and restart the system. (The system will then autodetect and install the USB 2.0 driver.)

3-2 Application Software

This page displays all the utilities and applications that GIGABYTE develops and some free software. You can click the **Install** button on the right of an item to install it.

hipset rivers	Install Application Programs Click the "Install" button on the right of an application to install it.
pplication	Install GIGABYTE Utilities Install Application Software Install New Utilitie
echnical	G.O.M. (Gigabyte Online Manager) Size 9 11MB
lanuals	Sec 3 1108 A web-based system management tool that allows client system hardware information such as CPU and memory and graphics card and much more to be monitored or controlled via a host.
ontact	EasyTune 6
	Size:12.43MB
ystem	An easy-to-use Windows-based system enhancement utility allowing quick access to a variety of performance features.
	DMI Viewer
ownload	Size 2 89MB
enter	DMI Viewer provides a management tool for viewing motherboard hardware information.
uto	Face Wizard
reen	Size 3.02MB
	Face Wizard provides utility for customizing BIOS boot up screen.
	@8105

3-3 Technical Manuals

This page provides GIGABYTE's application guides, content descriptions for this driver disk, and the motherboard manuals.

	Technical Manuals		
	Application Guides	Driver Disk Contents	User's Manual
ation			
ical	DES2(Dynamic Energy Saver 2)		
ical	 EasyTune 6 		
	GOIM (GIGABYTE Online Manage	4	
	O.O.M. (GGADYTE Online Manage O.Share	ŋ	
ot	Smart 6		
	Xpress Recover 2		
	 Easy Energy Saver 		
n (Realtek Ethemet Diagnostic Utility 	0	
oad r			
to			
en			

3-4 Contact

For the detailed contact information of the GIGABYTE Taiwan headquarter or worldwide branch offices, click the URL on this page to link to the GIGABYTE website.



3-5 System

This page provides the basic system information.



3-6 Download Center

To update the BIOS, drivers, or applications, click the **Download Center** button to link to the GIGABYTE website. The latest version of the BIOS, drivers, or applications will be displayed.

Chipset Drivers	Install Chipset Drivers We recommend that you install the drivers listed below for your motherboard. Please click "Install All" to install all	the driv
Univers	automatically.	a and data
Application	Xpress Install Install Single Items	
Software		
/ Technical	Install All	
Manuals		
	Easy Energy Saver	
Contact	Version:1.0	
	Size/3.65MB	
System	GIGABYTE Easy Energy Saver is a revolutionary technology that delivers unparalleled power savings with the simple click of a lotton. Featuring an advanced proprietary hadvare and a bottave deligin, the unique nuits-para power plase design of GIGABYTE Easy Energy Saver allows for the most efficient switching of power phases depending on CPU workload.	
Download	Browser Configuration Utility	
Center	Version:1.1.11.0	
Center	Size 3 84MB	1
2 auto	This utility optimizes the internet search experience based on your country and language, and adds online games to your system.]
green	Realtek HD Audio Driver	
	Version R2 44(6066)	
	Size 213.70MB	1 -
	Realtek High Definition Audio Driver	1
	Realtek 8111/8168 LAN driver for gigabit (Vista)	
	Version 6 235 0304 2010	

3-7 New Utilities

This page provides a quick link to GIGABYTE's lately developed utilities for users to install. You can click the **Install** button on the right of an item to install it.

Install New Utilities
has been connect

1

Chapter 4 Unique Features

4-1 Xpress Recovery2



Xpress Recovery2 is a utility that allows you to quickly compress and back up your system data and perform restoration of it. Supporting NTFS, FAT32, and FAT16 file systems, Xpress Recovery2 can back up data on PATA and SATA hard drives and restore it.

Before You Begin:

- Xpress Recovery2 will check the first physical hard drive (Note) for the operating system. Xpress Recovery2 can only back up/restore the first physical hard drive that has the operating system installed.
- As Xpress Recovery2 will save the backup file at the end of the hard drive, make sure to leave enough unallocated space in advanced (10 GB or more is recommended; actual size requirements vary, depending on the amount of data).
- It is recommended to back up your system soon after the operating system and drivers are installed.
- The amount of data and hard drive access speed may affect the speed at which the data is backed up/ restored.
- · It takes longer to back up a hard drive than to restore it.

System Requirements:

- At least 512 MB of system memory
- · VESA compatible graphics card
- · Windows XP with SP1 or later, Windows Vista



- Xpress Recovery and Xpress Recovery2 are different utilities. For example, a backup file created with Xpress Recovery cannot be restored using Xpress Recovery2.
- · USB hard drives are not supported.
- · Hard drives in RAID/AHCI mode are not supported.

Installation and Configuration:

Turn on your system to boot from the Windows Vista setup disk.

A. Installing Windows Vista and Partitioning the Hard Drive

Name	Total Size	Free Space Type
Disk O Unallocated Space	80.0 08	809.08
Select		Drive options (phranced)

Here		Tetal Sce	Free Spece Type
Dation	le catad Space	80.008	00.100

Step 1:

Click Drive options.



(Note) Xpress Recovery2 checks the first physical hard drive in the following sequence: The first PATA IDE connector, the second PATA IDE connector, the first SATA connector, the second SATA connector and so forth. For example, when hard drives are attached to the first IDE and the first SATA connectors, the hard drive on the first IDE connector is the first physical drive. When hard drives are attached to the first and second SATA connectors, the hard drive on the first SATA connector is the first physical drive.

Nerre		Total Size		
Dist fam	Nice 1	780.08	70.048 par	Naty
Dat I Unefected Space		10008	13.098	

Step 3:

When partitioning your hard drive, make sure to leave unallocated space (10 GB or more is recommended; actual size requirements vary, depending on the amount of data) and begin the installation of the operating system.



Step 4:

After the operating system is installed, right-click the **Computer** icon on your desktop and select **Manage**. Go to **Disk Management** to check disk allocation.

				_
· Children Tanta	10.41	Brute Bass 1/91 Faster Green Box Pagella Antin Carl Dura	Due Hangement	
Construction Construction Construction Construction Construction Construction Construction Construction Construction	Steres to	Single Back (2P) Peetry Annue Netton:	Healeure	
	Column Same	D	1	
	dan non a filt a litta Color	Entill Cu 35:00 cms hation		

Step 5:

Xpress Recovery2 will save the backup file to the unallocated space (black stripe along the top). Please note that if there is no enough unallocated space, Xpress Recovery2 cannot save the backup file.

B. Accessing Xpress Recovery2

- Boot from the motherboard driver disk to access Xpress Recovery2 for the first time. When you see the following message: Press any key to startup Xpress Recovery2, press any key to enter Xpress Recovery2.
- After you use the backup function in Xpress Recovery2 for the first time, Xpress Recovery2 will stay
 permanent in your hard drive. If you wish to enter Xpress Recovery2 later, simply press <F9> during the
 POST.

C. Using the Backup Function in Xpress Recovery2



Step 1:

Select **BACKUP** to start backing up your hard drive data.

A Company The appropries	_			1618 K	
Compare The sporter Land B Later Tan Contractor		Loose Soul Participal Sales Longin Bear Participal Stationing of	Fam.	Artista Del Verservert	1
Bellen Jane Best Jane Best Jahren Best Jahren Best Jahren	Хр	ress Recovery2	will autor	matically c	reate a
A Deterthospe	nev	v partition to stor	e the back	up image fi	e.
	\sim				
	-				
	Tana Indiana	BUT OF ANY Number And Appendix State of the	110 00 martin, 100- Cardyners		
	Time 1 Incode do	2010			
	300 ADMR	GGIPTE BI UN 18-CPI Multi-Chrim, Falturi			

Step 2:

When finished, go to **Disk Management** to check disk allocation.

D. Using the Restore Function in Xpress Recovery2



Select **RESTORE** to restore the backup to your hard drive in case the system breaks down. The **RESTORE** option will not be present if no backup is created before.

E. Removing the Backup



Step 1: If you wish to remove the backup file, select **REMOVE**.



Step 2:

After the backup file is removed, no backup image file will be present in **Disk Management** and hard drive space will be freed up.



F. Exiting Xpress Recovery2

Select REBOOT to exit Xpress Recovery2.

4-2 BIOS Update Utilities

GIGABYTE motherboards provide two unique BIOS update tools, Q-Flash[™] and @BIOS[™]. GIGABYTE Q-Flash and @BIOS are easy-to-use and allow you to update the BIOS without the need to enter MS-DOS mode. Additionally, this motherboard features the DualBIOS[™] design, which enhances protection for the safety and stability of your computer by adding one more physical BIOS chip.



What is DualBIOS[™]?

Motherboards that support DualBIOS have two BIOS onboard, a main BIOS and a backup BIOS. Normally, the system works on the main BIOS. However, if the

main BIOS is corrupted or damaged, the backup BIOS will take over on the next system boot and copy the BIOS file to the main BIOS to ensure normal system operation. For the sake of system safety, users cannot update the backup BIOS manually.



What is Q-Flash[™]?

With Q-Flash you can update the system BIOS without having to enter operating systems like MS-DOS or Window first. Embedded in the BIOS, the Q-Flash tool

frees you from the hassles of going through complicated BIOS flashing process.



What is @BIOS[™]?

@BIOS allows you to update the system BIOS while in the Windows environment. @BIOS will download the latest BIOS file from the nearest @BIOS server

site and update the BIOS.

4-2-1 Updating the BIOS with the Q-Flash Utility

A. Before You Begin

- From GIGABYTE's website, download the latest compressed BIOS update file that matches your motherboard model.
- Extract the file and save the new BIOS file (e.g. 88GMAD22.F1) to your floppy disk, USB flash drive, or hard drive. Note: The USB flash drive or hard drive must use FAT32/16/12 file system.
- 3. Restart the system. During the POST, press the <End> key to enter Q-Flash. Note: You can access Q-Flash by either pressing the <End> key during the POST or pressing the <F8> key in BIOS Setup. However, if the BIOS update file is saved to a hard drive in RAID/AHCI mode or a hard drive attached to an independent IDE/SATA controller, use the <End> key during the POST to access Q-Flash.



Because BIOS flashing is potentially risky, please do it with caution. Inadequate BIOS flashing may result in system malfunction.

B. Updating the BIOS

When updating the BIOS, choose the location where the BIOS file is saved. The following procedure assumes that you save the BIOS file to a floppy disk.

Step 1:


 Insert the floppy disk containing the BIOS file into the floppy disk drive. In the main menu of Q-Flash, use the up or down arrow key to select Update BIOS from Drive and press <Enter>.



- The Save Main BIOS to Drive option allows you to save the current BIOS file.
- Q-Flash only supports USB flash drive or hard drives using FAT32/16/12 file system.
 - If the BIOS update file is saved to a hard drive in RAID/AHCI mode or a hard drive attached to an independent IDE/SATA controller, use the <End> key during the POST to access Q-Flash.
- 2. Select Floppy A and press <Enter>.

Q	Flash Utility v2.15	
Flash Type/Size	MXIC 25L8005/8006	1M
	0 file(s) found	n i
Floppy A	<drive></drive>	
HDD 1-0	<drive></drive>	
Enter		Off
Total size : 0	Free size : 0	011

3. Select the BIOS update file and press <Enter>.



Step 2:


The process of the system reading the BIOS file from the floppy disk is displayed on the screen. When the message "Are you sure to update BIOS?" appears, press <Enter> to begin the BIOS update. The monitor will display the update process.



- Do not turn off or restart the system when the system is reading/updating the BIOS.
- Do not remove the floppy disk, USB flash drive, or hard drive when the system is updating the BIOS.

Step 3:

When the update process is complete, press any key to return to the main menu.



Step 4:

Press <Esc> and then <Enter> to exit Q-Flash and reboot the system. As the system boots, you should see the new BIOS version is present on the POST screen.

Step 5:

During the POST, press <Delete> to enter BIOS Setup. Select Load Optimized Defaults and press <Enter> to load BIOS defaults. System will re-detect all peripheral devices after a BIOS update, so we recommend that you reload BIOS defaults.

		CMOS Setu	p Utility-Copyright	(C) 1984-2	2010 Award Software		
[[►	MB Intelligent Tweaker(M.I.T.)			Load Fail-Safe Defaults		
	►	Standard CMOS Features			Load Optimized Defaults		
	►	Advanced BIOS Features	eatures		Set Supervisor Password		
	►	 Integrated Peripherals 			Set User Password		
	 Power Manageme PnP/PCI Configur Load Optimized I 						
			Defaults (Y/N)? Y				
	►	PC Health Status					
	ESC	: Quit	↑↓→←: Select It	em	F11: Save CMOS to BIOS		
	F8: Q-Flash F10: Save &		F10: Save & Exi	t Setup	F12: Load CMOS from BIOS		
	Load Optimized Defaults						

Press <Y> to load BIOS defaults

Step 6:

Select **Save & Exit Setup** and then press <Y> to save settings to CMOS and exit BIOS Setup. The procedure is complete after the system restarts.

4-2-2 Updating the BIOS with the @BIOS Utility

A. Before You Begin

- In Windows, close all applications and TSR (Terminate and Stay Resident) programs. This helps prevent 1. unexpected failures when performing a BIOS update.
- 2. During the BIOS update process, ensure the Internet connection is stable and do NOT interrupt the Internet connection (for example, avoid a power loss or switching off the Internet). Failure to do so may result in a corrupted BIOS or a system that is unable to start.
- 3. Do not use the G.O.M. (GIGABYTE Online Management) function when using @BIOS.
- 4. GIGABYTE product warranty does not cover any BIOS damage or system failure resulting from an inadequate BIOS flashing.

B. Using @BIOS

@BIOS CURRENT MOTHERBOARD	0 000
Flash Memory Type : MXIC 25L8005/8006	Update BIOS from GIGABYTE Server
Flash Memory Size : 8M bits	Update BIOS from File
BIOS Sign on Message : GA-880GMA-UD2H D2 BIOS Vendor : AWARD BIOS	Save Current BIOS to File
BIUS VEIDUR : AWARD BIUS	About @BIOS
Load CMOS default after BIOS update Clear DMI data Pool	GIGABYTE

1. Update BIOS from GIGABYTE Server 🛃 Update the BIOS Using the Internet Update Function:

Click Update BIOS from GIGABYTE Server, select the @BIOS server site closest to your location and then download the BIOS file that matches your motherboard model. Follow the on-screen instructions to complete.



If the BIOS update file for your motherboard is not present on the @BIOS server site, please manually download the BIOS update file from GIGABYTE's website and follow the instructions in "Update the BIOS without Using the Internet Update Function" below.

2.

Click Update BIOS from File, then select the location where you save the BIOS update file obtained from the Internet or through other source. Follow the on-screen instructions to complete.

3. Save Current BIOS to File

Click Save Current BIOS to File to save the current BIOS file.

4. S Load CMOS default after BIOS update Load BIOS Defaults after BIOS Update:

Select the Load CMOS default after BIOS update check box and then the system will automatically load BIOS defaults after BIOS update and after the system restarts.

C. After Updating the BIOS

Restart your system after updating the BIOS.



Make sure that the BIOS file to be flashed matches your motherboard model. Updating the BIOS with an incorrect BIOS file could cause your system not to boot.

4-3 EasyTune 6

GIGABYTE's EasyTune 6 is a simple and easy-to-use interface that allows users to fine-tune their system settings or do overclock/overvoltage in Windows environment. The user-friendly EasyTune 6 interface also includes tabbed pages for CPU and memory information, letting users read their system-related information without the need to install additional software.

The EasyTune 6 Interface

nednoda	Ratio Core Boo	HE .		Easy	Advance
	Power On	Target		Settings	Rese
CPU	2800.00 MHz	809.44 MHz			
FSB	200 MHz	200 MHz	40		+0
Memory	1332 MHz	1332 MHz			
PCI-E	100 MHz	100 MHz			
PCI	33 MHz	33 MHz			
Eas	y Boost	Easy Boost is an ove Edition CPUs and a further than it was a	educting flows the	utility set for A CPU to be ov	MD Black

Tabs Information

Tab	Function
CPU	The CPU tab provides information on the installed CPU and motherboard.
Memory	The Memory tab provides information on the installed memory module(s). You can select memory module on a specific slot to see its information.
C Tuner	 The Tuner tab allows you to change system clock settings and voltages. Easy mode allows you to adjust the CPU FSB only. Advanced mode allows you to individually change system clock settings and voltages settings using the sliders. Easy Boost is an easy-to-use auto-overclocking function ^(Note 1). When activated, the system automatically experiments all sorts of overclocking configurations till it hangs. After restart, the system will operate with the optimum configurations tested to let the CPU reach the best overclocking performance. Core Boost is configurable only in Advanced mode. With Core Boost ^(Note 2) enabled, you can unlock hidden CPU cores or disable the cores that have been activated ^(Note 3). Save allows you to load previous settings from a profile. After making changes in Easy mode/Advanced mode, be sure to click Set for these changes to take effect or click Default to restore to default values.
Graphics	The Graphics tab allows you to change the core clock and memory clock for your ATI or NVIDIA graphics card.
🌍 Smart	The Smart tab allows you to specify a Smart Fan mode. Smart Fan allows the CPU fan speed to be changed linearly based on the CPU temperature thresholds you set.
HW Monitor	The HW Monitor tab allows you to monitor hardware temperature, voltage and fan speed and set temperature/fan speed alarm. You can choose the alert sound from the buzzer or use your own sound file (.wav file).

(Note 1) Before enabling Easy Boost, right-click the EasyTune 6 icon with the notification area. Select Auto overclock last tune on the next reboot to allow the system to work with the optimum overclocking configuration after restart.

(Note 2) Restart the computer after enabling Core Boost for the settings to take effect.

(Note 3) The number of CPU cores that can be enabled/disabled depends on the CPU being used.



Available functions in EasyTune 6 may differ by motherboard model. Grayed-out area(s) indicates that the item is not configurable or the function is not supported.

Incorrectly doing overclock/overvoltage may result in damage to the hardware components such as CPU, chipset, and memory and reduce the useful life of these components. Before you do the overclock/overvoltage, make sure that you fully know each function of EasyTune 6, or system instability or other unexpected results may occur.

4-4 Easy Energy Saver

GIGABYTE Easy Energy Saver is a revolutionary technology that delivers unparalleled power savings with a click of the button. Featuring an advanced proprietary software design, GIGABYTE Easy Energy Saver is able to provide exceptional power savings and enhanced power efficiency without sacrificing computing performance.

The Easy Energy Saver Interface

A. Meter Mode

In Meter Mode, GIGABYTE Easy Energy Saver shows how much power they have saved in a set period of time.



Meter Mode - Button Information Table

	Button Description	
1	Easy Energy Saver On/Off Switch (Default: Off)	
2	Dynamic CPU Frequency Function On/Off Switch (Default: Off) (Note 1)	
3	CPU Throttling Display	
4	CPU Voltage Display	
5	3-Level CPU Voltage Switch (Default:1) (Note 2)	
6	Current CPU Power Consumption	
7	Meter Time	
8	Power Saving (Calculate power savings based on time)	
9	Meter/Timer Reset Switch	
10	Meter Mode Switch	
11	Total Mode Switch	
12	Close (Application will enter Stealth Mode)	
13	Minimize (Application will continue to run in taskbar)	
14	INFO/Help	
15	Live Utility Update (Check for the latest utility version)	

• The above data is for reference only. Actual performance may vary depending on motherboard model.

• CPU Power and Power Scores are for reference only. Actual results may vary based on testing method.

B. Total Mode

In Total Mode, users are able to see how much total power savings they have accumulated in a set period of time since activating Easy Energy Saver for the first time (Note 3).



Total Mode - Button Information Table

	Button Description	
1	Easy Energy Saver On/Off Switch (Default: Off)	
2	Dynamic CPU Frequency Function On/Off Switch (Default: Off) (Note 1)	
3	CPU Throttling Display	
4	CPU Voltage Display	
5	3-Level CPU Voltage Switch (Default:1) (Note 2)	
6	Current CPU Power Consumption	
7	Time/Date Easy Energy Saver Enabled	
8	Total Power Savings (Total power saving with Easy Energy Saver enabled) (Note 4)	
9	Meter Mode Switch	
10	Total Mode Switch	
11	Close (Application will enter Stealth Mode)	
12	Minimize (Application will continue to run in taskbar)	
13	INFO/Help	
14	Live Utility Update (Check for the latest utility version)	

C. Stealth Mode

In Stealth Mode, the system continues to work with the user-defined power saving settings, even after the system is restarted. Re-enter the application only if you want to make any changes or completely close the application.

- (Note 1) Maximize system power saving with Dynamic CPU Frequency Function; system performance may be affected.
- (Note 2) 1: Normal Power Saving (default); 2: Advanced Power Saving; 3: Extreme Power Saving.
- (Note 3) The total amount of power saved will be recorded until re-activated when only the Easy Energy Saver is under the enable status, and power savings meter is unable to reset to zero.
- (Note 4) Easy Energy Saver Meter will automatically reset when the total power saving reaches 99999999 Watts.

4-5 Q-Share

Q-Share is an easy and convenient data sharing tool. After configuring your LAN connection settings and Q-Share, you are able to share your data with computers on the same network, making full use of Internet resources.



Directions for using Q-Share

After installing Q-Share from the motherboard driver disk, go to Start>All Programs>GIGABYTE>Q-Share. exe to launch the Q-Share tool. Find the **Q-Share** icon **i** in the notification area and right-click on this icon to configure the data sharing settings.

Enable Incoming Folder	
Open Incoming Folder : C:\Q-ShareFolder	
Change Incoming Folder : C:\Q-ShareFolder	



Figure 1. Data Sharing Disabled

Figure 2. Data Sharing Enabled

Options Descriptions

Description
Displays the computers with data sharing enabled
Enables data sharing
Disables data sharing
Accesses the shared data folder
Changes the data folder to be shared (Note)
Updates Q-Share online
Displays the current Q-Share version
Exits Q-Share

(Note) This option is available only when data sharing is NOT enabled.

4-6 SMART Recovery

With SMART Recovery, users can quickly create backups of changed data files (Note 1) or copy files from a specific backup on PATA and SATA hard drives (partitioned on NTFS file system) in Windows Vista.


imart Recovery Pri	derence				-
Enable					
Schedule					
Set the daily solve	dule for creatin	g a restore ;	point.		
Storing Time : 1	2:00:00 AM	(d)			
Capacity					
Set the maximum					
for storing restore	point. The reco	ommend valu	ue is 30 percen	E.	
	0				03203
15%				501	30%
			_		
			OK		Cancel
	_				

Instructions:

In the main menu, click the **Config** button to open the **Smart Recovery Preference** dialog box.

The Smart Recovery Preference dialog box:

Button	Function
Enable	Enables automatic daily backup (Note 2)
LIIADIE	Lindbles automatic daily backup
Schedule	Sets a daily backup schedule
Capacity	Sets the percentage of hard drive space used for
	saving backups (Note 3)



Each partition can accommodate up to 64 backups (the actual limit depends on the size of each partition). When this limit is reached, the oldest backup will be ovewritten.



Instructions for copying files/folders from a backup:

To browse through your backups made at different time, select a backup time using the time scroll bar on the right or at the bottom of the screen. If you want to copy back a file/folder, select the file/folder you wish to copy and click the **Copy** button.

The files/folders listed on the screen are read-only so you cannot edit their contents.

(Note 1) The changed data refers to the data that has been modified, deleted, or newly added since the last backup.

- (Note 2) The system will make an automatic backup on changed data only once everyday. If the computer is turned on for a long time, the backup will be performed at the scheduled backup time. If the computer is turned off before the scheduled backup time, the backup will be performed on the next boot.
- (Note 3) We recommend that you preserve at least 25 percent of the hard drive space to optimize the storage space for the backups. The backups of the changed data will be stored in the original partition of the data.

4.7 Auto Green

Auto Green is an easy-to-use tool that provides users with simple options to enable system power savings via a Bluetooth cell phone. When the phone is out of the range of the computer's Bluetooth receiver, the system will enter the specified power saving mode.



od Bruetoeth Device Wiland	80
Enter the passkey for the Bluetooth device.	8
8 wites	
Use the same passion that you entered on the device.	
Passing: 12340178	
You should shrend use a passion, unless your devi- recommend using a passive that is Site. 16 digits for your secure it will be.	on does not support one. We to The bright the passkey, the
	Back Net > Cancer
	fan tiet) Gener
	face. [Mad) _ Cancer _
	for that Coror
Configuration	
Configuration	Other Settings
Configuration Configure BI devices Device Scan Time(sec) Rescan T	Other Settings

GIGABYTE"

The Configuration dialog box:

First, you have to set your Bluetooth cell phone as a portable key. On the Auto Green main menu, click Configure and then click Configure BT devices. Select the Bluetooth cell phone that you want to use as the portable key (Note 1). (If the screen doesn't display your Bluetooth cell phone, click Refresh to let Auto Green re-detect the device.)



Before creating a Bluetooth cell phone key, make sure your motherboard has a Bluetooth receiver and you have turned on the search and Bluetooth functions on your phone.



Configuring the Bluetooth cell phone key:

After you select a cell phone, the Add Bluetooth Device Wizard as shown on the left will appear. Enter a passkey (8~16 digits recommended) which will be used for pairing with the cell phone. Then enter the same passkey on your cell phone.

Configuring other Bluetooth settings:

On the Other Settings tab, you can set how much time it takes to scan your Bluetooth cell phone key, how many times to rescan the key to make sure it is in range of your computer, and when to turn off the hard drive if the system energy saving state lasts over the predetermined period of time. After completing the settings, click Set for the settings to take effect and then click Exit to guit.

Device Scan Time (sec.):

Set the length of time Auto Green scans your Bluetooth cell phone key, ranging from 5 to 30 seconds in 5-second increment. Auto Green searches for the key based on the length of time you set.

Rescan Times:

Set how many times Auto Green will rescan your Bluetooth cell phone key if it does not detect it, ranging from 2 to 5 times. Auto Green will keep rescanning according to the times you set. When the times limit is reached and your Bluetooth cell phone key is still not detected, the system will enter the selected energy saving mode.

Turn off HD:

Set when to turn off the hard drive. If the system inactivity time exceeds the specified time limit, the hard drive will be turned off.



Selecting a system energy saving mode:

Depending on your needs, select a system power saving mode on the Auto Green main menu and click Save to save the settings.

Button	Description
Standby	Enters Power on Suspend mode
Suspend	Enters Suspend to RAM mode
Disable	Disables this function

The Bluetooth dongle included in the motherboard package^(Note 2) allows you to wake up the system from Suspend to RAM mode without the need to press the power button first.

If your cell phone has been configured as the Auto Green key, you'll not be able to use it to connect to other Blu-(Note 1) etooth device(s) when Auto Green is enabled.

(Note 2) Whether the Bluetooth dongle is included depends on the motherboard models. Before installing the Bluetooth dongle, be sure to turn off other Bluetooth receiver on your computer.

Chapter 5 Appendix

5-1 Configuring SATA Hard Drive(s)

To configure SATA hard drive(s), follow the steps below:

- A. Install SATA hard drive(s) in your computer.
- B. Configure SATA controller mode in BIOS Setup.
- C. Configure a RAID array in RAID BIOS. (Note 1)
- D. Make a floppy disk containing the SATA RAID/AHCI driver for Windows XP. (Note 2)
- E. Install the SATA RAID/AHCI driver (Note 2) and operating system.

Before you begin

Please prepare:

- At least two SATA hard drives (to ensure optimal performance, it is recommended that you use two hard drives with identical model and capacity). If you do not want to create RAID, you may prepare only one hard drive.
- An empty formatted floppy disk.
- Windows Vista/XP setup disk.
- Motherboard driver disk.

5-1-1 Configuring AMD SB850 SATA Controller

A. Installing SATA hard drive(s) in your computer

Attach one end of the SATA signal cable to the rear of the SATA hard drive and the other end to available SATA port on the motherboard. Then connect the power connector from your power supply to the hard drive.

(Note 1) Skip this step if you do not want to create RAID array on the SATA controller.

(Note 2) Required when the SATA controller is set to AHCI or RAID mode.

B. Configuring SATA controller mode in BIOS Setup

Make sure to configure the SATA controller mode correctly in system BIOS Setup.

Step 1:

Turn on your computer and press <Delete> to enter BIOS Setup during the POST (Power-On Self-Test). Make sure **OnChip SATA Controller** is enabled. To enable RAID for the SATA3_0/1/2/3 connectors, set **On-Chip SATA Type** to **RAID**. To enable RAID for the SATA3_4 and eSATA connectors, set **OnChip SATA Type** to **RAID** and set **OnChip SATA Port4/5 Type** to **As SATA Type** (Figure 1). To enable support for RAID 5, set **OnChip SATA RAID5 Support** to **Enabled**.

	CMOS Se	tup Utility-Copyright (C) 1984-201 Integrated Peripherals	010 Award Software
•	OnChip SATA Controller OnChip SATA Type OnChip SATA AType OnChip SATA APOrt4/5 Type OnChip SATA RAID5 Support OnChip SATA RAID5 Support Onboard LAN Function Onboard LAN Function Onboard LAN Boot ROM SMART LAN Onboard Audio Function Onboard J394 Function Onboard 1394 Function Onboard USB 3.0 Controller USB Legacy Function USB Storage Function Onboard Serial Port 1	[Enabled] [RAID] [As SATA Type] [Enabled] [Enabled] [Enabled] [Disabled] [Press Enter] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Astigned] [Astigned] [Astigned]	Item Help Menu Level >
	L→←: Move Enter: Select F5: Previous Values	+/-/PU/PD: Value F10: S F6: Fail-Safe Defaults	Save ESC: Exit F1: General Help F7: Optimized Defaults

Figure 1

Step 2: Save changes and exit BIOS Setup.



The BIOS Setup menus described in this section may differ from the exact settings for your motherboard. The actual BIOS Setup menu options you will see shall depend on the motherboard you have and the BIOS version.

C. Configuring RAID set in RAID BIOS

Enter the RAID BIOS setup utility to configure a RAID array. Skip this step and proceed with the installation of Windows operating system for a non-RAID configuration.

Step 1:

After the POST memory test begins and before the operating system boot begins, look for a message which says "Press <Ctrl-F> to enter RAID Option ROM Utility" (Figure 2). Press <Ctrl> + <F> to enter the RAID BIOS setup utility.



Figure 2

Step 2:

Main Menu

This is the first option screen when you enter the BIOS RAID Setup utility. (Figure 3).

To view the disk drives assigned to arrays, press <1> to enter the **View Drive Assignments** window.

To create an array, press <2> to enter the LD View/LD Define Menu window.

To delete an array, press <3> to enter the **Delete LD Menu** window.

To view controller settings, press <4> to enter the Controller Configuration window.

Option ROM Utility (c) 2009 Adv	anced Micro Devices, Inc.	
	[Main Menu]	
	View Drive Assignments [1] LD View/ LD Define Menu. [2] Delete LD Menu. [3] Controller Configuration. [4]	
	[Keys Available]	
Press 14 to Select Option		[ESC] Exit

Figure 3

Create Arrays Manually

To create a new array, press <2> to enter the LD View Menu window (Figure 4). To create an array, press <Ctrl+C> to access the LD Define Menu.

Option ROM Utility (c) 2009 Advanced Micro Devices, Inc.
[LD View Menu]
< There is no any LD >
[1] [1] [1] Down [PaUp/PaDn] Switch Page [Ctrl+C] Define LD [Enter] View LD [Ctrl+V] View Single Disk [ESC] Exit

Figure 4


In the LD Define Menu, use the up or down arrow key to move to an item for further configuration (Figure 5).

IDN: I	D Maura			D	
LD No L	D Name		RAID Mode	Drv	
LD 1 L	ogical Drive 1		RAID 0		
Stripe Blocl Gigabyte Bo	k: 64 KB oundary: ON		Fast Init: Cache Mode:	ON WriteThru	
Port:ID 01:00 02:00	Drive Model WDC WD800JD-22LSA0 WDC WD800JD-22LSA0	Capabilitie SATA 3G SATA 3G	s Capacit 79.8 80.0		Assignment N N
[1]][n [4]]Dov	vn [PaUp/PaDn] Switch Page	= [Keys Available] = [Space] Change Option			

Figure 5

In the following procedure, we'll create RAID 0 as an example.

- 1. Under the **RAID Mode** section, press the <SPACE> key to select **RAID 0**.
- 2. Set the Stripe Block size. 64 KB is the default.
- 3. Under the Drives Assignments section, press the up or down arrow key to highlight a drive.
- 4. Press the <SPACE> key or <Y>to change the Assignment option to Y. This action adds the drive to the disk array. The Drv section will show the number of disks assigned.
- 5. Press <Ctrl>+<Y> keys to save the information. The message in Figure 6 will appear. Press <Ctrl+Y> to input the array name. If you do not input the array name, the default array name will be used.



When the next message appears, press <Ctrl>+<Y> to clear the MBR or press other keys to ignore this option.





 Then, the message in Figure 8 will appear. Press <Ctrl>+<Y> to set the capacity of the RAID array or press other keys to set the array to its maximum capacity.



Figure 8

- 8. After the creation is complete, the screen will return to LD View Menu where you will see the newlycreated array.
- 9. Press <Esc> to return to Main Menu and press <Esc> again if you want to exit the RAID BIOS utility.

View Drive Assignments

The **View Drive Assignments** option in the **Main Menu** displays whether the attached hard drives are assigned to a disk array or are unassigned. Under the **Assignment** column, drives are labeled with their assigned disk array or shown as **Free** if unassigned.

Optio	on ROM U1	tility (c) 2009 Advanced Micro		Assignments] =====	
	Port:ID	Drive Model	Capabilities	Capacity (GB)	Assignment
	01:00	WDC WD800JD-22LSA0	SATA 3G	79.89	
	02:00	Extent 1 WDC WD800JD-22LSA0	SATA 3G	79.82 80.2	LD 1-1
		Extent 1		80.02	LD 1-2
			E Kevs A	wailable]	
] Up [↓] l SC] Exit	Down [PaUp/PaDn] Switch P			

Figure 9

Delete an Array

The Delete Array menu option allows for deletion of disk array assignments.



Deleting an existing disk array could result in loss of data. Record all array information including the array type, the disk members, and stripe block size in case you wish to undo a deletion.

- 1. To delete an array, press <3> in the **Main Menu** to enter the **Delete LD Menu**. Then highlight the array you wish to delete and press the <Delete> key or the <Alt>+<D> keys.
- The View LD Defination Menu will appear (as shown in Figure 10) showing which drives are assigned to this array. Press <Ctrl>+<Y> if you are sure to delete the array or other keys to abort.
- 3. When the array is deleted, the screen will return to Delete LD Menu. Press <Esc>to return to Main Menu.

LD No LI	D Name	iew LD Defination Menu	RAID Mode	Drv	Capacity(GB)
LD 1 GI	ЗТ		RAID 0		
Stripe Block	: 64 KB		Cache Mode:		
		[Drives Assignments]			
Port:ID 01:00	Drive Model WDC WD800JD-22LSA0	Capabilities SATA 3G	Capacit 79 8		
02:00	WDC WD800JD-22LSA0 WDC WD800JD-22LSA0	SATA 3G	79.8 80.0		
		to delete the data in the d other key to abort	isk!		

5-1-2 Making a SATA RAID/AHCI Driver Diskette

(Required for AHCI and RAID Mode)

To successfully install operating system onto SATA hard drive(s) that is/are configured to RAID/AHCI mode, you need to install the SATA controller driver during the OS installation. Without the driver, the hard drive may not be recognized during the Windows setup process. First of all, copy the driver for the SATA controller from the motherboard driver disk to a floppy disk. For installing Windows Vista, you also can copy the SATA controller driver driver driver from the motherboard driver disk to a USB flash drive. See the instructions below about how to copy the driver in MS-DOS and Windows mode.

In MS-DOS mode:

Prepare a startup disk that has CD-ROM support and a blank formatted floppy disk. Steps:

- 1: Boot from the startup disk.
- 2: Remove the startup disk and insert the prepared floppy disk and the motherboard driver disk (here we assume that the drive letter for your optical drive is D:\).
- 3: At the A:\> prompt, type the following command. Press <Enter> after the command (Figure 1):

A:\>copy	d:	\bootdrv	\SB8xxx'	\x86*.	* (Note)

A:\\dir Uolume in drive A is GIGABWTE Uolume Serial Number is 100D-3259 Directory of A:\	
Alloopy ditheetdretskoochd65*.*_	
Figu	ure 1

(Note) Type the driver directory based on the operating system to be installed. Refer to the following table for the SATA driver directories for different Windows operating systems.

Operating System	Directory
Windows XP 32-bit	Bootdrv\SBxxx\x86
Windows XP 64-bit	Bootdrv\SBxxx\x64
Windows Vista 32-bit (AHCI mode)	Bootdrv\SBxxxV\AHCI\LHx86
Windows Vista 32-bit (RAID mode)	Bootdrv\SBxxxV\RAID\LH
Windows Vista 64-bit (AHCI mode)	Bootdrv\SBxxxV\AHCI\LHx64
Windows Vista 64-bit (RAID mode)	Bootdrv\SBxxxV\RAID\LH64A
Windows 7 32-bit (AHCI mode)	Bootdrv\SBxxxW7\AHCI\Win7x86
Windows 7 32-bit (RAID mode)	Bootdrv\SBxxxW7\RAID\W7
Windows 7 64-bit (AHCI mode)	Bootdrv\SBxxxW7\AHCI\Win7x64
Windows 7 64-bit (RAID mode)	Bootdrv\SBxxxW7\RAID\W764A

In Windows mode:

Steps:

- 1: Use an alternative system and insert the motherboard driver disk.
- 2: From your optical drive folder, double click the Menu.exe file in the BootDrv folder (Figure 2). A Command Prompt window will open similar to that in Figure 3.
- 3: Insert the blank formatted disk. Select the controller driver by pressing the corresponding letter from the menu and press <Enter>. For example, from the menu in Figure 3, select 3) ATI AHCI/RAID Driver for XP for Windows XP operating system.

Your system will then automatically copy the driver files to the floppy disk. Press any key to exit when finished.








Figure 2


5-1-3 Installing the SATA RAID/AHCI Driver and Operating System

With the SATA RAID/AHCI driver diskette and correct BIOS settings, you are ready to install Windows Vista/ XP onto your hard drive(s). The followings are examples of Windows XP and Vista installation.

A. Installing Windows XP

Step 1:

Restart your system to boot from the Windows XP setup disk and press <F6> as soon as you see the message "Press F6 if you need to install a 3rd party SCSI or RAID driver" (Figure 1). A screen will then appear asking you to specify additional device.





Step 2:

Insert the floppy disk containing the SATA RAID/AHCI driver and press <S>. Then a controller menu similar to Figure 2 below will appear. Select **AMD AHCI Compatible RAID Controller-x86 platform** and press <Enter>.




Figure 2

Step 3:

On the next screen, press <Enter> to continue the driver installation. After the driver installation, you can proceed with the Windows XP installation.

B. Installing Windows Vista

The procedure below assumes that only one RAID array exists in your system.

Step 1:

Restart your system to boot from the Windows Vista setup disk and perform standard OS installation steps. When a screen similar to that below appears (RAID hard drive will not be detected at this stage), select **Load Driver** (Figure 3).

Drive option	s (gdvanced)
	Drive option

Figure 3

Step 2:

Insert the motherboard driver disk (Method A) or the removable storage device such as USB flash drive that contains the SATA RAID/AHCI driver (Method B), then specify the location of the driver (Figure 4). Note: For users using a SATA optical drive, be sure to copy the driver files from the motherboard driver disk to a USB flash drive before installing Windows Vista (go to the **BootDrv** folder and save the whole **SBxxxV** folder to the USB flash drive). Then use Method B to load the driver.

Method A:


Insert the motherboard driver disk into your system and browse to the following directory:

\BootDrv\SBxxxV\RAID\LH

For Windows Vista 64-bit, browse to the LH64A folder.

Method B:

Insert the USB flash drive containing the driver files and browse to the LH (for Windows Vista 32-bit) or LH64A (for Windows Vista 64-bit) folder.



Step 3:

When a screen as shown in Figure 5 appears, select AMD AHCI Compatible RAID Controller and click Next.

	installed.		
AND AHCI Compatible	RAID Controller		
1		in commentant	
Hide drivers that are not o			

Step 4:

After the driver is loaded, the RAID drive will appear. Select the RAID drive and then click **Next** to continue the OS installation (Figure 6).

	Name	Total Size	Free Space Type	
S.	Disk 0 Unallocated Space	80.0 GB	80.0 GB	

Figure 6

Rebuilding an Array:

Rebuilding is the process of restoring data to a hard drive from other drives in the array. Rebuilding applies only to fault-tolerant arrays such as RAID 1, RAID 5, or RAID 10. To replace the old drive, make sure to use a new drive of equal or greater capacity. The procedures below assume a new drive is added to replace a failed drive to rebuild a RAID 1 array.

While in the operating system, make sure the chipset drivers have been installed from the motherboard driver disk. Then launch the **AMD RAIDXpert** from **All Programs** in the **Start Menu**.



Step 1:

Enter the login ID and password (default: "admin"), and then click **Sign in** to launch **AMD RAIDXpert**.



Step 3:

Select one available drive and click **Start Now** to start the rebuilding process.



Step 2:

Select the RAID array to be rebuilt under Logical Drive View and click the Rebuild tab in the Logical Drive Information pane.



Step 4:

The rebuilding progress is displayed on the screen and you can select **Pause/Resume/ Abort/Restart** during the rebuilding process.



Step 5:

When done, the array's status on the **Information** page in the **Logical Drive Information** pane will display as **Functional**.

5-2 Configuring Audio Input and Output

5-2-1 Configuring 2/4/5.1/7.1-Channel Audio

The motherboard provides six audio jacks on the back panel which support 2/4/5.1/7.1-channel ^(Note) audio. The picture to the right shows the default audio jack assignments.

The integrated HD (High Definition) audio provides jack retasking capability that allows the user to change the function for each jack through the audio driver.



For example, in a 4-channel audio configuration, if a Side speaker is plugged into the default Center/Subwoofer speaker out jack, you can retask the Center/Subwoofer speaker out jack to be Side speaker out.



To install a microphone, connect your microphone to the Mic in jack and manually configure the jack for microphone functionality.

Audio signals will be present on both of the front and back panel audio connections simultaneously. If you want to mute the back panel audio (only supported when using an HD front panel audio module), refer to instructions on the next page.

High Definition Audio (HD Audio)

HD Audio includes multiple high quality digital-to-analog converters (DACs) that support 44.1KHz/48KHz/ 96KHz/192KHz sampling rate. HD Audio features multistreaming capabilities that allow multiple audio streams (in and out) to be simultaneously processed. For example, users can listen to MP3 music, have an Internet chat, make a telephone call over the Internet, and etc. all at the same time.

A. Configuring Speakers

(The following instructions use Windows Vista as the example operating system.)

Step 1:

After installing the audio driver, the **HD Audio Manager** icon **a** will appear in the notification area. Double-click the icon to access the **HD Audio Manager**.



(Note) 2/4/5.1/7.1-Channel Audio Configurations:

Refer to the following for multi-channel speaker configurations.

- 2-channel audio: Headphone or Line out.
- 4-channel audio: Front speaker out and Side speaker out.
- 5.1-channel audio: Front speaker out, Side speaker out, and Center/Subwoofer speaker out.
- 7.1-channel audio: Front speaker out, Rear speaker out, Center/Subwoofer speaker out, and Side speaker out.

Step 2:

Connect an audio device to an audio jack. The **The cur**rent connected device is dialog box appears. Select the device according to the type of device you connect. Then click **OK**.

Step 3:

On the **Speakers** screen, click the **Speaker Configuration** tab. In the **Speaker Configuration** list, select **Stereo**, **Quadraphonic**, **5.1 Speaker**, or **7.1 Speaker** according to the type of speaker configuration you wish to set up. Then the speaker setup is completed.

B. Configuring Sound Effect

You may configure an audio environment on the Sound Effects tab.

C. Activating an AC'97 Front Panel Audio Module

If your chassis provides an AC'97 front panel audio module, to activate the AC'97 functionality, click the tool icon on the **Speaker Configuration** tab. On the **Connector Settings** dialog box, select the **Disable front panel jack detection** check box. Click **OK** to complete.





GIGABYTE

•

D. Muting the Back Panel Audio (For HD Audio Only)

Click Device advanced settings on the top right corner on the Speaker Configuration tab to open the Device advanced settings dialog box. Select the Mute the rear output device, when a front headphone plugged in check box. Click OK to complete.









5-2-2 Configuring S/PDIF In/Out

The S/PDIF In and Out cable (optional) provides S/PDIF In and S/PDIF Out functionalities.




A. Installing the S/PDIF In and Out Cable:



Step 1:

First, attach the connector at the end of the cable to the SPDIF_IO header on your motherboard.





B. Configuring S/PDIF In:

The S/PDIF In jacks on the SPDI/F In and Out cable allow you to input digital audio signals to the computer for audio processing.

Step:

After connecting the S/PDIF In device, access the **Digital Input** screen. Click the **Default Format** tab to select the default format. Click **OK** to complete.

The second secon	Broke advanced
A day, while you be careful and a set of the careful and the c	
Select the sample rate and bit dipth to be used when number in shared made.	Partheau B

(Note) The actual locations of the S/PDIF In and S/PDIF Out connectors may differ by model.

C. Configuring S/PDIF Out:

The S/PDIF out jacks can transmit audio signals to an external decoder for decoding to get the best audio quality. Install the S/PDIF in and out cable (or connect a S/PDIF optical cable to the optical S/PDIF out connector on the motherboard back panel) if you want to output S/PDIF digital audio signals to an external decoder.

C-1. Connecting a S/PDIF Out Cable:

Step:

Connect a S/PDIF coaxial cable or a S/PDIF optical cable (either one) to an external decoder for transmitting the S/PDIF digital audio signals.



S/PDIF Coaxial Cable

C-2. Configuring S/PDIF Out:

Step:

On the **Digital Output** screen ^(Note), click the **Default Format** tab and then select the sample rate and bit depth. Click **OK** to complete.

S/PDIF Optical Cable

The offer order country and the offer sea	Contra advances militaria
Man Kalani L - ()- K Mandhalla (shuhtarar	
Note: Transf Note: Transf No	North Control of Contr
GIGABYTE	-

(Note) Enter the **Digital Output(Optical)** screen to configure further settings if you use the S/PDIF Out connector(s) on the back panel for digital audio output or enter the **Digital Output** screen if you use the internal S/PDIF In/Out connector (SPDIF_IO) for digital audio output.



5-2-3 Enabling the Dolby Home Theater Function



Before Dolby Home Theater is enabled, you get only 2-channel playback output (from the front speakers) when playing 2-channel stereo sources. You must play 4-, 5.1-, or 7.1- channel content to get 4-, 5.1-, or 7.1- channel audio effects. With Dolby Home Theater enabled, 2-channel stereo content will be transformed into multi-channel audio, creating a virtual surround sound environment^(Note).

Install the **Dolby GUI Software** driver from the motherboard driver disk. Click the **Start** icon (20). Point to **All Programs**, **Dolby Control Center** to access the utility.

(The following illustration demonstrates a 7.1-speaker configuration as an example.)



1. Dolby Pro Logic IIx

Click Dolby Pro Logic IIx. The system will expand 2-channel audio for a 7.1-channel surround sound playback.

2. Natural Bass


Click Natural Bass to enable speaker bass effect.


(Note) When Dolby Digital Live is enabled, only digital audio output (S/PDIF) is working, and you will not hear any sound from analog speakers or headphone.

5-2-4 Configuring Microphone Recording

Step 1:

After installing the audio driver, the **HD Audio Manager** icon **and** will appear in the notification area. Double-click the icon to access the **HD Audio Manager**.





Step 2:

Connect your microphone to the Mic in jack (pink) on the back panel or the Mic in jack (pink) on the front panel. Then configure the jack for microphone functionality.

Note: The microphone functions on the front panel and back panel cannot be used at the same time.




Step 3:

Go to the **Microphone** screen. Do not mute the recording volume, or you'll not be able to record the sound. To hear the sound being recorded during the recording process, do not mute the playback volume. It is recommended that you set the volumes at a middle level.







Step 4:

To raise the recording and playback volume for the microphone, click the **Microphone Boost** icon 😰 on the right of the **Recording Volume** slider and set the Microphone Boost level.





Step 5:

After completing the settings above, click **Start**, point to **All Programs**, point to **Accessories**, and then click **Sound Recorder** to begin the sound recording.



* Enabling Stereo Mix

If the HD Audio Manager does not display the recording device you wish to use, refer to the steps below. The following steps explain how to enable Stereo Mix (which may be needed when you want to record sound from your computer).


9

Step 1:

Locate the **Volume** icon **M** in the notification area and right-click on this icon. Select **Recording Devices**.

👽 🤫 📑 🌒 🛛 🙀 🕩 5:45 PM





Step 3:

When the **Stereo Mix** item appears, right-click on this item and select **Enable**. Then set it as the default device.



Step 4:

Now you can access the HD Audio Manager to configure Stereo Mix and use Sound Recorder to record the sound.

Management of the second of th	AREAD AND A ANALOG
Given Dorem March to say the set of the set	North North

5-2-5 Using the Sound Recorder



A. Recording Sound

- 1. Make sure you have connected the sound input device (e.g. microphone) to the computer.
- 2. To record the audio, click the Start Recording button sun Recording.
- 3. To stop recording audio, click the Stop Recording button Stop Recording.

Be sure to save the recorded audio file upon completion.

B. Playing the Recorded Sound

You can play your recording in a digital media player program that supports your audio file format.

5-3 Troubleshooting

5-3-1 Frequently Asked Questions

To read more FAQs for your motherboard, please go to the Support&Downloads\Motherboard\FAQ page on GIGABYTE's website.

- Q: In the BIOS Setup program, why are some BIOS options missing?
- A: Some advanced options are hidden in the BIOS Setup program. Press <Delete> to enter BIOS Setup during the POST. In the Main Menu, press <Ctrl>+<F1> to show the advanced options.
- Q: Why is the light of my keyboard/optical mouse still on after the computer shuts down?
- A: Some motherboards provide a small amount of standby power after the computer shuts down and that's why the light is still on.
- Q: How do I clear the CMOS values?
- A: For motherboards that have a CMOS_SW button, press this button to clear the CMOS values (before doing this, please turn off the computer and unplug the power cord). For motherboards that have a clearing CMOS jumper, refer to the instructions on the CLR_CMOS jumper in Chapter 1 to short the jumper to clear the CMOS values. If your board doesn't have this jumper, refer to the instructions on the motherboard battery in Chapter 1. You can temporarily remove the battery from the battery holder to stop supplying power to the CMOS, which will clear the CMOS values after about one minute.
- Q: Why do I still get a weak sound even though I have turned my speaker to the maximum volume?
- A: Make sure your speaker is equipped with an internal amplifier. If not, try a speaker with power/amplifier.
- Q: Why cannot I install the onboard HD audio driver successfully? (For Windows XP only)
- A: Step 1: First, make sure Service Pack 1 or Service Pack 2 has been installed (check in My Computer > Properties > General > System). If not, please update it from Microsoft's website. Then make sure the Microsoft UAA Bus Driver for High Definition Audio has been installed successfully (check in My Computer > Properties > Hardware > Device Manager > System Devices).
 - Step 2: Check if Audio Device on High Definition Audio Bus or Unknown device is present in Device Manager or Sound, video, and game controllers. If yes, please disable this device. (If not, skip this step.)
 - Step 3: Then go back to My Computer > Properties > Hardware > Device Manager > System devices and right-click on Microsoft UAA Bus Driver for High Definition Audio and select Disable and Uninstall.
 - Step 4: In Device Manager, right-click on the computer name and select Scan for hardware changes. When the Add New Hardware Wizard appears, click Cancel. Then install the onboard HD audio driver from the motherboard driver disk or download the audio driver from GIGABYTE's website to install.

For more details, go to the Support&Downloads\Motherboards\FAQ page on our website and search for "onboard HD audio driver."

- Q: What do the beeps emitted during the POST mean?
- A: The following Award BIOS beep code descriptions may help you identify possible computer problems.

 (For reference only.)
 1 long, 3 short: Keyboard error

 1 short: System boots successfully
 1 long, 3 short: Keyboard error


 2 short: CMOS setting error
 1 long, 9 short: BIOS ROM error


 1 long, 1 short: Memory or motherboard error
 Continuous long beeps: Graphics card not inserted properly

 1 long, 2 short: Monitor or graphics card error
 Continuous short beeps: Power error

5-3-2 Troubleshooting Procedure

If you encounter any troubles during system startup, follow the troubleshooting procedure below to solve the problem.







If the procedure above is unable to solve your problem, contact the place of purchase or local dealer for help. Or go to the **Support&Downloads\Technical Service Zone** page to submit your question. Our customer service staff will reply you as soon as possible.

5-4 Regulatory Statements

Regulatory Notices

This document must not be copied without our written permission, and the contents there of must not be imparted to a third party nor be used for any unauthorized purpose. Contravention will be prosecuted. We believe that the information contained herein was accurate in all respects at the time of printing. GIGABYTE cannot, however, assume any responsibility for errors or omissions in this text. Also note that the information in this document is subject to change without notice and should not be construed as a commitment by GIGABYTE.

Our Commitment to Preserving the Environment

In addition to high-efficiency performance, all GIGABYTE motherboards fulfill European Union regulations for RoHS (Restriction of Certain Hazardous Substances in Electrical and Electronic Equipment) and WEEE (Waste Electrical and Electronic Equipment) environmental directives, as well as most major worldwide safety requirements. To prevent releases of harmful substances into the environment and to maximize the use of our natural resources, GIGABYTE provides the following information on how you can responsibly recycle or reuse most of the materials in your "end of life" product.

Restriction of Hazardous Substances (RoHS) Directive Statement

GIGABYTE products have not intended to add and safe from hazardous substances (Cd, Pb, Hg, Cr+6, PBDE and PBB). The parts and components have been carefully selected to meet RoHS requirement. Moreover, we at GIGABYTE are continuing our efforts to develop products that do not use internationally banned toxic chemicals.

Waste Electrical & Electronic Equipment (WEEE) Directive Statement

GIGABYTE will fulfill the national laws as interpreted from the 2002/96/EC WEEE (Waste Electrical and Electronic Equipment) directive. The WEEE Directive specifies the treatment, collection, recycling and disposal of electric and electronic devices and their components. Under the Directive, used equipment must be marked, collected separately, and disposed of properly.

WEEE Symbol Statement



The symbol shown below is on the product or on its packaging, which indicates that this product must not be disposed of with other waste. Instead, the device should be taken to the waste collection centers for activation of the treatment, collection, recycling and disposal procedure. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health

and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local government office, your household waste disposal service or where you purchased the product for details of environmentally safe recycling.

- When your electrical or electronic equipment is no longer useful to you, "take it back" to your local or regional waste collection administration for recycling.
- If you need further assistance in recycling, reusing in your "end of life" product, you may contact us at the Customer Care number listed in your product's user's manual and we will be glad to help you with your effort.

Finally, we suggest that you practice other environmentally friendly actions by understanding and using the energy-saving features of this product (where applicable), recycling the inner and outer packaging (including shipping containers) this product was delivered in, and by disposing of or recycling used batteries properly. With your help, we can reduce the amount of natural resources needed to produce electrical and electronic equipment, minimize the use of landfills for the disposal of "end of life" products, and generally improve our quality of life by ensuring that potentially hazardous substances are not released into the environment and are disposed of properly.

China Restriction of Hazardous Substances Table

The following table is supplied in compliance with China's Restriction of Hazardous Substances (China RoHS) requirements:



关于符合中国《电子信息产品污染控制管理办法》的声明 Management Methods on Control of Pollution from Electronic Information Products (China RoHS Declaration) 产品中有毒有害物质或元素的名称及含量

Hazardous Substances Table						
				赘(Hazardou:		
部件名称(Parts)	铅(Pb)	汞(Hg)	镐(Cd)	六价络 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB板 PCB	0	0	0	0	0	0
结构件及风扇 Mechanical parts and Fan	×	0	0	0	0	0
芯片及其他主动零件 Chip and other Active components	×	0	0	0	0	0
连接器 Connectors	×	0	0	0	0	0
被动电子元器件 Passive Components	×	0	0	0	0	0
线材 Cables	0	0	0	0	0	0
焊接金属 Soldering metal	0	0	0	0	0	0
助焊剂, 散热膏, 标签及其他耗材 Flux,Solder Paste,Label and other Consumable Materials	0	0	0	0	0	0
O:表示该有毒有當物质在该部件所有均质材料中的含量均在SJ/TI1363-2006标准规定的限量要求以下。 Indicates that this hazardous substance contained in all homogenous materials of this part is below the limit requirement SJ/T 11363-2006						
×:表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。 Indicates that this hazardous substance contained in at least one of the homogenous materials of this part is above the limit requirement in SJ/T 11363-2006						
对销售之日的所受售产品,本表显示我公司供应链的电子信息产品可能包含这些物质。注意。在所售产品中 可能会也可能不会含有所有所列的部件。 This table shows where these substances may be found in the supply chain of our electronic information products, as of the date of the sale of the enclosed products. Note that some of the component types listed above may or may not be a part of the enclosed product.						



. GIGA-BYTE TECHNOLOGY CO., LTD. Address: No.6, Bau Chiang Road, Hsin-Tien, Taipei 231. Taiwan TEL: +886-2-8912-4000 FAX: +886-2-8912-4003 Tech, and Non-Tech, Support (Sales/Marketing) : http://ggts.gigabyte.com.tw WEB address (English): http://www.gigabyte.com WEB address (Chinese): http://www.gigabyte.tw G.B.T. INC. - U.S.A. TEL: +1-626-854-9338

FAX: +1-626-854-9339 Tech. Support: http://rma.gigabyte.us Web address: http://www.gigabyte.us

- G.B.T. INC (USA) - Mexico

Tel: +1-626-854-9338 x 215 (Soporte de habla hispano) FAX: +1-626-854-9339 Correo: soporte@gigabyte-usa.com Tech. Support:

http://rma.gigabyte.us

Web address: http://latam.giga-byte.com

Giga-Byte SINGAPORE PTE, LTD, - Singapore

WEB address : http://www.gigabyte.sg

Thailand

WEB address : http://th.giga-byte.com

Vietnam

WEB address : http://www.gigabyte.vn

 NINGBO G.B.T. TECH. TRADING CO., LTD. - China WEB address : http://www.gigabyte.cn Shanghai TEL:+86-21-63410999 FAX: +86-21-63410100 Beiiina TEL: +86-10-62102838 FAX: +86-10-62102848 Wuhan TEL:+86-27-87851061 FAX: +86-27-87851330 GuangZhou TEL:+86-20-87540700 FAX: +86-20-87544306 Chenadu TEL: +86-28-85236930 FAX: +86-28-85256822 Xian TEL: +86-29-85531943 FAX: +86-29-85510930 Shenvang TEL: +86-24-83992901 FAX: +86-24-83992909 GIGABYTE TECHNOLOGY (INDIA) LIMITED - India WEB address : http://www.gigabyte.in Saudi Arabia WEB address : http://www.gigabyte.com.sa · Gigabyte Technology Pty. Ltd. - Australia WEB address : http://www.gigabyte.com.au

G.B.T. TECHNOLOGY TRADING GMBH - Germany	Hungary
WEB address : http://www.gigabyte.de	WEB address : http://www.giga-byte.hu
• G.B.T. TECH. CO., LTD U.K.	Turkey
WEB address : http://www.giga-byte.co.uk	WEB address : http://www.gigabyte.com.tr
Giga-Byte Technology B.V The Netherlands	Russia
WEB address : http://www.giga-byte.nl	WEB address : http://www.gigabyte.ru
GIGABYTE TECHNOLOGY FRANCE - France	Poland
WEB address : http://www.gigabyte.fr	WEB address : http://www.gigabyte.pl
Sweden	Ukraine
WEB address : http://www.gigabyte.se	WEB address : http://www.gigabyte.ua
• Italy	Romania
WEB address : http://www.giga-byte.it	WEB address : http://www.gigabyte.com.ro
• Spain	Serbia
WEB address : http://www.giga-byte.es	WEB address : http://www.gigabyte.co.rs
• Greece	Kazakhstan
WEB address : http://www.gigabyte.com.gr	WEB address : http://www.gigabyte.kz
Czech Republic	You may go to the GIGABYTE website, select your language
WEB address : http://www.gigabyte.cz	in the language list on the top right corner of the website.

GIGABYTE Global Service System



To submit a technical or non-technical (Sales/Marketing) question, please link to: http://ggts.gigabyte.com.tw Then select your language to enter the system.