

8I845GE-RZ / 8I845GE-RZ-C

Intel® Pentium® 4 Processor Motherboard

User's Manual

Rev. 1001

12ME-I845GERZ-1001

Copyright

© 2004 GIGABYTE TECHNOLOGY CO., LTD

Copyright by **GIGA-BYTE TECHNOLOGY CO., LTD. ("GBT")**. No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of **GBT**.

Trademarks

Third-party brands and names are the property of their respective owners.

Notice

Please do not remove any labels on motherboard, this may void the warranty of this motherboard.

Due to rapid change in technology, some of the specifications might be out of date before publication of this booklet.

The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein.

Declaration of Conformity

The undersigned hereby declares that the product is in conformity with the following standards:

Standard: FCC Part 15, Subpart B, Class B, Digital Device
Standard: FCC Part 15, Subpart B, Class B, Digital Device

I hereby declare that the product is in conformity with the following standards:

In conformity with the following standards:

In accordance with FCC Part 15, Subpart B, Class B, Digital Device

Mother Board

81845GE-RZ

EN 60950

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-2

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-2

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-2

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-2

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-2

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

EN 60950-1

Units and methods of measurement of radio emission characteristics of radio transmitting equipment

Date:

Oct. 15, 2004

Signature:

THERRY HART

DECLARATION OF CONFORMITY

Per FCC Part 2, Section 2.1077(a)



Responsible Party Name: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street

City of Industry, CA 91748

Phone/Fax No: (818) 854-9338/ (818) 854-9339

I hereby declare that the product

Product Name: Motherboard

Model Number: 81845GE-RZ

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109

(a) Class B Digital Device

Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any interference received, including that may cause undesired operation.

Representative Person's Name: ERIC LEE

Signature: Eric Lee

Date: Oct. 15, 2004

Preparing Your Computer

Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

1. Unplug your computer when working on the inside.
2. Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
3. Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.



CAUTION

Installing the motherboard to the chassis

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

Table of Content

Chapter 1 Introduction	5
Features Summary	5
8I845GE-RZ Series Motherboard Layout	7
Block Diagram	8
Hardware Installation Process	9
Step 1: Install the Central Processing Unit (CPU)	9
Step 1-1: CPU Installation	10
Step 1-2: CPU Cooling Fan Installation	10
Step 2: Install Memory Modules	11
Step 3: Install AGP Card	12
Step 4: Install I/O Peripherals Cables	12
Step 4-1: I/O Back Panel Introduction	12
Step 4-2: Connectors Introduction	13
 Chapter 2 BIOS Setup	 21
The Main Menu (For example: BIOS Ver. : F1)	21
Standard CMOS Features	23
Advanced BIOS Features	25
Integrated Peripherals	27
Power Management Setup	29
PnP/PCI Configurations	31
PC Health Status	32
Frequency/Voltage Control	33
Top Performance	34
Load Fail-Safe Defaults	34
Load Optimized Defaults	35
Set Supervisor/User Password	35
Save & Exit Setup	36
Exit Without Saving	36
 Chapter 3 Driver Installation	 37

Chapter 1 Introduction

Features Summary

CPU	<ul style="list-style-type: none"> • Socket 478 for Intel® Pentium® 4 (Northwood, Prescott^(note 1)) processor with HT Technology • Supports 533/400MHz FSB • L2 cache varies with processors
Chipset	<ul style="list-style-type: none"> • North Bridge: Intel® 845GE • South Bridge: Intel® ICH4
Memory	<ul style="list-style-type: none"> • 3 184-pin DDR sockets • Supports DDR333/DDR266 DIMMs^(note 2) • Supports up to 2GB (Max.) • Supports only 2.5V DDR SDRAM
Slots	<ul style="list-style-type: none"> • 1 AGP slot 4X (1.5V) device support • 5 PCI slots
IDE Connections	<ul style="list-style-type: none"> • 2 IDE connection (UDMA 33/ATA 66/ATA 100), allows connection of 4 IDE devices
FDD Connections	<ul style="list-style-type: none"> • 1 FDD connection, allows connection of 2 FDD devices
Peripherals	<ul style="list-style-type: none"> • 1 parallel port supporting Normal/EPP/ECP mode • 1 VGA port, 1 COMA port, onboard COMB connection • 6 USB 2.0/1.1 ports (rear x 2, front x 4 via cable) • 1 front audio connector • 1 PS/2 keyboard port • 1 PS/2 mouse port
Onboard VGA	<ul style="list-style-type: none"> • Built-in Intel® 82845GE Chipset
Onboard LAN	<ul style="list-style-type: none"> • RLT8100C* • 1 RJ45 port*
Onboard Audio	<ul style="list-style-type: none"> • C-Media 9761A CODEC • Supports Line In ; Line Out ; MIC In • Supports 2 / 4 / 6 channel audio • Supports SPDIF In/Out connection • CD In/AUX In/Game Port
BIOS	<ul style="list-style-type: none"> • Use of licensed AWARD BIOS • Supports Q-Flash

to be continued.....

(Note 1) Prescotts processors with up to 533MHz FSB are supported.

(Note 2) Due to (Intel 845PE/GE/GV) chipset architecture limitation, DDR333 memory modules are supported only when you install a Pentium 4 processor with 533MHz FSB.

A Pentium 4 processor with 400MHz FSB will support DDR266 memory modules.


*** For 8I845GE-RZ only.

I/O Control	<ul style="list-style-type: none">• IT8712
Hardware Monitor	<ul style="list-style-type: none">• CPU / System fan speed detection• System voltage detection• CPU temperature detection• CPU/System fan fail warning• CPU overheating warning
Additional Features	<ul style="list-style-type: none">• Supports EasyTune 4• Supports @BIOS
Form Factor	<ul style="list-style-type: none">• ATX form factor; 29.5cm x 21cm



Please set the CPU host frequency in accordance with your processor's specifications. We don't recommend you to set the system bus frequency over the CPU's specification because these specific bus frequencies are not the standard specifications for CPU, chipset and most of the peripherals. Whether your system can run under these specific bus frequencies properly will depend on your hardware configurations, including CPU, Chipsets, Memory, Cards....etc.


8I845GE-RZ Series Motherboard Layout



*** For 8I845GE-RZ only.

For 8I845GE-RZ-C only.

Block Diagram



*** For 8I845GE-RZ only.

Hardware Installation Process


To set up your computer, you must complete the following steps:

Step 1- Install the Central Processing Unit (CPU)

Step 2- Install memory modules

Step 3- Install expansion cards

Step 4- Install I/O Peripherals cables



Step 1: Install the Central Processing Unit (CPU)

Before installing the CPU, please comply with the following conditions:



1. Please make sure that the motherboard supports the CPU.
2. Please take note of the one indented corner of the CPU. If you install the CPU in the wrong direction, the CPU will not insert properly. If this occurs, please change the insert direction of the CPU.
3. Please add an even layer of heat sink paste between the CPU and heatsink.
4. Please make sure the heatsink is installed on the CPU prior to system use, otherwise overheating and permanent damage of the CPU may occur.
5. Please set the CPU host frequency in accordance with the processor specifications. It is not recommended that the system bus frequency be set beyond hardware specifications since it does not meet the required standards for the peripherals. If you wish to set the frequency beyond the proper specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc.

HT functionality requirement content :

Enabling the functionality of Hyper-Threading Technology for your computer system requires all of the following platform components:



- CPU: An Intel® Pentium 4 Processor with HT Technology
- Chipset: An Intel® Chipset that supports HT Technology
- BIOS: A BIOS that supports HT Technology and has it enabled
- OS: An operation system that has optimizations for HT Technology

Step 1-1: CPU Installation




Figure 1.
Pull the rod to the 90-degree directly.




Figure 2.
Locate Pin 1 in the socket and look for a (golden) cut edge on the CPU upper corner. Insert the CPU into the socket. (Do not force the CPU into the socket.) Then move the socket lever to the locked position while holding pressure on the center of the CPU.

Step 1-2: CPU Cooling Fan Installation



Figure 1.
Apply the thermal tape(or grease) to provide better heat conduction between your CPU and cooling fan.



Figure 2.
Fasten the cooling fan supporting-base onto the CPU socket on the motherboard.




Figure 3.
Make sure the CPU fan is plugged to the CPU fan connector, and then the installation is completed.

Step 2: Install Memory Modules



Before installing the memory modules, please comply with the following conditions:

1. Please make sure that the memory used is supported by the motherboard. It is recommended that memory of similar capacity, specifications and brand be used.
2. Before installing or removing memory modules, please make sure that the computer power is switched off to prevent hardware damage.
3. Memory modules have a foolproof insertion design. A memory module can be installed in only one direction. If you are unable to insert the module, please switch the direction.
4. Because of chipset (Intel 845PE/GE) limitations, DDR333 memory modules are supported only when you install a Pentium 4 processor with 533MHz FSB. A Pentium 4 processor with 400MHz FSB will support DDR266 memory modules.

The motherboard has 3 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.




Fig.1

The DIMM socket has a notch, so the DIMM memory module can only fit in one direction. Insert the DIMM memory module vertically into the DIMM socket. Then push it down.



Fig. 1

Fig.2

Close the plastic clip at both edges of the DIMM sockets to lock the DIMM module.

Reverse the installation steps when you wish to remove the DIMM module.




Fig. 2

Step 3: Install AGP Card

1. Read the related expansion card's instruction document before installing the expansion card into the computer.
2. Please make sure your AGP card is AGP 4X (1.5V).




3. Please carefully pull out the small white-drawable bar at the end of the AGP slot when you try to install/ Uninstall the AGP card. Please align the AGP card to the onboard AGP slot and press firmly down on the slot. Make sure your AGP card is locked by the small white-drawable bar.



AGP Card

Step 4: Install I/O Peripherals Cables

Step 4-1: I/O Back Panel Introduction



a PS/2 Keyboard and PS/2 Mouse Connector

To install a PS/2 port keyboard and mouse, plug the mouse to the upper port (green) and the keyboard to the lower port (purple).

b Parallel Port

The parallel port allows connection of a printer, scanner and other peripheral devices.

c Serial Port

Devices like mice, modems, and etc. can be connected to Serial port.

d VGA Port

Monitor can be connected to VGA port.

e Game/MIDI port

This connector supports joystick, MIDI keyboard and other related audio devices.


f Line Out (Front Speaker Out)

Connect the stereo speakers, earphone or front surround channels to this connector.

*** For 8I845GE-RZ only.

- ④ **Line In**
Devices like CD-ROM, walkman etc. can be connected to Line In jack.
- ⑤ **MIC In**
Microphone can be connected to MIC In jack.
- ⑥ **LAN Port ***
The LAN port provides Internet connection.
- ⑦ **USB port**
Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker...etc. have a standard USB interface. Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

Step 4-2: Connectors Introduction



1) ATX_12V	10) F_AUDIO
2) ATX	11) CD_IN
3) CPU_FAN	12) SPDIF_IO
4) SYS_FAN	13) SUR_CEN
5) FDD	14) F_USB1 / F_USB2
6) IDE1 / IDE2	15) CI
7) AUX_IN	16) COMB
8) F_PANEL	17) CLR_CMOS
9) BAT	18) PWR_LED

*** For 8I845GE-RZ only.


1/2) ATX_12V/ATX (Power Connector)

With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard. Before connecting the power connector, please make sure that all components and devices are properly installed. Align the power connector with its proper location on the motherboard and connect tightly.

The ATX_12V power connector mainly supplies power to the CPU. If the ATX_12V power connector is not connected, the system will not start.


Caution!

Please use a power supply that is able to handle the system voltage requirements. It is recommended that a power supply that can withstand high power consumption be used (300W or greater). If a power supply is used that does not provide the required power, the result can lead to an unstable system or a system that is unable to start.




3) CPU_FAN (CPU FAN Connector)

Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600 mA.



4) SYS_FAN (System FAN Connector)


This connector allows you to link with the cooling fan on the system case to lower the system temperature.



5) FDD (Floppy Connector)

Please connect the floppy drive ribbon cables to FDD. It supports 360K,720K,1.2M,1.44M and 2.88Mbytes floppy disk types.


The red stripe of the ribbon cable must be the same side with the Pin1.



6) IDE1/ IDE2 (IDE1/IDE2 Connector)


Please connect first harddisk to IDE1 and connect CDROM to IDE2.

The red stripe of the ribbon cable must be the same side with the Pin1.



7) AUX_IN (AUX In Connector)



Connect other device (such as PCI TV Tuner audio out) to the connector.



Pin No.	Definition
1	AUX-L
2	GND
3	GND
4	AUX-R



8) F_PANEL (2x10 pins connector)

Please connect the power LED, PC peaker, reset switch and power switch etc. of your chassis front panel to the F_PANEL connector according to the pin assignment above.



HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+) Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+) Pin 2- Pin 3: NC Pin 4: Data(-)
RST (Reset Switch)	Open: Normal Operation Close: Reset Hardware System
PW (Soft Power Connector)	Open: Normal Operation Close: Power On/Off
MSG (Message LED/Power/ Sleep LED)	Pin 1: LED anode(+) Pin 2: LED cathode(-)
NC	NC

9) BAT (Battery)



CAUTION


- ❖ Danger of explosion if battery is incorrectly replaced.
- ❖ Replace only with the same or equivalent type recommended by the manufacturer.
- ❖ Dispose of used batteries according to the manufacturer's instructions.

If you want to erase CMOS...

1. Turn OFF the computer and unplug the power cord.
2. Remove the battery, wait for 30 second.
3. Re-install the battery.
4. Plug the power cord and turn ON the computer.

10) F_AUDIO (Front Audio Panel Connector)


If you want to use Front Audio connector, you must remove jumpers on pins 5-6, 9-10. In order to utilize the front audio header, your chassis must have front audio connector. Also please make sure the pin assignments on the cable are the same as the pin assignments on the MB header. To find out if the chassis you are buying support front audio connector, please contact your dealer. Please note, you can have the alternative of using front audio connector or of using rear audio connector to play sound.



Pin No.	Definition
1	MIC
2	GND
3	REF
4	POWER
5	FrontAudio(R)
6	RearAudio(R)
7	Reserved
8	No Pin
9	FrontAudio(L)
10	RearAudio(L)

11) CD_IN (CD In Connector)


Connect CD-ROM or DVD-ROM audio out to the connector.



Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

12) SPDIF_IO (SPDIF In/Out Connector)


The SPDIF output is capable of providing digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder. Use this feature only when your stereo system has digital input function. Use SPDIF IN feature only when your device has digital output function. Be careful with the polarity of the SPDIF_IO connector. Check the pin assignment carefully while you connect the SPDIF_IO cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional SPDIF_IO cable, please contact your local dealer.



Pin No.	Definition
1	VCC
2	No Pin
3	SPDIF
4	SPDIFI
5	GND
6	GND

13) SUR_CEN (Surround Center Connector)


Please contact your nearest dealer for optional SUR_CEN cable.



Pin No.	Definition
1	SUROUTL
2	SUROUTR
3	GND
4	No Pin
5	CENTER_OUT
6	BASS_OUT

14) F_USB1 / F_USB2 (Front USB Connector)


Be careful with the polarity of the F_USB connector. Check the pin assignment carefully while you connect the F_USB cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional F_USB cable, please contact your local dealer.



Pin No.	Definition
1	Power
2	Power
3	USB DX-
4	USB Dy-
5	USB DX+
6	USB Dy+
7	GND
8	GND
9	No Pin
10	NC

15) CI (Chassis Intrusion, Case Open)


This 2-pin connector allows your system to detect if the chassis cover is removed. You can check the "Case Open" status in BIOS.



Pin No.	Definition
1	Signal
2	GND

16) COMB (COMB Connector)


Be careful with the polarity of the COMB connector. Check the pin assignment carefully while you connect the COMB cable because incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional COMB cable, please contact your local dealer.





Pin No.	Definition
1	NDCDB-
2	NSINB
3	NSOUTB
4	NDTRB-
5	GND
6	NDSRB-
7	NRTSB-
8	NCTSB-
9	NRIB-
10	No Pin

17) CLR_CMOS (Clear CMOS)


You may clear the CMOS data to its default values by this jumper. To clear CMOS, temporarily short pins 1-2. Default doesn't include a jumper on pins 1-2 to prevent improper use of this header.



- 1
 Open: Normal
- 1
 Short: Clear CMOS

18) PWR_LED

PWR_LED is connected with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode. If you use dual color LED, power LED will turn to another color.



- 1


Pin No.	Definition
1	MPD+
2	MPD-
3	MPD-

Chapter 2 BIOS Setup

Chapter 2 provides an overview of the BIOS Setup Program, which allows users to modify the basic system configurations. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

ENTERING BIOS Setup

Turning on the computer and pressing immediately allow you to enter BIOS Setup. If you need more advanced BIOS settings, please press **Ctrl** and **F1** keys on the BIOS main screen to access the the advanced BIOS settings.

CONTROL KEYS

<↑><↓><←><→>	Move to select item
<Enter>	Select Item
<Esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-./PgDn>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F2>	Item Help
<F5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<F6>	Load the file-safe default CMOS value from BIOS default table
<F7>	Load the Optimized Defaults
<F8>	Q-Flash utility
<F9>	System Information
<F10>	Save all the CMOS changes, only for Main Menu

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

The Main Menu (For example: BIOS Ver. : F1)

Once you enter Award BIOS CMOS Setup Utility, the Main Menu (as figure below) will appear on the screen. The Main Menu allows you to select from eight setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software	
<ul style="list-style-type: none">▶ Standard CMOS Features▶ Advanced BIOS Features▶ Integrated Peripherals▶ Power Management Setup▶ PnP/PCI Configurations▶ PC Health Status▶ Frequency/Voltage Control	<ul style="list-style-type: none">Top PerformanceLoad Fail-Safe DefaultsLoad Optimized DefaultsSet Supervisor PasswordSet User PasswordSave & Exit SetupExit Without Saving
Ese: Quit F8: Q-Flash	↑↓→←: Select Item F10: Save & Exit Setup
Time, Date, Hard Disk Type...	



If you can't find the settings you want, press **Ctrl and F1** in BIOS main menu to access the hidden advanced options.

- **Standard CMOS Features**

This setup page includes all the items in standard compatible BIOS.

- **Advanced BIOS Features**

This setup page includes all the items of Award special enhanced features.

- **Integrated Peripherals**

This setup page includes all onboard peripherals settings.

- **PowerManagement Setup**

This setup page includes all the items of Green function features.

- **PnP/PCI Configurations**

This setup page includes all the configurations of PCI & PnP ISA resources.

- **PC Health Status**

This setup page includes the information of the system auto-detected temperature, voltage, and fan speed.

- **Frequency/VoltageControl**

This setup page allows to control CPU clock and frequency ratio.

- **TopPerformance**

If you wish to maximize the performance of your system, try to enable **Top Performance**.

- **Load Fail-Safe Defaults**

Fail-Safe Defaults indicates the value of the system parameters with which the system would be in safe configuration.

- **Load Optimized Defaults**

Optimized Defaults indicates the value of the system parameters which the system would be in best performance configuration.

- **Set Supervisor Password**

Change, set, or disable password. It allows you to limit access to the system and BIOS Setup, or just to BIOS Setup.

- **Set User Password**

Change, set, or disable password. It allows you to limit access to the system.

- **Save & Exit Setup**

Save CMOS value settings to CMOS and exit BIOS Setup.

- **Exit Without Saving**

Abandon all CMOS value changes and exit BIOS Setup.

Standard CMOS Features

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
Standard CMOS Features

Date (mm:dd:yy)	Fri, Jan 9 2004	Item Help
Time (hh:mm:ss)	22:31:24	Menu Level ▶ Change the day, month, year
▶ IDE Primary Master	[None]	<Week> Sun. to Sat.
▶ IDE Primary Slave	[None]	<Month> Jan. to Dec.
▶ IDE Secondary Master	[None]	<Day> 1 to 31 (or maximum allowed in the month)
▶ IDE Secondary Slave	[None]	<Year> 1999 to 2098
Drive A	[1.44M, 3.5"]	
Drive B	[None]	
Floppy 3 Mode Support	[Disabled]	
Halt On	[All, But Keyboard]	
Base Memory	640K	
Extended Memory	127M	
Total Memory	128M	
↑↓←→: Move Enter: Select +/~/PU/PD: Value F10: Save ESC: Exit F1: General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

☞ Date

The date format is <week>, <month>, <day>, <year>.

- ▶ Week From Sun. to Sat., determined by the BIOS and for display only.
- ▶ Month From Jan. to Dec.
- ▶ Day From 1st to 31st (or the maximum allowed in the month).
- ▶ Year From Year 1999 to 2098.

☞ Time

The format used to express time is hours:minutes:seconds. The time is calculated based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.

☞ IDE Primary Master, Slave / IDE Secondary Master, Slave

- ▶ IDE HDD Auto-Detection Press "Enter" to select this option for automatic device detection.
- ▶ IDE Primary/Secondary Master(Slave) setup You can use one of the three methods below:
 - Auto Allows BIOS to automatically detect IDE devices during POST. (Default value)
 - None Select this if no IDE devices are used and the system will skip the automatic detection step and allow for faster system start up.
 - Manual User can manually input the correct settings
- ▶ Access Mode Use this to set the access mode for the hard drive. The four options are: CHS/LBA/Large/Auto (Default:Auto)

Hard drive information should be labeled on the outside drive casing.

Enter the appropriate option based on this information.

- ▶ Capacity Capacity of currently installed hard disk.
- ▶ Cylinder Number of cylinders
- ▶ Head Number of heads
- ▶ Precomp Write precomp
- ▶ Landing Zone Landing zone
- ▶ Sector Number of sectors

☞ Drive A / Drive B

The category identifies the types of floppy disk (drive A and drive B) installed in the computer.

- ▶▶ None No floppy disk is installed
- ▶▶ 360K, 5.25" 5.25 inch PC-type standard drive; 360K byte capacity.
- ▶▶ 1.2M, 5.25" 5.25 inch AT-type high-density drive; 1.2M byte capacity (3.5 inch when 3 Mode is Enabled).
- ▶▶ 720K, 3.5" 3.5 inch double-sided drive; 720K byte capacity
- ▶▶ 1.44M, 3.5" 3.5 inch double-sided drive; 1.44M byte capacity.
- ▶▶ 2.88M, 3.5" 3.5 inch double-sided drive; 2.88M byte capacity.

☞ Floppy 3 Mode Support (for Japan Area)

- ▶▶ Disabled Normal Floppy Drive. (Default value)
- ▶▶ Drive A Enable Drive A 3 Mode support.
- ▶▶ Drive B Enable Drive B 3 Mode support.
- ▶▶ Both Enable both Drive A and B 3 Mode support.

☞ Halt on

The category determines whether the computer will stop if an error is detected during power up.

- ▶▶ All Errors Whenever the BIOS detects a non-fatal error the system will stop.
- ▶▶ No Errors The system boot will not stop for any error that may be detected and you will be prompted.
- ▶▶ All, But Keyboard The system boot will not stop for a keyboard error; it will stop for all other errors. (Default value)
- ▶▶ All, But Diskette The system boot will not stop for a disk error; it will stop for all other errors.
- ▶▶ All, But Disk/Key The system boot will not stop for a keyboard or disk error; it will stop for all other errors.

☞ Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

▶▶ Base Memory

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is typically 512K for systems with 512K memory installed on the motherboard, or 640K for systems with 640K or more memory installed on the motherboard.

▶▶ Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1 MB in the CPU's memory address map.

▶▶ TotalMemory

This item displays the memory size that used.

Advanced BIOS Features

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
Advanced BIOS Features

First Boot Device	[Floppy]	Item Help
Second Boot Device	[HDD-0]	Menu Level ▶
Third Boot Device	[CDROM]	Select Boot Device Priority
Boot Up Floppy Seek	[Disabled]	[Floppy] Boot from floppy
Password Check	[Setup]	[LS120] Boot from LS120
CPU Hyper-Threading ^{note 1}	[Enabled]	[HDD-0] Boot from First HDD
Limit CPUID Max. to 3 ^{note 2}	[Enabled]	[HDD-1] Boot from second HDD
Init Display First	[Onboard/AGP]	
Graphics Aperture Size ^{note 3}	[128MB]	
Graphics Share Memory ^{note 4}	[8M]	
↑↓←→: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Note 1: This option appears only when the Intel Pentium® 4 processor you install on the system supports the Hyper-Threading Technology.

Note 2: This option is available only when you install an Intel® Prescott processor

Note 3/4: This option is available only when you use the onboard VGA function.

First / Second / Third Boot Device

- ▶ Floppy Select your boot device priority by Floppy.
- ▶ LS120 Select your boot device priority by LS120.
- ▶ HDD-0-3 Select your boot device priority by HDD-0-3.
- ▶ SCSI Select your boot device priority by SCSI.
- ▶ CDROM Select your boot device priority by CDROM.
- ▶ ZIP Select your boot device priority by ZIP.
- ▶ USB-FDD Select your boot device priority by USB-FDD.
- ▶ USB-ZIP Select your boot device priority by USB-ZIP.
- ▶ USB-CDROM Select your boot device priority by USB-CDROM.
- ▶ USB-HDD Select your boot device priority by USB-HDD.
- ▶ LAN Select your boot device priority by LAN.
- ▶ Disabled Select your boot device priority by Disabled.

Boot Up Floppy Seek

During POST, BIOS will determine the floppy disk drive installed is 40 or 80 tracks. 360K type is 40 tracks 720K, 1.2M and 1.44M are all 80 tracks.

- ▶ Disabled BIOS will not search for the type of floppy disk drive by track number. Note that there will not be any warning message if the drive installed is 360K. (Default value)
- ▶ Enabled BIOS searches for floppy disk drive to determine if it is 40 or 80 tracks. Note that BIOS can not tell from 720K, 1.2M or 1.44M drive type as they are all 80 tracks.

🔑 PasswordCheck

- ▶▶ Setup The system will boot but will not access to Setup page if the correct password is not entered at the prompt. (Default value)
- ▶▶ System The system will not boot and will not access to Setup page if the correct password is not entered at the prompt.

🔑 CPUHyper-Threading

This option is available only when you install an Intel® Hyper-Threading processor.

- ▶▶ Disabled Disable CPU Hyper Threading.
- ▶▶ Enabled Enable CPU Hyper Threading Feature. Please note that this feature is only working for operating system with multi processors mode supported. (Default value)

🔑 Limit CPUID Max. to 3

This option is available only when you install an Intel® Prescott processor.

- ▶▶ Enabled Limit CPUID Maximum value to 3 when using older OS like NT4. (Default value)
- ▶▶ Disabled Disable CPUID Limit for Windows XP.

🔑 Init Display First

Select the first initiation of the monitor display from onboard/AGP or PCI VGA card.

- ▶▶ PCI Set Init Display First to PCI.
- ▶▶ Onboard/AGP Set Init Display First to onboard/AGP. (Default value)

🔑 Graphics Aperture Size

This option is available only when you use the onboard VGA function.

- ▶▶ 128MB Set Graphics Aperture Size to 128MB. (Default value)
- ▶▶ Disabled Disable this function.

🔑 Graphics ShareMemory

This option is available only when you use the onboard VGA function.

- ▶▶ 8MB Set Graphics Share Memory to 8MB. (Default value)
- ▶▶ 1MB Set Graphics Share Memory to 1MB.

Integrated Peripherals

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
Integrated Peripherals

On-Chip Primary PCI IDE	[Enabled]	<div>Item Help</div> <div>Menu Level ▶</div> <div>If a hard disk controller card is used, set at Disabled</div> <div>[Enabled] Enable onboard IDE PORT</div> <div>[Disabled] Disable onboard IDE PORT</div>
On-Chip Secondary PCI IDE	[Enabled]	
IDE1 Conductor Cable	[Auto]	
IDE2 Conductor Cable	[Auto]	
USB Controller	[Enabled]	
USB Keyboard Support	[Disabled]	
USB Mouse Support	[Disabled]	
AC97 Audio	[Auto]	
Onboard H/W LAN *	[Enabled]	
Onboard LAN Boot ROM *	[Disabled]	
Onboard Serial Port 1	[3F8/IRQ4]	
Onboard Serial Port 2	[2F8/IRQ3]	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[SPP]	
x ECP Mode Use DMA	3	
Game Port Address	[201]	
Midi Port Address	[Disabled]	
x Midi Port IRQ	10	
<div>↑↓↔←→: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help</div> <div>F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults</div>		

On-Chip Primary PCI IDE

- ▶ Enabled Enable onboard 1st channel IDE port. (Default value)
- ▶ Disabled Disable onboard 1st channel IDE port.

On-Chip Secondary PCI IDE

- ▶ Enabled Enable onboard 2nd channel IDE port. (Default value)
- ▶ Disabled Disable onboard 2nd channel IDE port.

IDE1 Conductor Cable

- ▶ Auto BIOS autodetects IDE1 conductor cable. (Default Value)
- ▶ ATA66/100 Set IDE1 Conductor Cable to ATA66/100 (80-pin). Please make sure your IDE device and cable is compatible with ATA66/100.
- ▶ ATA33 Set IDE1 Conductor Cable to ATA33 (40-pin). Please make sure your IDE device and cable is compatible with ATA33.

IDE2 Conductor Cable

- ▶ Auto BIOS autodetects IDE2 conductor cable. (Default Value)
- ▶ ATA66/100 Set IDE2 Conductor Cable to ATA66/100 (80-pin). Please make sure your IDE device and cable is compatible with ATA66/100.
- ▶ ATA33 Set IDE2 Conductor Cable to ATA33 (40-pin). Please make sure your IDE device and cable is compatible with ATA33.

USB Controller

- ▶ Enabled Enable USB Controller. (Default value)
- ▶ Disabled Disable USB Controller.

*** For 81845GE-RZ only.

☞ USB Keyboard Support

- Enabled Enable USB Keyboard Support.
- Disabled Disable USB Keyboard Support. (Default value)

☞ USB Mouse Support

- Enabled Enable USB Mouse Support.
- Disabled Disable USB Mouse Support. (Default value)

☞ AC97 Audio

- Auto Autodetect onboard AC'97 audio function. (Default value)
- Disabled Disable this function.

☞ Onboard H/W LAN *

- Enabled Enabled onboard LAN function. (Default value)
- Disabled Disable this function.

☞ Onboard LAN Boot ROM *

- Enabled Enable to invoke the boot ROM of the onboard LAN chip.
- Disabled Disable this function. (Default value)

☞ Onboard Serial Port 1

- Disabled Disable onboard Serial port 1.
- 3F8/IRQ4 Enable onboard Serial port 1 and address is 3F8/IRQ4. (Default value)
- 2F8/IRQ3 Enable onboard Serial port 1 and address is 2F8/IRQ3.
- 3E8/IRQ4 Enable onboard Serial port 1 and address is 3E8/IRQ4.
- 2E8/IRQ3 Enable onboard Serial port 1 and address is 2E8/IRQ3.
- Auto BIOS will automatically setup the Port 1 address.

☞ Onboard Serial Port 2

- Disabled Disable onboard Serial port 2
- 3F8/IRQ4 Enable onboard Serial port 2 and address is 3F8/IRQ4.
- 2F8/IRQ3 Enable onboard Serial port 2 and address is 2F8/IRQ3. (Default value)
- 3E8/IRQ4 Enable onboard Serial port 2 and address is 3E8/IRQ4.
- 2E8/IRQ3 Enable onboard Serial port 2 and address is 2E8/IRQ3.
- Auto BIOS will automatically setup the Port 2 address. .

☞ Onboard Parallel Port

- Disabled Disable onboard LPT port.
- 378/IRQ7 Enable onboard LPT port and address is 378/IRQ7. (Default Value)
- 278/IRQ5 Enable onboard LPT port and address is 278/IRQ5.
- 3BC/IRQ7 Enable onboard LPT port and address is 3BC/IRQ7.

☞ Parallel Port Mode

- SPP Use Parallel port as Standard Parallel Port. (Default Value)
- EPP Use Parallel port as Enhanced Parallel Port.
- ECP Use Parallel port as Extended Capabilities Port.
- ECP+EPP Use Parallel port as ECP & EPP mode.

*** For 8I845GE-RZ only.

⚙ **ECP Mode Use DMA**

This feature allows you to select Direct Memory Access(DMA) channel if the ECP mode selected. This option is available only when **Parallel Port Mode** is set to ECP or ECP+EPP.

- ▶▶ 1 Set ECP Mode Use DMA to 1.
- ▶▶ 3 Set ECP Mode Use DMA to 3. (Default value)

⚙ **Game Port Address**

- ▶▶ Disabled Disable this function
- ▶▶ 201 Enable this function and set gameport address to 201. (Default value)
- ▶▶ 209 Enable this function and set gameport address to 209.

⚙ **Midi Port Address**

- ▶▶ Disabled Disable this function. (Default value)
- ▶▶ 330 Enable this function and set midiport address to 330.
- ▶▶ 300 Enable this function and set midiport address to 300.

⚙ **Midi Port IRQ**

This option is available when the Midi Port Address is not set to "Disabled."

- ▶▶ 5 Set midiport IRQ to 5.
- ▶▶ 10 Set midiport IRQ to 10. (Default value)

Power Management Setup

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
Power Management Setup

ACPI Suspend Type	[S1(POS)]	Item Help
Power LED in S1 state	[Blinking]	Menu Level ▶
Soft-Off by PWR-BTTN	[Instant-Off]	[S1]
PME Event Wake Up	[Enabled]	Set suspend type to
Modem Ring On	[Enabled]	Power On Suspend under
Resume by Alarm	[Disabled]	ACPI OS
x Date (of Month) Alarm	Everyday	
x Time (hh:mm:ss) Alarm	0 : 0 : 0	
Power On by Mouse	[Disabled]	[S3]
Power On by Keyboard	[Disabled]	Set suspend type to
x KB Power ON Password	Enter	Suspend to RAM under
AC BACK Function	[Soft-Off]	ACPI OS
↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help		
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

⚙ **ACPI Suspend Type**

- ▶▶ S1(POS) Set ACPI suspend type to S1. (Default Value)
- ▶▶ S3(STR) Set ACPI suspend type to S3.

⚙ **Power LED in S1 state**

- ▶▶ Blinking The Power LED will be blinking during S1 state. (Default value)
- ▶▶ Dual/OFF The Power LED will be turned off or change color.

☞ Soft-off by PWR-BTTN

- Instant -Off Once a user presses the power button, the system will be turned off instantly. (Default Value)
- Delay 4 sec. Press power button for 4 seconds to turn off the system. System enters suspend mode if the power button is pressed for less than 4 seconds.

☞ PME Event Wake Up

- Disabled Disable this function.
- Enabled Enable PME Event Wake up. (Default Value)

☞ ModemRingOn

- Disabled Disable Modem Ring on function.
- Enabled Enable Modem Ring on function. (Default Value)

☞ Resume by Alarm

You can enable **Resume by Alarm** and key in month/date/time to turn on system.

- Disabled Disable this function. (Default Value)
- Enabled Enable alarm function to POWER ON system.

If Resume by Alarm is Enabled.

Date (of Month) Alarm: Everyday, 0~31

Time (hh: mm: ss) Alarm: (0~23) : (0~59) : (0~59)

☞ Power On by Mouse

- Double Click Double-click the mouse to turn on the system.
- Disabled Disable this function. (Default Value)

☞ Power On by Keyboard

- Keyboard 98 If your keyboard has a "Power" button, enable this function to press the button to turn off the system.
- Password Input password (from 1 to 5 characters) and press Enter to set the Keyboard Power On Password.
- Disabled Disable this function. (Default Value)

☞ KB Power On Password

When "Power On by Keyboard" is set at Password, you can set the password here.

- Enter Input password (from 1 to 5 characters) and press Enter to set the Keyboard Power On password.

☞ AC BACK Function

- Soft-Off When AC-power back to the system, the system will be in "Off" state. (Default value)
- Full-On When AC-power back to the system, the system always in "On" state.
- Memory When AC-power back to the system, the system will return to the Last state before AC-power off.

PnP/PCI Configurations

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software PnP/PCI Configurations		
PCI1/5 IRQ Assignment	[Auto]	Item Help
PCI2 IRQ Assignment	[Auto]	Menu Level ▶
PCI3 IRQ Assignment	[Auto]	Device(s) using this INT:
PCI4 IRQ Assignment	[Auto]	USB 1.1 Host Cntrlr -Bus 0 Dev29 Func 2
↑↓→←: Move Enter: Select +/~/PU/PD: Value F10: Save ESC: Exit F1: General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

⏮ PCI1/5 IRQ Assignment

- ▶ Auto Auto assign IRQ to PCI 1/5. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 1/5.

⏮ PCI2 IRQ Assignment

- ▶ Auto Auto assign IRQ to PCI 2. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 2.

⏮ PCI3 IRQ Assignment

- ▶ Auto Auto assign IRQ to PCI 3. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 3.

⏮ PCI4 IRQ Assignment

- ▶ Auto Auto assign IRQ to PCI 4. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 3.

PC Health Status

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
PC Health Status

		Item Help
Reset Case Open Status	[Disabled]	Menu Level ▶
Case Opened	No	
Vcore	1.348V	[Disabled]
DDR25V	2.544V	Don't reset case open status
+3.3V	3.360V	
+12V	11.858V	
Current CPU Temperature	27° C	[Enabled]
Current CPU FAN Speed	4821 RPM	Clear case open status and set to be Disabled at next boot
Current SYSTEM FAN Speed	0 RPM	
CPU Warning Temperature	[Disabled]	
CPU FAN Fail Warning	[Disabled]	
System FAN Fail Warning	[Disabled]	
↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Reset Case Open Status

- ▶ Disabled Don't reset case open status. (Default value)
- ▶ Enabled Clear case open status at next boot.

Case Opened

If the case is closed, **Case Opened** will show "No."

If the case is opened, **Case Opened** will show "Yes."

If you want to reset **Case Opened** value, enable **Reset Case Open Status** and save the change to CMOS, and then your computer will restart.

Current Voltage (V) Vcore/+3.3V/DDR25V/+12V

- ▶ Detect system's voltage status automatically.

Current CPU Temperature

- ▶ Detect CPU Temp. automatically.

Current CPU/SYSTEM FAN Speed (RPM)

- ▶ Detect CPU/SYSTEM Fan speed status automatically.

CPU Warning Temperature

Alarm occurs when the current CPU temperature is higher than the selected temperature.

- ▶ 60°C / 140°F Monitor CPU temperature at 60°C / 140°F.
- ▶ 70°C / 158°F Monitor CPU temperature at 70°C / 158°F.
- ▶ 80°C / 176°F Monitor CPU temperature at 80°C / 176°F.
- ▶ 90°C / 194°F Monitor CPU temperature at 90°C / 194°F.
- ▶ Disabled Disable this function. (Default value)

CPU/SYSTEM FAN Fail Warning

- ▶ Disabled Disable fan warning function. (Default value)
- ▶ Enabled Enable fan warning function. Alarm occurs when FAN stops.

Frequency/Voltage Control

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software
Frequency/Voltage Control

CPU Clock Ratio	[15X]	Item Help
CPU Host Clock Control	[Disabled]	
x CPU Host Frequency (Mhz)	133	Menu Level ▶
x Fixed PCI/AGP Frequency	33/66	
Host/DRAM Clock ratio	[Auto]	Set CPU Ratio if CPU Ratio is unlocked
Memory Frequency (Mhz)	333	
PCI/AGP Frequency (Mhz)	33/66	
↑↓→←: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help		
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		



Incorrect using these features may cause your system broken. For power users only.

⚙ CPU Clock Ratio

This setup option will be automatically assigned by CPU detection.
The option will display "Locked" and read only if the CPU ratio is not changeable.

⚙ CPU Host Clock Control

Please note that if your system is overclocked and cannot restart, please wait 20 secs.
for automatic system restart or clear the CMOS setup data and perform a safe restart.

- ▶ Disabled Disable CPU Host Clock Control. (Default value)
- ▶ Enabled Enable CPU Host Clock Control.

⚙ CPU Host Frequency (Mhz)

This item will be available when "CPU Host Clock Control" is set to Enabled.
▶ 100MHz ~ 355MHz Set CPU Host Clock from 100MHz to 355MHz.
If you use a Pentium 4 CPU with FSB 533MHz, please set "CPU Clock" to 133MHz. For a P4 CPU
with FSB 400MHz, please set it to 100MHz.
Inappropriate using it may cause your system corrupted. For power End-User use only!

⚙ Fixed PCI/AGP Frequency

You can choose those modes to adjust PCI/AGP frequency. (Select PCI/AGP frequency
asynchronous with CPU frequency).

⚙ Host/DRAM Clock ratio

For FSB (Front Side Bus) frequency=400MHz,
▶ 2.0 Memory Frequency = Host clock X 2.0.
▶ 2.66 Memory Frequency = Host clock X 2.66.
▶ Auto Set Memory frequency by DRAM SPD data. (Default value)
For FSB (Front Side Bus) frequency=533MHz,
▶ 2.0 Memory Frequency = Host clock X 2.0.
▶ 2.5 Memory Frequency = Host clock X 2.5.
▶ Auto Set Memory frequency by DRAM SPD data. (Default value)


Memory Frequency (Mhz)

The values depend on CPU Host Frequency.

PCI/AGP Frequency (Mhz)

The values depend on Fixed PCI/AGP Frequency.

Top Performance




If you wish to maximize the performance of your system, enable "Top Performance."

▶ Disabled Disable this function. (Default Value)

▶ Enabled Enable Top Performance function.


⚠ "Top Performance" will increase H/W working speed. Different system configuration (both H/W component and OS) will effect the result. For example, the same H/W configuration might not run properly with Windows XP, but works smoothly with Windows NT. Therefore, if your system is not perform enough, the reliability or stability problem will appear sometimes, and we will recommend you disabling the option to avoid the problem as mentioned above.

Load Fail-Safe Defaults




Fail-Safe defaults contain the most appropriate values of the system parameters that allow minimum system performance.

Load Optimized Defaults



Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

Set Supervisor/User Password



When you select this function, the following message will appear at the center of the screen to assist you in creating a password.


Type the password, up to eight characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password. To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

The BIOS Setup program allows you to specify two separate passwords: SUPERVISOR PASSWORD and a USER PASSWORD. When disabled, anyone may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration fields, the User password is required to access only basic items.

If you select "System" at "Password Check" in Advance BIOS Features Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.


If you select "Setup" at "Password Check" in Advance BIOS Features Menu, you will be prompted only when you try to enter Setup.

Save & Exit Setup



Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.
Type "N" will return to Setup Utility.

Exit Without Saving



Type "Y" will quit the Setup Utility without saving to RTC CMOS.
Type "N" will return to Setup Utility.

Chapter 3 Install Drivers


Install Drivers




Pictures below are shown in Windows XP

Insert the driver CD-title that came with your motherboard into your CD-ROM drive, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

INSTALL CHIPSET DRIVER


This page shows the drivers that need to be installed for the system. Click each item to install the driver manually or switch to the  to install the drivers automatically.



Message: Some device drivers will restart your system automatically. After restarting your system the "Xpress Install" will continue to install other drivers.

The "Xpress Install" uses the "Click and Go" technology to install the drivers automatically. Just select the drivers you want then click the "GO" button. The  will execute the installation for you by itself.


We recommend that you install all components in the list.



Click "GO".



For USB2.0 driver support under Windows XP operating system, please use Windows Service Pack. After install Windows Service Pack, it will show a question mark "?" in "Universal Serial Bus controller" under "Device Manager". Please remove the question mark and restart the system (System will auto-detect the right USB2.0 driver).



You have completed drivers installation.

Item Description

- Intel Chipset Software Installation Utility
Tell the operating system how the chipset components will be configured.
- Intel Application Accelerator
Designed to improve performance of the storage sub-system and overall system performance.
- Intel Extreme Graphics Driver (Win2K/XP)
For Intel® 845G/GL/GE/GV Chipsets.
- USB Patch for WinXP
This patch driver can help you to resolve the USB device wake up S3 hang up issue in XP.
- RealTek LAN Driver*
RealTek 10/100 LAN driver for 81xx series chips.
- C-Media AC97 Audio Driver
Install C-Media AC97 audio driver.
- Intel USB 2.0 Driver
It is recommended that you use the Microsoft Windows update for the most updated driver for XP/2K.

*** For 8I845GE-RZ only.



Contact Us

• Taiwan (Headquarters)

GIGA-BYTE TECHNOLOGY CO., LTD.

Address: No.6, Bau Chiang Road, Hsin-Tien, Taipei Hsien, Taiwan

TEL: +886 (2) 8912-4888

FAX: +886 (2) 8912-4003

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address (English): <http://www.gigabyte.com.tw>

WEB address (Chinese): <http://chinese.giga-byte.com>

• U.S.A.

G.B.T. INC.

Address: 17358 Railroad St, City of Industry, CA 91748.

TEL: +1 (626) 854-9338

FAX: +1 (626) 854-9339

Tech. Support :

<http://www.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.com>

• Germany

G.B.T. TECHNOLOGY TRADING GMBH

Address: Friedrich-Ebert-Damm 11222047 Hamburg

TEL: +49-40-2533040 (Sales)

+49-1803-428468 (Tech.)

FAX: +49-40-25492343 (Sales)

+49-1803-428329 (Tech.)

Tech. Support :

<http://de.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.de>

• Japan

NIPPON GIGA-BYTE CORPORATION

WEB address : <http://www.gigabyte.co.jp>

• Singapore

GIGA-BYTE SINGAPORE PTE. LTD.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

• U.K.

G.B.T. TECH. CO., LTD.

Address: GUnit 13 Avant Business Centre 3 Third Avenue, Denbigh West Bletchley Milton Keynes, MK1 1DR, UK, England

TEL: +44-1908-362700

FAX: +44-1908-362709

Tech. Support :

<http://uk.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://uk.giga-byte.com>

• The Netherlands

GIGA-BYTE TECHNOLOGY B.V.

TEL: +31 40 290 2088

NL Tech.Support: 0900-GIGABYTE (0900-44422983)

BE Tech.Support: 0900-84034

FAX: +31 40 290 2089

Tech. Support :

<http://nz.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.nl>

- **China**

NINGBO G.B.T. TECH. TRADING CO., LTD.

Tech. Support :

<http://cn.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.com.cn>

Shanghai

TEL: +86-021-63410999

FAX: +86-021-63410100

Beijing

TEL: +86-010-82886651

FAX: +86-010-82888013

Wuhan

TEL: +86-027-87851061

FAX: +86-027-87851330

GuangZhou

TEL: +86-020-87586074

FAX: +86-020-85517843

Chengdu

TEL: +86-028-85236930

FAX: +86-028-85256822

Xian

TEL: +86-029-85531943

FAX: +86-029-85539821

Shenyang

TEL: +86-024-23960918

FAX: +86-024-23960918-809

- **Australia**

GIGABYTE TECHNOLOGY PTY. LTD.

Address: 3/6 Garden Road, Clayton, VIC 3168 Australia

TEL: +61 3 85616288

FAX: +61 3 85616222

Tech. Support :

<http://www.giga-byte.com.au/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.com.au>

- **France**

GIGABYTE TECHNOLOGY FRANCES S.A.R.L.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.fr>

- **Russia**

Moscow Representative Office Of Giga-Byte Technology Co., Ltd.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.ru>

- **Poland**

Representative Office Of Giga-Byte Technology Co., Ltd.

POLAND

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support (Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.pl>
