

When you installing AGP card, please make sure the following notice is fully understood and practiced. If your AGP card has "AGP 4X/8X(1.5V) notch" (show below), please make sure your AGP card is AGP 4X/8X (1.5V).





Caution: AGP 2X(3.3V) card is not supported by Intel® 845(GE/PE) / 845(E/G) / 850(E)/E7205 / 865(P/G/PE)/875P. You might experience system unable to boot up normally. Please insert an AGP Pro 4X/8X (1.5V) card

Example 1: Diamond Vipper V770 golden finger is compatible with 2X/4X mode AGP slot. It can be switched between AGP 2X(3.3V) or 4X(1.5V) mode by adjusting the jumper. The factory default for this card is 2X(3.3V).

The GA-8PENXP motherboards might not function properly, if you install this card without switching the jumper to 4X(1.5V) mode in it.

Example 2: Some ATi Rage 128 Pro graphics cards made by "Power Color", the graphics card manufacturer & some SiS 305 cards, their golden finger is compatible with 2X/4X mode AGP slot, but they support 2X(3.3V) only. The GA-8 PENXP motherboards might not function properly, If you install this card in it.

Note: Although Gigabyte's AG32S(G) graphics card is based on ATi Rage 128 Pro chip, the design of AG32S(G) is compliance with AGP 4X(1.5V) specification. Therefore, AG32S (G)will work fine with Intel® 845(GE/PE) / 845(E/G) / 850(E) /E7205 / 865(P/G/PE)/875P. based motherboards.



Before you install PCl cards, please remove the Dual BIOS label from PCl slots if there is one.



- The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein.
- Third-party brands and names are the property of their respective owners.
- Please do not remove any labels on motherboard, thismay void the warranty of this motherboard.
- Due to rapid change in technology, some of the specifications might be out of date before publication of this booklet.



WARNING: Never run the processor without the heatsink properly and firmly attached. PERMANENT DAMAGE WILL RESULT!

Miss en gards: Ne faites jamais tourner le processeur vans que le dissipateur de chaleur seit fix correctement et fermement. UN DOMMAGE PERMANENT EN RÉSULTERA !

Achtung: Der Prozestor dorf mer in Betrieb genommen werden, wenn der W emeableiter ordnungsgem ß und fest angebracht ist. DIES HAT EINEN PERMANENTEN SCHADEN ZUR FOLGE!

Advertencia: Nunca haga funcionar el procesador sin el disipador de calor instalado correcta y firmemente. ¡SE PRODUCIRÁ UN DAÑO PERMANENTE!

Aviso: Nunca execute e processador sem o dissipador de calor estar adequado e firmemente conretado. O RESULTADO SERÁ UM DANO PERMANENTE!

警告。 将报落被军国语安装到处理器上之前,不要运行处理器。过病将水坛损坏处理器!

臂件: 將散熱器空間地安裝到底極器上之前,不要運行兩極器。遊動將永遠損壞處極器!

결교: 히트실크를 제대로 또 단점히 부탁시키지 않은 첫 프로젝시를 구동시키지 아침시오. 형구적 고강이 발생합니다!

着告: 永久的な損傷を防ぐため、ヒートシンクを止しくしっかりと取り付けるまでは、プロセッサを動作させないようにしてください。

Declaration of Conformity

We, Manufacturer/Importer (full address)

G.B.T. Technology Träding GMbH Ausschlager Weg 41, 1F, 20537 Hamburg, Germany

declare that the product (description of the apparatus, system, installation to which it refers)

Limits and methods of measurement

Mother Board

GA-8PENXP is in conformity with

(reference to the specification under which conformity is declared)

in accordance with 89/336 EEC-EMC Directive

☐ EN 61000-3-2* Disturbances in supply systems cause

	of radio disturbance characteristics of industrial, scientific and medical (ISM high frequency equipment	⊠ EN 60555-2	by household appliances and similar electrical equipment "Harmonics"		
□ EN 55013	Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment	☐ EN 61000-3-3* ☑ EN 60555-3	Disturbances in supply systems cause by household appliances and similar electrical equipment "Voltage fluctuations"		
□ EN 55014	Limits and methods of measurement of radio d isturbance characte ristics of household electrical appliances, portable tools and similar electrical apparatus	⊠ EN 50081-1 ⊠ EN 50082-1	Generic emission standard Part1: Residual commercial and light industry Generic immunity standard Part1: Residual commercial and light industry		
□ EN 55015	Limits and methods of measurement of radio d isturbance characteristics of fluore scent lamps and luminaries	□ EN 55081-2	Generic emission standard Part 2: Industrial environment		
□ EN 55020	Immunity from radio in terference of broadcast receivers and associated equipment	□ EN 55082-2	Generic emission standard Part 2: Industrial environment		
⊠ EN 55022	Limits and methods of measurement of radio disturbance characteristics of information technology equipment	□ ENV 55104	Immunity requirements for household appliances tools and similar apparatus		
☐ DIN VDE 0 855 ☐ part 10 ☐ part 12	Cabled distribution systems; Equipment for receiving and/or distribution from sound and television signals	□ EN50091-2	EMC requirements for uninterru ptible power systems (UPS)		
☑ CE marking The manufacturer also declares the conformity of above mentioned product					
with the actual required safety standards in accordance with LVD 73/23 EEC					
□ EN 60065	Safety requirements for mains operated electronic and related apparatus for household and similar general use	□ EN 60950	Safety for information technology equipment including electrical bussiness equipment		
□ EN 60335	Safety of household and similar electrical appliances	□ EN 50091-1	General and Safety requirments for uninterru ptible power systems (UPS)		
	<u>Ma</u>	nufacturer/Importer			

Date : April.14, 2003

Signature: Finnny Huang

Name: Timmy Huang

(Stamp)

☐ EN 55011

DECLARATION OF CONFORMITY

Per FCC Part 2 Section 2.1077(a)



Responsible PartName: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street

City of Industry, CA 91748

Phone/FaxNo: (818) 854-9338/ (818) 854-9339

hereby declares that the product

Product Name: Motherboard Model Number: GA-8PENXP

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109 (a), Class B Digital Device

Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any inference received, including that may cause undesired operation.

Representative Person's Name: ERIC LU

Signature: $Eric\ Lu$

Date: April. 14,2003

GA-8PENXP P4 Titan Series Motherboard

USER'S MANUAL

Pentium®4 Processor Motherboard Rev. 1001 12ME-8PENXP-1001

Table of Content

Item Checklist	4
Chapter 1 Introduction	5
Features Summary	5
GA-8PENXP Motherboard Layout	8
Block Diagram	9
Chapter 2 Hardware Installation Process	11
Step 1: Install the Central Processing Unit (CPU)	12
Step 1-1: CPU Installation	12
Step 1-2: CPU Cooling Fan Installation	13
Step 2: Install Memory Modules	14
Step 3: Install expansion cards	17
Step 3-1: AGP Card Installation	17
Step 3-2: DPS2 (Dual Power System 2) Installation	18
Step 4: Connect ribbon cables, cabinet wires and power supply	19
Step 4-1: I/O Back Panel Introduction	19
Step 4-2: Connectors & Jumper Setting Introduction	21
Chapter 3 BIOS Setup	39
The Main Menu (For example: BIOS Ver. : E7)	40
Standard CMOS Features	42
Advanced BIOS Features	45
Integrated Peripherals	47
Power Management Setup	53

PnP/PCI Configurations	56
PC Health Status	57
Frequency/Voltage Control	59
Select Language	62
Load Fail-Safe Defaults	63
Load Optimized Defaults	64
Set Supervisor/User Password	65
Save & Exit Setup	66
Exit Without Saving	67
Chapter 4 Technical Reference	69
@BIOS™ Introduction	69
EasyTune [™] 4 Introduction	70
DPS2 (Dual Power System 2) Introduction	71
Flash BIOS Method Introduction	72
Flash BIOS Method Introduction	
	82
2-/4-/6-Channel Audio Function Introuction	82

Item Checklist

- ☑ The GA-8PENXP motherboard
- ☑ CD for motherboard driver & utility
- ☑ GA-8PENXP user's manual
- ☑ Quick PC Installation Guide
- ☑ Giga RAID manual
- ☑ SATA RAID manual
- ☑ Motherboard Settings Label
- ☐ GC-SATA Card (Optional)

(Manual; SATA cable x1; Power cable x 1)

- ☑ IDE cable x3 / Floppy cable x 1
- ☑ 2 Port USB cable x 1
- ☑ IEEE 1394 cable x 1
- ☑ Serial ATA cable x 4
- ☑ Audio combo kit x1
 - (SURROUND-Kit + SPDIF Out KIT)
- ☑ I/O shield
- ☑ DPS2 x 1



Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use a grounded wist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

Chapter 1 Introduction

Features Summary

Form Factor	 30.5cm x 24.4cm ATX size form factor, 4 layers PCB.
CPU	Socket 478 for Intel® Micro FC-PGA2 Pentium® 4 processor
	 Intel Pentium®4 800MHz / 533MHz / 400MHz FSB
	Support Intel ® Pentium ® 4 (Northwood, Prescott) processor
	Support Intel ® Pentium ® 4 Processor with HT Technology
	2nd cache depend on CPU
Chipset	Intel® Chipset Springdale-PE HOST/AGP/Controller
	ICH5 I/O Controller Hub
Memory	6 184-pin DDR DIMM sockets
	 Supports Dual Channel DDR400/DDR333/DDR266 DIMM
	 Supports 128MB/256MB/512MB/1GB unbuffered DRAM
	 Supports up to 4GB DRAM (Max)
	Supports only DDR DIMM
VO Control	• ITE8712F
Slots	1 AGP Pro Slot Compliance with AGP 3.0 specification ,
	supporting 4X and 8X transfer rates
	 5 PCI slot supports 33MHz & PCI 2.3 compliant
On-Board IDE	2 IDE controllers on the Intel ICH5 PCI chipset
	provides IDE HDD/CD-ROM (IDE1, IDE2) with PIO, Bus Master
	(Ultra DMA33/ATA66/ATA100) operation modes.
	 IDE3 and IDE4 Compatible with RAID, Ultra ATA133/100.
Serial ATA	2 Serial ATA connectors in 150 Mb/s operation mode
	Controlled by ICH5
On-Board Peripherals	 1 Floppy port supports 2 FDD with 360K, 720K,1.2M, 1.44M
	and 2.88M bytes.
	 1 Parallel port supports Normal/EPP/ECP mode
	2 Serial ports (COMA & COMB)
	8 USB 2.0/1.1 ports (4 x Rear, 4 x Front by cable)
	• 3 IEEE1394 (by cable)
	1 IrDA connector for IR/CIR
	1 Front Audio connector

to be continued.....



Due to chipset (Intel 865PE) architecture limitation, DDR 400 m emory module is only supported when using FSB 800 Pentium 4 processor. A FSB 533 Pentium 4 processor will support DDR333 and DDR266 memory module. AFSB 400 Pentium 4 processor will only support DDR 266 memory



Only Silicon Image Sil3112 chip supports Serial ATA(SATA0_SII/SATA1_SII) connectors hot plug

CPU/FCPU 0System	Power/System Fan Revolution detect Power/System Fan Control Overheat Warning In Voltage Detect In Intel® 82547EI (KENAI II CSA) Chipset Fransfer rate 10/100/1000 supported
CPU 0System	Overheat Warning n Voltage Detect n Intel® 82547EI (KENAI II CSA) Chipset
• Syster	n Voltage Detect n Intel® 82547EI (KENAI II CSA) Chipset
	n Intel® 82547EI (KENAI II CSA) Chipset
On-Board LAN	, .
On Board Eritt	ansfer rate 10/100/1000 supported
Data tr	and or rate 107 1007 1000 cappoints
• 1RJ4	5 port
On-Board Sound • Realte	k AL C655 codec
 Suppo 	orts EZ-Jack Sensing function
	Out/2 front speaker
	n / 2 rear speaker(by s/w switch)
	/ center& subwoofer(by s/w switch)
	out / SPDIF In
• CD In	/ AUX In / Game port
	ard Giga RAID IT8212F chipset
	orts data striping (RAID 0) or mirroring (RAID 1) or
The state of the s	g+mirroring (RAID 0+RAID 1)
•	orts JBOD function
	orts concurrent dual ATA133 IDE controller operation
	ort ATAPI mode for HDD
	orts IDE bus master operation
	ortATA133/RAID mode switch by BIOS
	ys status and error checking messages during boot-up
•	ing supports automatic background rebuilds
	res LBA and Extended Interrupt 13 drive translation in
	iller onboard BIOS
On-Board SATA RAID Onbo	ard Silicon Image Sil3112A
	orts Disk striping (RAID0) or DISK Mirroring (RAID1)
	orts UDMA up to 150 MB/sec
	DMA and PIO Modes
	2 SATA Device
·	and ATA/ATAPI6
	orts hot plug funcion (SATA0_SII/SATA1_SII)
- Suppl	to he continued

to be continued.....

On-Board IEEE1394	• TSB43AB23
PS/2 Connector	PS/2 Keyboard interface and PS/2 Mouse interface
BIOS	Licensed Phoenix BIOS, 4M bit x 2 FWH
ысс	Supports Dual BIOS
	Supports Multi Language
	Supports Face Wizard
	Supports Q-Flash
Additional Foot was	
Additional Features	 Supports CPU Dual Power System 2 (DPS2)
	 PS/2 Keyboard power on by password
	PS/2 Mouse power on
	External Modem wake up
	STR(Suspend-To-RAM)
	Wake on LAN (WOL)
	AC Recovery
	Poly fuse for keyboard over-current protection
	USB KB/Mouse wake up from S3
	Supports CPU Smart Fan Control function
	Supports @BIOS
	Supports EasyTune 4
	Supports clear password function
Overclocking	Over Voltage (DDR/AGP/CPU) by BIOS
	Over Clock (DDR/AGP/CPU/PCI) by BIOS



HT functionality requirement content :


Enabling the functionality of Hyper-Threading Technology for your computer system requires all of the following platform components:

- CPU: An Intel® Pentium 4 Processor with HT Technology
- Chipset An Intel® Chipset that supports HT Technology
- BIOS: A BIOS that supports HT Technology and has it enabled
- OS: An operation system that has optimizations for HT Technology




Please set the CPU host frequency in accordance with your processor's specifications. We don't recommend you to set the system bus frequency over the CPU's specification because these specific bus frequencies are not the standard specifications for CPU, chipset and most of the peripherals. Whether your system can run under these specific bus frequencies properly will depend on your hardware configurations, including CPU, Chipsets,SDRAM,Cards....etc.

GA-8PENXP Motherboard Layout




Block Diagram



Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following steps:

- Step 1- Install the Central Processing Unit (CPU)
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect ribbon cables, cabinet wires, and power supply



Congratulations you have accomplished the hardware installation! Turn on the power supply or connect the power cable to the power outlet. Continue with the BIOS/software installation.


Step 1: Install the Central Processing Unit (CPU)




Before installing the processor, adhere to the following warning:

- 1. Please make sure the CPU type is supported by the motherboard.
 - 2.If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.

Step 1-1: CPU Installation



1. Angling the rod to 65-degree maybe feel a kind oftight, and then continue pull the rod to 90-degree when a noise "cough" made.



2. Pull the rod to the 90-degree directly.



3. CPU Top View



 Locate Pin 1 in the socket and look for a (golden) cutedge on the CPU upper corner. Then insert the CPU into the socket

Step 1-2: CPU Heat Sink Installation




Before installing the CPU cooling fan, adhere to the following warning: 1.Please use Intel approved cooling fan.

- 2. We recommend you to apply the thermal tape to provide better heat conduction between your CPU and cooling fan.
 - (The CPU cooling fan might stick to the CPU due to the hardening of the thermal paste. During this condition if you try to remove the cooling fan, you might pull the processor out of the CPU socket alone with the cooling fan, and might damage the processor. To avoid this from happening, we suggest you to either use thermal tape instead of thermal paste, or remove the cooling fan with extreme caution.)
- 3. Make sure the CPU fan power cable is plugged in to the CPU fan connector, this completes the installation.
 - Please refer to CPU cooling fan user's manual for more detail installation procedure.



 Fasten the heatsink supporting-base onto the CPU socket on the mainboard.



Make sure the CPU fan is plugged to the CPU fan connector, than install complete.


Step 2: Install memory modules



Before installing the memory modules, adhere to the following warning:

- 1. When DIMM LED is ON, do not install / remove DIMM from socket.
- 2. Please note that the DIMM module can only fit in one direction due to the one notch. Wrong orientation will cause improper installation. Please change the insert orientation.

The motherboard has 6 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.



DDRIntroduction

Established on the existing SDRAM industry infrastructure, DDR (Double Data Rate) memory is a high performance and cost-effective solution that allows easy adoption for memory vendors, OEMs and system integrators.

DDR memory is a sensible evolutionary solution for the PC industry that builds on the existing SDRAM infrastructure, yet makes awesome advances in solving the system performance bottleneck by doubling the memory bandwidth. DDR SDRAM will offer a superior solution and migration path from existing SDRAM designs due to its availability, pricing and overall market support. PC2100 DDR memory (DDR266) doubles the data rate through reading and writing at both the rising and falling edge of the clock, achieving data bandwidth 2X greater than PC133 when running with the same DRAM clock frequency. With peak bandwidth of 2.664GB per second, DDR memory enables system OEMs to build high performance and low latency DRAM subsystems that are suitable for servers, workstations, high-end PC's and value desktop SMA systems.

Dual Channel DDR:

8PENXP supports Dual Channel Technology.

When Dual Channel Technology is activated, the bandwidth of memory bus will be double the original one, with the fastest speed at 6.4GB/s DDR400.

 $\ensuremath{\mathsf{8PENXP}}$ includes six DIMM slots, and each Channel has 3 DIMMs as following:

➤ Channel A : DIMM 1, 2, 3➤ Channel B : DIMM 4, 5, 6

Below are the explanations:



- One, three, or five DDR memory modules are installed: The Dual Channel Technology will not operate when one, three, or five DDR memory modules are installed and they will only work as Single Channel.
- 2. Two DDR memory modules are installed (the same memory size and type): The Dual Channel Technology will operate when two DDR memory modules are inserted individually into Channel A and Channel B (DIMM 1 pairs up with DIMM 4, DIMM 2, 5 and DIMM 3, 6). However, if the two DDR memory modules are inserted into the same Channel (DIMM 1,2, 3 or DIMM 4,5,6) then Dual Channel Technology will not operate.
- Three or five DDR memory modules are installed: Please note that The Dual Channel Technology will not operate when three or five DDR memory modules are installed; part of them will not be detected.
- 4. If four DDR memory modules are installed (two pairs of DDR memory modules with the same memory size and type): The Dual Channel Technology will operate when a pair of DDR memory modules are inserted into DIMM1, 4 and another pair into DIMM 2,5.

If six DDR memory modules are installed: To activate the Dual Channel Technology and to
make the size of each DDR memory module detected, please use six DDR memory modules with identical size and type and insert them into the six DIMMs following the sequence
below:

DIMM 1: Double or Single Side

DIMM 2: Single Side

DIMM 3: Single Side

DIMM 4: Double or Single Side (if DIMM1 is inserted a double-side module, then DIIMM4 must also be inserted a double-side one.)

DIMM 5: Single Side DIMM 6: Single Side

The following tables include all memory-installed combination types:

(Please note that those types not in the tables will not boot up.)

• Figure 1: Dual Channel Technology (DS: Double Side, SS: Single Side)

	DIMM 1	DIMM 2	DIMM 3	DIMM 4	DIMM5	DIMM6
	DS/SS	Х	Х	DS/SS	Х	Х
2memory modules	Х	DS/SS	Х	Х	DS/SS	Х
	Х	Х	DS/SS	Х	Χ	DS/SS
4 memory modules	DS/SS	DS/SS	Х	DS/SS	DS/SS	Х
6memory modules	DS/SS	SS	SS	DS/SS	SS	SS

• Figure 2: Don't operate Dual Channel Technology (DS: Double Side, SS: Single Side)

		,	
	DIMM 1	DIMM 3	DIMM5
	DS/SS	Х	Х
1 memory module	Х	DS/SS	X
	Х	Х	DS/SS
2 memory modules	DS/SS	DS/SS	X
3memory modules	DS/SS	SS	SS


Step 3: Install expansion cards

Step 3-1: AGP Card Installation

- 1. Read the related expansion card's instruction document before install the expansion card into the computer.
- 2. Remove your computer's chassis cover, screws and slot bracket from the computer.
- 3. Press the expansion card firmly into expansion slot in motherboard.
- 4. Be sure the metal contacts on the card are indeed seated in the slot.
- 5. Replace the screw to secure the slot bracket of the expansion card.
- 6. Replace your computer's chassis cover.
- 7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
- 8. Install related driver from the operating system.



Please align the AGP card to the onboard AGP PRO slot and press firmly down on the slot.



If you are installing a AGP PRO graphic card, please remove the protecting plate first.



When an AGP 2X (3.3V) card is installed the $2X_DET$ will light up, indicating a non-supported graphics card is inserted. Informing users that system might not boot up normally due to AGP 2X (3.3V) is not supported by the chipset.

Step 3-2: DPS2 (Dual Power System 2) Installation

What is DPS2?

DPS2 (Dual Power System 2) is a daughter card which can provide you the Dual Power System function. A cool stylish neon blue DPS2 that supply a total 6-phase power circuit design, delivers a high durable power design for the new generation Intel® platform.



The DPS2 can work in a Dual Power System:


Parallel Mode:
 DPS2 and motherboard CPU power can work simultaneously, providing a total of 6-phase power circuit.

How to install a DPS2?

- 1. The DPS2connector has a notch, so the DPS2 can only fit in one direction.
- 2. Insert the DPS2 vertically into the socket and then push it down.
- 3. Fix the DPS2 on the motherbard with the clip.
- 4. Reverse the installation steps if you want to remove the DPS2.

Step 4: Connect ribbon cables, cabinet wires and power supply

Step 4-1: I/O Back Panel Introduction



PS/2 Keyboard and PS/2 Mouse Connector




PS/2 Mouse Connector (6 pin Female)

PS/2 Keyboard Connector (6 pin Female)

➤ This connector supports standard PS/2 keyboard and PS/2 mouse.


2/4 USB/LAN Connector



➤ Before you connectyour device(s) into USB connector(s), please make sure your device(s) such as USB keyboard,mouse, scanner, zip, speaker...etc. Have a standard USB interface. Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

Parallel Port and Serial Ports (COMA / COMB)

Parallel Port (25 pin Female)



➤ This connector supports 2 standard COM ports and 1 Parallel port. Device like printer can be connected to Parallel port; mouse and modem etc. can be connected to Serial ports.

Audio Connectors



After install onboard audio driver, you may connect speaker to Line Out jack, microphone to MIC In jack. Device like CD-ROM, walkman etc. can be connected to Line-In jack.

Please note:

You are able to use 2-/4-/6-channel audio feature by S/W selection.

If you want to enable 6-channel function, you have 2 choose for hardware connection.

Method1:


Connect "Front Speaker" to "Line Out"
Connect "Rear Speaker" to "Line In"
Connect "Center and Subwoofer" to "MIC Out".

Method2:

You can refer to page 30, and contact your nearest dealer for optional SUR_CEN cable.



If you want the detail information for 2-/4-/6-channel audio setup installation, please refer to page 82.




Step 4-2 : Connectors & Jumper Setting Introduction

1) ATX_12V	16) F_AUDIO
2) ATX	17) SUR_CEN
3) CPU_FAN	18) SPDIF_IO
4) SYS_FAN	19) CD_IN
5) PWR_FAN	20) AUX_IN
6) NB_FAN	21) F_USB1/F_USB2
7) FDD	22) IR_CIR
8) IDE1 / IDE2	23) GAME
9) IDE3 / IDE4	24) INFO_LINK
10) SATAO_SB/SATA1_SB	25) F1_1394/F2_1394
11) SATA0_SII / SATA1_SII	26) CI
12) F_PANEL	27) WOL
13) PWR_LED	28) CLR_PWD
14) RAM_LED	29) BAT
15) 2X_DET	

1) ATX_12V (+12V Power Connector)

This connector (ATX_12V) supplies the CPU operation voltage (Vcore). If this "ATX_12V connector" is not connected, system cannot boot.







Pin No.	Definition
1	GND
2	GND
3	+12V
4	+12V

2) ATX (ATX Power)

AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.






Pin No.	Definition
1	3.3V
2	3.3V
3	GND
4	VCC
5	GND
6	VCC
7	GND
8	Power Good
9	5V SB (stand by +5V)
10	+12V
11	3.3V
12	-12V
13	GND
14	PS_ON(soft on/off)
15	GND
16	GND
17	GND
18	-5V
19	VCC
20	VCC

3) CPU_FAN (CPU Fan Connector)

Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600 mA.






Pin No.	Definition
1	GND
2	+12V
3	Sense

4) SYS_FAN (System Fan Connector)

This connector allows you to link with the cooling fan on the system case to lower the system temperature.






Pin No.	Definition
1	GND
2	+12V
3	Sense

5) PWR_FAN (Power Fan Connector)

This connector allows you to link with the cooling fan on the system case to lower the system temperature.






Pin No.	Definition
1	GND
2	+12V
3	Sense

6) NB_FAN (Chip Fan Connector)

If you installed wrong direction, the chip fan will not work. Sometimes will damage the chip fan.(Usually black cable is GND)






Pin No.	Definition
1	GND
2	VCC

7) FDD (Floppy Connector)

Please connect the floppy drive ribbon cables to FDD. It supports 360K, 1.2M, 720K, 1.44M and 2.88M bytes floppy disk types.

The red stripe of the ribbon cable must be the same side with the Pin1.




8) IDE1 / IDE2 (IDE1 / IDE2 Connector)

Important Notice:


Please connect first hard disk to IDE1 and connect CD-ROM to IDE2.

The red stripe of the ribbon cable must be the same side with the Pin1.




9) IDE3 / IDE4 (RAID/ATA133, Green Connector)

Important Notice: The red stripe of the ribbon cable must be the same side with the Pin1. If you wish to use IDE3 and IDE4, please use it in unity with BIOS (either RAID or ATA133). Then, install the correct driver to have proper operation. For details, please refer to the ITE RAID manual.




(BIOS Default Value :ATA, If you want to use RAID function, please change "Integrated Peripherals-RAID Controller Function " to "RAID")



10/11) [SATA0_SB / SATA1_SB];[SATA0_SII /SATA1_SII] (Serial ATA Connector)

You can connect the Serial ATA device to this connector, it provides you high speed transfer rates (150 MB/sec).





CAUTION

These two Serial ATA(SATA0_SII/SATA1_SII) connectors support hot plug function.

12) F_PANEL (2 x 10 pins Connector)

Please connect the power LED, PC speaker, reset switch and power switch etc. of your chassis front panel to the F_PANEL connector according to the pin assignment above.






HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+)
(Blue)	Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+)
(Amber)	Pin 2- Pin 3: NC
	Pin 4: Data(-)
RES (Reset Switch)	Open: Normal Operation
(Green)	Close: Reset Hard ware System
PW (Soft Power Connector)	Open: Normal Operation
(Red)	Close: Power On/Off
MSG(Message LED/ Power/ Sleep LED)	Pin 1: LED anode(+)
(Yellow)	Pin 2: LED cathode(-)
NC (Purple)	NC

13) PWR_LED

PWR_LED is connect with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode. If you use dual color LED, power LED will turn to another color.






Pin No.	Definition
1	MPD+
2	MPD-
3	MPD-

14) RAM_LED


Do not remove memory modules while RAM_LED is on. It might cause short or other unexpected damages due to the stand by voltage. Remove memory modules only when AC power cord is disconnected.





15) 2X_DET


When an AGP 2X (3.3V) card is installed the 2X_DET will light up, indicating a non-supported graphics card is inserted. Informing users that system might not boot up normally due to AGP 2X (3.3V) is not supported by the chipset



16) F_AUDIO (Front Audio Connector)

If you want to use FrontAudio connector, you must remove 5-6, 9-10 Jumper.

In order to utilize the front audio header, your chassis must have front audio connector. Also please make sure the pin assignment on the cable is the same as the pin assignment on the MB header. To find out if the chassis you are buying support front audio connector, please contact your dealer. Please note, you can have the alternative of using front audio connector or of using rear audio connector to play sound.






Pin No.	Definition
1	MIC
2	GND
3	REF
4	Power
5	FrontAudio (R)
6	Rear Audio (R)
7	Reserved
8	No Pin
9	FrontAudio (L)
10	Rear Audio (L)

17) SUR_CEN (Surround Center Connector)

Please contact your nearest dealer for optional SUR_CEN cable.




6	5
	*
2	1

Pin No.	Definition
1	SUROUTL
2	SUROUTR
3	GND
4	No Pin
5	CENTER_OUT
6	BASS_OUT

18) SPDIF_IO (SPDIF Out Connector)


The SPDIF output is capable of providing digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder. Use this feature only when your stereo system has digital input function. Please contact your nearest dealer for optional SPDIF cable.



Pin No.	Definition
1	VCC
2	No Pin
3	SPDIF
4	SPDIFI
5	GND
6	GND

19) CD_IN (CD In Connector)

Connect CD-ROM or DVD-ROM audio out to the connector.






Pin No.	Definition
1	AUX-L
2	GND
3	GND
4	AUX-R

20) AUX_IN (AUX In Connector)

Connect other device (such as PCITV Tunner audio out) to the connector.






Pin No.	Definition
1	AUX-L
2	GND
3	GND
4	AUX-R


21) F_USB1 / F_USB2 (Front USB Connector, Yellow)

Be careful with the polarity of the front USB connector. Check the pin assignment while you connect the front USB cable. Please contact your nearest dealer for optional front USB cable.



22) IR_CIR

Make sure the pin 1 on the IR device is aling with pin one the connector. To enable the IR/CIR function on the board, you are required to purchase an option IR/CIR module. For detail information please contact your autherized Gigabyte distributor. To use IR function only, please connect IR module to Pin1 to Pin5.






Pin No.	Definition
1	VCC
2	NC
3	IRRX
4	GND
5	IRTX
6	NC
7	CIRRX
8	+5VSB
9	CIRT X
10	NC

23) GAME (Game Connector)

This connector supports joystick, MIDI keyboard and other relate audio devices.






Pin No.	Definition
1	VCC
2	GRX1_R
3	GND
4	GPSA2
5	VCC
6	GPX2_R
7	GPY2_R
8	MSI_R
9	GPSA1
10	GND
11	GPY1_R
12	VCC
13	GPSB1
14	MSO_R
15	GPSB2
16	No Pin

24) INFO_LINK

This connector allows you to connect some external devices to provide you extra function.






Pin No.	Definition
1	SMBCLK
2	VCC
3	SMBDATA
4	GPIO
5	GND
6	GND
7	No Pin
8	NC
9	+12V
10	+12V

25) F1_1394/F2_1394 (IEEE 1394 Connector)

Please Note: Serial interface standard set by Institute of Electrical and Electronics Engineers , which has features like high speed, high bandwidth and hot plug.



F1_1394 2 10

Pin No.	Definition
1	TPA2+
2	TPA2-
3	GND
4	GND
5	TPB2+
6	TPB2-
7	Power
8	Power
9	NoPin
10	GND


F2_1394



Definition
Power
Power
TPA0+
T PA0-
GND
GND
TPB0+
TPB0-
Power
Power
TPA1+
TPA1-
GND
NoPin
TPB1+
TPB1-

26) CI (CASE OPEN)

This 2-pin connector allows your system to enable or disable the "Case Open" item in BIOS, if the system case begin remove.




1 👀

Pin No.	Definition
1	Signal
2	GND

27) WOL (Wake On LAN)

This connector allows the remove servers to manage the system that installed this motherboard via your network adapter which also supports WOL.






Pin No.	Definition
1	+5V SB
2	GND
3	Signal

28) CLR_PWD

When Jumper is set to "open" and system is restarted, the password that is set will be cleared. On the contrary when Jumper is set to "close", the current status remains.







Open: Clear Password



Close: Normal

29) BATTERY





CAUTION

- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.

If you want to erase CM OS...

- 1. Turn OFF the computer and unplug the power cord.
- 2. Remove the battery, wait for 30 second.
- 3. Re-install the battery.
- 4. Plug the power cord and turn ON the computer.

Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

ENTERING SETUP

Powering ON the computer and pressing < Del> immediately will allow you to enter Setup. If you require more advanced BIOS settings, please go to "Advanced BIOS" setting menu. To enter Advanced BIOS setting menu, press "Ctrl+F1" key on the BIOS screen.

CONTROL KEYS

<^>	Move to previous item	
<↓>	Move to next item	
<←>	Move to the item in the left hand	
<→>	Move to the item in the right hand	
Enter	Select item	
<esc></esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and	
	Option Page Setup Menu - Exit current page and return to Main Menu	
<+/PgUp>	Increase the numeric value or make changes	
<-/PgDn>	Decrease the numeric value or make changes	
<f1></f1>	General help, only for Status Page Setup Menu and Option Page Setup Menu	
<f2></f2>	Item Help	
<f3></f3>	Reserved	
<f4></f4>	Reserved	
<f5></f5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu	
<f6></f6>	Load the file-safe default CMOS value from BIOS default table	
<f7></f7>	Load the Optimized Defaults	
<f8></f8>	Dual BIOS/Q-Flash function	
<f9></f9>	System Information	
<f10></f10>	Save all the CMOS changes, only for Main Menu	

- 39 - BIOS Setup

GETTING HELP

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

The Main Menu (For example: BIOS Ver. : E7)

Once you enterAward BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. The Main Menu allows you to select from eight setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

► Standard CMOS Features	Select Language
▶ Adv anc ed BIOS Fe atures	Load Fail-Safe Defaults
▶ Integrated Peripherals	Load Optimized Defaults
▶ Power Management Setup	Set Supervisor Password
▶ PnP/PC I Configurations	Set U ser Pass w ord
▶ PC Health Status	Save & Exit Setup
► Frequency/Voltage Control	Exit Without Saving
ESC: Quit	F3: Change Language
F8: Dual BIOS / Q-Flash	F10: Save & Exit Setup
Time, Date, H	ard Disk Ty pe

Figure 1: Main Menu



If you can't find the setting you want, please press "Ctrl+F1" to search the advanced option widden.

- Standard CMOS Features
 - This setup page includes all the items in standard compatible BIOS.
- Advanced BIOS Features

This setup page includes all the items of Award special enhanced features.

GA-8PENXP Motherboard

- 40 -

• Integrated Peripherals

This setup page includes all onboard peripherals.

• Power Management Setup

This setup page includes all the items of Green function features.

• PnP/PCI Configurations

This setup page includes all the configurations of PCI & PnP ISA resources.

• PC Health Status

This setup page is the System auto detect Temperature, voltage, fan, speed.

• Frequency/Voltage Control

This setup page is control CPU's clock and frequency ratio.

• Select Language

This setup page is select multi language.

• Load Fail-Safe Defaults

Fail-Safe Defaults indicates the value of the system parameters which the system would be in safe configuration.

• Load Optimized Defaults

Optimized Defaults indicates the value of the system parameters which the system would be in best performance configuration.

Set Supervis or password

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

• Set User password

Change, set, or disable password. It allows you to limit access to the system.

• Save & Exit Setup

Save CMOS value settings to CMOS and exit setup.

• Exit Without Saving

Abandon all CMOS value changes and exit setup.

- 41 - BIOS Setup

Standard CMOS Features

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Standard CMOS Features

Date (mm:dd:yy)	Mon, Mar 17 2003	Item Help
Time (hh:mm:ss)	22:31:24	Menu Level ▶
		Change the day, month,
▶IDE Primary Master	[None]	y ear
▶IDE Primary Slave	[None]	
▶IDE Secondary Master	[None]	<week></week>
▶IDE Secondary Slave	[None]	Sun. to Sat.
B: 4		
Drive A	[1.44M, 3.5"]	<month></month>
Driv e B	[None]	Jan. to Dec.
Floppy 3 Mode Support	[Disabled]	
		<day></day>
Halt On	[All, But Keyboard]	1 to 31 (or maximum
		allowed in the month)
Base Memory	640K	
Extended Memory	127M	<year></year>
Total Memory	128M	1999 to 2098
↑↓→←: Mov e Enter:Select +/-/PU	J/PD:Value F10:Sav e ESC:	Exit F1:General Help
F3: Language F5:Previous Value	s F6:Fail-Safe Defaults F	7:Optimized Defaults

Figure 2: Standard CMOS Features

∵ Date

The date format is <week>, <month>, <day>, <year>.

- ▶ Week The w eek, from Sun to Sat, determined by the BIOS and is display only
- → Month The month, Jan. Through Dec.

42

- → Day The day, from 1 to 31 (or the maximum allowed in the month)
- → Year The year, from 1999 through 2098

○ Time

The times format in < hour > <minute > <second > . The time is calculated base on the 24-hour military-time clock. For ex ample, 1 p.m. is 13:00:00.

DE Primary Master, Slave / IDE Secondary Master, Slave

The category identifies the types of hard disk from drive C to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the key board and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

CYLS.	Number of cylinders
→ HEADS	Number of heads
▶ PREC OMP	Write precomp
→ LANDZONE	Landing zone
⇒ SECTORS	Number of sectors

If a hard disk has not been installed select NONE and press <Enter>.

☐ Drive A / Drive B

The category identifies the types of floppy disk drive A or drive B that has been installed in the computer.

None	No floppy drive installed
→ 360K, 5.25"	5.25 inch PC-type standard driv e; 360K byte capacity.
→ 1.2M, 5.25"	5.25 inch AT-type high-density drive; $1.2 M$ byte capacity
	(3.5 inch when 3 Mode is Enabled).
→ 720K, 3.5"	3.5 inch double-sided drive; 720K byte capacity
→ 1.44M, 3.5"	3.5 inch double-sided drive; 1.44M byte capacity.
→ 2.88M, 3.5"	3.5 inch double-sided drive; 2.88M byte capacity.

- 43 - BIOS Setup

Floppy 3 Mode Support (for Japan Area)

Disabled Normal Floppy Drive. (Default v alue)
 Drive A Drive A is 3 mode Floppy Drive.
 Drive B is 3 mode Floppy Drive.
 Both Drive A & B are 3 mode Floppy Drives.

□ Halt on

The category determines whether the computer will stop if an error is detected during power up.

NO Errors
The system boot will not stop for any error that may be detected and you

will be prompted.

★ All Errors Whenever the BIOS detects a non-fatal error the system boot will be stopped.

→ All, But Key board The system boot will not stop for all errors except a key board error.

(Default value)

★ All, But Diskette The system boot will not stop for all errors except a disk error.

▶ All, But Disk/Key The system boot will not stop for all errors except key board and disk errors.

™ Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

Base Memory

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is typically 512 K for systems with 512K memory installed on the motherboard, or 640 K for systems with 640 K or more memory installed on the motherboard.

Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1MB in the CPU's memory address map.

44

Advanced BIOS Features

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Advanced BIOS Features

SCSI/SATA/RAID Boot Order	[SCSI]	Item Help
303/ SAIA/RAID BOOK OIDE	[30 31]	пент пер
First Boot Device	[Floppy]	Menu Level ▶
Second Boot Device	[HDD-03]	Select onboard RAID or
Third Boot Device	[CDROM]	PCI SCSI boot rom
Password Check	[Setup]	order
# CPU Hyper-Threading	[Enabled]	
↑↓→←: Mov e Enter:Select	+/-/PU/PD:Value F10:Sav e	ESC:Exit F1:General Help
F3: Language F5:Previo	us Values F6:Fail-Safe Defaults	F7:Optimized Defaults

Figure 3: Advanced BIOS Features

SCSI /SATA/RAID Boot Order

This feature allows you to select the boot order Serial ATA, RAID or SCSI device.

▶ SCSI Select your boot device priority by PCI SCSI.
 ▶ RAID Select your boot device priority by RAID.
 ▶ SATA Select your boot device priority by Serial ATA.

- 45 - BIOS Setup

[&]quot; # " System will detect automatically and show up when you install the Intel® Pentium® 4 processor with HT Technology.

First / Second / Third Boot Device

→ Floppy Select your boot device priority by Floppy. **→** LS120 Select your boot device priority by LS120. → Hard Disk Select your boot device priority by Hard Disk. **→** CDROM Select your boot device priority by CDROM. **₩** ZIP Select your boot device priority by ZIP. **₩** USB-FDD Select your boot device priority by USB-FDD. **₩** USB-ZIP Select your boot device priority by USB-ZIP. **→** USB-C DROM Select your boot device priority by USB-CDROM. → USB-HDD Select your boot device priority by USB-HDD. **→** LAN Select your boot device priority by LAN. ▶ Disabled Select your boot device priority by Disabled.

Password Check

▶ Setup The system will boot but will not access to Setup page if the correct

passw ord is not entered at the prompt. (Default v alue)

➤ System The system will not boot and will not access to Setup page if the correct

passw ord is not entered at the prompt.

CPU Hyper-Threading

▶ Enabled Enables CPU Hyper Threading Feature. Please note that this feature is only

working for operating system with multi processors mode supported.

(Default value)

Disables CPU Hy per Threading.

46

Integrated Peripherals

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Integrated Peripherals

	grated Peripherals	1
On-Chip Primary PCI IDE	[Enabled]	Item Help
On-Chip Secondary PCI IDE	[Enabled]	Menu Level ►
On-Chip SATA	[Manual]	If a hard disk
SATA Port0 Configure as	[SATA Port0]	controller card is
SATA Port1 Configure as	SATA Port1	used, set at Disabled
SATA RAID Function	[Enabled]	
USB Controller	[Enabled]	[Enabled]
USB 2.0 Controller	[Enabled]	Enabled onboard IDE
USB Keyboard Support	[Disabled]	Port
USB Mouse Support	[Disabled]	
AC97 Audio	[Auto]	[Disabled]
Onboard H/W SATA	[Enabled]	Disabled onboard IDE
Serial ATA Function	[RAID]	Port
Onboard H/W GIGARAID	[Enabled]	
GigaR AID Function	[RAID]	
Onboard H/W LAN	[Enabled]	
Onboard LAN Boot ROM	[Disabled]	
Onboard Serial Port 1	[3F8/IRQ4]	
Onboard Serial Port 2	[2F8/IRQ3]	
UART Mode Select	[Normal]	
x UR2 Duplex Mode	Half	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[SPP]	
x ECP Mode Use DMA	3	
Game Port Address	[201]	
Midi Port Address	[Disabled]	
Midi Port IRQ	10	
CIR Port Address	[Disabled]	
x CIR Port IRQ	11	
	/PD: Value F10: Save ES	
F3: Language F5: Previous Value	es F6: Fail-Safe Defaults	F7: Optimized Defaults

Figure 4: Integrated Peripherals

- 47 - BIOS Setup

On-Chip Primary PCI IDE

▶ Enabled Enable onboard 1st channel IDE port. (Default v alue)

→ Disabled Disable onboard 1st channel IDE port.

On-Chip Secondary PCI IDE

► Enabled Enable onboard 2nd channel IDE port. (Default v alue)

→ Disabled Disable onboard 2nd channel IDE port.

On-chip SATA

▶ Disabled Disable SATA controller.

★ Auto When there is no device to be plugged in IDE1 or IDE2, SATA controller will

remap to IDE control ler.

Manual Set SATA Mode manually. (Default Value)

SATA Port0 Configure as

DE Pri. Master
 Remap SATA Port 0 to IDE Pri. Master.
 IDE Pri. Slave
 Remap SATA Port 0 to IDE Pri. Slave.
 DE Sec. Master
 Remap SATA Port 0 to IDE Sec. Master.
 DE Sec. Slave
 Remap SATA Port 0 to IDE Sec. Slave.

SATA Port0 SATA controller set to SATA port0. As this mode, it support by WinXP or

later OS only. (Default v alue)

▶ SATA Port1 SATA controller set to SATA port1. As this mode, it support by WinXP or

later OS only.

SATA Port1 Configure as

▶ The v alues depend on SATA Port0 .

SATA RAID Function

▶ Enabled Enable SATA Raid function when SATA Mode set to SATA Port 0 & SATA

Port 1 only. (Default v alue)

▶ Disable SATA Raid function.

: USB Controller

▶ Enabled Enable USB Controller. (Default v alue)

▶ Disable USB Controller.

USB 2.0 Controller

Disable this function if you are not using onboard USB 2.0 feature.

• Enabled Enable USB 2.0 Controller. (Default value)

▶ Disabled Disable USB 2.0 Controller.

USB Keyboard Support

▶ Enabled Enable USB Key board Support.

▶ Disabled Disable USB Key board Support. (Default v alue)

USB Mouse Support

▶ Enabled Enable USB Mouse Support.

▶ Disabled Disable USB Mouse Support. (Default v alue)

AC97 Audio

→ Auto Auto detect AC'97 audio function. (Default Value)

▶ Disabled Disable AC'97 audio function.

Onboard H/W SATA

Disable this option if you are not using the onboard Serial ATA feature.

▶ Enabled Enabled Onboard H/W Serial ATA support.(Default v alue)

Disabled Disabled Onboard H/W Serial ATA .

Serial ATA Function

▶ RAID Select onboard Serial ATA chip function as RAID.(Default v alue)

▶BASE Select onboard Serial ATA chip function as BASE.

Onboard H/W GIGARAID

► Enable Enable onboard RAID function. (Default v alue)

▶ Disable Disable this function.

- 49 - BIOS Setup

□ GigaRAID Function

▶ RAID Set onboard GigaRAID chip function as RAID. (Default v alue)

▶ ATA Set onboard GigaRAID chip function as ATA.

Onboard H/W 1394

► Enable Enabled onboard IEEE 1394 function. (Default v alue)

▶ Disable Disabled this function.

Onboard H/W LAN

► Enabled Enable Onboard H/W LAN function. (Default v alue)

▶ Disabled Disable this function.

Onboard LAN Boot ROM

This function decide whether to invoke the boot ROM of the onboard LAN chip.

▶ Disabled Disable this function. (Default Value)

▶ Enabled Enable this function.

Onboard Serial Port 1

→ Auto BIOS will automatically setup the port 1 address.

▶ 3F8/IRQ4 Enable onboard Serial port 1 and address is 3F8. (Default v alue)

⇒ 2F8/IRQ3 Enable onboard Serial port 1 and address is 2F8.
 ⇒ 3E8/IRQ4 Enable onboard Serial port 1 and address is 3E8.
 ⇒ 2E8/IRQ3 Enable onboard Serial port 1 and address is 2E8.

▶ Disabled Disable onboard Serial port 1.

Onboard Serial Port 2

▶ Auto BIOS will automatically setup the port 2 address.
 ▶ 3F8/IRQ4 Enable onboard Serial port 2 and address is 3F8.

⇒ 2F8/IRQ3 Enable onboard Serial port 2 and address is 2F8. (Default value)

⇒ 3E8/IRQ4 Enable onboard Serial port 2 and address is 3E8.
 ⇒ 2E8/IRQ3 Enable onboard Serial port 2 and address is 2E8.

→ Disabled Disable onboard Serial port 2.

50

GA-8PENXP Motherboard

UART Mode Select

This item allows you to determine which Infra Red(IR) function of Onboard I/O chip.

▶ ASKIR Set onboard I/O chip UART to ASKIR Mode.
 ▶ IrDA Set onboard I/O chip UART to IrDA Mode.

▶ Normal Set onboard I/O chip UART to Normal Mode. (Default Value)

UR2 Dupl ex Mode

This feature allows you to seclect IR mode.

This function will available when "UART Mode Select" doesn't set at Normal.

→ Half IR Function Duplex Half. (Default Value)

Full IR Function Duplex Full.

Onboard Parallel port

This feature allows you to select from a given set of parameters if the parallel port uses the onboard I/O controller.

→ Disabled Disable onboard LPT port.

→ 378/IRQ7 Enable onboard LPT port and address is 378/IRQ7. (Default Value)

⇒ 278/IRQ5 Enable onboard LPT port and address is 278/IRQ5.
 ⇒ 3BC/IRQ7 Enable onboard LPT port and address is 3BC/IRQ7.

Parallel Port Mode

This feature allows you to connect with an advanced printer via the port mode it supports.

⇒ SPP Using Parallel port as Standard Parallel Port. (Default Value)

▶ EPP Using Parallel port as Enhanced Parallel Port.
 ▶ ECP Using Parallel port as Extended Capabilities Port.
 ▶ ECP+EPP Using Parallel port as ECP & EPP mode.

ECP Mode Use DMA

This feature allows you to select Direct Memory Access (DMA) channel if the ECP mode selected.

This function will available when "Parallel Port Mode" set at ECP or ECP+EPP.

→ 3 Set ECP Mode Use DMA to 3. (Default Value)

→ 1 Set ECP Mode Use DMA to 1.

- 51 - BIOS Setup

Game Port Address

⇒ 201 Set Game Port Address to 201. (Default Value)

→ 209 Set Game Port Address to 209.

▶ Disabled Disable this function.

○ Midi Port Address

⇒ 300 Set Midi Port Address to 300.
 ⇒ 330 Set Midi Port Address to 330.
 ⇒ Disabled Disable this function. (Default Value)

™ Midi Port IRQ

⇒ 5 Set Midi Port IRQ to 5.

→ 10 Set Midi Port IRQ to 10. (Default Value)

CIR Port Address

⇒ 310
 ⇒ 320
 ⇒ Disabled
 ⇒ Set C IR Port Address to 320.
 ⇒ Disabled
 ⇒ Disable this function. (Default Value)

CIR Port IRQ

⇒ 5 Set CIR Port IRQ to 5.

→ 11 Set C IR Port IR Q to 11. (Default Value)

Power Management Setup

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Power Management Setup

	1 OW OF INIGHIAGOFFICER	
ACPI Suspend Type	[S1(POS)]	Item Help
Power LED in S1 state	[Blinking]	Menu Level ▶
Off by Power button	[Instant-off]	[S1]
PME Event Wake Up	[Enabled]	Set suspend ty pe to
ModemRingOn/WakeOnLan	[Enabled]	Power On Suspend under
Resume by Alarm	[Disabled]	ACPI OS
x Date (of Month) Alarm	Ev er y day	
x Time (hh:mm:ss) Alarm	0:0:0	[S3]
Power On by Mouse	[Disabled]	Set suspend ty pe to
Power On by Key board	[Disabled]	Suspend to RAM under
x KB Power ON Password	Enter	ACPI OS
AC Back Function	[Soft-Off]	
↑↓→←: Mov e Enter: Select	+/-/PU/PD: Value F10: Save ESC	: Exit F1: General Help
F3: Language F5: Previou	s Values F6: Fail-Safe Defaults	F7: Optimized Defaults

Figure 5: Power Management Setup

○ ACPI Suspend Type

- ▶ S1(POS) Set ACPI suspend type to S1. (Default Value)
- ► S3(STR) Set ACPI suspend type to S3.

Power LED in S1 state

- ▶ Blinking In standby mode(S1), pow er LED will blink. (Default Value)
- Dual/OFF In standby mode(S1):
 - a. If use single color LED, power LED will turn off.
 - b. If use dual color LED, power LED will turn to another color.

- 53 - BIOS Setup

Off by Power button

▶ Instant-off
Press power button then Power off instantly. (Default v alue)

→ Delay 4 Sec. Press power button 4 sec. to Power off. Enter suspend if button is pressed

less than 4 sec.

PME Event Wake Up

▶ Disabled Disable this function.

▶ Enabled Enable PME Event Wake up. (Default Value)

ModemRingOn/WakeOnLAN

An incoming call via modem can awake the system from any suspend state or an input signal comes from the other client server on the LAN can awake the system from any suspend state.

Disabled Disable Modem Ring on/wake on Lan function.
 ⇒ Enabled Enable Modem Ring on/wake on Lan. (Default Value)

Resume by Alarm

You can set "Resume by Alarm" item to enabled and key in Data/time to power on sy stem.

▶ Disabled Disable this function. (Default Value)

▶ Enabled Enable alarm function to POWER ON sy stem.

If RTC Alarm Lead To Power On is Enabled.

Date (of Month) Alarm: Everyday, 1~31

Time (hh: mm: ss) Alarm: (0~23): (0~59): (0~59)

Power On By Mouse

▶ Disabled Disabled this function. (Default v alue)

Mouse Click Double click on PS/2 mouse left button to power on the system.

Power On By Keyboard

This feature allows you to set the method for powering-on the sy stem.

The option "Password" allows you to set up to 5 alphanumeric characters to power-on the system. The option "Keyboard 98" allows you to use the standard keyboard 98 to power on the system.

▶ Pass word Enter from 1 to 5 characters to set the Key board Pow er On Pass word.

▶ Disabled Disabled this function. (Default v alue)

▶ Key board 98 If your key board have "POWER Key" button, you can press the key to

power on the system.

KB Power ON Password

When "Power On by Keyboard" set at Password, you can set the password here.

▶ Enter Input password (from 1 to 5 characters) and press Enter to set the Key board

Power On password.

AC BACK Function

▶ Soft-Off When AC-power back to the system, the system will be in "Off" state.

(Default Value

▶ Full-On▶ Mem oryWhen AC-power back to the system, the system always in "On" state.▶ Mem oryWhen AC-power back to the system, the system will return to the Last state

before AC-power off.

PnP/PCI Configurations

CMOS Setup Utility-Copy right (C) 1984-2003 Aw ard Softw are

PnP/PC I Configurations

PCI 1/PCI 5 IRQ Assignment	[Auto] Item Help
PCI 2 IRQ Assignment	[Auto] Menu Level ▶
PCI 3 IRQ Assignment	[Auto] Device(s) using this
PCI 4 IRQ Assignment	[Auto] INT: IDE Cntrlr -Bus 0 Dev 31 Func 2 Network Cntrlr -Bus 2 Dev 1 Func 0 USB 1.1 Host Cntrlr -Bus 0 Dev 29 Func 2
↑↓→←: Mov e Enter:Select +/-/PU/PD	:Value F10:Sav e ESC:Exit F1:General Help
F3: Language F5:Previous Values F	F6:Fail-Safe Defaults F7:Optimized Defaults

Figure 6: PnP/PCI Configurations

PCI 1/PCI 5 IRQ Assignment

▶ Auto Auto assign IRQ to PCI 1/PCI 5. (Default value)
 ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 1/PCI 5.

PCI 2 IRQ Assignment

▶ Auto Auto assign IRQ to PCI 2. (Default value)
 ▶ 3,4,5,7,9,10,11,12,14,15 to PCI 2.

PCI 3 IRQ Assignment

▶ Auto Auto assign IRQ to PCI 3. (Default value)
 ▶ 3,4,5,7,9,10,11,12,14,15 to PCI 3.

PCI 4 IRQ Assignment

▶ Auto Auto assign IRQ to PC I 4. (Default value)
 ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PC I 4.

GA-8PENXP Motherboard

- 56 -

2003/4/11, 下午 03:59

PC Health Status

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software PC Health Status

1011	Carti Otatas	!
Reset Case Open Status	[Disabled]	Item Help
Case Opened	Yes	Menu Level ▶
Vcore	OK	[Disabled]
DDR 25V	OK	Don't reset case
+3.3V	OK	open s tatus
+5V	OK	
+12V	OK	[Enabled]
Current CPU Temperature	33°C	Clear case open
Current CPU FAN Speed	4687 RPM	status at next boot
Current POWER FAN Speed	0 RPM	
Current SYSTEM FAN Speed	0 RPM	
CPU Warning Temperature	[Disabled]	
CPU FAN Fail Warning	[Disabled]	
POWER FAN Fail Warning	[Disabled]	
SYSTEM FAN Fail Warning	[Disabled]	
CPU Smart FAN Control	[Enabled]	
↑↓→←: Mov e Enter: Select +/-/PU/PD:	Value F10: Save ESC:	Exit F1: General Help
F3: Language F5: Previous Values	F6: Fail-Safe Defaults	F7: Optimized Defaults

Figure 7: PC Health Status

Reset Case Open Status

Case Opened

If the case is closed, "Case Opened" will show "No".

If the case have been opened, "Case Opened" will show "Yes".

If you want to reset "Case Opened" value, set "Reset Case Open Status" to "Enabled" and save CMOS, your computer will restart.

$^{\circ}$ Current Voltage (V) Vcore / DDR25V / +3.3V / +5V / +12V

▶ Detect system's voltage status automatically.

- 57 - BIOS Setup

Current CPU Temperature

▶ Detect CPU Temp. automatically.

Current CPU/POWER/SYSTEM FAN Speed (RPM)

▶ Detect CPU/POWER/SYSTEM Fan speed status automatically.

· CPU Warning Temperature

★ 60°C / 140°F
 Monitor CPU Temp. at 60°C / 140°F.
 ★ 70°C / 158°F
 Monitor CPU Temp. at 70°C / 158°F.
 ★ 80°C / 176°F
 Monitor CPU Temp. at 80°C / 176°F.
 ★ 90°C / 194°F
 Monitor CPU Temp. at 90°C / 194°F.
 ★ Disabled
 Disable this function.(Default value)

CPU FAN Fail Warning

▶ Disabled Fan Warning Function Disable. (Default value)

▶ Enabled Fan Warning Function Enable.

POWER FAN Fail Warning

▶ Disabled Fan Warning Function Disable. (Default value)

▶ Enabled Fan Warning Function Enable.

SYSTEM FAN Fail Warning

▶ Disabled Fan Warning Function Disable. (Default value)

▶ Enabled Fan Warning Function Enable.

CPUSmart FAN Control

▶ Disabled Disable this function.

► Enabled Enable CPU Smart Fan control function.(Default v alue)

a. When the CPU temperature is higher than 40 degrees Celsius, CPU fan

will run at full speed.

b. When the CPU temperature is lower than 40 degrees Celsius, CPU fan

will run at low speed.

GA-8PENXP Motherboard

- 58 -

Frequency/Voltage Control

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Frequency/Voltage Control

CPU Clock Ratio	[15X]	Item Help
CPU Host Clock Control	[Disabled]	Menu Level ▶
× CPU Host Frequency (Mhz)	133	Over CPU Clock Serial ATA device
* AGP/PCI/SRC Fixed	66/33/100	is very sensitive to
Memory Frequency For	[Auto]	SRC clock. SRC over
Memory Frequency (Mhz)	266	clock may make Serial
AGP/PCI/SRC Frequency (Mhz)	66/33/100	ATA device function can't
DIMM OverVoltage Control	[Normal]	work properly.
AGP Ov erVoltage Control	[Normal]	
CPU Voltage Control	[Normal]	
Normal CPU Vcore	1.5250V	
↑↓→←: Mov e Enter:Select +/-/PU/PD:Value	e F10:Save ESC	:Exit F1:General Help
F3: Language F5:Previous Values F6:F	ail-Safe Defaults	F7:Optimized Defaults

Figure 8: Frequency/Voltage Control

* Those items will be available when "CPU Host Clock Control" is set to Enabled.

CPU Clock Ratio

This option will not be shown or not be available if you are using a CPU with the locked ratio.

► 15X~21X It depends on CPU Clock Ratio.

This setup option will automatically assign by CPU detection.

For C-Stepping P4: 8X, 10X~24X default: 15X For Northwood CPU: 12X~24X default: 16X

The option will display "Locked" and read only if the CPU ratio is not changeable.

- 59 - BIOS Setup

CPU Host Clock Control

Note: If system hangs up before enter CMOS setup utility, wait for 20 sec for times out reboot. When time out occur, system will reset and run at CPU default Host clock at next boot.

▶ Disabled Disable CPU Host Clock Control. (Default v alue)

▶ Enabled Enable CPU Host Clock Control.

CPU Host Frequency (Mhz)

- ► 100MHz ~ 355MHz Set CPU Host Clock from 100MHz to 355MHz.
- ▲ Incorrect using it may cause your system broken. For power End-User use only!

□ AGP/PCI/SRC Fixed

Serial ATA device is very sensitive to SRC clock. SRC over clock may make Serial ATA device function can't work properly.

Adjust AGP/PCI/SRC clock asychrohous with CPU.

Memory Frequency For

for FSB(Front Side Bus) frequency=400MHz,

▶ 2.0 Memory Frequency = Host clock X 2.0.
 ▶ 2.66 Memory Frequency = Host clock X 2.66.

→ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

for FSB(Front Side Bus) frequency = 533MHz,

▶ 2.0 Memory Frequency = Host clock X 2.0.
 ▶ 2.5 Memory Frequency = Host clock X 2.5.

→ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

for FSB(Front Side Bus) frequency=800MHz,

▶ 2.0 Memory Frequency = Host clock X 2.0.
 ▶ 1.6 Memory Frequency = Host clock X 1.6.
 ▶ 1.33 Memory Frequency = Host clock X 1.33.

▶ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

Memory Frequency (Mhz)

GA-8PENXP Motherboard

AGP/PCI/SRC Frequency (Mhz)

→ The v alues depend on Fixed AGP/PCI/SRC Frequency.

DIMM OverVoltage Control

Normal	Set DIMM OverVoltage	Control to Normal.	(Default value)
--------	----------------------	--------------------	-----------------

→ +0.1V Set DIMM OverVoltage Control to +0.1V.
 → +0.2V Set DIMM OverVoltage Control to +0.2V.
 → +0.3V Set DIMM OverVoltage Control to +0.3V.

▲ Incorrect using it may cause your system broken. For power End-User use only!

• AGP OverVoltage Control

▶ Normal Set AGP OverVoltage Control to Normal. (Default value)

→ +0.1V Set AGP OverVoltage Control to +0.1V.
 → +0.2V Set AGP OverVoltage Control to +0.2V.
 → +0.3V Set AGP OverVoltage Control to +0.3V.

▲ Incorrect using it may cause your system broken. For power End-User use only!

CPU Voltage Control

- ➤ Supports adjustable CPU V core from 0.8375V to 1.6000V by 0.025V step.

 (Default v alue: Normal)
- ♠ Incorrect using it may cause your system broken. For power End-User use only!

Normal CPU Vcore

▶ Display your CPU Vcore Voltage.

- 61 - BIOS Setup

Select Language

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 10: Select Language

Select Language

Multi Language is supports 7 languages. There are English, Japanese, French, Spanish, German, Simplified Chinese, Traditional Chinese.

62

Load Fail-Safe Defaults

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 11: Load Fail-Safe Defaults

Load Fail-Safe Defaults

Fail-Safe defaults contain the most appropriate values of the system parameters that allow minimum system performance.

- 63 - BIOS Setup

Load Optimized Defaults

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 12: Load Optimized Defaults

Load Optimized Defaults

Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

Set Supervisor/User Password

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 13: Password Setting

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password, up to eight characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

The BIOS Setup program allows you to specify two separate passwords:

SUPERVISOR PASSWORD and a USER PASSWORD. When disabled, any one may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration felds, the User password is required to access only basic items.

If you select "System" at "Password Check" in Advance BIOS Features Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.

If you select "Setup" at "Password Check" in Advance BIOS Features Menu, you will be prompted only when you try to enter Setup.

- 65 - BIOS Setup

Save & Exit Setup

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 14: Save & Exit Setup

Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS. Type "N" will return to Setup Utility.

GA-8PENXP Motherboard

Exit Without Saving

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 15: Exit Without Saving

Type "Y" will quit the Setup Utility without saving to RTC CMOS. Type "N" will return to Setup Utility.

- 67 - BIOS Setup

GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard -68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
GA-8PENXP Motherboard - 68 -			
	GA-8PENXP Motherboard	- 68 -	

Chapter 4 Technical Reference

@BIOS™ Introduction

Gigabyte announces @BIOS Windows BIOS Live Update Utility



Have you ever updated BIOS by yourself? Or like many other people, you just know what BIOS is, but always hesitate to update it? Because you think updating newest BIOS is unnecessary and actually you don't know how to update it.

Maybe not like others, you are very experienced in BIOS updating and spend quite a lot of time to do it. But of course you don't like to do it too much. First, download different BIOS from website and then switch the operating system to DOS mode. Secondly, use different flash utility to update BIOS. The above process is not a interesting job. Besides, always be carefully to store the BIOS source code correctly in your disks as if you update the wrong BIOS, it will be a nightmare.

Certainly, you wonder why motherboard vendors could not just do something right to save your time and effort and save you from the lousy BIOS updating work? Here it comes! Now Gigabyte announces @BIOS -- the first Windows BIOS live update utility. This is a smart BIOS update software. It could help you to download the BIOS from internetand update it. Not like the other BIOS update software, it's a Windows utility. With the help of "@BIOS", BIOS updating is no more than a click.

Besides, no matter which mainboard you are using, if it's a Gigabyte's product*, @BIOS help you to maintain the BIOS. This utility could detect your correct mainboard model and help you to choose the BIOS accordingly. It then downloads the BIOS from the nearest Gigabyte ftp site automatically. There are several different choices; you could use "Internet Update" to download and update your BIOS directly. Or you may want to keep a backup for your current BIOS, just choose "Save Current BIOS" to save it first. You make a wise choice to use Gigabyte, and @BIOS update your BIOS smartly. You are now worry free from updating wrong BIOS, and capable to maintain and manage your BIOS easily. Again, Gigabyte's innovative product erects a milestone in motherboard industries.

For such a wonderful software, how much it costs? Impossible! It's free! Now, if you buy a Gigabyte's motherboard, you could find this amazing software in the attached driver CD. But please remember, connected to internet at first, then you could have a internet BIOS update from your Gigabyte @BIOS.

EasyTune™ 4 Introduction

Gigabyte announces EasyTune™ 4 Windows based Overclocking utility

EasyTune 4 carries on the heritage so as to pave the way for future generations.



Overclock" might be one of the most common issues in computer field. But have many users ever tried it? The answer is probably "no". Because "Overclock" is thought to be very difficult and includes a lot of technical know-how, sometimes "Overclock" is even considered as special skills found only in some enthusiasts. But as to the experts in "Overclock", what's the truth? They may spend quite a lot of time and money to study, try and use many different hardware or BIOS tools

to do "Overclock". And even with these technologies, they still learn that it's quite a risk because the safety and stability of an "Overclock" system is unknown. Now everything is different because of a Windows based overclocking utility "EasyTune 4" --announced by Gigabyte. This windows based utility has totally changed the gaming rule of "Overclock". This is the first windows based overclocking utility is suitable for both normal and power users. Users can choose either "Easy Mode" or "Advanced Mode" for overclocking at their convenience. For users who choose "Easy Mode", they just need to click "Auto Optimize" to have autoed and immediate CPU overclocking. This software will then overdrive CPU speed automatically with the result being shown in the control panel. If users prefer "Overclock" by them, there is also another choice. Click "Advanced Mode" to enjoy "sport drive" class Overclocking user interface. "Advanced Mode", allows users to change the system bus /AGP / Memory working frequency in small increments to get ultimate system performance. It operates in coordination with Gigabyte motherboards. Besides, it is different from other traditional overclocking methods. EasyTune 4 doesn't require users to change neither BIOS nor hardware switch/ iumper setting; on the other hand, they can do "Overclock" at easy step. Therefore, this is a safer way for "Overclock" as nothing is changed on software or hardware. If user runs EasyTune 4 over system's limitation, the biggest lost is only to restart the computer again and the side effect is then well controlled. Moreover, if one well-performed system speed has been tested in EasyTune 4, user can "Save" this setting and "Load" it in next time. Obviously, Gigabyte EasyTune 4 has already turned the "Overclock" technology toward to a newer generation. This wonderful software is now free bundled in Gigabyte motherboard attached in driver CD. Users may make a test drive of "EasyTune 4" to find out more amazing features by themselves.

*Some Gigabyte products are not fully supported by EasyTune 4. Please find the products supported list in the web site.

*Any "Overclocking action" is at user's risk, Gigabyte Technology will not be responsible for any damage or instability to your processor, motherboard, or any other components.

DPS2 (Dual Power System 2) Introduction




DPS2 - A new innovation technology from Gigabyte Technology in which gives you a total of 6-phase power circuit design. Providing 2 extra phase power circuits that motherboard design guideline recommended. In a DPS2 (Dual Power System 2)

designed motherboard, an additional 3-phase power circuit DPS2 daughter card is added on the motherboard. Providing a more durable and stable power circuit to sustain a larger electric current up to 150A. DPS2 specially design for the future coming processor, which demands a higher working frequency and a more stable and durable power circuit.

Working mode in a Dual Power System 2:

Parallel Mode:

Both DPS2 and onboard power circuit working simultaneously, providing a total of 6-phase power circuit. If any power circuit fails, the remaining power circuit will keep working as main power circuit.



Flash BIOS Method Introduction

Method 1: Dual BIOS / Q-Flash

A. What is Dual BIOS Technology?

Dual BIOS means that there are two system BIOS (ROM) on the motherboard, one is the Main BIOS and the other is Backup BIOS. Under the normal circumstances, the system works on the Main BIOS. If the Main BIOS is corrupted or damaged, the Backup BIOS can take over while the system is powered on. This means that your PC will still be able to run stably as if nothing has happened in your BIOS.

B. How to use Dual BIOS and Q-Flash Utility?

1.) After power on the computer, pressing immediately during POST (Power On Self Test) it will allow you to enter Award BIOS CMOS SETUP, then press <F8> to enter Flash utility.

Standard CMOS Features Select Language Advanced BTOS Features Load Fail-Safe Defaults Integrated Perioherals Load Octimized Defaults Enter Dual BIOS / Q-Flash Utility (Y/N)? Y Power M ▶ PnP/PCI Configurations Set User Password PC Health Status Save & Exit Setup Frequency/Voltage Control. Exit Without Saving F3: Change Language F8: D.al BIOS / O-Flash F10: Save & Exit Setup Time, Date, Hard Disk Type...

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

2.) Award Dual BIOS Flash ROM Programming Utility

Dual BIOS Utility V1.30				
Boot From	Main Bios			
Main ROM Type/Size	SST 49LF003A	512K		
Backup ROM Type/Size	SST 49LF003A	512K		
Wide Range Protection	Disable			
Boot From	Main Bios			
Auto Recovery	Enable			
Halt On Error	Disable			
Keep DMI Data	Enable			
Copy Main ROM Data to Backup				
Load Default Settings				
Save Settings to CMOS				
Q-Flash Utility				
Update Main BIOS from Floppy				
Update Backup BIOS from Floppy				
Save Main BIOS to Floppy				
Save Backup BIOS to Floppy				
PgDn/PgUp: Modify ↑↓: Moxe	ESC: Reset	F10: Power Off		

3.) Dual BIOS Item explanation:

• Wide Range Protection: Disable(Default), Enable

Status 1:

If any failure (ex. Update ESCD failure, checksum error or reset...) occurs in the Main BIOS, just before the Operating System is loaded and after the power is on, and that the Wide Range Protection is set to "Enable", the PC will boot from Backup BIOS automatically.

Status 2:

If the ROM BIOS on peripherals cards(ex. SCSI Cards, LAN Cards,...) emits signals torequest restart of the system after the user make any alteration on it, the boot up BIOS will not be changed to the Backup BIOS.

· Boot From : Main BIOS(Default), Backup BIOS

Status 1:

The user can set to boot from main BIOS or Backup BIOS.

Status 2:

If one of the main BIOS or the Backup BIOS fails, this item "Boot From: Main BIOS(Default)" will become gray and will not be changed by user.

· Auto Recovery : Enable(Default), Disable

When one of the Main BIOS or Backup BIOS occurs checksum failure, the working BIOS will automatically recover the BIOS of checksum failure.

(In the Power Management Setup of the BIOS Setting, if ACPI Suspend Type is set to Suspend to RAM, the Auto Recovery will be set to Enable automatically.)

(If you want to enter the BIOS setting, please press "Del" key when the boot screen appears.)

· Halt On Error : Disable(Default), Enable

If the BIOS occurs a checksum error or the Main BIOS occurs a WIDE RANGE PROTECTION error and Halt On Error set to Enable, the PC will show messages on the boot screen, and the system will pause and wait for the user's instruction.

If Auto Recovery : Disable, it will show <or the other key to continue.>

If Auto Recovery : Enable, it will show <or the other key to Auto Recover.>

Keep DMI Data : Enable(Default), Disable

Enable: The DMI data won't be replaced by flashing new BIOS.(recommend)

Disable: The DMI data will be replaced by flashing new BIOS.

Copy Main ROM Data to Backup

(If you boot from Backup ROM, this item will change to "Copy Backup ROM Data to Main) Auto recovery message:

BIOS Recovery: Main to Backup

The means that the Main BIOS works normally and could automatically recover the Backup BIOS.

BIOS Recovery: Backup to Main

The means that the Backup BIOS works normally and could automatically recover the Main BIOS. (This auto recovery utility is set by system automatically and can't be changed by user.)

· Load Default Settings

Load dual BIOS default value.

Save Settings to CMOS

Save revised setting.


C. What is Q-Flash Utility?

Q-Flash utility is a pre-O.S. BIOS flash utility enables users to update its BIOS within BIOS mode, no more fooling around any OS.

D. How to use Q-Flash?

Load Main BIOS from Floppy / Update Backup BIOS from Floppy

In the A: drive, insert the "BIOS" diskette, then Press Enter to Run.



Press Enter to Run.

Are you sure to update BIOS?

[Enter] to contiune Or [ESC] to abort...

Press Enter to Run.


!! COPY BIOS Completed -Pass !!

Please press any key to continue....

Congratulation! You have completed the flashed and now can restart system.

Save Main BIOS to Floppy / Save Backup BIOS to Floppy

In the A:drive, insert the floppy disk, then Press Enter to Run.



Congratulate you have accomplished the saving.

CONTROLKEYS

<pgdn pgup=""></pgdn>	Make changes
<^>	Move to previous item
< √ >	Move to next item
<enter></enter>	Run
<esc></esc>	Reset
<f10></f10>	Power Off



DualBIOS™ Technology FAQ

GIGABYTE Technology is pleased to introduce DualBIOS technology, a hot spare for your system BIOS. This newest "Value-added" feature, in a long series of innovations from GIGABYTE, is available on this motherboard. Future GIGABYTE motherboards will also incorporate this innovation.

What's DualBIOS™?

On GIGABYTE motherboards with DualBIOS there are physically two BIOS chips. For simplicity we'll call one your "Main BIOS" and the other we'll call your "Backup BIOS" (your "hot spare"). If your Main BIOS fails, the Backup BIOS almost automatically takes over on your next system boot. Almost automatically and with virtually zero down time! Whether the problem is a failure in flashing your BIOS or a virus or a catastrophic failure of the Main BIOS chip, the result is the same - the Backup BIOS backs you up, almost automatically.

I. Q: What is DualBIOS™ technology?

Answer:

DualBIOS technology is a patented technology from Giga-Byte Technology. The concept of this technology is based on the redundancy and fault tolerance theory. DualBIOS™ technology simply means there are two system BIOSes (ROM) integrated onto the motherboard. One is a main BIOS, and the other is a backup BIOS. The mainboard will operate normally with the main BIOS, however, if the main BIOS is corrupt or damaged for various reasons, the backup BIOS will be automatically used when the system powered-On. Your PC will operate as before the main BIOS was damaged, and is completely transparent to the user.

II. Q: Why does anyone need a motherboard with DualBIOS™ technology? Answer:

In today's systems there are more and more BIOS failures. The most common reasons are virus attacks, BIOS upgrade failures, and/or deterioration of the BIOS (ROM) chip itself.

- 1. New computer viruses are being found that attack and destroy the system BIOS. They may corrupt your BIOS code, causing your PC to be unstable or even not boot normally.
- 2. BIOS data will be corrupted if a power loss/surge occurs, or if a user resets the system, or if the power button is pressed during the process of performing a system BIOS upgrade.
- 3. If a user mistakenly updates their mainboard with the incorrect BIOS file, then the system may not be able to boot correctly. This may cause the PC system hang in operation or during boot.
- 4. A flash ROM's life cycle is limited according to electronic characteristics. The modern PC utilizes the Plug and Play BIOS, and is updated regularly. If a user changes peripherals often, there is a slight chance of damage to the flash ROM.

With Giga-Byte Technology's patented DualBIOS™ technology you can reduce the possibility of hangs during system boot up, and/or loss BIOS data due to above reasons.

This new technology will eliminate valuable system down time and costly repair bills cause by BIOS failures.

III. Q: How does DualBIOS™ technology work?

Answer:

This new technology will eliminate valuable system down time and costly repair bills cause by BIOS failures.

- DualBIOS™ technology provides a wide range of protection during the boot up procedure. It
 protects your BIOS during system POST, ESCD update, and even all the way to PNP detection/assignment.
- 2. DualBIOS™ provides automatic recovery for the BIOS. When the first BIOS used during boot up does not complete or if a BIOS checksum error occurs, boot-up is still possible. In the DualBIOS™ utility, the "Auto Recovery" option will guarantee that if either the main BIOS or backup BIOS is corrupted, the DualBIOS™ technology will use the good BIOS and correct the wrong BIOS automatically.
- 3. DualBIOS™ provides manual recovery for the BIOS. DualBIOS™ technology contains a built-in flash utility, which can flash your system BIOS from backup to main and/or visa versa. There is no need for an OS-dependent flash utility program.
- 4. DualBIOS™ contains a one-way flash utility. The built-in one-way flash utility will ensure that the corrupt BIOS is not mistaken as the good BIOS during recovery and that the correct BIOS (main vs. backup) will be flashed. This will prevent the good BIOS from being flashed.

IV. Q: Who Needs DualBIOS™ technology?

Answer:

This new technology will eliminate valuable system down time and costly repair bills cause by BIOS failures.

- 1. Every user should have DualBIOS™ technology due to the advancement of computer viruses. Everyday, there are new BIOS-type viruses discovered that will destroy your system BIOS. Most commercial products on the market do not have solutions to guard against this type of virus intrusion. The DualBIOS™ technology will provide a state-of-the-art solution to protect your PC:
 - Case I.) Vicious computer viruses may wipe out your entire system BIOS. With a conventional single system BIOS PC, the PC will not be functional until it is sent for repairs.
 - Case II.) If the "Auto Recovery" option is enabled in the DualBIOS™ utility, and if a virus corrupts your system BIOS, the backup BIOS will automatically reboot the system and correct the main BIOS.
 - Case III.) A user may override booting from the main system BIOS. The DualBIOS™ utility may be entered to manually change the boot sequence to boot from the backup BIOS.
- 2. During or after a BIOS upgrade, if DualBIOS™ detects that the main BIOS is corrupt, the backup BIOS will take over the boot-up process automatically. Moreover, it will verify the main and backup BIOS checksums when booting-up. DualBIOS™ technology examines the checksum of the main and backup BIOS while the system is powered on to guarantee your BIOS operates properly.
- 3. Power Users will have the advantage of having two BIOS versions on their mainboard. The benefit is being able to select either version BIOS to suit the performance system needs.
- 4. Flexibility for high-end desktop PCs and workstation/servers. In the DualBIOS™ utility, the option can be set, "Halt On When BIOS Defects" to be enabled to halt your system with awarning message that the main BIOS has been corrupted. Most workstation/servers require constant operation to guarantee services have not been interrupted. In this situation, the "Halt On When BIOS Defects" message may be disabled to avoid system pauses during normal booting. Another advantage you gain from Giga-Byte's DualBIOS™ technology is the ability to upgrade from dual 2 Mbit BIOS to dual 4 Mbit BIOS in the future if extra BIOS storage is need.


Method 2 : @BIOS™ Utility

If you don't have DOS boot disk, we recommend that you used Gigabyte @BIOS™ program to flash BIOS.





3.Click "✓". Click here



Methods and steps:

- I. Update BIOS through Internet
 - a. Click "Internet Update" icon
 - b. Click "Update New BIOS" icon
- c. Select @BIOS™ sever
- d. Select the exact model name on your motherboard
- e. System will automatically download and update the BIOS.

II. Update BIOS NOT through Internet:

- a. Do not click "Internet Update" icon
- b. Click "Update New BIOS"
- c. Please select "All Files" in dialog box while opening the old file.
- d. Please search for BIOS unzip file, downloading from internet or any other methods (such as: 8PENXP.F1).
- e. Complete update process following the instruction.

III. Save BIOS

In the very beginning, there is "Save Current BIOS" icon shown in dialog box. It means to save the current BIOS version.

IV. Check out supported motherboard and Flash ROM:

In the very beginning, there is "About this program" icon shown in dialog box. It can help you check out which kind of motherboard and which brand of Flash ROM are supported.

Note:

- a. In method I, if it shows two or more motherboard's model names to be selected, please make sure your motherboard's model name again. Selecting wrong model name will cause the system unbooted.
- b. In method II, be sure that motherboard's model name in BIOS unzip file are the same as your motherboard's. Otherwise, your system won't boot.
- c. In method I, if the BIOS file you need cannot be found in @BIOS™ server, please go onto Gigabyte's web site for downloading and updating it according to method II.
- d. Please note that any interruption during updating will cause system unbooted.

2-/4-/6-Channel Audio Function Introuction

The installation of windows 98SE/2K/ME/XP is very simple. Please follow next step to install the function!

Stereo Speakers Connection and Settings:

We recommend that you use the speaker with amplifier to acquire the best sound of fact if the steeso output is applied.

SIEP 1:

Correct the stereo speakers or earphone to "Line Out".



SIEP 2:

After installation of the audio driver, you'll find an

icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





SIEP 3:

Select "Speaker Configuration", and choose the "2 channel for stereo speakers out put".

 2-channel mode for stereo speaker output



4 Channel Analog Audio Output Mode

SIEP 1:

Correct the front dramels to "Line Out", the near dramels to "Line In".



SIEP 2:

After installation of the adio driver, you'll find an

icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





SIEP 3:


Select "Speaker Configuration", and choose the "4 channel for 4 speakers out put".

Disable "Only SURROUND-KIT", and press "OK".

4-channel mode for 4 speaker output

When the "Environment settings" is "None", the sound would be performed as stereo mode (2 channels output). Please select the other settings for 4 channels output.






Basic 6 Channel Analog Audio Output Mode

Use the back audio panel to correct the audio output without any additional module.

SIEP 1:

Cornect the front channels to "Time Out", the rear channels to "Time In", and the Center/Subwoofer channels to "MIC In".



SIEP 2:

After installation of the adio driver, you'll find an

icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.






SIEP 3:

Select "Speaker Configuration", and droose the "6 channel for 5.1 speakers out put".

Disable "Only SURROUND-KIT" and pess "OK".





Advanced 6 Channel Analog Audio Output Mode (using Audio Combo Kit, Optional Device):

(Audio Combo Kit provides SPDIF output part : optical & coaxis and SURROUND-KIT : Rear R/L & CEN / Subwoofer)

SURROUND-KIT access analog output to rear

dramels and Center/Subvorfer dramels. It is the best solution if you need 6 dramel output, Line In and MIC at the same time. "SURFOUND-KIT" is included in the GICABYTE unique "Audio Conbo Kit" as picture.



SIEP1:

Insert the "SURCOND-KIT" in the back of the case , and fix it with the screw.



SIEP 2:

Connect the "SURROUND-KIT" to SUR_CEN on the M/R



SIEP 3:

Correct the front channels to back audio panel's


"Line Out", the rear channels to SURROUND-KIT'S REAR R/L, and the Center/Subwoofer channels to SURROUND-KIT'S SUB CENTER.



SIEP 4:

Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





SIEP 5:

Select "Speaker Configuration", and choose the "6 dramels for 5.1 speakers out put".

Enable "Only SURROUND-KIT" and press "OK".





Basic & Advanced 6 Channel Analog Audio Output ModeNotes:

When the "Environment settings" is "None", the sound would be performed as stereo mode(2 channels output). Please select the other settings for 6 channels output.



SPDIF Output Device (Optional Device)

A "SPDIF output" device is available on the motherboard. Cable with rear bracket is provided and could link to the "SPDIF output" connector (As picture.) For the further linkage to decoder, rear bracket provides coaxial cable and Fiber connecting port.



1 Carrect the SPDIF output device to the rear backet of PC, and fix it with screw.



2. Correct. SPDIF device to the notherboard.



3. Connect SPDIF to the SPDIF decoder.



Jack-Sensing Introuction



Jack-Sensing provides audio connectors error-detection function.




Install Microsoft DirectX8.1 before to enable Jack-Sensing support for Windows 98/985E/2000

Jack-Sensing includes 2 parts: AUTO and MANUAL. Following is an example for 2 channels (Windows XP):

Introduction of audio connectors

You may connect CDROM, Walkman or others action input devices to Line In jack, speakers, earphone or others output devices to Line Out jack, and microphone to MIC In jack.



Auto-detecting:

Please correct the devices to the right jacks as above.

A window will appear as right picture if you setup the devices properly.

Please note that 3D audio function will only appear when 3D audio inputs.



If you set wrang with the carrectors, the warning message will one out as right picture.



Manual setting:

If the device picture shows diff fevert from what you set, please press "Manual Selection" to set.

	_
	_
	_
	_

Chapter 5 Appendix

Install Drivers



Pictures below are shown in Windows XP


Insert the driver CD-title that came with your motherboard into your CD-ROM drive, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

INSTALL CHIPSET DRIVER

This page shows the drivers that need to be installed for the system. Click each item to install the driver manually or switch to the to install the drivers automatically.




The "Xpress Install" uses the "Click and Forget" technology to install the drivers automatically. Just select the drivers you want then click the "GO" button. The will finish the installation for you automatically.



- 91 - Appendix





Item Description

- Intel Chipset Software Installation Utility
 Tell the operating system how the chipset components will be configured.
- USB Patch for WinXP
- This patch driver can help you to resolve the USB device wake up S3 hang up issue in XP. Intel 82562/82562EX/82540EM/82547EI LAN Driver
- For Intel(R) PRO/10/100/1000/Wireless Ethernet connections
 RealTek ALC101A/201A/202/650/655 AC97 Codec Driver
 For Intel(R) ICH/ICH2/ICH4/ICH5/ICH5R AC97 audio
- Intel Application Accelerator RAID
 Designed to provide functionality for the Intel® SATA RAID controller.
- GIGARAID IT8212 RAID Driver For GigaRAID IT8212 RAID IDE controller
- Intel USB 2.0 Driver
 It is recommended that you use the Microsoft Windows update for the most updated driver for XP/2K



For USB2.0 driver support under Windows XP operating system, please use Windows Service Pack. After install Windows Service Pack, it will show a question mark "?" in "Universal Serial Bus controller" under "Device Manager". Please remove the question mark and restart the system (System will auto-detect the right USB2.0 driver).

2003/4/11, 下午 04:31

GA-8PENXPMotherboard

- 92 -

SOFTWAREAPPLICATION

This page reveals the value-added software developed by Gigabyte and its worldwide partners.



- Gigabyte Windows Utilities Manager (GWUM) This utility can integrate the Gigabyte's applications in the system tray
- Gigabyte Management Tool (GMT) A useful tool which can manage the computer via the network
- EasyTune 4
- Powerful utility that integrates the overclocking and hardware monitoring functions DMI Viewer
- Windows based utility which is used to browse the DMI/SMBIOS information of the system
- Face-Wizard
 - New utility for adding BIOS logo
- @BIOS
 - Gigabyte windows flash BIOS utility
- Acrobate-Book Useful utility from Adobe
- AcrobatReader
 - Popular utility from Adobe for reading .PDF file format documents
- Norton Internet Security (NIS) Integrated utility which includes anti-virus, ads, etc.
- DirectX 9.0
 - Install Microsoft DirectX 9.0 to enable 3D hardware acceleration that support for operating system to achieve better 3D performence.
- Silicon Image SATA Raid utility RAID utility for Silicon Image Serial-ATA 3112
- GigaRAID Utility RAID utility for GigaRAID IT8212



Please do not install "Silicon Image SIL3112 SATARaid Driver Utility" under WIN98 or WIN ME if there is no Serial ATA Deivce.

For top performance and compatibility, it is recommend to use the SATA daughter Card which has Silcon Image Chipset.

> - 93 -Appendix

SOFTWARE INFORMATION

This page list the contects of softwares and drivers in this CD title.



HARDWARE INFORMATION

This page lists all device you have for this motherboard.



CONTACTUS

Please see the last page for details.



GA-8PENXPM otherboard

- 94 -

Face-Wizard Utilities Installation

What is Face-Wizard™?


Face-Wizard™ is a windows based utility with user-friendly interface that allows users to change the boot-up logo with picture from Gigabyte Logo Gallery on web site or other compatible picture you have.

How does it work?

Face-Wizard™ allows user to select BIOS on board or file in hard drive, floppy disk, zip, MO or other storage devices and combine the compatible picture you prefer into BIOS. And not only this, Face-Wizard™ also helps user to update BIOS in windows mode.

What's benefit for using Face-Wizard™?

It can personalize boot-up logo to show your unique style from others, and never again looking at the black and white boot-up screen.



- 95 - Appendix

EasyTune 4 Utilities Installation


Powerful utility that integrates the overclocking and hardware monitoring functions













FAQ

Below is a collection of general asked questions. To check general asked questions based on a specific motherboard model, please log on to http://tw.giga-byte.com/faq/faq.htm

Question 1: I cannot see some options that were included in previous BIOS after updating BIOS. Why?

Answer: Some advanced options are hidden in new BIOS version. Please press Ctrl and F1 keys after entering BIOS menu and you will be able to see these options.

Questions 2: Why is the light of my keyboard/optical mouse still on after computer shuts down? Answer: In some boards, a small amount of electricity is kept on standby after computer shuts down and that's why the light is still on.

Question 3: Why cannot luse all functions in EasyTune™4?

Answer: The availability of the listed functions in EasyTune™ 4 depends on the MB chipset. If the chipset doesn't support certain functions in EasyTune™ 4, these functions will be locked automatically and you will not be able to use them.

Question 4: Why do I fail to install RAID and ATA drivers under Win 2000 and XP on boards that support RAID function after I connect the boot HDD to IDE3 or IDE4?

Answer: First of all, you need to save some files in the CD-ROM to a floppy disk before installing drivers. You also need to go through some rather different steps in the installation process. Therefore, we suggest that you refer to the installation steps in the RAID manual at our website. (Please download it at http://tw.giga-byte.com/support/user_pdf/raid_manual.pdf)

- 97 - Appendix

Question 5: How do I clear CMOS?

Answer: If your board has a Clear CMOS jumper, please refer to the Clear CMOS steps in the manual. If your board doesn't have such jumper, you can take off the on-board battery to leak voltage to clear CMOS. Please refer to the steps below:

Steps:

- 1. Turn off power.
- 2. Disconnect the power cord from MB.
- 3. Take out the battery gently and put it aside for about 10 minutes (Or you can use a metal object to connect the positive and negative pins in the battery holder to make them short for one minute).
- 4. Re-insert the battery to the battery holder.
- 5. Connect power cord to MB again and turn on power.
- 6. Press Del to enter BIOS and load Fail-Safe Defaults.
- 7. Save changes and reboot the system.

Question 6: Why does system seem unstable after updating BIOS?

Answer: Please remember to load Fail-Safe Defaults (Or Load BIOS Defaults) after flashing BIOS. However, if the system instability still remains, please clear CMOS to solve the problem.

Question 7: Why do I still get a weak sound after turning up the speaker to the maximum volume? **Answer:** Please make sure the speaker you are using is equipped with an internal amplifier. If not, please change another speaker with power/amplifier and try again later.

Question 8: How do I disable onboard VGA card in order to add an external VGA card? **Answer:** Gig abyte motherboards will auto-detect the external VGA card after it is plugged in, so you don't need to change any setting manually to disable the onboard VGA.

Question 9: Why cannot I use the IDE 2?

Answer: Please refer to the user manual and check whether you have connected any cable that is not provided with the motherboard package to the USB Over Current pin in the Front USB Panel. If the cable is your own cable, please remove it from this pin and do not connect any of your own cables to it.

Question 10: Sometimes I hear different continuous beeps from computer after system boots up. What do these beeps usually stand for?

Answer: The beep codes below may help you identify the possible computer problems. However, they are only for reference purposes. The situations might differ from case to case.

→AMI BIOS Beep Codes

*Computer gives 1 short beep when system boots successfully.

*Except for beep code 8, these codes are always fatal.

- 1 beep Refresh failure
- 2 beeps Parity error
- 3 beeps Base 64K memory failure
- 4 beeps Timer not operational
- 5 beeps Processor error
- 6 beeps 8042 gate A20 failure
- 7 beeps Processor exception interrupt error
- 8 beeps Display memory read/write failure
- 9 beeps ROM checksum error
- 10 beeps CMOS shutdown register read/write error
- 11 beeps Cache memory bad

→ AWARD BIOS Beep Codes


- 1 short: System boots successfully
- 2 short CMOS setting error
- 1 long 1 short: DRAM or M/B error
- 1 long 2 short: Monitor or display card error
- 1 long 3 short Keyboard error
- 1 long 9 short BIOS ROM error
- Continuous long beeps: DRAM error
- Continuous short beeps: Power error

- 99 - Appendix

Troubleshooting




If you encounter any trouble during boot up, please follow the troubleshooting procedures.



GA-8PENXPMotherboard

- 100 -



If the above procedure unable to solve your problem, please contact with your local retailer or national distributor for help. Or, you could submit your question to the service mail via Gigabyte website technical support zone (http://www.gigabyte.com.tw). The appropriate response will be provided ASAP.

- 101 - Appendix

8penxp_1001_a.p65 101 2003/4/11, 下午 04:31

Technical Support/RMA Sheet

Contact Person:		'			
Modelname/Lot	Number:				PCB revision:
BIOS version:		0.8.//			
Hardware	Mfs.	Mode	Iname	Size:	Driver/Utility:
Configuration					
CPU					
Memory					
Brand					
VideoCard					
Audio Card					
HDD					
CD-ROM /					
DVD-ROM					
Modem					
Network					
AMR / CNR					
Keyboard					
Mouse					
Powersupply					
Other Device					
Problem Descrip	tion:	•			
_					

<u>Acronyms</u>

Acronyms	Meaning
ACPI	Advanced Configuration and Power Interface
APM	Advanced Power Management
AGP	Accelerated Graphics Port
AMR	Audio Modem Riser
ACR	Advanced Communications Riser
BIOS	Basic Input / Output System
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRM	Dual Retention Mechanism
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCD	Extended System Configuration Data
ECC	Error Checking and Correcting
EMC	Electromagnetic Compatibility
EPP	Enhanced Parallel Port
ESD	Electrostatic Discharge
FDD	Floppy Disk Device
FSB	FrontSide Bus
HDD	Hard Disk Device
IDE	Integrated Dual Channel Enhanced
IRQ	Interrupt Request

to be continued.....

Acronyms	Meaning
IOAPIC	Input Output Advanced Programmable Input Controller
ISA	Industry Standard Architecture
LAN	Local Area Network
I/O	Input/ Output
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Instrument Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System
OEM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static RandomAccess Memory

 - 105 -	Appendix

GA-8PENXPMotherboard	- 1	06 -	

8penxp_1001_a.p65 106 2003/4/11, 下午 04:32

 - 107 -	Appendix

CONTACTUS

Contact us via the information in this page all over the world.

• Taiwan

Gigabyte Technology Co., Ltd.

Address: No.6, Bau Chiang Road, Hsin-Tien, Taipei

Hsien, Taiwan, R.O.C.

TEL: 886 (2) 8912-4888 (50 lines)

FAX: 886 (2) 8912-4004

E-mail:english@gigabyte.com.tw

Web Address: http://www.gigabyte.com.tw

• USA

G.B.T. INC.

Address: 17358 Railroad St, City of Industry, CA

91748.

Tel: 1 (626) 854-9338 Fax: 1 (626) 854-9339 E-mail:sales@giga-byte.com support@giga-byte.com

Web Address: www.giga-byte.com

Germany

G.B.T. Technology Trading GmbH

Tel: 49-40-2533040

Fax: 49-40-25492343 (Sales)
Tel: 49-01803-428468 (Tech.)
Fax: 49-01803-428329 (Tech.)
E-mail:support@gigabyte.de
Web Address: www.gigabyte.de

JAPAN/Nippon Giga-Byte Corporation

WebAddress:www.gigabyte.co.jp

• U.K

G.B.T. TECH. CO. LTD. Tel: 44-1908-362700 Fax: 44-1908-362709

E-mail:support@gbt-tech.co.uk WebAddress: www.gbt-tech.co.uk

• The Netherlands

Giga-Byte Technology B.V.

Address: Postbus 1385, 5602 BJ, Eindhoven, The

Netherlands

Tel: +31 40 290 2088 Fax: +31 40 290 2089 E-mail:info@giga-byte.nl

WebAddress: http://www.giga-byte.nl

• China

Shanghai Office

Tel: 86-21-64737410 Fax: 86-21-64453227

WebAddress: www.gigabyte.com.cn

Guang Zhou Office
Tel: 86-20-87586273
Fax: 86-20-87544306

WebAddress: www.gigabyte.com.cn

Beijing Office

Tel: 86-10-82856054 86-10-82856064 86-10-82856094 Fax: 86-10-82856575

WebAddress: www.gigabyte.com.cn E-mail:bjsupport@gigabyte.com.cn

Chengdu Office

Tel: 86-28-85236930 Fax: 86-28-85256822

WebAddress: www.gigabyte.com.cn

108