

When you installing AGP card, please make sure the following notice is fully understood and practiced. If your AGP card has "AGP 4X/8X (1.5V) notch"(show below), please make sure your AGP card is AGP 4X/8X (1.5V).



Caution: AGP 2X card is not supported by Intel® 845(GE/PE) / 845(E/G) / 850(E) / E7205 / 865(G/PE/P) / 875P. You might experience system unable to boot up normally. Please insert an AGP 4X/8X card.



Example 1: Diamond Vipper V770 golden finger is compatible with 2X/4X mode AGP slot. It can be switched between AGP 2X(3.3V) or 4X/8X(1.5V) mode by adjusting the jumper. The factory default for this card is 2X(3.3V). The GA-8IP900MK (or any AGP 4X/8X only) motherboards might not function properly, if you install this card without switching the jumper to 4X/8X (1.5) mode in it.

Example 2: Some ATi Rage 128 Pro graphics cards made by "Power Color", the graphics card manufacturer & some SiS 305 cards, their golden finger is compatible with 2X(3.3V)/4X(1.5V) mode AGP slot, but they support 2X(3.3V) only. The GA-8IP900MK (or any AGP 4X/8X only) motherboards might not function properly, If you install this card in it.

Note : Although Gigabyte's AG32S(G) graphics card is based on ATi Rage 128 Pro chip, the design of AG32S(G) is compliance with AGP 4X(1.5V) specification. Therefore, AG32S(G) will work fine with Intel® 845(GE/PE) / 845(E/G) / 850(E) / E7205 / 865(G/PE/P) / 875P based motherboards.

8ip900mk_1001_f.p65 93 2003/4/22,下午 03:51



- The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein.
- Third-party brands and names are the property of their respective owners.
- Please do not remove any labels on motherboard, this may void the warranty of this motherboard.
- Due to rapid change in technology, some of the specifications might be out of date before publication of this booklet.



- WARNING: Never run the processor without the heatsink properly and firmly attached. PERMANENT DAMAGE WILL RESULT!
- Mise en garde: Ne faites jamais tourner le processeur sans que le dissipateur de chaleur soit fix correctement et fermement. UN DOMMAGE PERMANENT EN RÉSULTERA!
- Achtung: Der Prozessor darf nur in Betrieb genommen werden, wenn der W rmeableiter ordnungsgem β und fest angebracht ist. DIES HAT EINEN PERMANENTEN SCHADEN ZUR FOLGE!
- Advertencia: Nunca haga funcionar el procesador sin el disipador de calor instalado correcta y firmemente. ¡SE PRODUCIRÁ UN DAÑO PERMANENTE!
- Aviso: Nunca execute o processador sem o dissipador de calor estar adequado e firmemente conectado. O RESULTADO SERÁ UM DANO PERMANENTE!
- 警告: 将散热板牢固地安装到处理器上之前,不要运行处理器。过热将永远损坏处理器!
- 警告: 將散熱器牢固地安裝到處理器上之前,不要運行處理器。過熱將永遠損壞處理器!
- 경고: 히트싱크를 제대로 또 난난히 부착시키지 않은 제 프로세서를 구동시키지 마십시오. 영구적 고장이 발생합니다!
- 警告: 永久的な損傷を防ぐため、ヒートシンクを正しくしっかりと取り付けるまでは、プロセッサを動作させないようにしてください。

8ip900mk_1001_f.p65 94 2003/4/22, 下午 03:51

Declaration of Conformity

We, Manufacturer/Importer (full address)

G.B.T. Technology Träding GMbH Ausschlager Weg 41, 1F, 20537 Hamburg, Germany

declare that the product

(description of the apparatus, system, installation to which it refers)

Mother Board GA-8IP900MK

is in conformity with

(reference to the specification under which conformity is declared)

in accordance with 89/336 EEC-EMC Directive

□ EN 61000-3-2*

Disturbances in supply systems cause

□ EN 55011

Limits and methods of measurement

			Signature: Timmy Huan	ıg
	electrical appliances	nufacturer/Importer	uninterruptible powersystems (UPS)	
□ EN 60335	Safety of household and similar	□ EN 50091-1	General and Safety requirements for	
LI EN 00003	electronic and related apparatus for household and similar general use	□ EN 60950	Safety for information technology equipment including electrical bussiness equipment	
□ EN 60065	The manufacturer also declares t with the actual required safety sta Safety requirements for mains operated	•	VD 73/23 EEC	
□ CE marking	The manufacture designed	(EC conformity r	narking)	
	•	CE _{(EC conformity r}	marking)	
□ part 10 □ part 12	for receiving and/or distribution from sound and television signals		power systems (UPS)	
☐ DIN VDE 0855	information technology equipment Cabled distribution systems; Equipment	□ EN50091-2	EMC requirements for uninterruptible	
⊠ EN 55022	Limits and methods of measurement of radio disturbance characteristics of	□ ENV 55104	Immunity requirements for household appliances tools and similar apparatus	
	equipment		Industrial environment	
□ EN 55020	Immunity from radio interference of broadcast receivers and associated	□ EN 55082-2	Generic emission standard Part 2:	
	of radio disturbance characteristics of fluorescent lamps and luminaries		Industrial environment	
□ EN 55015	Limits and methods of measurement	□ EN 55081-2	Generic emission standard Part 2:	
	household electrical appliances, portable tools and similar electrical apparatus	⊠ EN 50082-1	Generic immunity standard Part 1: Residual commercial and light industry	
□ EN 55014	Limits and methods of measurement of radio disturbance characteristics of	☑ EN 50081-1	Generic emission standard Part 1: Residual commercial and light industry	
□ EN 55013	Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment	☐ EN 60555-3	Disturbances in supply systems cause by household appliances and similar electrical equipment "Voltage fluctuations"	
	industrial, scientific and medical (ISM high frequency equipment		electrical equipment "Harmonics"	
	of radio disturbance characteristics of	☑ EN 60555-2	by household appliances and similar	

Date : April 8, 2003

Name:

Timmy Huang

8ip900mk_1001_f.p65 2003/4/22, 下午 03:52

(Stamp)

DECLARATION OF CONFORMITY

Per FCC Part 2 Section 2.1077(a)



Responsible Party Name: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street City of Industry, CA 91748

Phone/Fax No: (818) 854-9338/ (818) 854-9339

hereby declares that the product

Product Name: Motherboard ModelNumber:GA-8IP900MK

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109(a), Class B Digital Device

Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any inference received, including that may cause undesired operation.

Representative Person's Name: ERIC LU

Signature: Eric Lu

Date: April 8, 2003

8ip900mk_1001_f.p65 96 2003/4/22,下午 03:52

GA-8IP900MK P4 Titan Series Motherboard

USER'S MANUAL

Pentium® 4 Processor Motherboard Rev . 1001 12ME-8IP900MK-1001

Table of Content

Item Checklist Chapter 1 Introduction Features Summary GA-8IP900MK Motherboard Layout Block Diagram Chapter 2 Hardware Installation Process Step 1: Install the Central Processing Unit (CPU) Step 1-1: CPU Installation Step 1-2: CPU Cooling Fan Installation	
Chapter 1 Introduction	5
Features Summary	5
GA-8IP900MK Motherboard Layout	7
Block Diagram	8
Chapter 2 Hardware Installation Process	11
Step 1: Install the Central Processing Unit (CPU)	12
Step 1-1: CPU Installation	12
Step 2: Install Memory Modules	
Step 3: Install expansion cards	
Step 4: Connect ribbon cables, cabinet wires and power supply Step 4-1: I/O Back Panel Introduction	
Step 4-2: Connectors Introduction	
Chapter 3 BIOS Setup	33
The Main Menu (For example: BIOS Ver.: F2)	34
Standard CMOS Features	36
Advanced BIOS Features	39
Integrated Peripherals	41
Power Management Setup	46
PnP/PCI Configurations	
PC Health Status	50
Frequency/Voltage Control	52
Load Fail-Safe Defaults	54

Load Optimized Defaults	55
Set Supervisor/User Password	56
Save & Exit Setup	57
Exit Without Saving	58
Chapter 4 Technical Reference	61
@BIOS™ Introduction	61
EasyTune™ 4 Introduction	62
Flash BIOS Method Introduction	63
Method 1 : Q-Flash	
Method 2: @BIOS Utility	65
2-/4-/6-Channel Audio Function Introuction	67
Jack-Sensing Introuction	73
Chapter 5 Appendix	77

Item Checklist

☑ The GA-8IP900MK motherboard ☑ Serial ATA cable x 2 2 Port USB Cable x 1 CD for motherboard driver & utility ☐ 4 Port USB Cable x 1 ☑ GA-8IP900MK user's manual ☐ SPDIF Kit x 1 (SPDIF Out Kit) ☐ Quick PC Installation Guide ☐ IEEE 1394 Cable x1 ☐ SATA RAID Manual ☐ Audio Combo Kit x 1 ☐ GC-SATA Card (optional) (SURROUND-Kit + SPDIF Out Kit) (Manual; SATA cable x 1; Power cable x 1) ☐ Motherboard Settings Label ☑ I/O Shield ☑ IDE cable x 1 / Floppy cable x 1



Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use agrounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- 5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

Chapter 1 Introduction Features Summary

Form Factor	24.4cm x 24.4cm Micro ATX size form factor, 4 layers PCB
CPU	Socket 478 for Intel® Micro FC-PGA2 Pentium® 4 processor
	Support Intel® Pentium® 4 (Northwood, Prescott) processor
	 Support Intel® Pentium® 4 Processor with HT Technology *
	Intel® Pentium® 4 533/400MHz FSB
	2nd cache depends on CPU
Chipset	Intel® Chipset 865P HOST/AGP/Controller
	Intel® ICH5 I/O C ontroller Hub
Memory	4 184-pin DDR DIMM sockets
	 Supports Dual C hannel DDR333/DDR266 DIMM
	 Supports 128MB/256MB/512MB/1GB unbuffered DRAM
	 Supports up to 4GB DRAM (Max)
	 Supports only DDR DIMM
I/O Control	• ITE8712F
Slots	3 PCI slot supports 33MHz & PCI 2.3 compliant
On-Board IDE	2 IDE controllers provides IDE HDD/CD-ROM (IDE1, IDE2) with
	PIO, Bus Master (Ultra DMA33/ATA66/ATA100) operation modes
	 Can connect up to 4 IDE devices
SerialATA	2 Serial ATA connectors in 150 MB/s operation mode
	Controlled by ICH5
On-Board Peripherals	 1 Floppy port supports 2 FDD with 360K, 720K,1.2M, 1.44M
	and 2.88M bytes
	 1 Parallel port supports Normal/EPP/ECP mode
	2 Serial ports (COMA & COMB)
	 8 USB 2.0/1.1 ports (4 x Rear, 4 x Front by cable)
	1 IrDA connector for IR/CIR
	1 Front Audio connector
Hardware Monitor	CPU/Sy stem fan revolution detect
	CPU temperature detect
	CPU warning temperature
	System voltage detect
	CPU/System fan fail warning
On-Board LAN	Builit in Intel® 82562 Chipset
	Data transfer rate 10/100 supported
	• 1 RJ45 port

to be continued.....

On-Board Sound	 Realtek ALC 655 codec
	 Supports Jack Sensing function
	 Line Out / 2 front speaker
	 Line In / 2 rear speaker (by s/w sw itch)
	 Mic In / center & subwoofer (by s/w switch)
	CD In / AUX In / Game port
PS/2 Connector	PS/2 Keyboard interface and PS/2 Mouse interace
BIOS	Licensed Phoenix BIOS, 2M bit FWH
Additional Features	PS/2 Keyboard pow er on by password
	 PS/2 Mouse pow er on
	 STR (Suspend-To-RAM)
	AC Recovery
	 Poly fuse for key board over-current protection
	 USB KB/Mouse w ake up from S3
	Supports @BIOS
	Supports EasyTune 4
	Supports clear password function



"*" HT functionality requirement content :

Enabling the functionality of Hyper-Threading Technology for your computer system requires all of the following platform components:


- CPU: An Intel® Pentium 4 Processor with HT Technology
- Chipset: An Intel® Chipset that supports HT Technology
- BIOS: A BIOS that supports HT Technology and has it enabled
- OS: An operation system that has optimizations for HT Technology




Please set the CPU host frequency in accordance with your processor's specifications.

We don't recommend you to set the system bus frequency over the CPU's specification because these specific bus frequencies are not the standard specifications for CPU, chipset and most of the peripherals. Whether your system can run under these specific bus frequencies properly will depend on your hardware configurations, including CPU, Chipsets, SDRAM, Cards...etc.

GA-8IP900MK Motherboard Layout



Block Diagram




- 9 -

Introduction

Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following steps:

- Step 1- Install the Central Processing Unit (CPU)
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect ribbon cables, cabinet wires, and power supply



Congratulations! You have accomplished the hardware installation!

Turn on the power supply or connect the power cable to the power outlet. Continue with the BIOS/software installation.


Step 1: Install the Central Processing Unit (CPU)




Before in stalling the processor, adhere to the following warning:

- 1. Please make sure the CPU type is supported by the motherboard.
- 2. If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.

Step 1-1: CPU Installation



 Angling the rod to 65-degree may be feel akind of tight, and then continue pull the rod to 90-degree when a noise "cough" made.



2. Pull the rod to the 90-degree directly.



3. CPU Top View



 Locate Pin 1 in the socket and look fora (golden) cut edge on the CPU upper corner. Then insert the CPU into the socket.

Step 1-2: CPU Cooling Fan Installation




Before installing the CPU cooling fan, adhere to the following warning:

- 1. Please use Intel approved cooling fan.
- 2. We recommend you to apply the thermal tape to provide better heat conduction between your CPU and cooling fan.
 - (The CPU cooling fan might stick to the CPU due to the hardening of the thermal paste. During this condition if you try to remove the cooling fan, you might pull the processor out of the CPU socket alone with the cooling fan, and might damage the processor. To avoid this from happening, we suggest you to either use thermal tape instead of thermal paste, or remove the cooling fan with extreme caution.)
- 3. Make sure the CPU fan power cable is plugged in to the CPU fan connector, this completes the installation.
 - Please refer to CPU cooling fan user's manual for more detail installation procedure.



 Fasten the cooling fan supportingbase onto the CPU socket on the motherboard.



Make sure the CPU fan is plugged to the CPU fan connector, than install complete.


Step 2: Install Memory Modules



Before in stalling the memory modules, adhere to the following warning:

- 1. When DIMM LED is ON, do not install / remove DIMM from socket.
- 2. Please note that the DIMM module can only fit in one direction due to the one notch. Wrong orientation will cause improper installation. Please change the insert orientation.

The motherboard has 4 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.





 The DIMM socket has a notch, so the DIMM memory module can only fit in one direction.



Insert the DIM M memory module vertically into the DIMM socket. Then push it down.



- Close the plastic clip at both edges of the DIMM sockets to lock the DIMM module.
 - Reverse the installation steps when you wish to remove the DIMM module.

DDR Introduction

Established on the existing SDRAM industry infrastructure, DDR (Double Data Rate) memory is a high performance and cost-effective solution that allows easy adoption for memory vendors, OEMs and system integrators.

DDR memory is a sensible ev olutionary solution for the PC industry that builds on the existing SDRAM infrastructure, yet makes awesome advances in solving the system performance bottleneck by doubling the memory bandwidth. DDR SDR AM will offer a superior solution and migration path from existing SDRAM designs due to its availability, pricing and overall market support. PC2100 DDR memory (DDR266) doubles the data rate through reading and writing at both the rising and falling edge of the clock, achieving data bandwidth 2X greater than PC 133 when running with the same DRAM clock frequency. With peak bandwidth of 2.664 GB per second, DDR memory enables system OEMs to build high performance and low latency DRAM subsystems that are suitable for servers, workstations, high-end PC's and value desktop SMA systems.

Dual Channel DDR:

GA-8IP900MK supports Dual Channel Technology.

When Dual Channel Technology is activated, the bandwidth of memory bus will be double the original one with the fastest speed at 5.3GB/s DDR333.

GA-8IP900MK includes four DIMM slots, and each Channel has 2 DIMMs as following:

Channel A : DIMM 1, 2Channel B : DIMM 3, 4

Below are the explanations:



If you want to operate the Dual Channel Technology, please note the following explanations due to the limitation of Intel chipset specifications.

- Only one DDR memory module is installed: The Dual Channel Technology can't
 operate when only one DDR memory module is installed. Additionally, you can boot the
 system only when the memory module is inserted into Channel A. On the other hand,
 the memory module must be inserted into DIMM1 or DIMM3 sockets.
- 2. Two DDR memory modules are installed (the same memory size and type): The Dual Channel Technology will operate when two memory modules are inserted individually into Channel A and B. If you install two memory modules in the same channel, the Dual Channel Technology will not operate. Additionally, you can boot the system only when one of the memory modules is inserted into Channel A. On the other hand, the memory module must be inserted into DIMM1 or DIMM3 sockets.
- 3. Three DDR memory modules are installed: Please note that the Dual Channel Technology will "not" operate when three DDR memory modules are installed. If you install three memory modules, the system will only detect those memory modules inserted in Channel A, and those in Channel B will not be detected!

4. Four DDR memory modules are installed: If you install four memory modules at the same time, the Dual Channel Technology will operate only when those modules have the same memory size and type.

The following tables include all memory-installed combination types: (Please note that those types not in the tables will not boot up.)

• Figure 1: Dual Channel Technology (DS: Double Side, SS: Single Side)


	DIMM1	DIMM2	DIMM3	DIMM 4
2 memory modules	DS/SS	Χ	DS/SS	Χ
	X	DS/SS	Х	DS/SS
4 memory modules	DS/SS	DS/SS	DS/SS	DS/SS

• Figure 2: Don't operate Dual Channel Technology (DS: Double Side, SS: Single Side)

	DIMM1	DIMM2	DIMM3	DIMM4
1 me mory mo dule	DS/SS	Χ	Χ	Х
	X	Х	DS/SS	Х
2 me mory mod ules	DS/SS	DS/SS	Х	X

Step 3: Install expansion cards

- Read the related expansion card's instruction document before install the expansion card into the computer.
- 2. Remove your computer's chassis cover, screws and slot bracket from the computer.
- 3. Press the expansion card firmly into expansion slot in motherboard.
- 4. Be sure the metal contacts on the card are indeed seated in the slot.
- 5. Replace the screw to secure the slot bracket of the expansion card.
- 6. Replace your computer's chassis cover.
- 7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
- 8. Install related driver from the operating system.








Please carefully pull out the small white-drawable bar at the end of the AGP slot when you try to install! Uninstall the AGP card. Please align the AGP card to the onboard AGP slot and press firmly down on the slot .Make sure your AGP card is locked by the small white-drawable bar.



When an AGP 2X (3.3V) card is installed the 2X_DET will light up, indicating a non-supported graphics card is inserted. Informing users that system might not boot up normally due to AGP 2X (3.3V) is not supported by the chipset.

Step 4: Connect ribbon cables, cabinet wires and power supply

Step 4-1: I/O Back Panel Introduction



PS/2 Keyboard and PS/2 Mouse Connector




PS/2 Mouse Connector (6 pin Female)

PS/2 Key board Connector (6 pin Female)


➤ This connector supports standard PS/2 keyboard and PS/2 mouse.

2/4 USB/LAN Connector




➢ Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB key board, mouse, scanner, zip, speaker...etc. Have a standard USB interface. Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS v endor for possible patch or driver upgrade. For more information please contact your OS or device(s) v endors.

• Parallel Port and Serial Ports (COMA/COMB)



This connector supports 2 standard COM ports and 1 Parallel port. Device like printer can be connected to Parallel port; mouse and modem etc can be connected to Serial ports.

Audio Connectors



After install onboard audio driver, you may connect speaker to Line Out jack, microphone to MIC In jack. Device like CD-ROM, walkman etc. can be connected to Line-In jack.

Please note:

You are able to use 2-/4-/6-channel audio feature by $\,\mbox{S/W}$ selection.

If you want to enable 6-channel function, you have 2 choose for hardware connection.

Meth od 1:

Connect "Front Speaker" to "Line Out"
Connect "Rear Speaker" to "Line In"
Connect "Center and Subwoofer" to "MIC Out".


Meth od 2:

You can refer to page 28, and contact your nearest dealer for optional SUR_CEN cable.



If you want the detail information for 2-/4-/6-channel audio setup installation, please refer to page 67.


Step 4-2: Connectors Introduction



1)	ATX_12V	12)	2X_DET
2)	ATX	13)	F_AUDIO
3)	CPU_FAN	14)	CD_IN
4)	SYS_FAN	15)	AUX_IN
5)	FDD	16)	SUR_CEN
6)	IDE1 / IDE2	17)	F_USB1 / F_USB2
7)	SATA0 / SATA1	18)	IR_CIR
8)	BAT	19)	GAME
9)	F_PANEL	20)	INFO_LINK
10)	PWR_LED	21)	CI
11)	DIMM_LED	22)	CLR_PWD

1) ATX_12V (+12V Power Connector)

This connector (ATX_12V) supplies the CPU operation v oltage (Vcore). If this "ATX_12V connector" is not connected, system cannot boot.







Pin No.	Definition
1	GND
2	GND
3	+12V
4	+12V

2) ATX (ATX Power)

AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.






Pin No.	Definition
1	3.3V
2	3.3V
3	GND
4	VCC
5	GND
6	VCC
7	GND
8	Power Good
9	5V SB (stand by +5V)
10	+12V
11	3.3V
12	-12V
13	GND
14	PS_ON(soft on/off)
15	GND
16	GND
17	GND
18	-5V
19	VCC
20	VCC

3) CPU_FAN (CPU Fan Connector)

Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600 mA.






Pin No.	Definition
1	GND
2	+12V
3	Sense

4) SYS_FAN (System Fan Connector)

This connector allows you to link with the cooling fan on the system case to lower the system temperature.







Pin No.	Definition
1	GND
2	+12V
3	Sense

5) FDD (Floppy Connector)

Please connect the floppy drive ribbon cables to FDD. It supports 360K, 1.2M, 720K, 1.44M and 2.88M bytes floppy disk types.

The red stripe of the ribbon cable must be the same side with the Pin1.







6) IDE1 / IDE2 (IDE1 / IDE2 Connector)

Important Notice:

Please connect first hard disk to IDE1 and connect CD-ROM to IDE2.


The red stripe of the ribbon cable must be the same side with the Pin1.





7) SATA0 / SATA1 (Serial ATA Connector)


You can connect the Serial ATA device to this connector, it provides you high speed transfer rates (150MB/sec).






Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND

8) BAT (BATTERY)





CAUTION


- Danger of explosion if battery is incorrectly replaced.
- Replace only w ith the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.


If you want to erase CMOS...

- 1. Turn OFF the computer and unplug the power cord.
- 2. Remove the battery, wait for 30 second.
- 3. Re-install the battery.
- 4. Plug the pow er cord and turn ON the computer.

9) F_PANEL (2 x 10 pins Connector)

Please connect the power LED, PC speaker, reset switch and power switch etc of your chassisfront panel to the F_PANEL connector according to the pin assignment above.






HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+)
(Blue)	Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+)
(Amber)	Pin 2- Pin 3: NC
	Pin 4: Data(-)
RES (Reset Sw itch)	Open: Normal Operation
(Green)	Close: Reset H ardware System
PW (Soft Power Connector)	Open: Normal Operation
(Red)	Close: Power On/Off
MSG(Message LED/ Power/ Sleep LED)	Pin 1: LED anode(+)
(Yellow)	Pin 2: LED cathode(-)
NC (Purple)	NC

10) PWR_LED


PWR_LED is connect with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode. If you use dual color LED, power LED will turn to another color.



Pin No.	Definition
1	MPD+
2	MPD-
3	MPD-

11) DIMM_LED


Do not remove memory modules while DIMM_LED is on. It might cause short or other unexpected damages due to the stand by voltage. Remove memory modules only when AC power cord is disconnected.





12) 2X_DET


When an AGP 2X (3.3V) card is installed the 2X_DET will light up, indicating a non-supported graphics card is inserted. Informing users that system might not boot up normally due to AGP 2X (3.3V) is not supported by the chipset.





13) F_AUDIO (Front Audio Connector)

If you want to use Front Audio connector, you must remove 5-6, 9-10 Jumper. In order to utilize the front audio header, your chassis must have front audio connector. Also please make sure the pin assigment on the cable is the same as the pin assigment on the MB header. To find out if the chassis you are buying support front audio connector, please contact your dealer. Please note, you can have the alternative of using front audio connector or of using rear audio connector to play sound.






Pin No.	Definition
1	MIC
2	GND
3	REF
4	Power
5	Front Audio (R)
6	Rear Audio (R)
7	Reserved
8	No Pin
9	Front Audio (L)
10	Rear Audio (L)

14) CD_IN (CD In Connector)

Connect CD-ROM or DVD-ROM audio out to the connector.






Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

15) AUX_IN (AUX In Connector)

Connect other device (such as PCTTV Tunner audio out) to the connector.






Pin No.	Definition
1	AUX-L
2	GND
3	GND
4	AUX-R

16) SUR_CEN (Surround Center Connector)

Please contact your nearest dealer for optional SUR_CEN cable.







Pin No.	Definition
1	SUR OUTL
2	SUR OUTR
3	GND
4	No Pin
5	CENTE R_OUT
6	BASS_OUT

17) F_USB1 / F_USB2 (Front USB Connector, Yellow)

Be careful with the polarity of the front USB connector. Check the pin assignment while you connect the front USB cable. Please contact your nearest dealer for optional front USB cable.






	2				10	
F USB2	P.	8	7	6	9	
F_USBZ	0	٠	E	N	Ш	
	1				9	

Pin No.	Definition
1	Power
2	Power
3	USB Dx-
4	USB Dy-
5	USB Dx+
6	USB Dy+
7	GND
8	GND
9	No Pin
10	NC

18) IR_CIR

Make sure the pin 1 on the IR device is aling with pin one the connector. To enable the IR/CIR function on the board, you are required to purchase an option IR/CIR module. For detail information please contact your autherized Gigaby te distributor. To use IR function only, please connect IR module to Pin1 to Pin5.




6				1	0
	٠	0		•	
*	4	•	10	٠	
1				5	

Pin No.	Definition			
1	VCC			
2	NC			
3	IRRX			
4	GND			
5	IRTX			
6	NC			
7	CIRRX			
8	+5VSB			
9	CIRTX			
10	NC			

19) GAME (Game Connector)

This connector supports joy stick, MIDI key board and other relate audio devices.






Pin No.	Definition			
1	VCC			
2	GRX 1_R			
3	GND			
4	GPSA2			
5	VCC			
6	GPX2_R			
7	GPY2_R			
8	MSI_R			
9	GPSA1			
10	GND			
11	GPY1_R			
12	VCC			
13	GPSB1			
14	MSO_R			
15	GPSB2			
16	No Pin			

20) INFO_LINK

This connector allows you to connect some external devices to provide you extra function.






Pin No.	Definition			
1	SMB CLK			
2	VCC			
3	SMBDATA			
4	GPIO			
5	GND			
6	GND			
7	No Pin			
8	NC			
9	+12V			
10	+12V			

21) CI (CAS E OPEN)

This 2-pin connector allows your system to enable or disable the "Case Open" item in BIOS, if the system case begin remove.





(39)

Pin No.	Definition		
1	Signal		
2	GND		

22) CLR_PWD

When Jumper is set to "open" and system is restarted, the password that is set will be cleared. On the contrary when Jumper is set to "close", the current status remains.





Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

ENTERING SETUP

Powering ON the computer and pressing < Del> immediately will allow you to enter Setup. If you require more advanced BIOS settings, please go to "Advanced BIOS" setting menu. To enter Advanced BIOS setting menu, press "Ctrl+F1" key on the BIOS screen.

CONTROL KEYS

< ^>	Move to previous item
<↓>	Move to next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
Enter	Select item
<esc></esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<f1></f1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<f2></f2>	Item Help
<f3></f3>	Reserved
<f4></f4>	Reserved
<f5></f5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<f6></f6>	Load the file-safe default CMOS value from BIOS default table
<f7></f7>	Load the Optimized Defaults
<f8></f8>	Q-Flash function
<f9></f9>	System Information
<f10></f10>	Save all the CMOS changes, only for Main Menu

- 33 - BIOS Setup

GETTING HELP

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

The Main Menu (For example: BIOS Ver. : F2)

Once you enter Award BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. The Main Menu allows you to select from eight setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

➤ Standard CMOS Features Load Fail-Safe Defaults			
► Advanced BIOS Features	Load Optimized Defaults		
► Integrated Peripherals	Set Supervisor Password		
▶ Power Management Setup	Set U ser Pass w ord		
▶ PnP/PC I Configurations	Save & Exit Setup		
▶ PC Health Status	Exit Without Saving		
► Frequency/Voltage Control			
ESC: Quit ↑↓→←: Select Item			
F8: Q-Flash	F10: Save & Exit Setup		
Time, Date, Hard Disk Ty pe			

Figure 1: Main Menu



If you can't find the setting you want, please press "Ctrl+F1" to search the advanced option widden.

Standard CMOS Features

This setup page includes all the items in standard compatible BIOS.

Advanced BIOS Features

This setup page includes all the items of Award special enhanced features.

GA-8IP900MK Motherboard

- 34 -

8ip900mk_1001_b.p65 34 2003/4/22, 下午 03:54

• Integrated Peripherals

This setup page includes all onboard peripherals.

• Power Management Setup

This setup page includes all the items of Green function features.

• PnP/PCI Configurations

This setup page includes all the configurations of PCI & PnP ISA resources.

• PC Health Status

This setup page is the System auto detect Temperature, voltage, fan, speed.

• Frequency/Voltage Control

This setup page is control CPU's clock and frequency ratio.

• Load Fail-Safe Defaults

Fail-Safe Defaults indicates the value of the system parameters which the system would be in safe configuration.

• Load Optimized Defaults

Optimized Defaults indicates the value of the system parameters which the system would be in best performance configuration.

• Set Supervis or pass word

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

• Set User password

Change, set, or disable password. It allows you to limit access to the system.

• Save & Exit Setup

Save CMOS value settings to CMOS and exit setup.

Exit Without Saving

Abandon all CMOS value changes and exit setup.

- 35 - BIOS Setup

Standard CMOS Features

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Standard CMOS Features

Date (mm:dd:yy)	Sat, Mar 22 2003	Item Help
Time (hh:mm:ss)	22:31:24	Menu Level ▶
		Change the day, mont
▶IDE Primary Master	[None]	y ear
▶IDE Primary Slave	[None]	
▶IDE Secondary Master	[None]	<week></week>
▶IDE Secondary Slave	[None]	Sun. to Sat.
Driv e A	[1.44M, 3.5"]	<month></month>
Driv e B	[None]	Jan. to Dec.
Floppy 3 Mode Support	[Disabled]	
		<day></day>
Halt On	[All, But Keyboard]	1 to 31 (or maximum
		allowed in the month)
Base Memory	640K	
Extended Memory	111M	<ye ar=""></ye>
Total Memory	112M	1999 to 2098

F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

Figure 2: Standard CMOS Features

Date

The date format is <week>, <month>, <day>, <year>.

▶ Week The w eek, from Sun to Sat, determined by the BIOS and is display only

▶ Month The month, Jan. Through Dec.

→ Day The day, from 1 to 31 (or the maximum allowed in the month)

▶ Year The year, from 1999 through 2098

GA-8IP900MK Motherboard

- 36 -

□ Time

The times format in <hour> <minute> <second>. The time is calculated base on the 24-hour military-time clock. For ex ample, 1 p.m. is 13:00:00.

DE Primary Master, Slave / IDE Secondary Master, Slave

The category identifies the types of hard disk from drive C to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

▶ CYLS.	Number of cylinders
▶ HEADS	Number of heads
▶ PREC OMP	Write precomp
▶ LANDZONE	Landing zone
⇒ SECTORS	Number of sectors

If a hard disk has not been installed select NONE and press <Enter>.

Drive A / Drive B

The category identifies the types of floppy disk drive A or drive B that has been installed in the computer.

None	No floppy drive installed
→ 360K, 5.25"	5.25 inch PC-type standard drive; 360K byte capacity.
▶ 1.2M, 5.25"	5.25 inch AT-type high-density drive; 1.2M byte capacity
	(3.5 inch when 3 Mode is Enabled).
₱ 720K, 3.5"	3.5 inch double-sided drive; 720K byte capacity
► 1.44M, 3.5"	3.5 inch double-sided drive; 1.44M byte capacity.
→ 2.88M, 3.5"	3.5 inch double-sided drive; 2.88M byte capacity.

- 37 - BIOS Setup

8ip900mk_1001_b.p65 37 2003/4/22, 下午 03:54

Floppy 3 Mode Support (for Japan Area)

Disabled Normal Floppy Drive. (Default v alue)
 Drive A
 Drive A is 3 mode Floppy Drive.
 Drive B is 3 mode Floppy Drive.
 Both Drive A & B are 3 mode Floppy Drives.

□ Halt on

The category determines whether the computer will stop if an error is detected during power up.

NO Errors
The system boot will not stop for any error that may be detected and you

will be prompted.

★ All Errors Whenever the BIOS detects a non-fatal error the system boot will be stopped.

▶ All, But Key board The system boot will not stop for all errors except a key board error.

(Default value)

➡ All, But Disk ette The system boot will not stop for all errors except a disk error.

▶ All, But Disk/Key The system boot will not stop for all errors except key board and disk errors.

™ Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

Base Memory

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is ty pically 512 K for systems with 512K memory installed on the motherboard, or 640 K for systems with 640 K or more memory installed on the motherboard.

Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1MB in the CPU's memory address map.

Advanced BIOS Features

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software
Advanced BIOS Features

First Boot Device	[Floppy]	Item Help
Second Boot Device	[HDD-0]	Menu Level ▶
Third Boot Device	[CDROM]	Select Boot Device
Password Check	[Setup]	Priority
# CPU Hyper-Threading	[Enabled]	
		[Floppy]
		Boot from floppy
		[LS120]
		Boot from LS120
↑↓→←: Mov e Enter:Select +/-/PU/PD:Value	F10:Sav e ESC:Ex	it F1:General Help
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults		

Figure 3: Advanced BIOS Features

First / Second / Third Boot Device

⇒ Floppy	Select your boot device priority by Floppy.
→ LS120	Select your boot device priority by LS120.
→ Hard Disk	Select your boot device priority by Hard Disk.
→ CDROM	Select your boot device priority by CDROM.
₩ ZIP	Select your boot device priority by ZIP.
⇒ USB-FDD	Select your boot device priority by USB-FDD.
⇒ USB-ZIP	Select your boot device priority by USB-ZIP.
⇒ USB-C DROM	Select your boot device priority by USB-CDROM.
→ USB-HDD	Select your boot device priority by USB-HDD.
→ LAN	Select your boot device priority by LAN.
Disabled	Select your boot device priority by Disabled.

- 39 - BIOS Setup

8ip900mk_1001_b.p65 39 2003/4/22, 下午 03:54

[&]quot; # " System will detect automatically and show up when you install the Intel® Pentium® 4 processor with HT Technology.

Password Check

Setup The system will boot but will not access to Setup page if the correct

passw ord is not entered at the prompt. (Default v alue)

➤ System The system will not boot and will not access to Setup page if the correct

passw ord is not entered at the prompt.

© CPU Hyper-Threading

▶ Enabled Enables CPU Hyper Threading Feature. Please note that this feature is only

working for operating system with multi processors mode supported.

(Default value)

Disables CPU Hy per Threading.

[&]quot;#"System will detect automatically and show up when you install the Intel® Pentium® 4 processor with HT Technology.

Integrated Peripherals

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software Integrated Peripherals

	• '	
On-Chip Primary PCI IDE	[Enabled]	Item Help
On-Chip Secondary PCI IDE	[Enabled]	Menu Level ▶
On-Chip SATA	[Auto]	If a hard disk
x SATA Port0 Configure as	SATA Port0	controller card is
SATA Port1 Configure as	SATA Port1	used, set at Disabled
USB Controller	[Enabled]	
USB 2.0 Controller	[Enabled]	[Enabled]
USB Key board Support	[Disabled]	Enabled onboard IDE
USB Mouse Support	[Disabled]	Port
AC97 Audio	[Au to]	
Onboard H/W LAN	[Enabled]	[Disabled]
Onboard Serial Port 1	[3F8/IRQ4]	Disabled onboard IDE
Onboard Serial Port 2	[2F8/IRQ3]	Port
UART Mode Select	[Normal]	
x UR2 Duplex Mode	Half	
Onboard Parallel Port	[378/IRQ7]	
Parallel Port Mode	[SPP]	
x ECP Mode Use DMA	3	
Game Port Address	[201]	
Midi Port Address	[330]	
Midi Port IRQ	[10]	
↑↓→←: Mov e Enter:Select	+/-/PU/PD:Value F10:Sav e ESC:Exi	t F1:General Help

Figure 4: Integrated Peripherals

F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults

- 41 - BIOS Setup

8ip900mk_1001_b.p65 41 2003/4/22, 下午 03:54

On-Chip Primary PCI IDE

▶ Enabled Enable onboard 1st channel IDE port. (Default v alue)

▶ Disabled Disable onboard 1st channel IDE port.

On-Chip Secondary PCI IDE

▶ Enabled Enable onboard 2nd channel IDE port. (Default v alue)

▶ Disabled Disable onboard 2nd channel IDE port.

On-chip SATA

▶ Disabled Disable SATA controller.

→ Auto When there is no device to be plugged in IDE1 or IDE2, SATA controller will

remap to IDE controller. (Default Value)

→ Manual Set SATA Mode manually.

SATA Port0 Configure as

This item will available when "On-chip SATA" set at "Manual".

DE Pri. Master
 Remap SATA Port 0 to IDE Pri. Master.
 IDE Pri. Slave
 Remap SATA Port 0 to IDE Pri. Slave.
 DE Sec. Master
 Remap SATA Port 0 to IDE Sec. Master.
 DE Sec. Slave
 Remap SATA Port 0 to IDE Sec. Slave.

▶ SATA Port0 SATA controller set to SATA port0. As this mode, it support by WinXP or

later OS only. (Default v alue)

SATA Port1 SATA controller set to SATA port1. As this mode, it support by WinXP or

later OS only.

SATA Port1 Configure as

>> The values depend on SATA Port0.

*** USB Controller

▶ Enabled Enable USB Controller. (Default v alue)

▶ Disabled Disable USB Controller.

USB 2.0 Controller

Disable this function if you are not using onboard USB 2.0 feature.

• Enabled Enable USB 2.0 Controller. (Default v alue)

▶ Disabled Disable USB 2.0 Controller.

USB Keyboard Support

▶ Enabled Enable USB Key board Support.

▶ Disabled Disable USB Keyboard Support. (Default v alue)

□ USB Mouse Support

▶ Enabled Enable USB Mouse Support.

→ Disable USB Mouse Support. (Default v alue)

AC97 Audio

→ Auto Auto detect AC'97 audio function. (Default Value)

▶ Disabled Disable AC'97 audio function.

Onboard H/W LAN

▶ Enabled Enable Onboard H/W LAN function. (Default v alue)

▶ Disabled Disable this function.

Onboard Serial Port 1

→ Auto BIOS will automatically setup the port 1 address.

▶ 3F8/IRQ4 Enable onboard Serial port 1 and address is 3F8. (Default value)

⇒ 2F8/IRQ3 Enable onboard Serial port 1 and address is 2F8.
 ⇒ 3E8/IRQ4 Enable onboard Serial port 1 and address is 3E8.
 ⇒ 2E8/IRQ3 Enable onboard Serial port 1 and address is 2E8.

▶ Disabled Disable onboard Serial port 1.

- 43 - BIOS Setup

Onboard Serial Port 2

Auto BIOS will automatically setup the port 2 address.
 → 3F8/IRQ4 Enable onboard Serial port 2 and address is 3F8.

⇒ 2F8/IRQ3 Enable onboard Serial port 2 and address is 2F8. (Default v alue)

⇒ 3E8/IRQ4 Enable onboard Serial port 2 and address is 3E8.
 ⇒ 2E8/IRQ3 Enable onboard Serial port 2 and address is 2E8.

▶ Disabled Disable onboard Serial port 2.

UART Mode Select

This item allows you to determine which Infra Red(IR) function of Onboard I/O chip.

▶ Normal Set onboard I/O chip UART to Normal Mode. (Default Value)

▶ IrDA Set onboard I/O chip UART to IrDA Mode.
 ▶ ASKIR Set onboard I/O chip UART to ASKIR Mode.
 ▶ SCR Set onboard I/O chip UART to SCR Interface.

UR2 Dupl ex Mode

This feature allows you to seclect IR mode.

This function will available when "UART Mode Select" doesn't set at Normal/SCR.

→ Half IR Function Duplex Half. (Default Value)

▶ Full IR Function Duplex Full.

Onboard Parallel port

This feature allows you to select from a given set of parameters if the parallel port uses the onboard I/O controller.

▶ Disabled Disable onboard LPT port.

⇒ 378/IRQ7 Enable onboard LPT port and address is 378/IRQ7. (Default Value)

▶ 278/IRQ5 Enable onboard LPT port and address is 278/IRQ5.
 ▶ 3BC/IRQ7 Enable onboard LPT port and address is 3BC/IRQ7.

□ Parallel Port Mode

This feature allows you to connect with an advanced printer via the port mode it supports.

▶ SPP Using Parallel port as Standard Parallel Port. (Default Value)

▶ EPP Using Parallel port as Enhanced Parallel Port.▶ ECP Using Parallel port as Ex tended Capabilities Port.

▶ ECP+EPP Using Parallel port as ECP & EPP mode.

GA-8IP900MK Motherboard

ECP Mode Use DMA

This feature allows you to select Direct Memory Access (DMA) channel if the ECP mode selected.

This function will available when "Parallel Port Mode" set at ECP or ECP+EPP.

→ 3 Set ECP Mode Use DMA to 3. (Default Value)

→ 1 Set ECP Mode Use DMA to 1.

Game Port Address

▶ 201 Set Game Port Address to 201. (Default Value)

⇒ 209 Set Game Port Address to 209.

▶ Disabled Disable this function.

Midi Port Address

→ 300 Set Midi Port Address to 300.

⇒ 330 Set Midi Port Address to 330.(Default Value)

▶ Disabled Disable this function.

Midi Port IRQ

⇒ 5 Set Midi Port IRQ to 5.

→ 10 Set Midi Port IRQ to 10. (Default Value)

- 45 - BIOS Setup

Power Management Setup

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Power Management Setup

ACPI Suspend Type	[S1(POS)]	Item Help
Power LED in S1 state	[Blinking]	Menu Level ▶
Off by Power button	[Instant-off]	[S1]
PME Event Wake Up	[Enabled]	Set suspend ty pe to
ModemR ingOn/Wake OnLan	[Enabled]	Power On Suspend under
Resume by Alarm	[Disabled]	ACPI OS
x Date (of Month) Alarm	Everyday	
x Time (hh:mm:ss) Alarm	0:0:0	[S3]
Power On by Mouse	[Disabled]	Set suspend ty pe to
Power On by Key board	[Disabled]	Suspend to RAM under
x KB Power ON Password	Enter	ACPI OS
AC Back Function	[Soft-Off]	
↑↓→←: Mov e Enter:Select +/-/PU/PD:\	√alue F10:Sav.e ESC:l	Exit F1:General Help

↑↓→←: Mov e Enter:Select +/-/PU/PD:Value F10:Sav e ESC:Exit F1:General Help F5:Previous Values F6: Fail-Safe Defaults F7:Optimized Defaults

Figure 5: Power Management Setup

ACPI Suspend Type

► S1(POS) Set ACPI suspend type to S1. (Default Value)

⇒ S3(STR) Set ACPI suspend type to S3.

Power LED in S1 state

▶ Blinking In standby mode(S1), pow er LED will blink. (Default Value)

▶ Dual/OFF In standby mode(S1):

a. If use single color LED, power LED will turn off.

b. If use dual color LED, power LED will turn to another color.

GA-8IP900MK Motherboard

- 46 -

8ip900mk_1001_b.p65 46 2003/4/22, 下午 03:55

Off by Power button

▶ Instant-off
Press power button then Power off instantly. (Default v alue)

▶ Delay 4 Sec. Press power button 4 sec. to Power off. Enter suspend if button is pressed

less than 4 sec.

PME Event Wake Up

▶ Disable this function.

▶ Enabled Enable PME Event Wake up. (Default Value)

ModemRingOn/WakeOnLAN

An incoming call via modem can awake the system from any suspend state or an input signal comes from the other client server on the LAN can awake the system from any suspend state.

Disabled Disable Modem Ring on/wake on Lan function.
 ▶ Enabled Enable Modem Ring on/wake on Lan. (Default Value)

Resume by Alarm

You can set "Resume by Alarm" item to enabled and key in Data/time to power on system.

▶ Disabled Disable this function. (Default Value)

▶ Enabled Enable alarm function to POWER ON sy stem.

If RTC Alarm Lead To Power On is Enabled.

Date (of Month) Alarm: Everyday, 1~31

Time (hh: mm: ss) Alarm: (0~23): (0~59): (0~59)

Power On By Mouse

▶ Disabled Disabled this function. (Default v alue)

Mouse Click Double click on PS/2 mouse left button to power on the sy stem.

Power On By Keyboard

This feature allows you to set the method for powering-on the system.

The option "Password" allows you to set up to 5 alphanumeric characters to power-on the system. The option "Keyboard 98" allows you to use the standard keyboard 98 to power on the system.

▶ Password Enter from 1 to 5 characters to set the Key board Pow er On Password.

▶ Disabled Disabled this function. (Default v alue)

▶ Key board 98 If your key board have "POWER Key" button, you can press the key to

power on the system.

- 47 - BIOS Setup

8ip900mk_1001_b.p65 47 2003/4/22,下午 03:55

KB Power ON Password

When "Power On by Keyboard" set at Password, you can set the password here.

▶ Enter Input password (from 1 to 5 characters) and press Enter to set the Key board

Power On password.

AC BACK Function

▶ Soft-Off When AC-power back to the system, the system will be in "Off" state.

(Default Value)

▶ Full-On
 When AC-power back to the system, the system always in "On" state.
 ▶ Memory
 When AC-power back to the system, the system will return to the Last state

before AC-power off.

PnP/PCI Configurations

CMOS Setup Utility-Copy right (C) 1984-2003 Award Software

PnP/PCI Configurations

PCI 1 IRQ Assignment	[Auto]	Item Help	
PCI 2 IRQ Assignment	[Auto]	Menu Level ▶	
PCI 3 IRQ Assignment	[Auto]		
↑↓→←: Mov e Enter:Select +/-/PU/PD:Valu	e F10:Sav e ESC:Ex	it F1:General Help	
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults			

Figure 6: PnP/PCI Configurations

PCI1 IRQ Assignment

Auto Auto assign IRQ to PCI 1/PCI 5. (Default value)
 → 3,4,5,7,9,10,11,12,14,15
 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 1/PCI 5.

PCI 2 IRQ Assignment

★ Auto Auto assign IRQ to PCI2. (Default value)
 ★ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI2.

PCI3 IRQ Assignment

▶ Auto Auto assign IRQ to PCI3. (Default value)
 ▶ 3,4,5,7,9,10,11,12,14,15 Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI3.

- 49 - BIOS Setup

PC Health Status

CMOS Setup Utility-Copyright (C) 1984-2002 Award Software PC Health Status

Reset Case Open Status	[Disabled]	Item Help	
Case Opened	Yes	Menu Level ▶	
Vcore	OK	[Disabled]	
DDR 25V	OK	Don't reset case	
+3.3V	OK	open status	
+5V	OK		
+12V	OK	[Enabled]	
Current CPU Temperature	33°C	Clear case open	
Current CPU FAN Speed	4687 RPM	status at next boot	
Current SYSTEM FAN Speed	0 RPM		
CPU Warning Temperature	[Disabled]		
CPU FAN Fail Warning	[Disabled]		
SYSTEM FAN Fail Warning	[Disabled]		
↑↓→←: Mov e Enter:Select +/-/PU/PD:Value	F10:Sav e ESC:Ex	t F1:General Help	
F5:Previous Values F6:Fail-Safe Defaults F7:Optimized Defaults			

Figure 7: PC Health Status

Reset Case Open Status

Case Opened

If the case is closed, "Case Opened" will show "No".

If the case have been opened, "Case Opened" will show "Yes".

If you want to reset "Case Opened" value, set "Reset Case Open Status" to "Enabled" and save CMOS, your computer will restart.

• Current Voltage (V) Vcore / DDR25V / +3.3V / +5V / +12V

▶ Detect system's voltage status automatically.

GA-8IP900MK Motherboard

- 50 -

· Current CPU Temperature

▶ Detect CPU Temp. automatically.

Current CPU/SYSTEM FAN Speed (RPM)

▶ Detect CPU/SYSTEM Fan speed status automatically.

CPU Warning Temperature

★ 60°C / 140°F
 Monitor CPU Temp. at 60°C / 140°F.
 ★ 70°C / 158°F
 Monitor CPU Temp. at 70°C / 158°F.
 ★ 80°C / 176°F
 Monitor CPU Temp. at 80°C / 176°F.
 ★ 90°C / 194°F
 Monitor CPU Temp. at 90°C / 194°F.
 ★ Disabled
 Disable this function.(Default v alue)

CPU FAN Fail Warning

▶ Disabled Fan Warning Function Disable. (Default value)

▶ Enabled Fan Warning Function Enable.

SYSTEM FAN Fail Warning

▶ Disabled Fan Warning Function Disable. (Default value)

▶ Enabled Fan Warning Function Enable.

- 51 - BIOS Setup

Frequency/Voltage Control

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software

Frequency/Voltage Control

CPU Clock Ratio	[15X]	Item Help	
CPU Host Clock Control	[Disabled]	Menu Level ▶	
* CPU Host Frequency (Mhz)	133		
* AGP/PCI/SRC Fixed	66/33/100		
Memory Frequency For	[Auto]		
Memory Frequency (Mhz)	266		
AGP/PCI/SRC Frequency (Mhz)	66/33/100		
↑↓→←: Mov e Enter:Select +/-/PU/PD:Value	↑↓→←: Mov e Enter:Select +/-/PU/PD:Value F10:Sav e ESC:Exit F1:General Help		
F5:Previous Values F6: Fail-Safe Defaults F7:Optimized Defaults			

Figure 8: Frequency/Voltage Control

* Those items will be available when "CPU Host Clock Control" is set to Enabled.

CPU Clock Ratio

This option will not be shown or not be available if you are using a CPU with the locked ratio.

▶ 15X~21X It depends on CPU Clock Ratio.

This setup option will automatically assign by CPU detection.

For C-Stepping P4: 8X, 10X~24X default: 15X For Northwood CPU: 12X~24X default: 16X

The option will display "Locked" and read only if the CPU ratio is not changeable.

CPU Host Clock Control

Note: If system hangs up before enter CMOS setup utility, wait for 20 sec for times out reboot. When time out occur, system will reset and run at CPU default Host clock at next boot.

➡ Disable CPU Host Clock Control. (Default v alue)

▶ Enabled Enable CPU Host Clock Control.

GA-8IP900MK Motherboard

- 52 -

• CPU Host Frequency (Mhz)

- ▶ 100MHz ~ 355MHz Set CPU Host Clock from 100MHz to 355MHz.
- ▲ Incorrect using it may cause your system broken. For power End-User use only!

AGP/PCI/SRC Fixed

Serial ATA device is very sensitive to SRC clock. SRC over clock may make Serial ATA device function can't work properly.

Adjust AGP/PCI/SRC clock asychrohous with CPU.

Memory Frequency For

for FSB(Front Side Bus) frequency =400MHz,

▶ 2.0 Memory Frequency = Host clock X 2.0.
 ▶ 2.66 Memory Frequency = Host clock X 2.66.

→ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

for FSB(Front Side Bus) frequency =533MHz,

▶ 2.0 Memory Frequency = Host clock X 2.0.▶ 2.5 Memory Frequency = Host clock X 2.5.

→ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

for FSB(Front Side Bus) frequency =800MHz,

Memory Frequency = Host clock X 2.0.
 1.6 Memory Frequency = Host clock X 1.5.
 1.33 Memory Frequency = Host clock X 1.33.

→ Auto Set Memory frequency by DRAM SPD data. (Default v alue)

Memory Frequency (Mhz)

The v alues depend on CPU Host Frequency (Mhz).

• AGP/PCI/SRC Frequency (Mhz)

The values depend on Fixed AGP/PCI/SRC Frequency.

- 53 - BIOS Setup

Load Fail-Safe Defaults

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 11: Load Fail-Safe Defaults

Load Fail-Safe Defaults

Fail-Safe defaults contain the most appropriate values of the system parameters that allow minimum system performance.

Load Optimized Defaults

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 12: Load Optimized Defaults

Load Optimized Defaults

Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

- 55 - BIOS Setup

Set Supervisor/User Password

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 13: Password Setting

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password, up to eight characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

The BIOS Setup program allows you to specify two separate passwords:

SUPERVISOR PASSWORD and a USER PASSWORD. When disabled, any one may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration felds, the User password is required to access only basic items.

If you select "System" at "Password Check" in Advance BIOS Features Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.

If you select "Setup" at "Password Check" in Advance BIOS Features Menu, you will be prompted only when you try to enter Setup.

GA-8IP900MK Motherboard

- 56 -

Save & Exit Setup

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 14: Save & Exit Setup

Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.

Type "N" will return to Setup Utility.

- 57 - BIOS Setup

Exit Without Saving

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software




Figure 15: Exit Without Saving

Type "Y" will quit the Setup Utility without saving to RTC CMOS. Type "N" will return to Setup Utility.

8ip900mk_1001_b.p65 59 2003/4/22, 下午 03:55

- 59 -

BIOS Setup

GA-8IP900MK Motherboard	- 60 -	

8ip900mk_1001_b.p65 60 2003/4/22, 下午 03:55

Chapter 4 Technical Reference

@BIOS™ Introduction

Gigabyte announces @BIOS™ Windows BIOS live update utility



Have you ever updated BIOS by yourself? Or like many other people, you just know what BIOS is, but always hesitate to update it? Because you think updating newest BIOS is unnecessary and actually you don't know how to update it.

Maybe not like others, you are very experienced in BIOS updating and spend quite a lot of time to do it. But of course you don't like to do it too much. First, download different BIOS from website and then switch the operating system to DOS mode. Secondly, use different flash utility to update BIOS. The above process is not a interesting job. Besides, always be carefully to store the BIOS source code correctly in your disks as if you update the wrong BIOS, it will be a nightmare.

Certainly, you wonder why motherboard vendors could not just do something right to save your time and effort and save you from the lousy BIOS updating work? Here it comes! Now Gigabyte announces @BIOS—the first Windows BIOS live update utility. This is a smart BIOS update software. It could help you to download the BIOS from internetand update it. Not like the other BIOS update software, it's a Windows utility. With the help of "@BIOS", BIOS updating is no more than a click.

Besides, no matter which mainboard you are using, if it's a Gigabyte's product*, @BIOS help you to maintain the BIOS. This utility could detect your correctmainboard model and help you to choose the BIOS accordingly. It then downloads the BIOS from the nearest Gigabyte ftp site automatically. There are several different choices; you could use "Internet Update" to download and update your BIOS directly. Or you may want to keep a backup for your current BIOS, just choose "Save Current BIOS" to save it first. You make a wise choice to use Gigabyte, and @BIOS update your BIOS smartly. You are now worry free from updating wrong BIOS, and capable to maintain and manage your BIOS easily. Again, Gigabyte's innovative producterects a milestone in mainboard industries.

For such a wonderful software, how much it costs? Impossible! It's free! Now, if you buy a Gigabyte's motherboard, you could find this amazing software in the attached driver CD. But please remember, connected to internet at first, then you could have a internet BIOS update from your Gigabyte @BIOS.

- 61 -

Technical Reference

EasyTune™ 4 Introduction

Gigabyte announces *EasyTune*[™] 4 Windows based Overclocking utility

EasyTune 4 carries on the heritage so as to pave the way for future generations.



Overclock might be one of the most common issues in computer field. But have many users ever tried it? The answer is probably "no". Because "Overclock" is thought to be very difficult and includes a lot of technical know-how, sometimes "Overclock" is even considered as special skills found only in some enthusiasts. But as to the experts in "Overclock", what's the truth? They may spend quite a lot of time and money to study, try and use many different

hardware or BIOS tools to do "Overclock". And even with these technologies, they still learn that it's quite a risk because the safety and stability of an "Overclock" system is unknown. Now everything is different because of a Windows based overclocking utility "EasyTune 4" – announced by Gigabyte. This windows based utility has totally changed the gaming rule of "Overclock". This is the first windows based overclocking utility is suitable for both normal and power users. Users can choose either "Easy Mode" or "Advanced Mode" for overclocking at their convenience. For users who choose "Easy Mode", they just need to click "Auto Optimize" to have autoed and immediate CPU overclocking. This software will then overdrive CPU speed automatically with the result being shown in the control panel. If users prefer "Overclock" by them, there is also another choice. Click "Advanced Mode" to enjoy "sport drive" class Overclocking user interface. "Advanced Mode", allows users to change the system bus / AGP / Memory working frequency in small increments to getultimate system performance. It operates in coordination with Gigabyte motherboards. Besides, it is different from other traditional over-clocking methods, EasyTune 4 doesn'trequire users to change neither BIOS nor hardware switch/jumper setting; on the other hand, they can do "Overclock" at easy step. Therefore, this is a safer way for "Overclock" as nothing is changed on software or hardware. If user runs EasyTune 4 over system's limitation, the biggest lost is only to restart the computer again and the side effect is then well controlled. Moreover, if one well-performed system speed has been tested in EasyTune 4, user can "Save" this setting and "Load" it in next time. Obviously, Gigabyte EasyTune 4 has already turned the "Overclock" technology toward to a newer generation. This wonderful software is now free bundled in Gigabyte motherboard attached in driver CD. Users may make a test drive of "EasyTune 4" to find outmore amazing features by themselves.

*Some Gigabyte products are not fully supported by EasyTune 4. Please find the products supported list in the web site.

*Any "Overclocking action" is at user's risk, Gigabyte Technology will not be responsible for any damage or instability to your processor, motherboard, or any other components.

Flash BIOS Method Introduction

Method 1: Q-Flash


A. What is Q-Flash Utility?

Q-Flash utility is a pre-O.S. BIOS flash utility enables users to update its BIOS within BIOS mode, no more fooling around any OS.


B. How to use Q-Flash?

a. After power on the computer, pressing immediately during POST (Power On SelfTest) it will allow you to enter AWARD BIOS CMOS SETUP, then press <F8> to enter Q-Flash utility.

CMOS Setup Utility-Copyright (C) 1984-2003 Award Software



b. Q-Flash Utility




- 63 - Technical Reference


8ip900mk_1001_t.p65 63 2003/4/22,下午 03:55

Load BIOS From Floppy


In the A:drive, insert the "BIOS" diskette, then Press Enter to Run.



Press Enter to Run.



Press Enter to Run.




Congratulation! You have completed the flashed and now can restart system.


Method 2: @BIOS Utility

If you don't have DOS boot disk, we recommend that you used Gigabyte @BIOS™ program to flash BIOS.









Methods and steps:

- I. Update BIOS through Internet
- a. Click "Internet Update" icon
- b. Click "Update New BIOS" icon
- c. Select@BIOS™ sever
- d. Selectthe exact model name on your motherboard.
- e. System will automatically download and update the BIOS.

II. Update BIOS NOT through Internet:

- a. Do not click "Internet Update" icon
- b. Click "Update New BIOS"
- c. Please select "All Files" in dialog box while opening the old file.
- d. Please search for BIOS unzip file, downloading from internet or any other methods (such as: 8IP900MK.F2).
- e. Complete update process following the instruction.

III. Save BIOS

In the very beginning, there is "Save Current BIOS" icon shown in dialog box. It means to save the current BIOS version.

IV. Check out supported motherboard and Flash ROM:

In the very beginning, there is "About this program" icon shown in dialog box. It can help you check out which kind of motherboard and which brand of Flash ROM are supported.

Note:

- a. In method I, if it shows two or more motherboard's model names to be selected, please make sure your motherboard's model name again. Selecting wrong model name will cause the systemunbooted.
- b. In method II, be sure that motherboard's model name in BIOS unzip file are the same as your motherboard's. Otherwise, your system won't boot
- c. In method I, if the BIOS file you need cannot be found in @BIOS™ server, please go onto Gigabyte's web site for downloading and updating it according to method II.
- d. Please note that any interruption during updating will cause system unbooted

2- / 4- / 6-Channel Audio Function Introuction

The installation of Windows 98SE/2K/ME/XP is very simple. Please follow next step to install the function!

Stereo Speakers Connection and Settings:

We recommend that you use the speaker with amplifier to acquire the best sound effect if the stereo output is applied.

STEP 1:

Connect the stereo speakers or earphone to "Line Out".



STEP 2:

After installation of the audio driver, you'll find an


icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





STEP 3:

Select "Speaker Configuration", and choose the "2 channels for stereo speakers out put".





- 67 -

Technical Reference

4 Channel Analog Audio Output Mode

STEP 1:

Connect the front channels to "Line Out", the rear channels to "Line In".



STEP 2:

After installation of the audio driver, you'll find an icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.






STEP 3:


Select "Speaker Configuration", and choose the "4 channels for 4 speakers out put".

Disable "Only SURROUND-KIT", and press "OK".

4-channel mode for 4 speaker output



When the "Environment settings" is "None", the sound would be performed as stereo mode (2 channels output). Please select the other settings for 4 channels output.



2003/4/22, 下午 03:56


GA-8IP900MK Motherboard

Basic 6 Channel Analog Audio Output Mode

Use the back audio panel to connect the audio output without any additional module.

STEP 1:

Connect the front channels to "Line Out", the rear channels to "Line In", and the Center/Subwoofer channels to "MIC In".



STEP 2:

After installation of the audio driver, you'll find an icon on the taskbar's status area. Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





000

STEP 3:

Select "Speaker Configuration", and choose the "6 channels for 5.1 speakers out put".

Disable "Only SURROUND-KIT" and pess "OK".



- 69 -

Technical Reference

T CONTROL !

<u>Advanced 6 Channel Analog Audio Output Mode (using Audio Combo Kit, Optional Device):</u>

(Audio Combo Kit provides SPDIF output port : optical & coaxis and SURROUND-KIT : Rear R/L & Center/subwoofer)

SURROUND-KIT access analog output to rear channels and Center/Subwoofer channels. It is the best solution if you need 6 channel output, Line In and MIC at the same time. "SURROUND-KIT" is included in the GIGABYTE unique "Audio Combo Kit" as picture.




STEP 1:

Insert the "Audio Combo Kit" in the back of the case, and fix it with the screw.



STEP 2:

Connect the "SURROUND-KIT" to SUR_CEN on the M/B.



STEP 3:

Connect the front channels to back audio panel's "Line Out", the rear channels to SURROUND-KIT's REAR R/L, and the Center/Subwoofer channels to SURROUND-KIT's SUB CENTER.



STEP 4:

Click the audio icon "Sound Effect" from the windows tray at the bottom of the screen.





STEP 5:

Select "Speaker Configuration", and choose the "6 channels for 5.1 speakers out put".


Enable "Only SURROUND-KIT" and press "OK".





Basic & Advanced 6 Channel Analog Audio Output Mode Notes:

When the "Environment settings" is "None", the sound would be performed as stereo mode (2 channels output). Please select the other settings for 6 channels output.



- 71 -

Technical Reference

SPDIF Output Device (Optional Device)


A "S/PDIF output" device is available on the motherboard. Cable with rear bracket is provided and could link to the "S/PDIF output" connector (As picture.) For the further linkage to decoder, rear bracket provides coaxial cable and Fiber connecting port.



1. Connect the SPDIF output device to the rear bracket of PC, and fix it with screw.



2. Connect SPDIF wire to the motherboard.



3. Connect co-axial or optical output to the AC3 decoder.



GA-8IP900MKMotherboard

Jack-Sensing Introuction



Jack-Sensing provides audio connectors error-detection function.



Install Microsoft DirectX8.1 before to enable Jack-Sensing support for Windows 98/98 SE/2000 /ME.

Jack-Sensing includes 2 parts: AUTO and MANUAL. Following is an example for 2 channels (Windows XP):

Introduction of audio connectors

You may connect CDROM, Walkman or others audio input devices to Line In jack, speakers, earphone or others output devices to Line Out jack, and microphone to MIC In jack.



Auto-detecting:

Please connect the devices to the right jacks as above. A window will appear as right picture if you setup the devices properly.

Please note that 3D audio function will only appear when 3D audio inputs.



- 73 -

Technical Reference

If you set wrong with the connectors, the warning message will come out as right picture.



Manual setting:

If the device picture shows different from what you set, please press "Manual Selection" to set.



8ip900mk_1001_t.p65 75 2003/4/22, 下午 03:56

- 75 -

Technical Reference

GA-8IP900MKMotherboard	- 76 -	
Or Con Goodwill Wide lord data	- 10 -	

8ip900mk_1001_t.p65 76 2003/4/22, 下午 03:56

Chapter 5 Appendix

Install Drivers



Pictures below are shown in Windows XP


Insert the driver CD-title that came with your motherboard into your CD-ROM drive, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

INSTALL CHIPSET DRIVER

This page shows the drivers that need to be installed for the system. Click each item to install the driver manually or switch to the to install the drivers automatically.



The "Xpress Install" uses the "Click and Forget" technology to install the drivers automatically. Just select the drivers you want then click the "GO" button. The will finish the installation for you automatically.



- 77 - Appendix





Driver installation finished!
You have to reboot system!

Item Description

- Intel Chipset Software Installation Utility
 Tell the operating system how the chipset components will be configured.
- USB Patch for WinXP
 This patch driver can help you to resolve the USB device wake up S3 hang up issue in XP.
- Intel 82562/82562EX/82540EM LAN Driver
 For Intel® PRO/10/100/1000/Wireless Ethernet connections
- RealTek ALC11A/201A/202/650 AC97 Codec Driver For Intel® ICH/ICH2/ICH4/ICH5/ICH5R AC97 audio
- Intel USB 2.0 Driver
 It is recommended that you use the Microsoft Windows update for the most updated driver for XP/2K



For USB2.0 driver support under Windows XP operating system, please use Windows Service Pack. After install Windows Service Pack, it will show a question mark "?" in "Universal Serial Bus controller" under "Device Manager". Please remove the question mark and restart the system (System will auto-detect the right USB2.0 driver).

GA-8IP900MK Motherboard

SOFTWARE APPLICATION

This page reveals the value-added software developed by Gigabyte and its worldwide partners.



- Gigabyte Windows Utilities Manager (GWUM)
 This utility can integrate the Gigabyte's applications in the system tray
- Gigabyte Management Tool (GMT)
 A useful tool which can manage the computer via the network
- EasyTune 4
 Powerful utility that integrates the overclocking and hardware monitoring functions
- DMI Viewer
 Windows based utility which is used to browse the DMI/SMBIOS information of the system
- Face-Wizard
 New utility for adding BIOS logo
- @BIOSGigabyte windows flash BIOS utility
- Acrobat e-Book
 Useful utility from Adobe
- Acrobat Reader
 - Popular utility from Adobe for reading .PDF file format documents
- Norton Internet Security (NIS)
 Integrated utility which includes anti-virus, ads, etc.
- DirectX 9.0 Install Microsoft DirectX 9 to enable 3D hardware acceleration that support for operating system to achieve better 3D performence.

- 79 - Appendix

SOFTWARE INFORMATION

This page list the contects of softwares and drivers in this CD title.



HARDWARE INFORMATION

This page lists all device you have for this motherboard.



CONTACT US

Please see the last page for details.




GA-8IP900MK Motherboard

EasyTune 4 Utilities Installation

Powerful utility that integrates the overclocking and hardware monitoring functions













- 81 - Appendix

FAQ

Below is a collection of general asked questions. To check general asked questions based on a specific motherboard model, please log on to http://tw.giga-byte.com/faq/faq.htm

Question 1: I cannot see some options that were included in previous BIOS after updating BIOS. Why?

Answer: Some advanced options are hidden in new BIOS version. Please press Ctrl and F1 keys after entering BIOS menu and you will be able to see these options.

Questions 2: Why is the light of my keyboard/optical mouse still on after computer shuts down? Answer: In some boards, a small amount of electricity is kept on standby after computer shuts down and that's why the light is still on.

Question 3: Why cannot I use all functions in EasyTune™ 4?

Answer: The availability of the listed functions in EasyTune[™] 4 depends on the MB chipset. If the chipset doesn't support certain functions in EasyTune[™] 4, these functions will be locked automatically and you will not be able to use them.

Question 4: Why do I fail to install RAID and ATA drivers under Win 2000 and XP on boards that support RAID function after I connect the boot HDD to IDE3 or IDE4?

Answer: First of all, you need to save some files in the CD-ROM to a floppy disk before installing drivers. You also need to go through some rather different steps in the installation process. Therefore, we suggest that you refer to the installation steps in the RAID manual at our website. (Please download it at http://tw.giga-byte.com/support/user_pdf/raid_manual.pdf)

Question 5: How do I clear CMOS?

Answer: If your board has a Clear CMOS jumper, please refer to the Clear CMOS steps in the manual. If your board doesn't have such jumper, you can take off the on-board battery to leak voltage to clear CMOS. Please refer to the steps below:

Steps:

- 1. Turn off power.
- 2. Disconnect the power cord from MB.
- 3. Take out the battery gently and put it aside for about 10 minutes (Or you can use a metal object to connect the positive and negative pins in the battery holder to make them short for one minute).
- 4. Re-insert the battery to the battery holder.
- 5. Connect power cord to MB again and turn on power.
- 6. Press Del to enter BIOS and load Fail-Safe Defaults.
- 7. Save changes and reboot the system.

Question 6: Why does system seem unstable after updating BIOS?

Answer: Please remember to load Fail-Safe Defaults (Or Load BIOS Defaults) after flashing BIOS. However, if the system instability still remains, please clear CMOS to solve the problem.

Question 7: Why do I still get a weak sound after turning up the speaker to the maximum volume? **Answer:** Please make sure the speaker you are using is equipped with an internal amplifier. If not, please change another speaker with power/amplifier and try again later.

Question 8: How do I disable onboard VGA card in order to add an external VGA card? **Answer:** Gigabyte motherboards will auto-detect the external VGA card after it is plugged in, so you don't need to change any setting manually to disable the onboard VGA.

Question 9: Why cannot I use the IDE 2?

Answer: Please refer to the user manual and check whether you have connected any cable that is not provided with the motherboard package to the USB Over Current pin in the Front USB Panel. If the cable is your own cable, please remove it from this pin and do not connect any of your own cables to it.

- 83 - Appendix

8ip900mk_1001_a.p65 83 2003/4/22, 下午 03:57

Question 10: Sometimes I hear different continuous beeps from computer after system boots up. What do these beeps usually stand for?

Answer: The beep codes below may help you identify the possible computer problems. However, they are only for reference purposes. The situations might differ from case to case.

→AMI BIOS Beep Codes

*Computer gives 1 short beep when system boots successfully.

*Except for beep code 8, these codes are always fatal.

- 1 beep Refresh failure
- 2 beeps Parity error
- 3 beeps Base 64K memory failure
- 4 beeps Timer not operational
- 5 beeps Processor error
- 6 beeps 8042 gate A20 failure
- 7 beeps Processor exception interrupt error
- 8 beeps Display memory read/write failure
- 9 beeps ROM checksum error
- 10 beeps CMOS shutdown register read/write error
- 11 beeps Cache memory bad


→ AWARD BIOS Beep Codes

- 1 short: System boots successfully
- 2 short: CMOS setting error
- 1 long 1 short: DRAM or M/B error
- 1 long 2 short: Monitor or display card error
- 1 long 3 short: Keyboard error
- 1 long 9 short: BIOS ROM error
- Continuous long beeps: DRAM error
- Continuous short beeps: Power error

Troubleshooting




If you encounter any trouble during boot up, please follow the troubleshooting procedures.



- 85 - Appendix

8ip900mk_1001_a.p65 85 2003/4/22,下午 03:57



If the above procedure unable to solve your problem, please contact with your local retailer or national distributor for help. Or, you could submit your question to the service mail via Gigabyte website technical support zone (http://www.gigabyte.com.tw). The appropriate response will be provided ASAP.

GA-8IP900MK Motherboard

- 86 -

8ip900mk_1001_a.p65 86 2003/4/22, 下午 03:57

Technical Support/RMA Sheet

Contact Person: E-mail Add. :	Model name/Lot Number: BIOS version: O.S./A.S.: Hardware Mfs. Model name Size: Driver/Utility Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem
BIOS version: O.S./A.S.: Hardware Mfs. Model name Size: Driver/Utility: Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	BIOS version: O.S./A.S.: Hardware Mfs. Model name Size: Driver/Utility Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem
BIOS version: O.S./A.S.: Hardware Mfs. Model name Size: Driver/Utility: Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	BIOS version: O.S./A.S.: Hardware Mfs. Model name Size: Driver/Utility Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem
Hardware Mfs. Model name Size: Driver/Utility: Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	Hardware Mfs. Model name Size: Driver/Utility Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem
Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem
Configuration CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	Configuration , CPU , Memory , Brand , Video Card , Audio Card , HDD , CD-ROM / , DVD-ROM , Modem ,
CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	CPU Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Modem
Memory Brand Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply Power supply	Memory Brand Video Card
Brand Video Card Audio Card ————————————————————————————————————	Brand Video Card Audio Card — HDD — CD-ROM / — DVD-ROM — Modem —
Video Card Audio Card HDD CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply Power supply	Video Card
Audio Card	Audio Card
HDD	HDD
CD-ROM / DVD-ROM Modem Network AMR / CNR Keyboard Mouse Power supply	CD-ROM / DVD-ROM Modem
DVD-ROM Modem Metwork Modem Network Modem AMR / CNR Modem Keyboard Mouse Power supply Modem	DVD-ROM
Modem Network AMR / CNR Keyboard Mouse Power supply	Modem
Network AMR / CNR Keyboard Mouse Power supply	
AMR / CNR Keyboard Mouse Power supply	Network
Keyboard Mouse Power supply	
Mouse Power supply	AMR / CNR
Power supply	Keyboard
	Mouse
Other Device	
	Other Device
Problem Description:	Problem Description:

- 87 - Appendix

Acronyms

Acronyms	Meaning
ACPI	Advanced Configuration and Power Interface
APM	Advanced Power Management
AGP	Accelerated Graphics Port
AMR	Audio Modem Riser
ACR	Advanced Communications Riser
BIOS	Basic Input / Output System
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRM	Dual Retention Mechanism
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCD	Extended System Configuration Data
ECC	Error Checking and Correcting
EMC	Electromagnetic Compatibility
EPP	Enhanced Parallel Port
ESD	Electrostatic Discharge
FDD	Floppy Disk Device
FSB	Front Side Bus
HDD	Hard Disk Device
IDE	Integrated Dual Channel Enhanced
IRQ	Interrupt Request

to be continued.....

Acronyms	Meaning
IOAPIC	Input Output Advanced Programmable Input Controller
ISA	Industry Standard Architecture
LAN	Local Area Network
I/O	Input / Output
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Instrument Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System
OEM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory

- 89 - Appendix

GA-8IP900MK Motherboard	- 90 -	

8ip900mk_1001_a.p65 90 2003/4/22, 下午 03:57

Memo

8ip900mk_1001_a.p65 91 2003/4/22, 下午 03:57

- 91 -

CONTACT US

Contact us via the information in this page all over the world.

Taiwan

Gigabyte Technology Co., Ltd.

Address: No.6, Bau Chiang Road, Hsin-Tien, Taipei

Hsien, Taiwan, R.O.C.

TEL: 886 (2) 8912-4888 (50 lines)

FAX: 886 (2) 8912-4004

E-mail:english@gigabyte.com.tw

Web Address: http://www.gigabyte.com.tw

USA

G.B.T. INC.

Address: 17358 Railroad St, City of Industry, CA

91748.

Tel: 1 (626) 854-9338 Fax: 1 (626) 854-9339

E-mail:sales@giga-byte.com

support@giga-byte.com

Web Address: www.giga-byte.com

Germany

G.B.T. Technology Trading GmbH

Tel: 49-40-2533040

Fax: 49-40-25492343 (Sales) Tel: 49-01803-428468 (Tech.)

Fax: 49-01803-428329 (Tech.) E-mail:support@gigabyte.de

Web Address: www.gigabyte.de

• Japan/Nippon Giga-Byte Corporation

Web Address: www.gigabyte.co.jp

U.K

G.B.T. TECH. CO. LTD.

Tel: 44-1908-362700 Fax: 44-1908-362709

E-mail:support@gbt-tech.co.uk Web Address: www.gbt-tech.co.uk The Netherlands

Giga-Byte Technology B.V.

Address: Postbus 1385, 5602 BJ, Eindhoven, The

Netherlands

Tel: +31 40 290 2088 Fax: +31 40 290 2089

E-mail:info@giga-byte.nl

Web Address: http://www.giga-byte.nl

• China

Shanghai Office

Tel: 86-21-64737410 Fax: 86-21-64453227

Web Address: www.gigabyte.com.cn

GuangZhou Office

Tel: 86-20-87586273 Fax: 86-20-87544306

Web Address: www.gigabyte.com.cn

Beijing Office

Tel: 86-10-82856054 86-10-82856064 86-10-82856094 Fax: 86-10-82856575

Web Address: www.gigabyte.com.cn

E-mail:bjsupport@gigabyte.com.cn

Chengdu Office

Tel: 86-28-85236930 Fax: 86-28-85256822

Web Address: www.gigabyte.com.cn