

GA-5DXSL-RH
Xeon® 3000 Series Processor Motherboard

USER'S MANUAL

Xeon® 3000 Series Processor Motherboard
Rev. 1001



* The WEEE marking on the product indicates this product must not be disposed of with user's other household waste and must be handed over to a designated collection point for the recycling of waste electrical and electronic equipment!!



* The WEEE marking applies only in European Union's member states.

Table of Content

WARNING!	3
Chapter 1 GA-5DXSL-RH Motherboard Component	4
Chapter 2 Hardware Installation Process	6
2-1: Install Memory Module	6
2-2: Connect ribbon cables, cabinet wires, and power supply	8
2-2-1 : I/O Back Panel Introduction	8
2-3: Connectors Introduction & Jumper Setting	10
Chapter 3 BIOS Setup	23
Main	25
Advanced	27
Advanced Processor Options	28
Memory Configuration	31
Advanced Chipset Control	32
PCI Configuration	34
I/O Device Configuration	35
IDE Configuration	40
Floppy Configuration	42
Boot Configuration	43
DMI Event Logging	45
Hardware Monitor	47
Security	50
Server	52
System Management	53
Console Redirection	54
Boot	56
Exit	57
Chapter 4 INTEL RAID BIOS Configuration	62

**WARNING!**

Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.


1. Unplug your computer when working on the inside.
2. Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
3. Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

Chapter 1 GA-5DXSL-RH Motherboard Component

No.	Description	No.	Description
1	CPU	26	PCI4
2	Intel 3200 chipset	27	PCI-E3 (x1 bandwidth)
3	Intel ICH9R	28	PCI-E2 (x4 bandwidth)
4	ITE IT8718F-S	29	PCI-E1 (x8 bandwidth)
5	BIOS Flash ROM	30	DIMMA1
6	XGI Volari Z9s	31	DIMMA2
7	VGA Memory	32	DIMMB1
8	Broadcom BCM5721 GbE	33	DIMMB2
9	Intersil 6326 (PWM controller)	34	CPU fan cable connector
10	Floppy cable connector	35	Power fan cable connector
11	Front USB 1 cable connector	36	System fan cable connector
12	Front USB 2 cable connector	37	Front fan cable connector
13	COM2	38	Rear fan cable connector
14	SATA cable connector 0	39	I2C connector
15	SATA cable connector 1	40	PS/2port
16	SATA cable connector 2	41	USB port
17	SATA cable connector 3	42	COM port
18	SATA cable connector 4	43	VGA port
19	SATA cable connector 5	44	LAN port
20	Front Panel	45	24-pin ATX power connector
21	TPM connector	46	8-pin ATX power connector
22	IPMB2	47	Case open intrusion jumper
23	IPMB1	48	Clear CMOS jumper
24	IPMI BMC Module Slot	49	Battery
25	PCI5		



Chapter 2 Hardware Installation Process

2-1: Install Memory Module

GA-5DXSL-RH has 4 dual inline memory module (DIMM) sockets. It supports Dual Channels Technology. The BIOS will automatically detects memory type and size during system boot. For detail DIMM installation, please refer to the following instructions.






Table 1. Supported DIMM Module Type

Size	Organization	RAM Chips/DIMM
256MB	8MB x 8 x 4 bks	8
	16MB x 4 x 4bks	16
512MB	16MB x 8 x 4bks	8
	32MB x 4 x 4bks	16
1GB	32MB x 8 x 4bks	8
	64MB x 4 x 4bks	16


Installation Steps:

1. Unlock a DIMM socket by pressing the retaining clips outwards.
2. Aling a DIMM on the socket such that the notch on the DIMM exactly match the notch in the socket.
3. Firmly insert the DIMM into the socket until the retaining clips snap back in place.
4. When installing the memory into the DIMM socket, we recommend to populate the memory as a pair. One in Channel A module and one in Channel B module for best performance. Please populate DIMM starting from Channel A (Yellow slot).
Note that each logical DIMM must be made of two identical DIMMs having the same device size on each and the same DIMM size.
5. Reverse the installation steps if you want to remove the DIMM module.

**Locked Retaining Clip**

2-2: Connect ribbon cables, cabinet wires, and power supply

2-2-1 : I/O Back Panel Introduction



❶ PS/2 Keyboard and PS/2 Mouse Connector

To install a PS/2 port keyboard and mouse, plug the mouse to the upper port (green) and the keyboard to the lower port (purple).

❷ USB Ports

Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker...etc. have a standard USB interface.

Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver updated. For more information please contact your OS or device(s) vendors.

❸ Serial Port


Modem can be connected to Serial port.

❹ VGA Port

Monitor can be connected to VGA port.


❺ LAN Port

The LAN port provides Internet connection of Gigabit Ethernet with data transfer speeds of 10/100/1000Mbps. This port supports IPMI 2.0.

LAN LED Description


Name	Color	Condition	Description
LED1	Green	ON	LAN Link / no Access
	Green	BLINK	LAN Access
	-	OFF	Idle
LED2	-	OFF	10Mbps connection
	-	OFF	Port identification with 10 Mbps connection
	Green	ON	100Mbps connection
	Green	BLINK	Port identification with 100Mbps connection
	Yellow	ON	1Gbps connection
	Yellow	BLINK	Port identification with 1Gbps connection
	-	-	-

2-3: Connectors Introduction & Jumper Setting



- | | |
|-------------|--|
| 1. ATX1 | 15. CPU_FAN |
| 2. ATX_12V1 | 16. PSU_FAN1 |
| 3. FDD1 | 17. SYS_FAN1 |
| 4. SATA0 | 18. FRONT_FAN |
| 5. SATA1 | 19. REAR_FAN |
| 6. SATA2 | 20. F_Panel1 |
| 7. SATA3 | 21. TPM_20 |
| 8. SATA4 | 22. BAT1 |
| 9. SATA5 | 23. JP1 (Clear CMOS jumper) |
| 10. F_USB1 | 24. JP2_1 (Password jumper) |
| 11. F_USB2 | 25. JP3_1 (BIOS recovery jumper) |
| 12. COM2 | 26. JP4_1 (BOOT select strapsj jumper) |
| 13. IPMB1 | 27. JP4_2 (BOOT select strapsj jumper) |
| 14. IPMB2 | |



1) ATX1 (Auxukiary Power Connector)



- AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

PIN No.	Definition
1	+3.3V
2	+3.3V
3	GND
4	+5V
5	GND
6	+5V
7	GND
8	POK
9	5VSB
10	+12V
11	+12V
12	+3.3V
13	+3.3V
14	-12V
15	GND
16	PSON
17	GND
18	GND
19	GND
20	-5V
21	+5V
22	+5V
23	+5V
24	GND

2) ATX_12V1 (Auxukiary +12V Power Connector)





Pin No.	Definition
1	GND
2	GND
3	GND
4	GND
5	P12V_CPU
6	P12V_CPU
7	P12V_CPU
8	P12V_CPU

- This connector (ATX +12V) is used only for CPU Core Voltage.


3) FDD1 (Floppy cable connector)

Please connect the floppy drive ribbon cables to FDD. It supports 720K, 1.2M, 1.44M and 2.88Mbytes floppy disk types. The red stripe of the ribbon cable must be the same side with the Pin1.



4/ 5/ 6/ 7/ 8/ 9) SATA 0~5 (Serial ATA cable connectors)

You can connect the Serial ATA device to this connector, it provides you high speed transfer rates (3.0Gb/s).




Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND


10/11) F_USB1/F-USB2 (Front USB cable connectors)

Be careful with the polarity of the front USB connector. Check the pin assignment carefully while you connect the front USB cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional front USB cable, please contact your local dealer.

F_USB2





F_USB1



Pin No.	Definition
1	Power
2	Power
3	USB Dx-
4	USB Dy-
5	USB Dx+
6	USB Dy+
7	GND
8	GND
9	No Pin
10	NC


12) COM2 (Serial port connector)





Pin No.	Definition
1	DCD-
2	SIN2
3	SOUT2
4	DTR2-
5	GND
6	DSR2-
7	RTS2-
8	CTS2-
9	RI2-
10	NC


13) IPMB1



1

Pin No.	Definition
1	Clock
2	GND
3	Data

14) IPMB2




1

Pin No.	Definition
1	Data
2	GND
3	Clock
4	NC

15) CPU_FAN (CPU fan cable connector)


Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 1A .



Pin No.	Definition
1	GND
2	12V
3	Sense
4	Control

16) PSU_FAN1 (Power fan cable connector)


This connector allows you to link with the cooling fan on the system case to lower the system temperature.



Pin No.	Definition
1	GND
2	+12V
3	Sense

17) SYS_FAN1 (System fan cable onnector)


This connector allows you to link with the cooling fan on the system case to lower the system temperature. These connectors are for system use only.



Pin No.	Definition
1	GND
2	+12V
3	Sense

18/ 19) FRONT_FAN/REAR_FAN (System fan cable onnector)

This connector allows you to link with the cooling fan on the system case to lower the system temperature. These connectors are for system use only.



1 FRONT_FAN

1




REAR_FAN

Pin No.	Definition
1	GND
2	12V
3	Sense
4	Control

20) F_Panel (2X12 Pins Front Panel connector)


Please connect the power LED, PC speaker, reset switch and power switch of your chassis front panel to the F_PANEL connector according to the pin assignment above.





Pin No.	Signal Name	Description
1.	PWLED+	Power LED Signal anode (+)
2.	5VSB	P5V Stand By Power
3.	KEY	Pin Removed
4.	COOL_FAULT_LED+	Cooling fault LED Signal anode (+)
5.	PWLED-	Power LED Signal cathode(-)
6.	COOL_FAULT_LED-	Cooling fault LED Signal cathode(-)
7.	HD+	Hard Disk LED Signal anode (+)
8.	SYS_FAULT+	System Fan Fail LED Signal
9.	HD-	Hard Disk LED Signal cathode(-)
10.	SYS_FAULT-	System Status LED Signal
11.	PWB+	Power Button Signal anode (+)
12.	L1_ACT	LAN1 access LED Signal
13.	PWB+_GND	Power Button Ground
14.	L1_LNK-	LAN1 linked LED Signal cathode(-)
15.	RST_BTN-	Reset Button cathode(-)
16.	SENSOR_SDA	SMBus Data
17.	RST_BTN_GND	Reset Button Ground
18.	SENSOR_SCL	SMBus Clock
19.	ACPI_SLEEP	No Connect
20.	CASE_OPEN-	Chassis intrusion Signal
21.	ACPI_SLEEP-	No Connect
22.	L2_ACT	LAN2 access LED Signal
23.	NMI_SW-	NMI Switch cathode(-)
24.	L2_LNK-	LAN2 linked LED Signal cathode(-)

21) TPM_20 (TPM cable connector)

TPM, Trusted Platform Module offers facilities for secure generation of cryptographic keys, the ability to limit the use of keys (to either signing / verification or encryption / decryption). TPM chip is unique to a particular device, it is capable of performing platform authentication.



22) BAT1 (Battery)



CAUTION

- ❖ Danger of explosion if battery is incorrectly replaced.
- ❖ Replace only with the same or equivalent type recommended by the manufacturer.
- ❖ Dispose of used batteries according to the manufacturer's instructions.


If you want to erase CMOS...



1. Turn OFF the computer and unplug the power cord.
2. Remove the battery, wait for 30 second.
3. Re-install the battery.
4. Plug the power cord and turn ON the computer.

23) JP1 (Clear CMOS jumper)


You may clear the CMOS data to restore its default values by this jumper.

Default value doesn't include the "Shunter" to prevent from improper use this jumper. To clear CMOS, temporarily short 2-3 pin.



- 1  1-2 Close: Normal (Default setting)
- 1  2-3 Close: Clear CMOS


24) JP2_1 (Skip password jumper)





1  1-2 Close: Normal (Default setting)


1  2-3 Close: Skip Supervisor Password in BIOS setup menu


25) JP3_1 (BIOS recovery jumper)




- 1  1-2 Close: Enable BIOS Recovery function.
- 1  2-3 Close: Normal (Default setting)

26/27) JP4_1/JP4_2 (Boot select straps jumper)



1  1-2 Close: Normal (Default setting)

1  2-3 Close: Enable Boot select straps.

Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

ENTERING SETUP

Power ON the computer and press <F2> immediately will allow you to enter Setup.

CONTROL KEYS

<↑>	Move to previous item
<↓>	Move to next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
<Esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F2>	Reserved
<F3>	Reserved
<F4>	Reserved
<F6>	Reserved
<F7>	Reserved
<F8>	Reserved
<F9>	Load the Optimized Defaults
<F10>	Save all the CMOS changes, only for Main Menu

GETTINGHELP

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

- **Main**

This setup page includes all the items in standard compatible BIOS.

- **Advanced**

This setup page includes all the items of AMI special enhanced features.

(ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

- **Security**

Change, set, or disable password. It allows you to limit access the system and setup.

- **Server**

Server additional features enabled/disabled setup menus.

- **Boot**

This setup page include all the items of first boot function features.

- **Exit**

There are five options in this selection: Exit Saving Changes, Exit Discarding Changes, Load Optimal Defaults, Load Failsafe Defaults, and Discard Changes.

Main

Once you enter Phoenix BIOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.




Figure 1: Main

System Time

The time is calculated based on the 24-hour military time clock. Set the System Time (HH:MM:SS)

System Date

Set the System Date. Note that the "Day" automatically changed after you set the date. (Weekend: DD: MM: YY) (YY: 1099-2099)

BIOS Version

This item displays the information of BIOS Version.

🔑 **BIOS Date**

This item identifies the BIOS refresh date.

🔑 **Processor Information**

These following items display all information of current **CPU Type**, **CPU Speed**, and **CPU Count**. These items are display-only which is determined by POST (Power On Self Test) of the BIOS.

🔑 **Total Memory Size**

This item identifies the total memory size.

Advanced

About This Section: Advanced

With this section, allowing user to configure your system for basic operation. User can change the processor options, chipset configuration, PCI configuration and chipset control.




Figure 2: Advanced

Advanced Processor Options




Figure 2-1: Advanced Processor Options

⚙ Advanced Processor Option

This category includes the information of CPU Type, CPU Speed, Processor 1 CPUID, and Processor 1 L2 Cache. Setup menu for Thermal Management 2, C1 Enhanced Mode, C1 Enhanced Mode, Intel(R) Virtualization Technology, No Execute Mode Memory Protection, PECI Interface, and Intel EIST Support.

⚙ Thermal Management2

Thermal Management 2 enhances the features of power reduction capability. When TM2 is enabled, it will reduce the frequency and VID which results in a saving of power consumption of processor.

- ▶▶ Enabled Enabled Thermal Management 2. (Default setting)
- ▶▶ Disabled Disables this function.

☞ **C1 Enhanced Mode**

With enabling C1 Enhanced Mode, all logical processors in the physical processor have entered the C1 state, the processor will reduce the core clock frequency to system bus ratio and VID.

- ▶▶ Enabled Enabled C1 Enhanced Mode.
- ▶▶ Disabled Disables C1 Enhanced Mode. (Default setting)

☞ **Intel(R) Virtualization Technology**

Intel(R) Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple "virtual" systems. With processor and I/O enhancements to Intel's various platforms, Intel Virtualization Technology can improve the performance and robustness of today's software-only virtual machine solutions.

- ▶▶ Enabled Enabled VT Feature.
- ▶▶ Disabled Disables VT Feature. (Default setting)

☞ **No Execute Mode Mem. Protection**

- ▶▶ Enabled Enable No Execute Mode Memory Protection function. (Default setting)
- ▶▶ Disabled Disables No Execute Mode Memory Protection function.

☞ **PECI Interface**

The Platform Environmental Control Interface (PECI Interface) is designed specifically to convey system management information from the processor. It is a proprietary single wire bus between the processor and the chipset or other health monitoring device. Data from the Digital Thermal Sensors are processed and stored in a processor register (MSR) which is queried through the Platform Environment Control Interface (PECI).

- ▶▶ Enabled Enable PECI Interface
- ▶▶ Disabled Disable this function. (Default setting)

Intel EIST Support

Select the Power Management desired:

- | | |
|-----------------|---|
| » Enabled | C states and GV1/GV3 are enabled. (Default setting) |
| » C States Only | GV1/GV3 are disabled. |
| » GV1/GV3 Only | C states are disabled. |
| » Disabled | C states and GV1/GV3 are disabled. |

Memory Configuration




Figure 2-2: Memory Configuration

System Memory/Extended Memory/DIMM Group A1,A2, B1, B2 Status

This category is display-only which is determined by POST (Power On Self Test) of the BIOS.

Memory Reset

- ▶▶ Yes

Select 'Yes', system will clear the memory error status. Save the changes and restart system. After rebooting system, the Memory Reset item will set to 'No' automatically.
- ▶▶ No

Disable this function. (Default setting)

Advanced Chipset Control




Figure 2-3: Advanced Chipset Control

☞Wake On LAN / PME

This option allow user to determine the action of the system when a LAN/PME wake up event occurs.

- » Enabled Enable Wake On LAN/PME. (Default setting)
- » Disabled Disable this function.

Note: This item must enabled if you're running under Windows operating system.

☞Wake On Ring

This option allow user to determine the action of the system power is off and the modem is ringing.

- » Enabled Enable Wake On Ring.
- » Disabled Disable this function. (Default setting)

Note: This item must enabled if you're running under Windows operating system.

☞Wake On RTC Alarm

When "RTC Alarm Resume" item is set to enabled, system will wakeup from RTC. (This item will be functionalized under ACPI OS)

- ▶▶ Enabled Enable alarm function to POWER ON system.
- ▶▶ Disabled Disable this function. (Default setting)

Note: This item must enabled if you're running under Windows operating system.

PCI Configuration




Figure 2-4: PCI Configuration

☞ PCI Slot 1/2/3/4 Option ROM

- » Enabled Enabling this item to initialize device expansion ROM.
(Default setting)
- » Disabled Disable this function.

☞ LAN1 Option ROM Scan

- » Enabled Enabling this item to initialize device expansion ROM.
(Default setting)
- » Disabled Disable this function.

☞ Onboard VGA Control

- » Enabled Enable the onboard VGA device. (Default setting)
- » Disabled Disable this function.

I/O Device Configuration




Figure 2-5: I/O Device Configuration

Serial Port A

This allows users to configure serial port A by using this option.

- ▶▶ Enabled Enable the configuration (Default setting)
- ▶▶ Disabled Disable the configuration.

- ▶ Base I/O Address/IRQ
 - ▶▶ 3F8 Set IO address to 3F8. (Default setting)
 - ▶▶ 2F8 Set IO address to 2F8.
 - ▶▶ 3E8 Set IO address to 3E8.
 - ▶▶ 2E8 Set IO address to 2E8.

🔗 Serial Port B

This allows users to configure serial port B by using this option.

- ▶▶ Enabled Enable the configuration
- ▶▶ Disabled Disable the configuration. (Default setting)

▶ Base I/O Address/IRQ

- ▶▶ 3F8 Set IO address to 3F8.
- ▶▶ 2F8 Set IO address to 2F8. (Default setting)
- ▶▶ 3E8 Set IO address to 3E8.
- ▶▶ 2E8 Set IO address to 2E8.

🔗 Parallel Port

This allows users to configure parallel port by using this option.

- ▶▶ Enabled Enable the configuration.
- ▶▶ Disabled Disable the configuration. (Default setting)

▶ Mode

This option allows user to set Parallel Port transfer mode.

- ▶▶ Bi-directional Use this setting to support bi-directional transfers on the parallel port. (Default setting)
- ▶▶ EPP Using Parallel port as Enhanced Parallel Port.
- ▶▶ ECP Using Parallel port as Extended Capabilities Port.

▶ Base I/O Address

- ▶▶ 378 Set IO address to 378
- ▶▶ 278 Set IO address to 278.

► **Interrupt**

- » IRQ5 Set Interrupt as IRQ5. (Default setting)
- » IRQ7 Set Interrupt as IRQ7. (Default setting)

⚙ **PS/2 Mouse**

Set this option 'Enabled' to allow BIOS support for a PS/2 - type mouse.

- » Enabled 'Enabled' forces the PS/2 mouse port to be enabled regardless if a mouse is present. (Default setting)
- » Disabled 'Disabled' prevents any installed PS/2 mouse from functioning, but frees up IRQ12.

⚙ **USB Controller**


This item allows users to enable or disable the USB device by setting item to the desired value.

- » Enabled Enable USB controller. (Default setting)
- » Disabled Disable this function.

⚙ **Legacy USB Support**

This option allows user to function support for legacy USB.

- » Enabled Enables support for legacy USB (Default setting)
- » Disabled Disables support for legacy USB.



Serial ATA

- ▶▶Enabled Enables on-board serial ATA function. (Default setting)
- ▶▶Disabled Disables on-board serial ATA function.
- ▶ Native Mode Operation
This option allows user to set the native mode for Serial ATA function.
 - ▶▶Auto Auto detected. (Default setting)
 - ▶▶Serial ATA Set Native mode to Serial ATA.
- ▶ SATA RAID Enable
 - ▶▶Enabled Enabled SATA RAID function.
 - ▶▶Disabled Disable this function. (Default setting)

► SATA AHCI Enable

- Enabled Set this item to enable SATAAHCI function for WinXP-SP1+IAA driver supports AHCI mode.
- Disabled Disabled this function. (Default setting)

IDE Configuration




Figure 2-6: IDE Configuration

☞ SATA Port 1/2/3/4/5/6

The category identifies the types of hard disk from drive 1 to 6 that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

» TYPE

1-39: Predefined types.

Users: Set parameters by User.

Auto: Set parameters automatically. (Default Vaules)

CD-ROM: Use for ATAPI CD-ROM drives or double click [Auto] to set all HDD parameters automatically.

ATAPI Removable: Removable disk drive is installed here.

» Multi-Sector Transfer

This field displays the information of Multi-Sector Transfer Mode.

Disabled: The data transfer from and to the device occurs one sector at a time.

Auto: The data transfer from and to the device occurs multiple sectors at a time if the device supports it.

- | | |
|-------------------------|---|
| » LBA Mode | This field shows if the device type in the specific IDE channel support LBA Mode. |
| » 32-Bit I/O | Enable this function to max imize the IDE data transfer rate. |
| » Transfer Mode | This field shows the information of Teansfer Mode. |
| » Ultra DMA Mode | This filed displays the DMA mode of the device in the specific IDE channel. |

Floppy Configuration




Figure 2-7: Floppy Configuration

Legacy Diskette A

This category identifies the type of floppy disk drive A that has been installed in the computer.

- ▶▶ Disabled Disable this device.
- ▶▶ 360KB, 5^{1/4} in. 3^{1/2} inch AT-type high-density drive; 360K byte capacity
- ▶▶ 1.2MB, 3^{1/2} in. 3^{1/2} inch AT-type high-density drive; 1.2M byte capacity
- ▶▶ 720K, 3^{1/2} in. 3^{1/2} inch double-sided drive; 720K byte capacity
- ▶▶ 1.44M, 3^{1/2} in. 3^{1/2} inch double-sided drive; 1.44M byte capacity.
- ▶▶ 2.88M, 3^{1/2} in. 3^{1/2} inch double-sided drive; 2.88M byte capacity.

Note: The 1.25MB, 3^{1/2} reference a 1024 byte/sector Japanese media format. The 1.25MB, 3^{1/2} diskette requires 3-Mode floppy-disk drive.

Boot Configuration




Figure 2-8: Boot Configuration

☞ Boot time Diagnostic Screen

When this item is enabled, system will shows Diagnostic status when system boot.

- ▶▶ Enabled Display the diagnostic screen during system boot.
- ▶▶ Disabled Disable this function. (Default setting)

☞ Multiprocessor Specification

This option allows user to configure the multiprocessor(MP) specification revision level. Some operating system will require 1.1 for compatibility reasons.

- ▶▶ 1.4 Support MPS Version 1.4 . (Default setting)

- » 1.1 Support M PS Version 1.1.

Post Error Pause

If this item is set to enabled, the system will wait for user intervention on critical POST errors.

If this item is disabled, the system will boot with no intervention if possible.

- » Enabled Enable Post Error Pause. (Default setting)
- » Disabled Disable this function.

AC-LINK

This option provides user to set the mode of operation if an AC / power loss occurs.

- » Power On System power state when AC cord is re-plugged.
- » Stay Off Do not power on system when AC power is back.
- » Last State Set system to the last state when AC power is removed. Do not power on system when AC power is back. (Default setting)

NumLock

This option allows user to select power-on state for NumLock.

- » On Enable NumLock. (Default setting)
- » Off Disable this function.

Security Mode for PWR/RST button

- » Enabled Enable security mode for power and reset buttons.
- » Disabled Disable this function. (Default setting)

DMI Event Logging




Figure 2-9: DMI Event Logging

🔗Event log validity/Event log capacity

These two items display the current status of Event log validity and Event log capacity.

🔗View DMI event log

Press [Enter] to view DMI event log.

🔗Event Logging

- ▶▶ Enabled Select Enabled to allow logging of DMI events. (Default setting)
- ▶▶ Disabled Disable this function.

🔑 **Mark DMI as read**

Press [Enter] to mark all DMI events in the event log as read.

🔑 **Clear all Event Logs**

- ▶▶ Yes Clear all event logs.
- ▶▶ No Disable this function. (Default setting)

Hardware Monitor




Figure 2-10: Hardware Monitor

Phoenix TrustedCore(tm) Setup Utility									
Advanced									
Voltage Monitor					Item Specific Help				
DDR1V8	3.008 V				All items on this menu cannot be modified in user mode. If any items require changes, please consult your system Supervisor.				
VCC3	3.312 V								
VCCORE	1.200 V								
12V2	12.19 V								
5V	5.95 V								
F1	Help	^v	Select Item	-/+	Change Values	F9	Setup Defaults		
Esc	Exit	<>	Select Menu	Enter	Select > Sub-Menu	F10	Save and Exit		

Figure 2-10-1: Voltage Monitor

Phoenix TrustedCore(tm) Setup Utility									
Advanced									
Fan Monitor					Item Specific Help				
REAR_FAN	N/A				All items on this menu cannot be modified in user mode. If any items require changes, please consult your system Supervisor.				
FRONT_FAN	N/A								
CPU_FAN	4591 RPM								
F1	Help	^v	Select Item	-/+	Change Values	F9	Setup Defaults		
Esc	Exit	<>	Select Menu	Enter	Select > Sub-Menu	F10	Save and Exit		

Figure 2-10-2: Fan Monitor

🔓 **CPU/SystemTemperature**

» Display the current CPU temperature and system temperature.

🔓 **Voltage Monitor: DDR1V8, VCC3, VCORE, 12V2, 5V**

» Detect system's voltage status automatically.

🔓 **FAN Monitor: REARFAN/FRONTFAN/CPUFAN**

» Display the current front fanspeed, rear fan speed, and CPU fan speed.

Security

About This Section: Security

In this section, user can set either supervisor or user passwords, or both for different level of password securities. In addition, user also can set the virus protection for boot sector.




Figure 3: Security

Set Supervisor Password

You can install and change this options for the setup menus. Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password or press <Enter> key to disable this option.

🔓 **Set User Password**

You can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password.

🔓 **Password on boot**

Password entering will be required when system on boot.

- ▶▶ Enabled Requires entering password when system on boot.
- ▶▶ Disabled Disable this function. (Default setting)

Server




Figure 4: Server

System Management




Figure 4-1: System Management

☞Server Management

This category allows user to view the server management features. Including information of BIOS Version, Product Name, System Version, System Serial Number, Main Board ID, Main Board Serial Number, and, LAN1/2 MAC Address . All items in this menu cannot be modified, display only.

☞Clear Case Open Status

Press [Enter] to clear the Case Open Status.

Console Redirection




Figure 4-2: Console Redirection

☞ BIOS Redirection Port

If this option is set to enabled, it will use a port on the motherboard.

- » Serial Port A Use Serial Port A as the COM port address.
- » Serial Port B Use Serial Port B as the COM port address.
- » Disabled Disable this function. (Default setting)

☞ Baud Rate

This option allows user to set the specified baud rate.

- » Options 300, 1200, 2400, 9600, 19.2K, 38.4K, 57.6K, 115.2K.

☞ Terminal Type

This option allows user to select the specified terminal type. This is defined by IEEE.

- » Options VT100, VT100 8bit, PC-ANSI 7bit, VT100+, VT-UTF8

🔧 **Flow Control**

This option provide user to enable the flow control function.

- | | |
|------------|-------------------------------------|
| ▶▶ None | Not supported. |
| ▶▶ XON/OFF | Software control. |
| ▶▶ CTS/RTS | Hardware control. (Default setting) |

🔧 **Continue C.R. after POST**

This option allows user to enable console redirection after O.S has loaded.

- | | |
|--------|--|
| ▶▶ On | Enable console redirection after O.S has loaded. |
| ▶▶ Off | Disable this function. (Default setting) |

Boot




Figure 5: Boot

☞ Boot Priority Order

This field determines which type of device the system attempt to boot from after **PhoenixBIOS Post** completed. Specifies the boot sequence from the available devices. If the first device is not a bootable device, the system will seek for next available device.

Key used to view ot configure devices:

Up and Down arrows select a device.

<+> and <-> moves the device up or down.

<f> and <r> specifies the device fixed or removable.

<x> exclude or include the device to boot.

<1-4> Loads default boot sequence.

Exit




Figure 6: Exit

⚡ About This Section: Exit

Once you have changed all of the set values in the BIOS setup, you should save your changes and exit BIOS setup program. Select “Exit” from the menu bar, to display the following sub-menu.

- ⚡ Exit Saving Changes
- ⚡ Exit Discarding Changes
- ⚡ Load Setup Default
- ⚡ Discard Change
- ⚡ Save Changes


Exit Saving Changes

This option allows user to exit system setup with saving the changes.

Press <Enter> on this item to ask for the following confirmation message:

Pressing 'Y' to store all the present setting values tha user made in this time into CMOS.

Therefore, whenyou boot up your computer next time, the BIOS will re-configure your system according data in CMOS.




Exit Discarding Changes

This option allows user to exit system setup without changing any previous settings values in CMOS. The previous selection remain in effect. This will exit the Setup Utility and restart your computer when selecting this option.

Load Setup Default


This option allows user to load default values for all setup items. When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



✎ Discard Changes

This option allows user to load previous values from CMOS for all setup item.


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



☞ Save Changes

This option allows user to save setup data to CMOS.

When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



Press [Yes] to save setup data to CMOS.


Chapter 4 INTEL RAID BIOS Configuration

Configuring the Intel RAID BIOS


The Intel RAID BIOS setup lets you choose the RAID array type and which hard drives you want to make part of the array.

Entering the RAID BIOS Setup

- 1. After rebooting your computer, wait until you see the RAID software prompting you to press Ctrl + I. The RAID prompt appears as part of the system POST and boot process prior to loading the OS. You have a few seconds to press Ctrl + I before the window disappears.



Press Ctrl + I. The Intel RAID Utility - Create RAID Volume window appears (as illustrated below).



Create RAID Volume

Press **Enter** under **Create RAID Volume** to set up RAID.

Intel(R) Matrix Storage Manager option ROM V5.0.0.1011 ICH7R wRAID5
Copyright(C) 2003-04 Intel Corporation. All Rights Reserved.

[CREATE VOLUME MENU]

Name : RAID_Volume0
RAID Level : RAID0(Stripe)
Disks : Select Disks
Strip Size : 128KB
Capacity : 223.5 GB
Create Volume

[HELP]

Enter a string between 1 and 16 characters in length that can be used to uniquely identify the RAID volume. This name is case sensitive and can not contain special characters.

[↑↓]-Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

After entering the Create Volume Menu, you can set disk name with 1~16 letters (letters cannot be special characters) under **Name** item.

After setting disk name, press **Enter** to select **RAID Level**.

Intel(R) Matrix Storage Manager option ROM V5.0.0.1011 ICH7R wRAID5
Copyright(C) 2003-04 Intel Corporation. All Rights Reserved.

[CREATE VOLUME MENU]

Name : RAID_Volume0
RAID Level : RAID0(Stripe)
Disks : Select Disks
Strip Size : 128KB
Capacity : 223.5 GB
Create Volume

[HELP]

Choose the RAID level best suited to your usage model.

- RAID0- Data striped across multiple physical drives for performance.
- RAID1- Data mirrored across multiple physical drives for redundancy.
- RAID0+1- Striped volume whose segments are RAID 1 volumes. Requires four hard drives. Functionally equivalent to RAID 0+1.
- RAID5- Data and parity striped across three or more physical drives for performance and redundancy.

[↑↓]-Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

There are four RAID levels: RAID0(Stripe), RAID1(Mirror), RAID 0+1 (Striping + Mirroring) and RAID5. After selecting the RAID level, press **Enter** to select **Strip Size**.

The KB is a unit of Strip Size. You can set disk block size with this item.

The disk block size can be set from 4KB to 128KB. After you set disk block size, press **Enter** to set disk **Capacity**.

```
Intel(R) Matrix Storage Manager option ROM V5.0.0.1011 ICH7R wRAID5
Copyright(C) 2003-04 Intel Corporation. All Rights Reserved.

[ CREATE VOLUME MENU ]

Name : RAID_Volume0
RAID Level : RAID0(Stripe)
Disks : Select Disks
Strip Size : 128KB
Capacity : 223.5 GB
Create Volume

[ HELP ]

The following are typical values:
RAID 0 - 128KB
RAID 1 - 64KB
RAID 5 - 64KB

[↑↓]-Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select
```

```
Intel(R) Matrix Storage Manager option ROM V5.0.0.1011 ICH7R wRAID5
Copyright(C) 2003-04 Intel Corporation. All Rights Reserved.

[ CREATE VOLUME MENU ]

Name : RAID_Volume0
RAID Level : RAID0(Stripe)
Disks : Select Disks
Strip Size : 128KB
Capacity : 223.5 GB
Create Volume


[ HELP ]

Enter the volume capacity. The default value indicates the
maximum volume capacity using the selected disks. If less
than the maximum capacity is chosen, creation of a second
volume is needed to utilize the remaining space.


[↑↓]-Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select
```

Press **Enter** to enter **Create Volume** after setting disk capacity.


Press Enter under the Create Volume item.



An alert bar will be displayed warning you that all data on selected disks will be lost. Please press Y to complete the set-up of RAID.



After the completion, you will see the detailed information about the RAID, such as RAID level, disk block size, disk name and disk capacity, etc.



Delete RAID Volume

If you want to delete a RAID volume, please select the **Delete RAID Volume** option. Press **Enter** key and follow the instructions on the screen.

