GA-6PXSV1

LGA 2011 socket motherboard for Intel® E5-1600 series processors

User's Manual

Rev. 1001

Copyright

© 2012 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved.

The trademarks mentioned in this manual are legally registered to their respective owners.

Disclaimer

Information in this manual is protected by copyright laws and is the property of GIGABYTE. Changes to the specifications and features in this manual may be made by GIGABYTE without prior notice. No part of this manual may be reproduced, copied, translated, transmitted, or published in any form or by any means without GIGABYTE's prior written permission.

Documentation Classifications

In order to assist in the use of this product, GIGABYTE provides the following types of documentations:

- For guick set-up of the product, read the Quick Installation Guide included with the product.
- For detailed product information, carefully read the User's Manual.

For product-related information, check on our website at: http://www.gigabyte.com

Table of Contents


Box Contents			4	
GA-6PXSV	1 Mot	herb	ooard Layout	5
Chapter 1 H	Hardw	vare	Installation	8
	1-1	Insta	allation Precautions	8
•	1-2	Prod	duct Specifications	g
4			alling the CPU and CPU Cooler	
	1-3-		Installing the CPU	
	1-3-		Installing the CPU Cooler	
•	1-4		alling the Memory	
	1-4-		Four Channel Memory Configuration	
	1-4-	-2	Installing a Memory	15
	1-4-	-3	DIMM Population Table	15
1	1-5	Вас	k Panel Connectors	. 16
1	1-6	Inte	mal Connectors	. 18
Chapter 2 E	BIOS	Seti	p	.32
2	2-1	The	Main Menu	. 34
2	2-2	Adv	anced Menu	. 36
	2-2-	-1	Trusted Computing	37
	2-2-	-2	CPU Configuration	38
	2-2-	-2-1	CPU Power Management Configuration	41
	2-2-	-3	SATA Configuration	42
	2-2-	-4	USB Configuration	43
	2-2-	-5	Super IO Configuration	44
	2-2-	-6	H/W Monitor	46
	2-2-		Serial Port Console Redirection	
2	2-3	Chip	set Menu	. 49
	2-3-	-1	North Bridge Configuration	50
	2-3-	-1-1	IOH Configuration	51
	2-3-	-1-2	DIMM Information	54
	2-3-		South Bridge Configuration	
	2-3-		ME Subsystem	
2	2-4	Sec	urity Menu	. 58
2	2-5	Воо	t Option Menu	. 59
2	2-6	Воо	t Manager	. 60
2	2-7	Exit	Menu	61

Box Contents

- ☑ GA-6PXSV1 motherboard
- ✓ User's Manual
- ✓ Driver CD
- ☑ Two SATA cables
- √ I/O Shield

- The box contents above are for reference only and the actual items shall depend on the product package you obtain.
 The box contents are subject to change without notice.
- · The motherboard image is for reference only.

GA-6PXSV1 Motherboard Layout



Item	Code	Description
1	AUDIO1	Audio jacks
2	USB LAN1	LAN connector and USB connectors
3	USB_1394	1394 port and USB connectors
4	R_USB1	USB connectors
5	COM2	Serial port
6	COM1	Serial port
7	DDR3_P0_A0	DIMM slot (channel A-0)
8	DDR3_P0_A1	DIMM slot (channel A-1)
9	DDR3_P0_B0	DIMM slot (channel B-0)
10	DDR3_P0_B1	DIMM slot (channel B-1)
11	P2_CPU	8 pin power connector
12	CPU0	Intel LGA 2011 socket
13	DDR3_P0_D1	DIMM slot (channel D-1)
14	DDR3_P0_D0	DIMM slot (channel D-0)
15	DDR3_P0_C1	DIMM slot (channel C-1)
16	DDR3_P0_C0	DIMM slot (channel C-0)
17	P1	24 pin power connector
18	SYS_FAN2	System fan cable connectors
19	SATA01	SATA 6Gb/s connectors
20	SATA2345	SATA 3Gb/s connectors
21	BAT1	Battery socket
22	PWR_LED1	Power LED header
23	CLR_CMOS1	Clear CMOS jumper
24	F_PANEL1	Front panel connector
25	SYS_FAN3	System fan cable connectors
26	SAS0_3	Mini SAS connector
27	F_USB3_1	Front USB 3.0 connector
28	F_USB3_2	Front USB 3.0 connector
29	PCI	PCI slot (32bit/33MHz)
30	TPM	TPM module
31	F_1394	IEEE 1394 connector
32	BIOS_WP	BIOS write protect jumper
33 34	SSB_ME1	ME recovery jumper
35	BIOS_RVCR1 PASSWORD1	BIOS recovery jumper Clear password jumper
36		Front Audio connector
37	FAUDIO_ACZ SPDIF_JP1	SPDIF header
38	PCIE4	PCI-E slot 4 (x4 slot)
39	PCIE3	PCI-E slot 3 (x8 slot)
40	PCIE2	PCI-E slot 3 (x0 slot) PCI-E slot 2 (x16 slot/x8 signal)
40	PCIE1	PCI-E slot 2 (x16 slot)
71	I OIL I	1 OI-E 3101 1 (X 10 3101)

42	CPU_FAN1	CPU fan cable connector
43	SYS FAN1	System fan cable connector

Chapter 1 Hardware Installation

1-1 Installation Precautions

The motherboard contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Prior to installation, carefully read the user's manual and follow these procedures:

- Prior to installation, do not remove or break motherboard S/N (Serial Number) sticker or warranty sticker provided by your dealer. These stickers are required for warranty validation.
- Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components.
- When connecting hardware components to the internal connectors on the motherboard, make sure they are connected tightly and securely.
- When handling the motherboard, avoid touching any metal leads or connectors.
- It is best to wear an electrostatic discharge (ESD) wrist strap when handling electronic components such as a motherboard, CPU or memory. If you do not have an ESD wrist strap, keep your hands dry and first touch a metal object to eliminate static electricity.
- Prior to installing the motherboard, please have it on top of an antistatic pad or within an
 electrostatic shielding container.
- Before unplugging the power supply cable from the motherboard, make sure the power supply has been turned off.
- Before turning on the power, make sure the power supply voltage has been set according to the local voltage standard.
- Before using the product, please verify that all cables and power connectors of your hardware components are connected.
- To prevent damage to the motherboard, do not allow screws to come in contact with the motherboard circuit or its components.
- Make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
- · Do not place the computer system on an uneven surface.
- Do not place the computer system in a high-temperature environment.
- Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
- If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.

1-2 Product Specifications

(A) ODLI	0 1 (
CPU	 Support for Intel® Xeon® E5 series processors in the LGA2011 package L3 cache varies with CPU
Chipset	◆ Intel® BD82C604 (X79) PCH
Memory	8 x 1.5V DDR3 DIMM sockets supporting up to 64 GB (UDIMM) and 256GB (RDIMM) of system memory * Due to Windows 32-bit operating system limitation, when more than 4 GB of physical memory is installed, the actual memory size displayed will be less than 4 GB.
	Four channel memory architecture
	Support for DDR3 1600/1333/1066 MHz memory modules
	Support for ECC memory modules
LAN	1 x Intel® 82579LM supports 10/100/1000 Mbps
Expansion Slots	1 x PCI Express x16 slot, running at x16 (Gen3/PCIE1) * For optimum performance, if only one PCI Express graphics card is to be installed, be sure to install it in the PCIEX16 slot.
	◆ 1 x PCI Express x16 slot, running at x8 (Gen3/PCIE2)
	◆ 1 x PCI Express x8 slot, running at x8 (Gen3/PCIE3)
	1 x PCI Express x4 slot, running at x4 (Gen2/PCIE4)
	1 x PCI slot 32-Bit/33MHz
Onboard Audio	REALTEK ACL892 HD
Storage Interface	2 x SATA 3Gb/s connectors (SATA0/1)
	◆ 4 x SATA 3Gb/s connectors (SATA2/3/4/5)
	1 x SAS 3Gb/s connectors (SAS0_3)
USB	◆ 6 x USB 2.0/1.1 ports
(V)	$\bullet~$ Up to 4 USB 3.0 ports (4 via the USB brackets connected to the internal USB
	headers)
Internal	◆ 1 x 24-pin ATX main power connector
Connectors	1 x 8-pin ATX 12V power connector
	◆ 4 x SATA 3Gb/s connectors
	2 x SATA 6Gb/s connectors
	1 x SAS 3Gb/s connector
	1 x CPU fan header
	3 x System fan header
	1 x front panel header
	2 x USB 3.0 headers
	1 x TPM header
	1 x Front 1394 header Total all the advent
	1 x Front audio header
	1 x Power LED header

Back Panel	◆ 6 x USB 2.0/1.1 ports
Connectors	◆ 1 x RJ-45 port
	◆ 1 x IEEE 1394 port
	6 x Audio ports (4 x Line-out/ 1 x Line-in/ 1 x MIC)
	◆ 2 x COM ports
I/O Controller	• iTE IT8728 chip
Hardware	System voltage detection
Monitor	CPU/System temperature detection
	CPU/System/Power fan speed detection
	CPU overheating warning
	CPU/System/Power fan fail warning
	CPU/System fan speed control
	* Whether the CPU/system fan speed control function is supported will depend on
	the CPU/system cooler you install.
BIOS	1 x 64 Mbit flash
	◆ AMI BIOS
Form Factor	ATX Form Factor; 12 inch x 9.6 inch

 $^{^{\}star}$ GIGABYTE reserves the right to make any changes to the product specifications and product-related information without prior notice.

1-3 Installing the CPU and CPU Cooler




Read the following guidelines before you begin to install the CPU:

- Make sure that the motherboard supports the CPU.
 (Go to GIGABYTE's website for the latest CPU support list.)
- Always turn off the computer and unplug the power cord from the power outlet before installing the CPU to prevent hardware damage.
- Locate the pin one of the CPU. The CPU cannot be inserted if oriented incorrectly. (Or you may locate the notches on both sides of the CPU and alignment keys on the CPU socket.)
- · Apply an even and thin layer of thermal grease on the surface of the CPU.
- Do not turn on the computer if the CPU cooler is not installed, otherwise overheating and damage of the CPU may occur.
- Set the CPU host frequency in accordance with the CPU specifications. It is not recommended
 that the system bus frequency be set beyond hardware specifications since it does not meet the
 standard requirements for the peripherals. If you wish to set the frequency beyond the standard
 specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc.

1-3-1 Installing the CPU

A. Locate the alignment keys on the motherboard CPU socket and the notches on the CPU.



B. Follow the steps below to correctly install the CPU into the motherboard CPU socket.



- Before installing the CPU, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the CPU.
- To protect the socket contacts, do not remove the protective plastic cover unless the CPU is inserted into the CPU socket. Save the cover properly and replace it if the CPU is removed.



Push the lever closest to the "unlock" marking "

(below referred as lever A) down and away from the socket to release it.




Step 3:
Gently press lever A to allow the load plate to rise. Open the load plate. (Note: DO NOT touch the socket contacts after the load plate is



Step 5:

opened.)

Once the CPU is properly inserted, carefully replace the load plate. Then secure lever B under its retention tab. The protective plastic cover may pop off from the load plate during the process of engaging the lever. Remove the cover. Save the cover properly and always replace it when the CPU is not installed.



Push the lever closest to the "lock" marking "\(^{\text{"}}\)" (below referred as lever B) down and away from the socket. Then lift the lever.



Step 4:

Hold the CPU with your thumb and index fingers. Align the CPU pin one marking (triangle) with the pin one corner of the CPU socket (or align the CPU notches with the socket alignment keys) and carefully insert the CPU into the socket vertically.



Step 6:

Finally, secure lever A under its retention tab to complete the installation of the CPU.

1-3-2 Installing the CPU Cooler

Refer to the steps below to correctly install the CPU cooler on the motherboard. (Actual installation process may differ depending the CPU cooler to be used. Refer to the user's manual for your CPU cooler.)



Step 1: Apply an even and thin layer of thermal grease on the surface of the installed CPU



Place the cooler atop the CPU, aligning the four mounting screws with the mounting holes on the ILM. (If your cooler has a fan grill which may cause interference when you tighten the screws, remove it first and replace it after tightening the



Step 3:
Use one hand to hold the cooler and the other to tighten the screws in a diagonal sequence with a screw driver. Begin tightening a screw with a few turns and repeat with the screw diagonally opposite the one you just tightened. Then do the same to the other pair. Next, fully tighten the four screws.



Finally, attach the power connector of the CPU cooler to the CPU fan header (CPU_FAN) on the motherboard.



Please pay more attention when removing the CPU cooler because the thermal grease/tape between the CPU cooler and CPU may adhere to the CPU. Inadequately removing the CPU cooler may damage the CPU.

1-4 Installing the Memory



Read the following guidelines before you begin to install the memory:


- Make sure that the motherboard supports the memory. It is recommended that memory of the same capacity, brand, speed, and chips be used.
 - (Go to GIGABYTE's website for the latest supported memory speeds and memory modules.)
- Always turn off the computer and unplug the power cord from the power outlet before installing
 the memory to prevent hardware damage.
- Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction.

1-4-1 Four Channel Memory Configuration

This motherboard provides four DDR3 memory sockets and supports Four Channel Technology. After the memory is installed, the BIOS will automatically detect the specifications and capacity of the memory. Enabling Four Channel memory mode will double the original memory bandwidth.

The eight DDR3 memory sockets are divided into four channels and each channel has two memory sockets as following:

Channel A: DDR3_P0_A0, DDR3_P0_A1 Channel B: DDR3_P0_B0, DDR3_P0_B1 Channel C: DDR3_P0_C0, DDR3_P0_C1 Channel D: DDR3_P0_D0, DDR3_P0_D1



Due to CPU limitations, read the following guidelines before installing the memory in Four Channel mode.

- 1. Four Channel mode cannot be enabled if only one DDR3 memory module is installed.
- 2. When enabling Four Channel mode with two or four memory modules, it is recommended that memory of the same capacity, brand, speed, and chips be used for optimum performance.

1-4-2 Installing a Memory




Before installing a memory module, make sure to turn off the computer and unplug the power to cord from the power outlet to prevent damage to the memory module.

Be sure to install DDR3 DIMMs on this motherboard.

Installation Step:

- Step 1. Insert the DIMM memory module vertically into the DIMM slot, and push it down.
- Step 2. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module.
- Note: For dual-channel and four-channel operation, DIMMs must be installed in matched pairs.
- Step 3. Reverse the installation steps when you wish to remove the DIMM module.




1-4-3 DIMM Population Table

	1N or 2N	DIMM1	DIMM0
	1N	Empty	Single-Rank
	1N	Empty	Dual-Rank
	1N	Empty	Quad-Rank
R-DIMM	1N	Single-Rank	Single-Rank
T DIMIN	1N	Single-Rank	Dual-Rank
	1N	Dual-Rank	Dual-Rank
	1N	Single-Rank	Quad-Rank
	1N	Dual-Rank	Quad-Rank
	1N	Quad-Rank	Quad-Rank

	1N or 2N	DIMM1	DIMM0
	1N	Empty	Single-Rank
	1N	Empty	Dual-Rank
U-DIMM	2N	Single-Rank	Single-Rank
	2N	Single-Rank	Dual-Rank
	2N	Dual-Rank	Dual-Rank

1-5 Back Panel Connectors



Serial Port

Connects to serial-based mouse or data processing devices.

USB 2.0/1.1 Port

The USB port supports the USB 2.0/1.1 specification. Use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc.

@ IEEE 1394 Port

Serial interface standard set by Institute of Electrical and Electronics Engineers, which hasfeatures with high speed, high bandwidth and hot plug.

RJ-45 LAN Port

The Gigabit Ethernet LAN port provides Internet connection at up to 1 Gbps data rate. The following describes the states of the LAN port LEDs.

Line In (Orange)

The default Line In jack. Devices like CD-ROM, walkman etc. can be connected to Line In jack.

Line Out (Front Speaker Out/Black)

The default Line Out (Front Speaker Out) jack. Stereo speakers, earphone or front surroundspeakers can be connected to Line Out (Front Speaker Out) jack.

MIC In (Grey)

The default MIC In jack. Microphone must be connected to MIC In jack.

Surround Speaker Out (Rear Speaker Out/Blue)


The default Surround Speaker Out (Rear Speaker Out) jack. Rear surround speakers can beconnected to Surround Speaker Out (Rear Speaker Out) jack.

Center/Subwoofer Speaker Out (Green)

The default Center/Subwoofer Speaker Out jack. Center/Subwoofer speakers can be connected to Center/Subwoofer Speaker Out jack.

Side Speaker Out (Pink)

The default Side Speaker Out jack. Surround side speakers can be connected to Side SpeakerOut jack.



Connection/Speed LED:

oomioodom opood LLB.				
State	Description			
Orange	1 Gbps data rate			
Green	100 Mbps data rate			
Off	10 Mbps data rate			


Activity LED:

State	Description	
Blinking	nking Data transmission or receiving is occurring	
Off No data transmission or receiving is occ		



- When removing the cable connected to a back panel connector, first remove the cable from your device and then remove it from the motherboard.
- When removing the cable, pull it straight out from the connector. Do not rock it side to side to prevent an electrical short inside the cable connector.

1-6 Internal Connectors



1)	P1	13)	F_USB3_2
2)	P2_CPU	14)	TPM
3)	CPU_FAN1 (CPU Fan)	15)	F_1394
4)	SYS_FAN1 (System Fan)	16)	FAUDIO_ACZ
5)	SYS_FAN2 (System Fan)	17)	SPDIF_JP1
6)	SYS_FAN3 (System Fan)	18)	BAT1
7)	PWR_LED1	19)	CLR_CMOS1
8)	SATA23/SATA45	20)	PASSWORD1
9)	SATA01	21)	BIOS_RVCR1
10)	F_PANEL1	22)	SSB_ME1
11)	SAS0_3	23)	BIOS_WP
12)	F_USB3_1		



Read the following guidelines before connecting external devices:


- · First make sure your devices are compliant with the connectors you wish to connect.
- Before installing the devices, be sure to turn off the devices and your computer. Unplug the
 power cord from the power outlet to prevent damage to the devices.
- After installing the device and before turning on the computer, make sure the device cable has been securely attached to the connector on the motherboard.

1/2) P1/P2 CPU (2x12 Main Power Connector and 2x4 12V Power Connector)

With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard. Before connecting the power connector, first make sure the power supply is turned off and all devices are properly installed. The power connector possesses a foolproof design. Connect the power supply cable to the power connector in the correct orientation. The 12V power connector mainly supplies power to the CPU. If the 12V power connector is not connected, the computer will not start.




To meet expansion requirements, it is recommended that a power supply that can withstand high power consumption be used (500W or greater). If a power supply is used that does not provide the required power, the result can lead to an unstable or unbootable system.





P2_CPU:				
Pin No.	Definition			
1	GND			
2	GND			
3	GND			
4	GND			
5	+12V			
6	+12V			
7	+12V			
8	+12V			






P1:

Pin No.	Definition	Pin No.	Definition
1	3.3V	13	3.3V
2	3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS_ON
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	Power Good	20	-5V
9	5VSB (stand by +5V)	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	3.3V	24	GND

3/4/5/6) CPU FAN1/SYS FAN1/SYS FAN2/SYS FAN3 (CPU Fan/System Fan Headers)

The motherboard has a 4-pin CPU fan header (FAN1), a 4-pin (FAN4) system fan headers. Most fan headers possess a foolproof insertion design. When connecting a fan cable, be sure to connect it in the correct orientation (the black connector wire is the ground wire). The motherboard supports CPU fan speed control, which requires the use of a CPU fan with fan speed control design. For optimum heat dissipation, it is recommended that a system fan be installed inside the chassis.






- Be sure to connect fan cables to the fan headers to prevent your CPU and system from overheating. Overheating may result in damage to the CPU or the system may hang.
- These fan headers are not configuration jumper blocks. Do not place a jumper cap on the headers.

0


7) PWR_LED1 (Power LED Header)



Р	in No.	Definition
	1	MPD+
	2	GND
	3	GND

8) SATA2345 (SATA 3Gb/s Connectors)

The SATA connectors conform to SATA 3Gb/s standard and are compatible with SATA 1.5Gb/s standard. Each SATA connector supports a single SATA device.





Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND




- A RAID 0 or RAID 1 configuration requires at least two hard drives. If more than two hard drives are configured, the total number of hard drives must be an even number.
- A RAID 10 configuration requires four hard drives.

(Note) When a RAID configuration is built across the SATA 6Gb/s channels, the system performance of the RAID configuration may vary depends on the devices are connected.

9) SATA01 (SATA 6Gb/s Connectors)

The SATA connectors conform to SATA 6Gb/s standard and are compatible with SATA 3Gb/s and 1.5Gb/s standard. Each SATA connector supports a single SATA device.






Pin No.	Definition
1	GND
2	TXP
3	TXN
4	GND
5	RXN
6	RXP
7	GND

10) F PANEL (Front Panel Header)

Connect the power switch, reset switch, speaker, chassis intrusion switch/sensor and system status indicator on the chassis to this header according to the pin assignments below. Note the positive and negative pins before connecting the cables.






Pin No.	Signal Name	Definition
1	HD+	Hard Disk LED Signal anode (+)
2	MSG/PD+	Power LED Signal anode (+)
3	HD-	Hard Disk LED Signal cathode(-)
4	MSG/PD-	Power LED Signal cathode(-)
5	RST+	Reset button Signal anode (+)
6	PW+	Power Button Signal anode (+)
7	RST-	Reset button Signal cathode(-)
8	PW-	Power Button Signal cathode(-)
9	NC	No Connect
10	NC	No Connect
11	NC	No Connect
12	NC	No Connect
13	GD+	Message
14	SP+	5V Power
15	GD-	Ground
16	NC	No Connect
17	GN+	No Connect
18	NC	No Connect
19	GN-	Ground
20	SP-	Speaker Signal cathode(-)

The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly.

11) SAS0_3 (Mini SAS cable connector)

The mini SAS connectors conform to SAS 3Gb/s standard.






SAS0_3

Definition	Pin No.	Definition
GND	B1	GND
RX0+	B2	TX0+
RX0-	В3	TX0-
GND	B4	GND
RX1+	B5	TX1+
RX1-	В6	TX1-
GND	B7	GND
SIB7	B8	SIB0
SIB3	В9	SIB1
SIB4	B10	SIB2
SIB5	B11	SIB6
GND	B12	GND
RX2+	B13	TX2+
RX2-	B14	TX2-
GND	B15	GND
RX3+	B16	TX3+
RX3-	B17	TX3-
GND	A18	GND
	GND RX0+ RX0- GND RX1+ RX1- GND SIB7 SIB3 SIB4 SIB5 GND RX2+ RX2- GND RX3+ RX3-	GND B1 RX0+ B2 RX0- B3 GND B4 RX1+ B5 RX1- B6 GND B7 SIB7 B8 SIB3 B9 SIB4 B10 SIB5 B11 GND B12 RX2+ B13 RX2- B14 GND B15 RX3+ B16 RX3- B3

12/13) F_USB3_1/F_USB3_2 (USB Headers)


The headers conform to USB 3.0 specification. Each USB header can provide two USB ports via an optional USB bracket. For purchasing the optional USB bracket, please contact the local dealer.





Pin No.	Definition
1	Power
2	IntA_P1_SSRX-
3	IntA_P1_SSRX+
4	GND
5	IntA_P1_SSTX-
6	IntA_P1_SSTX+
7	GND
8	IntA_P1_D-
9	IntA_P1_D+
10	NC
11	IntA_P2_D+
12	IntA_P2_D-
13	GND
14	IntA_P2_SSTX+
15	IntA_P2_SSTX-
16	GND
17	IntA_P2_SSRX+
18	IntA_P2_SSRX-
19	Power
20	No Pin


14) TPM (TPM Module)





Pin No.	Definition	Pin No.	Definition
1	CLK_33M_TPM	11	LPC_LAD0
2	GND	12	GND
3	LPC_LFRAME_N	13	NC
4	NC	14	NC
5	LPC_RST_TPM	15	P_3V3_AUX
6	NC	16	LPC_SERIRQ
7	LPC_LAD3	17	GND
8	LPC_LAD2	18	TPM Disable
9	P3V3	19	GND
10	LPC_LAD1	20	NC

15) F 1394 (IEEE 1394 Header)






n	Definition
٠.	
	FTPA1+
	FTPA1-
	GND
	GND
	FTPB1+
	FTPB1-
	BUSVCC1
	BUSVCC1
	No Pin
1	NC
	0.

16) FAUDIO ACZ (Front Panel Audio Header)


The front panel audio header supports Intel High Definition audio (HD) and AC'97 audio. You may connect your chassis front panel audio module to this header. Make sure the wire assignments of the module connector match the pin assignments of the motherboard header. Incorrect connection between the module connector and the motherboard header will make the device unable to work or even damage it.





Pin No.	Definition
1	MIC_L_F
2	AVD_GND
3	MIC_R_F
4	AVD
5	LINE2_R_F
6	MIC2_JD
7	AVD_JD
8	No Pin
9	LINE2_L_F
10	LINE2_JD

17) SPDIF_JP1 (SPDIF Header)




1 ••••5

Pin No.	Definition
1	GND
2	No Pin
3	SPDIF In
4	SPDIF Out
5	GND

19) BAT1 (Battery)

The battery provides power to keep the values (such as BIOS configurations, date, and time information) in the CMOS when the computer is turned off. Replace the battery when the battery voltage drops to a low level, or the CMOS values may not be accurate or may be lost.





You may clear the CMOS values by removing the battery:


- 1. Turn off your computer and unplug the power cord.
- Gently remove the battery from the battery holder and wait for one minute. (Or use a metal object like a screwdriver to touch the positive and negative terminals of the battery holder, making them short for 5 seconds.)
- 3. Replace the battery.
- 4. Plug in the power cord and restart your computer.



- Always turn off your computer and unplug the power cord before replacing the battery.
- · Replace the battery with an equivalent one. Danger of explosion if the battery is replaced with an incorrect model.
- Contact the place of purchase or local dealer if you are not able to replace the battery by yourself or uncertain about the battery model
- When installing the battery, note the orientation of the positive side (+) and the negative side (-) of the battery (the positive side should face up).
- Used batteries must be handled in accordance with local environmental regulations.

20) CLR_CMOS1 (Clearing CMOS Jumper)


Use this jumper to clear the CMOS values (e.g. date information and BIOS configurations) and reset the CMOS values to factory defaults. To clear the CMOS values, place a jumper cap on the two pins to temporarily short the two pins or use a metal object like a screwdriver to touch the two pins for a few seconds.






- Always turn off your computer and unplug the power cord from the power outlet before clearing the CMOS
 values
- After clearing the CMOS values and before turning on your computer, be sure to remove the jumper cap from the jumper. Failure to do so may cause damage to the motherboard.
- After system restart, go to BIOS Setup Exit menu and load factory defaults (select Load Default Values) or manually
 - configure the BIOS settings (refer to Chapter 2, "BIOS Setup," for BIOS configurations).

21) PASSWORD1 (Clearing Supervisor Password Jumper)




- 1 1-2 Close: Normal operation. (Default setting)
- 1 2-3 Close: Clear supervisor password.

22) BIOS_RVCR1 (BIOS Recovery Jumper)




- 1 ••• 1-2 Close: Normal operation. (Default setting)
- 1 2-3 Close: BIOS recovery mode.

23) SSB ME1 (ME Recovery Jumper)



- 1 1-2 Close: Enable ME recovery.
- 1 2-3 Close: Disable ME recovery. (Default setting)

24) BIOS_WP (BIOS Write Protect Jumper)



- 1 1-2 Close: Normal operation. (Default setting)
- 1 2-3 Close: Enable BIOS write protect function.

Chapter 2 BIOS Setup

BIOS (Basic Input and Output System) records hardware parameters of the system in the CMOS on the motherboard. Its major functions include conducting the Power-On Self-Test (POST) during system startup, saving system parameters and loading operating system, etc. BIOS includes a BIOS Setup program that allows the user to modify basic system configuration settings or to activate certain system features. When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS to keep the configuration values in the CMOS.

To access the BIOS Setup program, press the <F2> key during the POST when the power is turned on. To see more advanced BIOS Setup menu options, you can press <Ctrl> + <F1> in the main menu of the BIOS Setup program.



- BIOS flashing is potentially risky, if you do not encounter problems of using the current BIOS version, it is recommended that you don't flash the BIOS. To flash the BIOS, do it with caution. Inadequate BIOS flashing may result in system malfunction.
- It is recommended that you not alter the default settings (unless you need to) to prevent system
 instability or other unexpected results. Inadequately altering the settings may result in system's
 failure to boot. If this occurs, try to clear the CMOS values and reset the board to default values.
 (Refer to the "Load Optimized Defaults" section in this chapter or introductions of the battery/
 clearing CMOS jumper in Chapter 1 for how to clear the CMOS values.)

BIOS Setup Program Function Keys

<↑><↓>	Move the selection bar to select an item
<←><→>	Move the selection bar to select the screen
<enter></enter>	Execute command or enter the submenu
<esc></esc>	Main Menu: Exit the BIOS Setup program
	Submenus: Exit current submenu
<+/->	Press the buttons to change options
<f1></f1>	Show descriptions of the function keys
<f3></f3>	Restore the previous BIOS settings for the current submenus
<f9></f9>	Load the Optimized BIOS default settings for the current submenus
<f10></f10>	Save all the changes and exit the BIOS Setup program

BIOS Setup

■ The Function of the <F10> (For the Main Menu Only)

▶ F10: Save CMOS to BIOS

This function allows you to save the current BIOS settings to a profile. You can create up to 8 profiles (Profile 1-8) and name each profile. First enter the profile name (to erase the default profile name, use the SPACE key) and then press <Enter> to complete.

Advanced

This setup page includes all the items of AMI BIOS special enhanced features.

(ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

■ Security

Change, set, or disable supervisor and user password. Configuration supervisor password allows you to restrict access to the system and BIOS Setup.

A supervisor password allows you to make changes in BIOS Setup.

A user password only allows you to view the BIOS settings but not to make changes.

■ Chipset

Northbridge and Southbridge additional features configuration.

■ Boot Options

This setup page provides items for configuration of boot sequence.

■ Boot Manager

This setup page provides configuration of boot up devices.

■ Fxit

Save all the changes made in the BIOS Setup program to the CMOS and exit BIOS Setup. (Pressing <F10> can also carry out this task.)

Abandon all changes and the previous settings remain in effect. Pressing <Y> to the confirmation message will exit BIOS Setup. (Pressing <Esc> can also carry out this task.)

2-1 The Main Menu

Once you enter the BIOS Setup program, the Main Menu (as shown below) appears on the screen. Use arrow keys to move among the items and press <Enter> to accept or enter other sub-menu.

Main Menu Help


The on-screen description of a highlighted setup option is displayed on the bottom line of the Main Menu.

Submenu Help

While in a submenu, press <F1> to display a help screen (General Help) of function keys available for the menu. Press <Esc> to exit the help screen. Help for each item is in the Item Help block on the right side of the submenu.



- If you do not find the settings you want in the Main Menu or a submenu, press <Ctrl>+<F1> to access more advanced options.
 - When the system is not stable as usual, select the Load Default Values item to set your system
 to its defaults.
 - The BIOS Setup menus described in this chapter are for reference only and may differ by BIOS version



☞ BIOS Information:

Project Version

Display version number of the project.

☞ Memory Information:

→ Total Memory

Determines how much total memory is present during the POST.

Set the date following the weekday-month-day- year format.


→ System Time

Set the system time following the hour-minute- second format.

Display the current access privilege level.

2-2 Advanced Menu

The Advanced menu display submenu options for configuring the function of various hardware components. Select a submenu item, then press Enter to access the related submenu screen.



- Legacy OpROM Support
- □ Launch PXE OpROM

Enable/Disable PXE option ROM.

Options available: Enabled/Disabled. Default setting is Disabled.

Enable/Disable storage option ROM.

Options available: Enabled/Disabled. Default setting is Enabled.

2-2-1 Trusted Computing

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Configuration

TPM SUPPORT IEmable
TPM State IEmabled
Pending operation INonel

Current Status Information

TPM Enabled Status: IDisabled1
TPM Active Status: IDeactivated1
TPM Owner Status: IUnOwned1

Enables or Disables
BIOS support for
security device. O.S.
will not show Security
Device. TCG EFI
protocol and INT1A
interface will not be
available.

X: Select Screen
14: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F3: Previous Values
F9: Optimized Defaults
F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

☞ TPM Support

Select Enabled to activate TPM support feature.

Options available: Enabled/Disabled. Default setting is Enabled.

TPM State

Select Enabled to activate TPM State function.

Options available: Enabled/Disabled. Default setting is **Enabled**.

→ Pending TPM Support

Schedule TPM operation.

Options available: None/Enable Take Ownership.

☐ Current TPM Status Information.

Display current TPM status information.

(Note) This item is present only if TPM module is attached.

2-2-2 CPU Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced **CPU** Configuration Socket specific CPU Information CPU Speed 64-bit Supported Active Processor Core [A11] Limit CPUID Maximum [Disabled] Execute Disable Bit [Enabled] Intel Virtualization [Enabled] X: Select Screen 14: Select Item CPU Power Management Configuration Enter: Select +/-: Change Opt. F1: General Help F3: Previous Values F9: Optimized Defaults F10: Saue ESC: Exit Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc. Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced

Intel(R) Xeon(R) CPU	E5-1607 0 @ 3.00GHz	
CPU Signature	20646	
Microcode Patch	60f	
Max CPU Speed	3000 MHz	
Min CPU Speed	1200 MHz	
Processor Cores	4	
Intel HT Technology	Not Supported	
Intel VT-x Technology	Supported	
The second secon		><: Select Screen
L1 Data Cache	32 kB x 4	↑↓: Select Item
L1 Code Cache	32 kB x 4	Enter: Select
L2 Cache	256 kB x 4	+/-: Change Opt.
L3 Cache	10240 kB	F1: General Help
	iberiation spin =)	F3: Previous Values
		F9: Optimized Defaults
		F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

→ Socket 0 Information

→ CPU Signature

Displays the processor ID information.

Microcode Patch

Display Microcode patch.

→ Max CPU Speed

Display the maximum processor speed.

Min CPU Speed

Display the minimum processor speed.

Processor Cores

Display the information of the processor core.

□ Intel HT Technology

Display Intel Hyper Threading Technology function support information.

□ Intel VT-x Technology

Display Intel Virtualization Technology function support information.

☐ Cache Information

→ I 1 Data Cache

Display the information of L1 Data Cache.

☐ L1 Code Cache

Display the information of L1 Code Cache.

→ L2 Cache

Display the information of L2 Cache per Core.

→ L3 Cache

Display the information of total L3 Cache per socket.

Allows you to determine whether to enable all CPU cores.

Options available: All/1/2/3. Default setting is All.

→ Limit CPUID Maximum

When enabled, the processor will limit the maximum COUID input values to 03h when queried, even if the processor supports a higher CPUID input value.

When disabled, the processor will return the actual maximum CPUID input value of the processor when queried.

Options available: Enabled/Disabled. Default setting is Disabled.

□ Execute Disable Bit


When enabled, the processor prevents the execution of code in data-only memory pages. This provides some protection against buffer overflow attacks.

When disabled, the processor will not restrict code execution in any memory area. This makes the processor more vulnerable to buffer overflow attacks.

→ Intel Virtualization Select whether to enable the Intel Virtualization Technology function. VT allows a single platform to run multiple operating systems in independent partitions. Options available: Enabled/Disabled. Default setting is Enabled.

(Note) This item is present only if you install a CPU that supports this feature. For more information about Intel CPUs' unique features, please visit Intel's website.

2-2-2-1 CPU Power Management Configuration




→ Power Technology

Configure the power management features.

Options available: Disable/Energy Efficient/Custom. Default setting is **Energy Efficient**.

2-2-3 SATA Configuration



SATA Port 0/1/2/3/4/5

Press [Enter] to view the installed HDD devices.

→ SATA Mode

Select the on chip SATA type.

IDE Mode: When set to IDE, the SATA controller disables its RAID and AHCI functions and runs in the IDE emulation mode. This is not allowed to access RAID setup utility.

RAID Mode: When set to RAID, the SATA controllerenables both its RAID and AHCI functions. You will be allows access the RAID setup utility at boot time.

ACHI Mode: When set to AHCI,the SATA controller enables its AHCI functionality. Then the RAID function is disabled and cannot be access the RAID setup utility at boot time.

Options available: IDE/RAID/ACHI, Default setting is ACHI Mode.

2-2-4 USB Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced USB Configuration Enable/Disable legacy USB support. Detected HSB Devices 1 Keyboard, 2 Hubs USB3.0 Support [Enabled] XHCI Hand-off [Enabled] 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F3: Previous Values F9: Optimized Defaults F10: Save ESC: Exit Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

→ Detected USB Devices

Display the information of detected USB devices.

□ Legacy USB Support

Enables or disables support for legacy USB devices.

Options available: Enabled/Disabled. Default setting is Enabled.

→ USB 3.0 Support

When enabled, the onboard USB 3.0 device will function normally.

Options available: Enabled/Disabled. Default setting is Enabled.

This is a workround for OS without xHCl hand-off support. The xHCl ownership change should be claimed by XHCl driver.

2-2-5 Super IO Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced

Super IO Configuration

Super IO Chip IT8728
Serial Port 1 Configuration

► Serial Port 2 Configuration

Set Parameters of Serial Port 1 (COM1)

><: Select Screen
†4: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F3: Previous Values
F9: Optimized Defaults
F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Advanced

Serial Port 1 Configuration

0 1 1 1 1

Truap rear

Device Settings

IO=3F8h; IRQ=4;

Change Settings

Device Mode

[Auto]
[Standard Serial Po...]

X: Select Screen ↑↓: Select Item

Enable or Disable

Serial Port (COM)

Enter: Select

+/-: Change Opt.

F1: General Help F3: Previous Values

F9: Optimized Defaults

F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

→ Super IO Chip

DIsplay super IO chip information.

When enabled allows you to configure the serial port settings. When set to Disabled, displays no configuration for the serial port.

Options available: Enabled/Disabled. Default setting is Enabled.

□ Device Settings

Displays Serial Port 1/2 device configuration information.

Change Settings

Change Serial Port 1/2 device settings. When set to Auto allows the server's BIOS or OS to select a configuration.

Options available: Auto/IO=3F8; IRQ=4/IO=3F8h; IRQ=3,4,5,6,7,10,11,12/

IO=2F8h; IRQ=3,4,5,6,7,10,11,12 /IO=3E8h; IRQ=3,4,5,6,7,10,11,12/IO=2E8h; IRQ=3,4,5,6,7,10,11,12.


→ Device Mode

Change the Serial Port mode.

Options available: Standard Serial Port Mode (Normal Mode)/IrDA 1.0 (HP SIR) Mode (High Speed)/ ASKIRfdgdq Mode.

2-2-6 H/W Monitor

Press Enter to view the Hardware Monitor screen which displays a real-time record of the CPU/system temperature, fan speed, and voltage. Items on this window are non-configurable.



Displays current CPU, System, and rear edge of motherboard temperature.

CPU/System FAN1/2/3 Speed (RPM)

Displays current CPU and system fan speed.

□ Current Voltage: P_VCCP_P0/P_VCCQ_AB/P12V/P5V/P_PLL_CPU0/
 □ VCCP_P0/P_VCCQ_AB/P12V/P5V/P_PLL_CPU0/
 □ VCCP_P0/P_VCCQ_AB/P12V/P5V/P_PU0/
 □ VCCP_P0/P_VCQ_AB/P12V/P5V/P_PU0/
 □ VCCP_P0/P_VCQ_AB/P12V/P5V/P_PU0/
 □ VCCP_P0/P_VCQ_AB/P12V/P5V/P_PU0/
 □ VCCP_P0/P_VCQ_AB/P12V/P5V/P_PU0/
 □ VCCP_P0/P_VCQ_AB/P12V/P_PU0/
 □ VCCP_P0/P_VCQ_P0/P_VCQ_P0/P_PU0/
 □ VCCP_P0/P_VCQ_P0/P_PU0/P_PU0/P_PU0/P_PU0/P_PU0/P_PU0/P_PU0/P_PU0/P

P VDDQ CD/P 1V5 SSB/VBAT

Displays the current CPU and system voltages.

2-2-7 Serial Port Console Redirection

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

COM1

Console Redirection [Enabled]

Console Redirection Settings

COM2

Console Redirection [Disabled]

► Console Redirection Settings

Serial Port for Out-of-Band Management/ Windows Emergency Management Services (EMS)

Console Redirection [Disabled]

▶ Console Redirection Settings

Console Redirection Enable or Disable.

×: Select Screen

14: Select Item Enter: Select

+/-: Change Opt.

F1: General Help F3: Previous Values

F9: Optimized Defaults F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

COM1

Console Redirection Settings

Terminal Type IANSII
Bits per second [19200]
Data Bits [8]
Parity [None]
Stop Bits [1]
Flow Control [None]
UT-UTF8 Combo Key Sup [Enabled]

Emulation: ANSI: Extended ASCII char

set. VT100: ASCII char set. VT100+: Extends

VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8

encoding to map Unicode chars onto 1 or more

><: Select Screen ↑↓: Select Item

Enter: Select +/-: Change Opt. F1: General Help

F3: Previous Values F9: Optimized Defaults F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

Select whether to enable console redirection for specified device. Console redirection enables users to manage the system from a remote location.

Options available: Enabled/Disabled. Default setting is **Disabled**.

Console Redirection Settings

Press [Enter] to enter advanced meun for console redirection settings.

Terminal Type

Select a terminal type to be used for console redirection.

Options available: VT100/VT100+/ANSI /VT-UTF8.

Bits per second

Select the baud rate for console redirection.

Options available: 9600/19200/57600/115200.

Data Bits

Select the data bits for console redirection

Options available: 7/8.

→ Parity

A parity bit can be sent with the data bits to detect some transmission errors.

Even: parity bi is 0 if the num of 1's in the data bits is even.

Odd: parity bit is0if num of 1's the data bits is odd.

Mark: parity bit is always 1. Space: Parity bit is always 0.

Mark and Space Parity do not allow for error detection.

Options available: None/Even/Odd/Mark/Space.

Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

Options available: 1/2.

→ Flow Control


Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

Options available: None/Hardware RTS/CTS.

Enable/Disable VT-UTF8 Combo Key Support.

2-3 Chipset Menu

The Chipset menu display submenu options for configuring the function of North Bridge and South Bridge. Select a submenu item, then press Enter to access the related submenu screen.



2-3-1 North Bridge Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Chinset IOH Configuration Page Compatibility RID [Enabled] Memory Configuration Total Memoru 1024 MB (DDR3) Current Memory Mode Independent X: Select Screen Current Memory Speed 1066 MHz ↑↓: Select Item Memory Mode [Independent] Enter: Select DIMM Information +/-: Change Opt. F1: General Help F3: Previous Values F9: Optimized Defaults F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc

☐ Compatibility RID

Enable/Disable Compatibility RID function.

Options available: Enabled/Disabled. Default setting is Enabled.

☐ Total Memory

Determines how much total memory is present during the POST.

Current Memory Mode

Displays the cuurent memory mode. Memory mode can be determined in **Memory Mode** item.

□ Current Memory Speed

Displays the cuurent memory speed.

→ Memory Mode

Determine the memory mode.

When set to Indendent mode, all DIMMs are available to the operation system.

When set to Mirroring mode, the motherboard maintains two identical (redundant) copies of all data in memory.

When set to Lockstep mode, the motherboard uses two areas of memory to run the same set of operations in parallel.

When set to Sparing mode, a preset threshold of coorectable errors is used to trigger fail-over.

The spare memory is put online and used as active memory in place of the failed memory.

Options available: Indpendent /Mirroring/ Lockstep/Sparing.

Chipse		American Megatrends, Inc.
Intel(R) VT for Directe	d I/O Configuration	▲ Intel(R) VI for Directed I/O Configuration
Intel (R) I/OAT DCA Support UGA Priority TargetUGA Gen3 Equalization WA' IOH Resource Selectio MMIOH Size IOH 0 PCIe port Bifurca IOU1 - PCIe Port PORT 1A Link Speed IOU2 - PCIe Port PORT 2A Link Speed	[Disabled] [Enabled] [Offboard] Uga From CPU 0 [Disabled] [Auto] [64G] tion Control [x8] [GEN2] [x16] [GEN2]	><: Select Screen †4: Select Item Enter: Select +/-: Change Opt. F1: General Help F3: Previous Values F9: Optimized Defaults F10: Saue ESC: Exit
IOU3 - PCIe Port	[x8x8]	erican Megatrends, Inc.
Aptio Setup Utility	- Copyright (C) 2011	American Megatrends, Inc.
Chipse		
DCA Support	[Enabled]	▲ Select Target Link
VGA Priority TargetVGA Gen3 Equalization WA' IOH Resource Selectio MMIOH Size	[Offboard] Vga From CPU 0 [Disabled] [Auto] [646]	Speed Gen1, Gen2 or Gen3
VGA Priority TargetVGA Gen3 Equalization WA' IOH Resource Selectio	COffboardJ Vga From CPU 0 DisabledJ [Auto] [646]	

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc. Chipset Intel(R) UI-d DisabledI Enable/Disable Intel(R) Virtualization Technology for Directed I/O. ><: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F3: Previous Values F9: Optimized Defaults F10: Save ESC: Exit

Version 2.14.1216. Copyright (C) 2011 American Megatrends, Inc

→ IOH Configuration

□ Intel(R) VT for Directed I/O Configuration
 □

☐ Intel(R) I/OAT

Enable/Disable Intel OAT Technology function.

Options available: Enabled/Disabled. Default setting is Disabled.

→ DCA Support

Enable/Disable Direct Cache Access Support function.

Options available: Enabled/Disabled. Default setting is Enabled.

▽ VGA Priority

Define the display device priority.

Options available: Onboard/Offboard. Default setting is Offboard.

Target VGA

Displays the information of Target VGA.

Gen3 Equalization WA's

Enable/DIsable the support for Gen3 Equalization Workaround.

Options available: Enabled/Disabled. Default setting is Disabled.

IOH Resource Selection Type

When this item is set to Auto, PCI resources allocation across multiple IOHs is optimized automatically based on the PCI device present. When this item is set to Manual, user can force the PCI resource allocation across multiple IOHs based rations.

Options available: Auto/Manual. Default setting is Auto.

→ MMIOH Size

Options available: 1GB/2GB/4GB/8GB/16GB/32GB/64GB/128GB.

→ IOH 0/1 PCle port Bifurcation Control

→ IOU1 - PCle Port

Options available: x4x4/x8.

→ PORT 1A Link Speed

Options available: Gen1/Gen2.

→ IOU2 - PCle Port

Options available: x4x4x4x4x4x4x4x8/x8x4x4/x8x8/x16.

→ PORT 2A Link Speed

Options available: Gen1/Gen2/Gen3.

→ IOU3 - PCle Port

Options available: x4x4/x8.


→ PORT 3A Link Speed

Options available: Gen1/Gen2/Gen3.

□ Intel(R) VT-d

Enable/Disable Intel VT-d Technology function.

2-3-1-2 DIMM Information




- → DIMM Information:
- DIMM Group: CPU Socket 0 DIMM Information CPU Socket 0:

DDR3_P0_A0/DDR3_P0_A1/DDR3_P0_B0/DDR3_P0_B1 Status DDR3_P0_C0/DDR3_P0_C1/DDR3_P0_D0/DDR3_P0_D1 Status

The size of memory installed on each of the DDR3 slots.

2-3-2 South Bridge Configuration



→ PCH Information:

Name/Stepping Information

Displays the name and stepping information of the south bridge.

PCH Compatibility RID

Enable/Disable the support for PCH Compatibility Revision ID (CRID) functionality.

Options available: Enabled/Disabled. Default setting is Disabled.

→ GbE Controller

Enable/Disable onboard GbF LAN controller

Options available: Enabled/Disabled. Default setting is Enabled.

→ Wake on Lan from S5

Enable/Disable GbE control PXE in S5.

Options available: Enabled/Disabled. Default setting is Enabled.

☐ Restore on AC Power Loss.

Defines the power state to resume to after a sys- tem shutdown that is due to an interruption in AC power. When set to Last State, the system will return to the active power state prior to shutdown. When set to Stay Off, the system remains off after power shutdown.

Options available: Last State/Stay Off/Power On. The default setting depends on the BMC setting.

□ Deep Power off Mode

Enable/Disable Deep Power off Mode.

→ Onboard SATA RAID oprom

Enable/Disable onboard SATA RAID option ROM.

Options available: Enabled/Disabled. Default setting is **Enabled**.

→ Audio Configuration


→ Azalia HD Audio

Enable/Disable onboard audio controller.

Options available: Enabled/Disabled. Default setting is **Enabled**.

Enable/Disable onboard audio HDMI controller.

2-3-3 ME Subsystem




ME Subsystem Configuration

Enable/Disable ME subsystem configuration.

2-4 Security Menu

The Security menu allows you to safeguard and protect the system from unauthorized use by setting up access passwords.



There are two types of passwords that you can set:

· Administrator Password

Entering this password will allow the user to access and change all settings in the Setup Utility.

User Password

Entering this password will restrict a user's access to the Setup menus. To enable or disable this field, a Administrator Password must first be set. A user can only access and modify the System Time. System Date, and Set User Password fields.

Administrator Password


Press Enter to configure the Administrator password.

→ User Password

Press Enter to configure the user password.

2-5 Boot Option Menu

The Boot menu allows you to set the drive priority during system boot-up. BIOS setup will display an error message if the drive(s) specified is not bootable.



→ Boot Priority Order

☞ Boot Option

Press Enter to configure the boot priority.

By default, the server searches for boot devices in the following secquence:

- Hard drive.
- UEFI device.
- 3. Optical disc drive.
- 4. Removable device.

→ Bootup NumLock State

Enable or Disable Bootup NumLock function.

Options available: On/Off. Default setting is On.

Quiet Boot


Enables or disables showing the logo during POST.

Options available: Enabled/Disabled. Default setting is Disabled.

Interrupt 19 is the software interrupt that handles the boot disk function. When enabled, this BIOS feature allows the ROM BIOS of those host adaptors to "capture" Interrupt 19 during the boot process so that drives attached to these adaptors can function as bootable disks.

2-6 Boot Manager

The Boot manager menu allows you to specify the boot-up drive. BIOS setup will display an error message if the drive(s) specified is not bootable.




→ Built-in EFI Shell

Press Enter to configure the device as the boot-up drive.

2-7 Exit Menu

The Exit menu displays the various options to quit from the BIOS setup. Highlight any of the exit options then press **Enter**.



→ Save Changes and Exit

Saves changes made and close the BIOS setup.

Options available: Yes/No.

□ Discard Changes and Exit

Discards changes made and close the BIOS setup.

Options available: Yes/No.

→ Save Changes

Saves changes made in the BIOS setup.

Options available: Yes/No.

Discard Changes

Discards all changes made in the BIOS setup.

Options available: Yes/No.

☐ Load Default Values

Loads the default settings for all BIOS setup parameters. Setup Defaults are quite demanding in terms of resources consumption. If you are using low-speed memory chips or other kinds of low-performance components and you choose to load these settings, the system might not function properly.

Options available: Yes/No.

☐ Save as User Default Values

Saves as user default and close the BIOS setup. Options available: Yes/No.

□ Load User Default Values

Loads the user default settings for all BIOS setup parameters. Options available: Yes/No.