

GIGABYTE
Remote Management Console
User's Guide

Version: 1.0

Table of Contents

Using Your GIGABYTE Remote Management Console.....	2
Software Install	3
Prerequisites on remote management PC.....	3
Install Java Tool.....	3
Install UPnP tool.....	4
Search GIGABYTE server by using UPnP tool.....	5
GIGABYTE Remote Management Console Overview	6
Enter GIGABYTE Remote Management Console	7
System Information.....	8
Server Health	9
Configuration	13
Remote Control.....	20
Maintenance	22
KVM Function Description	24
Video Menu.....	24
Keyboard Menu.....	25
Mouse.....	26
Option	27
Device	28
Help.....	28

Using Your GIGABYTE Remote Management Console

The GIGABYTE Remote Management Console has a user-friendly Graphics User Interface (GUI) called the GIGABYTE Remote Management Console GUI. It is designed to be easy to use. It has a low learning curve because it uses a standard Internet browser. You can expect to be up and running in less than five minutes. This chapter allows you to become familiar with the GIGABYTE Remote Management Console GUI's various functions. Each function is described in detail.



Software Install

Prerequisites on remote management PC

Before installing Java tool and UPnP tool, please check your system for the following required configuration requirements:

- Supported environments: Microsoft Windows Vista, XP, Windows 2000, 2003, 2008 Server.
- JAVA Recommended Version 6 Update 12 (file size: ~ 7 MB)

Install Java Tool

Please follow the instruction to install Java in Windows operating system.

1. Go to <http://www.java.com>
2. Click Download on the upper right corner of the home page.
3. Click see all Java downloads
4. Click Windows XP/Vista/2000/2003/2008 Online
5. Choose the folder location. (Save the file to a known location on your computer)
6. Click Save.
7. Click Yes to replace.
8. Verify that the
 - Name of the file is **jre-6u12-windows-i586-p.exe or later version**
 - Size is approximately 7MB.
9. Close all applications including the browser.
10. Double-click on the saved file icon to start the installation process.

Install UPnP tool

Please follow the instruction to get Intel Device Spy for UPnP Technologies tool:

Download Device Spy for UPnP Technologies from the Intel website: <http://www.intel.com/>

Do a search for the following phrase: **Intel® Tools for UPnP Technologies**

The download page changes from time to time, so doing a search will give you the best results. Download the compressed file and uncompress it. The file will have a filename similar to the following:

[Download, Windows installer, .NET CLR 2.0 runtime required \(ZIP 3.7MB\)](#)

The ZIP file will contain an EXE file that will have a filename similar to the following:

Intel_Tools_4UT_v1768.exe

After you run the EXE file, the **Device Spy.exe** file will become available. Device Spy.exe is the file that contains the *Intel Device Spy for UPnP Technologies* program.


Device Spy: Intel's Universal Control Point (UCP). This tool readily tests "action" invocations and events. Device Spy also traces packets sent to UPnP devices.

For more information on how to use Intel Device Spy for UPnP Technologies see the documentation provided with it.


Search GIGABYTE server by using UPnP tool

Please follow the instruction to search GIGABYTE server by using UPnP tool:


1. Download the *Intel Device Spy for UPnP Technologies* program onto your remote client system. Run the *Intel Device Spy for UPnP Technologies* program.
2. The name GIGABYTE Remote Management Console Device will display in tree under UPnP Devices.



3. Select the GIGABYTE Remote Management Console Device to view its properties.
4. Click on the IP address located in the Presentation URL field to connect to your GIGABYTE server.
5. System will prompt a window for user name and password. Type "root" for username and "superuser" for password. Click "Login" button and you will successfully log into your GIGABYTE Remote Management Console.



GIGABYTE Remote Management Console Overview



1. There are two methods to prompt to the entrance of GIGABYTE Remote Management Console. You can open the UPnP tool (described in previous chapter), and click on the server. When the server is found, click on the "Presentation URL", and System will prompt a window for user name and password.
Or, you may open an IE browser and type in your identified IP. The IP address can be found by UPnP discovering.
2. A dialog box will be prompted to enter Username and password.
3. Enter the following values:
Username: **root**
Password: **superuser**




The default user name and password are in lower-case characters.



When you log in using the root user name and password, you have full administrative powers. It is advised that once you log in, you change the root password.


Enter GIGABYTE Remote Management Console

After you successfully log into your GIGABYTE Remote Management Console, you are greeted with the GIGABYTE Remote Management Console GUI.



System Status


System Status shows the current remote client system health status. It contains three different statuses: Normal, Warning, and Critical. Each status will be described in the following:



Normal: All sensors are normal and there's no sensor that has any alert.



Warning: There's at least one sensor that has warning alert.



Critical: There's at least one sensor that has critical alert.


Priority: Critical > Warning > Normal

System Information

System Information contains two major system information: Summary and FRU reading. Summary display the general system information, and FRU reading shows the major system component FRU information.

Summary

In the summary screen, it displays the information of IP address & MAC of BMC dedicated NIC, BMC F/W version, and GIGABYTE server power status.



The screenshot shows the GIGABYTE System Information web interface. The header includes the GIGABYTE TECHNOLOGY logo and the website URL www.gigabyte.com. The navigation menu contains System Status, System Information, Server Health, Configuration, Remote Control, Maintenance, and Logout. The System Status is indicated as Normal. The main content area is titled System Information and contains a Summary section with the following details:

- Device Power Status : On
- Firmware Revision : 0.09
- FRU Revision : 00.02
- SDR Revision : 00.02
- IP address : 10.1.111.27
- MAC address : 00:22:44:36:4F:49
- Firmware Build Time : May 6 2009 17:37:23

Below the summary, the Chassis locator (LED) State is shown as turn off, with a button to turn on.

© 2009 American Megatrends Inc.

FRU Reading

User also can get the FRU information by selecting FRU Reading from the function list of left window.

After selecting FRU Reading, it shows all FRU information. Or, you can select single FRU information by drop-down menu. FRU information includes: Chassis information, Board information, and Product information.

GIGABYTE TECHNOLOGY www.gigabyte.com **GIGABYTE**

System Status: **Normal** | System Information | Server Health | Configuration | Remote Control | Maintenance | Logout | HELP

System Information
This section contains general information about the system.

FRU Readings
This page displays system FRU information, including readings and status.

Select a FRU type category:
All FRU

FRU Information

FRU Device ID: 0

Chassis Info:
Chassis Type: Tower
Chassis Part Number: 0123456789AB
Chassis Serial Number: 01234567890123456789AB

Board Info:
Language: English
MfgDateTime: 2009/5/6 16:31
Board Product Name: GA_7TESH2
Board Serial Num: 01234567890123456789AB
Board Part Num: 0123456789AB

Product Info:

© 2009 American Megatrends Inc.

Server Health

This section shows you data related to the sensor's health, such as sensor reading and the event log.

GIGABYTE TECHNOLOGY www.gigabyte.com **GIGABYTE**

System Status: **Normal** | System Information | **Server Health** | Configuration | Remote Control | Maintenance | Logout | HELP

Server Health
This section shows you data related to the server's health, such as sensor readings and the event log.

Options

Sensor Readings	See the readings from the various sensors
Sensor Readings with Thresholds	See the readings from the various sensors, with thresholds included in the table
Event Log	See the events written to the event log

© 2009 American Megatrends Inc.

Sensor Readings: It reads all the sensor information of system. It lists the System's Voltage, System /CPU FAN, and CPU/System Temperature sensor information. You can select single sensor information from the drop-down list.

Sensor Display Color: On each sensor displays different color. The color indicates the health status of specified device.

The green color indicates the device is health and there's no sensor that has any alert.

The amber color indicates the device is at least one sensor that has warning alert.

The red color means the device is at least one sensor that has critical alert.

The screenshot displays the Gigabyte System Health monitoring interface. At the top, the Gigabyte logo and navigation menu are visible. The main content area shows the 'Server Health' status as 'Normal' with a green checkmark icon. Below this, the 'Sensor Readings' section is active, displaying a table of sensor data. The table includes columns for Name, Status, and Reading. A 'Refresh' button and a 'Show Thresholds' button are located at the bottom of the table. The footer of the page indicates '© 2009 American Megatrends Inc.'

Name	Status	Reading
CPU1 Temp	Normal	45 degrees C
CPU2 Temp	Not Available	Not Available
IOH Temp	Normal	48 degrees C
ICH10 Temp	Normal	41 degrees C
SYS Temp	Normal	39 degrees C
P_3V3_AUX	Normal	3.394 Volts
P_1V8_AUX	Normal	1.862 Volts
P12V	Normal	12.238 Volts
P5V	Normal	5.243 Volts
P2V2	Normal	2.270 Volts

Threshold:

You can click “Show Thresholds” to show the thresholds of every sensor. It displays the Low Non-Critical (NC), High Non-Critical (NC), High Critical Threshold (CT) threshold information, and these items can not be modified. When each threshold matches alert level, system will send the alert to the specified destinations. To configure the specified destination, please go to **Alert** section.

The screenshot shows the Gigabyte Server Health monitoring interface. The top navigation bar includes 'System Status', 'System Information', 'Server Health', 'Configuration', 'Remote Control', 'Maintenance', and 'Logout'. The 'Server Health' section is active, showing a 'Normal' status. Below this, there are 'Options' like 'Server Health', 'Sensor Readings', and 'Event Log'. The main content area is titled 'Sensor Readings' and contains a table of sensor data. The table has columns for Name, Status, Reading, and various threshold values (Low NR, Low CT, Low NC, High NC, High CT, High NR). The sensors listed include CPU1 Temp, CPU2 Temp, IOH Temp, ICH10 Temp, and SYS Temp. At the bottom of the table, there are 'Refresh' and 'Hide Thresholds' buttons.

Name	Status	Reading	Low NR	Low CT	Low NC	High NC	High CT	High NR
CPU1 Temp	Normal	44 degrees C	0 degrees C	0 degrees C	0 degrees C	80 degrees C	90 degrees C	0 degrees C
CPU2 Temp		Not Available	0 degrees C	0 degrees C	0 degrees C	80 degrees C	90 degrees C	0 degrees C
IOH Temp	Normal	49 degrees C	0 degrees C	0 degrees C	0 degrees C	63 degrees C	67 degrees C	0 degrees C
ICH10 Temp	Normal	40 degrees C	0 degrees C	0 degrees C	0 degrees C	63 degrees C	67 degrees C	0 degrees C
SYS Temp	Normal	40 degrees C	0 degrees C	0 degrees C	0 degrees C	63 degrees C	67 degrees C	0 degrees C

To refresh the sensor status, just click “Refresh” tab to re-read the sensor state.

Event Log: It records the event when sensor has abnormal state. When the log matches the pre-defined alert, the system will send out the notification automatically if it is pre-configured.

GIGABYTE TECHNOLOGY www.gigabyte.com GIGABYTE

System Status | System Information | **Server Health** | Configuration | Remote Control | Maintenance | Logout HELP

Normal

Server Health
This section shows you data related to the server's health, such as sensor readings and the event log.

Options

- Server Health
 - Sensor Readings
 - Event Log
- Refresh Page
- Logout

Event Log

Below is a table of the events from the system's event log. You can choose a category from the pull-down box to filter the events, and also sort them by clicking on a column header.

Select an event log category:
Sensor-Specific Events

Event Log: 84 event entries

Event ID	Time Stamp	Sensor Number	Sensor Name	Sensor Type	Description
93	05/15/2009 11:12:09	135	FAN_SYS6	Fan	Lower Critical - Going Low - Asserted
92	05/15/2009 11:12:09	135	FAN_SYS6	Fan	Lower Non-Critical - Going Low - Asserted
91	05/15/2009 11:12:09	134	FAN_SYS5	Fan	Lower Critical - Going Low - Asserted
90	05/15/2009 11:12:09	134	FAN_SYS5	Fan	Lower Non-Critical - Going Low - Asserted
89	05/15/2009 11:12:09	133	FAN_SYS4	Fan	Lower Critical - Going Low - Asserted
88	05/15/2009 11:12:09	133	FAN_SYS4	Fan	Lower Non-Critical - Going Low - Asserted

© 2009 American Megatrends Inc.

Configuration

GIGABYTE TECHNOLOGY www.gigabyte.com

System Status | System Information | Server Health | **Configuration** | Remote Control | Maintenance | Logout

Configuration
Use these pages to configure various settings, such as alerts, users, or network.

Options

- Configure
 - Alerts
 - LDAP
 - Mouse Mode
 - Network
 - Remote Session
 - SMTP
 - SSL
 - Users
 - Event Action

Refresh Page | Logout

Options

Alerts	Add, edit or remove alert destinations
LDAP	Configure settings to authenticate and access the LDAP server
Mouse mode	Change the mouse mode
Network	See the MAC address or change network settings, including dynamic and static IP assignment
Remote Session	Configure Remote session settings
SMTP	Configure the SMTP email server
SSL Certificate	See the default certificate and private key, or upload an SSL Certificate
Users	Add, edit, or remove users
Event Action	Each sensor has an operating range. When a sensor changes state, users can choose to initiate some type of action.

© 2009 American Megatrends Inc.

Alert: When the pre-defined alert level happened, system will send the alert by e-mail or by SNMP.

The e-mail address or the destination server can be configured. By selecting an alert and press the **Modify** button to configure it (see the following description about how to configure it), or **Send Test Alert** button to send a test alert to the destinations.

Click Delete button to delete the alert destinations

Configuration
Use these pages to configure various settings, such as alerts, users, or network.

List of Alerts

Below is a list of the configured alert destinations. You can select an alert and press the Modify button to configure it, or Send Test Alert to send a test alert to the destination.

LAN Channel: 1 | Alert Table: 15 entries

Alert #	Alert Level	Destination Address
1	Disable All	Not Configured
2	Disable All	Not Configured
3	Disable All	Not Configured
4	Disable All	Not Configured
5	Disable All	Not Configured
6	Disable All	Not Configured
7	Disable All	Not Configured
8	Disable All	Not Configured
9	Disable All	Not Configured
10	Disable All	Not Configured
11	Disable All	Not Configured

In this section, you can configure the alert destinations. By selecting an alert and press the **Modify** button to configure it, or **Send Test Alert** button to send a test alert to the destinations.

Click Delete button to delete the alert destinations

In this section, you can configure the method that the alert deliveries. If you want the alert to be sent by SNMP, you may select “SNMP Trap” as alert type, specify the event severity (such as Critical or Warning), and specify the Destination IP.

If you want the alert to be sent by email, you may select “e-mail” as alert type, specify the event severity (such as Critical or Warning), and specify the e-mail address, subject and message. After you finished the configuration, click ‘Save’ to save the settings or ‘Cancel’ to cancel all settings.

Modify Alert

Enter the information for the alert below and press Save.

LAN Channel Number: 1

Alert Type: Snmp Trap

Event Severity: Critical

Destination IP: Not Configured

Email Address:

Subject:

Message:

Save Cancel

LDAP: It can download user list of LDAP server then create GIGABYTE Remote Management Console user account from this list directly.

Check the box below to enable LDAP authentication and enter the required information to access the LDAP server. Press the **Save** button to save your changes.

The screenshot shows a web interface for configuring LDAP settings. At the top, there is a grey header with the title "Configuration" and a subtitle "Use these pages to configure various settings, such as alerts, users, or network." Below this is a sub-header "LDAP Settings". The main content area contains the following elements:

- A paragraph: "Check the box below to enable LDAP authentication and enter the required information to access the LDAP server. Press the Save button to save your changes."
- A checkbox labeled "Enable LDAP Authentication" which is currently unchecked.
- A "Port" field with a text input containing "389".
- An "IP Address" field with an empty text input.
- A "Bind Password" field with an empty text input.
- A "Bind DN" field with an empty text input.
- A "Searchbase" field with an empty text input.
- A "Save" button at the bottom left of the form area.

Mouse mode: There are two types for control mouse. **Set Mode to Absolute** and **Set Mode to Relative**. Select the mouse mode to use from the options below and press the **Save** button.

The screenshot shows a web interface for configuring mouse mode. At the top, there is a grey header with the title "Configuration" and a subtitle "Use these pages to configure various settings, such as alerts, users, or network." Below this is a sub-header "Mouse Mode Setting". The main content area contains the following elements:

- A paragraph: "Select the mouse mode to use from the options below and press the Save button."
- A status message: "Current Mouse Mode is ABSOLUTE."
- Two radio button options: "Set Mode to Absolute" (which is selected) and "Set Mode to Relative".
- A "Save" button at the bottom left of the form area.

Network: Display and set IP address information. You can view and modify the network settings on this page. Select whether to obtain an IP address automatically or configure one manually. It is recommended to use DHCP if your environment has a DHCP server. You can set DHCP (obtain the IP address automatically) or STATIC IP (configure the IP address manually) then click “Save”

Configuration
Use these pages to configure various settings, such as alerts, users, or network.

Network Settings

You can view and modify the network settings on this page. Select whether to obtain an IP address automatically or manually configure one.

LAN Channel Number

MAC Address

Current IP Address : 10.1.7.76

Obtain an IP address automatically (use DHCP)
 Use the following IP address

IP Address

Subnet Mask

Default Gateway

Remote Session:

The following options allow the user to enable or disable encryption on KVM or Media data during a redirection session. Select the remote session then press **Save** button.

Configuration
Use these pages to configure various settings, such as alerts, users, or network.

Remote Session

The following options allow the user to enable or disable encryption on KVM or Media data during a redirection session.

Enable KVM Encryption

Enable Media Encryption

Virtual Media Attach Mode:

SMTP: Set E-mail (SMTP) server IP address for sending alert notification to user.

Enter the IP address, User Name, Password, Sender Address and Machine Name for the SMTP Mail server below and press the **Save** button.

Configuration

Use these pages to configure various settings, such as alerts, users, or network.

SMTP Setting

Enter the IP address, User Name, Password, Sender Address and Machine Name for the SMTP Mail server below and press the Save button.

LAN Channel Number:	<input type="text" value="1"/>
SMTP Server IP:	<input type="text" value="155.229.80.15"/>
User Name:(Optional)	<input type="text" value="UserName"/>
Password:(Optional)	<input type="text"/>
Sender Address:	<input type="text" value="Ami@intel.com"/>
Machine Name:	<input type="text" value="IPMIServer"/>

SSL Upload: You can load your SSL file for encryption.

The dates for the default certificate and private key are shown below. To upload a new SSL certificate, use the **Browse** button to navigate to the certificate and press the **Upload** button.

Configuration

Use these pages to configure various settings, such as alerts, users, or network.

SSL Upload

The dates for the default certificate and private key are shown below. To upload a new SSL certificate, use the Browse button to navigate to the certificate and press the Upload button.

Default Certificate	Not Available
Default Privacy Key	Not Available
New SSL Certificate	<input type="text"/> <input type="button" value="瀏覽..."/>

User List: The list below shows the current list of configured users. If you would like to delete or modify a user, select their name in the list and press **Delete User** or **Modify User**. To add a new user, select an unconfigured slot and press **Add User**.

Configuration
Use these pages to configure various settings, such as alerts, users, or network.

User List

The list below shows the current list of configured users. If you would like to delete or modify a user, select their name in the list and press Delete User or Modify User. To add a new user, select an unconfigured slot and press Add User.

Number of configured users: 3

UserID	User Name	Network Privilege
1	anonymous	Administrator
2	root	Administrator
3	admin	Administrator
4	~	~
5	~	~
6	~	~
7	~	~
8	~	~
9	~	~
10	~	~

User Privileges: User privilege limits determine the maximum privilege that a user can have. Users can be configured to allow having up to Administrator level privilege, while another user may be restricted to allow no higher than operator level. User can configure the privileges level by selecting **Modify User** tab.

Users can be configured to operate with a particular maximum Privilege Level. Privilege levels tell the BMC which commands are allowed to be executed. The following table: User Privilege Levels, lists the currently defined privilege levels.

No access	This may be considered the lowest privilege level.
Operator	All BMC commands are allowed, except for configuration commands that can change the behavior of the out-of-band interfaces. For example, Operator privilege does not allow the capability to disable individual channels, or change user access privileges.
Administrator	All BMC commands are allowed, including configuration commands. An Administrator can even execute configuration commands that would disable the channel that the Administrator is communicating over.

Configuration

Use these pages to configure various settings, such as alerts, users, or network.

Modify User

Enter the new information for the user below and press Modify. Press Cancel to return to the user list.

User Name:	<input type="text" value="admin"/>
	<input checked="" type="checkbox"/> Change Password
Password:	<input type="password"/>
Confirm Password:	<input type="password"/>
Network Privileges:	<input type="text" value="Administrator"/>
	<ul style="list-style-type: none">AdministratorOperatorNo Access

Event Action

When a sensor changes state, users can choose to initiate some type of action.

* Global PEF Configuration

Select the type to enable or disable operating (power off, reset, power cycle, no action).

* Add PEF Entry

Select the type of sensor and sensor name. Waiting for the Event Offsets table to produce.

Then select PEF action and event offsets.

* Current PEF Filters


Display Current PEF Filters. A list of the PEF with sensor type, sensor number, sensor name, and PEF action.

* Delete PEF Entry


Select the entry that you want to delete. And Press "Delete PEF" button to setting.

Remote Control

This menu item allows you to start a Remote Console session with the host system..




KVM Remote Console Redirection: Press the “Launch Console” button to launch the redirection console and manage the server remotely. After pressing the button, a console will pop up as below:



For KVM remote redirection detail function description, please go to chapetr: **KVM Function Description**.

Power Control: This menu item allows you to remote power on, power off, power cycle, and reset your GIGABYTE server. Select one option and press **Perform Action** button.



Remote Control
This section allows you to perform various remote operations on the server, such as launching the remote console.

Power Control and Status

The current server power status is shown below. To perform a power control operation, select one of the options below and press Perform Action.

Host is currently on


- Reset Server
- Power Off Server - Immediate
- Power Off Server - Orderly Shutdown
- Power On Server
- Power Cycle Server

Perform Action


Maintenance

This menu item allows you to update the BMC Firmware and view the GIGABYTE Remote Management Web UI, FRU information.

Press **Firmware Updates** button to process firmware update. Please note that once you press the **Firmware Updates** button, you will not be able to perform any other tasks until firmware upgrade is completed and the device is rebooted.



Confirmation dialog box appears. Click **OK** button.




Click **Browse** button to select the firmware file and press **Upload firmware** button to refresh firmware.

The screenshot displays the Gigabyte Technology web interface. At the top, the Gigabyte logo and 'TECHNOLOGY' are on the left, and 'www.gigabyte.com' and the Gigabyte logo are on the right. Below the header is a navigation bar with links for 'System Information', 'Server Health', 'Configuration', 'Remote Control', 'Maintenance', and 'Logout'. A 'System Status' section shows a green checkmark icon and the word 'Normal'. The main content area is titled 'Maintenance' and contains the text: 'This section allows you to perform maintenance tasks on the device.' Below this is the 'Firmware Upload' section, which includes the following text: 'The device is now in Upgrade mode. Please specify the filename of the Firmware Image that you want to upgrade to. Clicking on the 'Browse' button will allow you to select the firmware image file. Once you do that, click on the 'Upload' button to upload the image file to the device.' There is a text input field labeled 'Select Firmware to Upload:' with a 'Browse...' button to its right. Below the input field are two buttons: 'Upload Firmware' and 'Cancel'. In the bottom right corner of the interface, there is a copyright notice: '© 2009 American Megatrends Inc.'

KVM Function Description


After selecting **KVM Remote Console Redirection** tab, system will lead you to the main menu of KVM window which is shown as below:



There are three different menus in the menu bar: Video, Keyboard, Mouse, Option, Device and Help. Each of tab function will be described in the following sections.

Video Menu

Under Video Menu, there are 6 different options: Pause Redirection, Resume Redirection, Refresh video, Compression, Full screen and Exit.




Pause Redirection: Click **Pause Redirection** will pause KVM redirection function.

Resume Redirection: To resume KVM console redirection, simply select this item.

Compression: By selecting compression will come out a sub-menu as below screen:

Options available: None, Type I, Type II and Both. User can select preferred compression type.




Refresh Video: Clicking **Refresh Video** will refresh your KVM Viewer screen.

Exit: Clicking **Exit**, will close the KVM Viewer window.

Keyboard Menu

Under Keyboard Menu, there are 8 different options: Hold Right Ctrl Key, Hold Right Alt Key, Hold Left Ctrl Key, Hold Left Alt Key, Left Windows Key, Right Windows Key, Alt+Ctrl+Del, and Full Keyboard.




Hold Right Ctrl Key: Clicking this option will hold the keyboard right **Control** key.

Hold Right Alt Key: Clicking this option will hold the keyboard right **Alt** key.

Hold Left Ctrl Key: Clicking this option will hold the keyboard left **Control** key.

Hold Left Alt Key: Clicking this option will hold the keyboard right **Alt** key.

Left Window Key: User can hold down the left windows key or press and release the left windows key by selecting this option.




Right Window Key: User can hold down the right windows key or press and release the right windows key by selecting this option.



Alt + Ctrl + Del: Clicking this option will process **Alt + Ctrl + Del** function to open the windows task manager windows.

Mouse

Clicking this option will synchronize the cursor of redirection console.




Option

The Option menu provide the redirection bandwidth selection and Keyboard/Mouse Encryption function.


Bandwidth: User can select either Auto Detecting bandwidth or select the following available options: 256Kps, 512 Kps, 1 Mps, 10 Mps, and 100Mps.

Keyboard/Mouse Encryption: This option provide redirection keyboard and mouse encryption function.



Device

Device option provides the virtual devices for client system. Available devices: CD-ROM, ISO file, Floppy/USB Key, and Floppy/USB Key Image.



Help

This option provide the information of current KVM Remote Console Utility version.

