

Declaration of Conformity

We, Manufacturer/Importer
(full address)

G.B.T. Technology Trading GmbH
Ausschläger Weg 41, 1F 20537 Hamburg, Germany

declare that the product
(description of the apparatus, system, installation to which it refers)

VGA Card
GV-NX72G128D

is in conformity with

(reference to the specification under which conformity is declared)
in accordance with 89/336 EEC-EMC Directive

<input type="checkbox"/> EN 55011	Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) high frequency equipment	<input checked="" type="checkbox"/> EN 61000-3-2	Disturbances in supply systems caused by household appliances and similar electrical equipment "Voltage fluctuations"
<input type="checkbox"/> EN 55013	Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment	<input checked="" type="checkbox"/> EN 55024	Information Technology equipment-Immunity characteristics-Limits and methods of measurement
<input type="checkbox"/> EN 55014-1	Limits and methods of measurement of radio disturbance characteristics of household electrical appliances, portable tools and similar electrical apparatus	<input type="checkbox"/> EN 50082-1	Generic immunity standard Part 1: Residual, commercial and light industry
		<input type="checkbox"/> EN 50082-2	Generic immunity standard Part 2: Industrial environment
<input type="checkbox"/> EN 55015	Limits and methods of measurement of radio disturbance characteristics of fluorescent lamps and luminaires	<input type="checkbox"/> EN 55014-2	Immunity requirements for household appliances tools and similar apparatus
<input type="checkbox"/> EN 55020	Immunity from radio interference of broadcast receivers and associated equipment	<input type="checkbox"/> EN 50091- 2	EMC requirements for uninterruptible power systems (UPS)
<input checked="" type="checkbox"/> EN 55022	Limits and methods of measurement of radio disturbance characteristics of information technology equipment		
<input type="checkbox"/> DIN VDE 0855	Cabled distribution systems; Equipment for receiving and/or distribution from sound and television signals		
<input type="checkbox"/> part 10			
<input type="checkbox"/> part 12			

CE marking



(EC conformity marking)

The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 2006/95/EC

<input type="checkbox"/> EN 60065	Safety requirements for mains operated electronic and related apparatus for household and similar general use	<input checked="" type="checkbox"/> EN 60950	Safety for information technology equipment including electrical business equipment
<input type="checkbox"/> EN 60335	Safety of household and similar electrical appliances	<input type="checkbox"/> EN 50091-1	General and Safety requirements for uninterruptible power systems (UPS)

Manufacturer/Importer

Signature : Timmy Huang

(Stamp)

Date : May 17, 2007

Name : Timmy Huang

DECLARATION OF CONFORMITY

Per FCC Part 2 Section 2.1077(a)



Responsible Party Name: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street

City of Industry, CA 91748

Phone/Fax No: (818) 854-9338/ (818) 854-9339

hereby declares that the product

Product Name: VGA Card

Model Number: GV-NX72G128D

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109
(a), Class B Digital Device

Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any inference received, including that may cause undesired operation.

Representative Person's Name: ERIC LU

Signature: Eric Lu

Date: May 17, 2007

Declaration of Conformity

We, Manufacturer/Importer
(full address)

G.B.T. Technology Trading GmbH
Ausschläger Weg 41, 1F 20537 Hamburg, Germany

declare that the product
(description of the apparatus, system, installation to which it refers)

VGA Card

GV-NX72G512P1/GV-NX72G512P2

is in conformity with

(reference to the specification under which conformity is declared)
in accordance with 89/336 EEC-EMC Directive

<input type="checkbox"/> EN 55011	Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) high frequency equipment	<input checked="" type="checkbox"/> EN 61000-3-2	Disturbances in supply systems caused by household appliances and similar electrical equipment "Voltage fluctuations"
<input type="checkbox"/> EN 55013	Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment	<input checked="" type="checkbox"/> EN 55024	Information Technology equipment-Immunity characteristics-Limits and methods of measurement
<input type="checkbox"/> EN 55014-1	Limits and methods of measurement of radio disturbance characteristics of household electrical appliances, portable tools and similar electrical apparatus	<input type="checkbox"/> EN 50082-1	Generic immunity standard Part 1: Residual, commercial and light industry
		<input type="checkbox"/> EN 50082-2	Generic immunity standard Part 2: Industrial environment
<input type="checkbox"/> EN 55015	Limits and methods of measurement of radio disturbance characteristics of fluorescent lamps and luminaires	<input type="checkbox"/> EN 55014-2	Immunity requirements for household appliances tools and similar apparatus
<input type="checkbox"/> EN 55020	Immunity from radio interference of broadcast receivers and associated equipment	<input type="checkbox"/> EN 50091- 2	EMC requirements for uninterruptible power systems (UPS)
<input checked="" type="checkbox"/> EN 55022	Limits and methods of measurement of radio disturbance characteristics of information technology equipment		
<input type="checkbox"/> DIN VDE 0855	Cabled distribution systems; Equipment for receiving and/or distribution from sound and television signals		
<input type="checkbox"/> part 10			
<input type="checkbox"/> part 12			

CE marking



(EC conformity marking)

The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 2006/95/EC

<input type="checkbox"/> EN 60065	Safety requirements for mains operated electronic and related apparatus for household and similar general use	<input checked="" type="checkbox"/> EN 60950	Safety for information technology equipment including electrical business equipment
<input type="checkbox"/> EN 60335	Safety of household and similar electrical appliances	<input type="checkbox"/> EN 50091-1	General and Safety requirements for uninterruptible power systems (UPS)

Manufacturer/Importer

Signature : Timmy Huang

(Stamp)

Date : June 14, 2007

Name : Timmy Huang

DECLARATION OF CONFORMITY

Per FCC Part 2 Section 2.1077(a)



Responsible Party Name: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street

City of Industry, CA 91748

Phone/Fax No: (818) 854-9338/ (818) 854-9339

hereby declares that the product

Product Name: VGA Card

Model Number: GV-NX72G512P1/
GV-NX72G512P2

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109
(a), Class B Digital Device

Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any inference received, including that may cause undesired operation.

Representative Person's Name: ERIC LU

Signature: Eric Lu

Date: June 14, 2007

GV-NX72G128D/ GV-NX72G512P1/ GV-NX72G512P2

GeForce™ 7200 GS Graphics Accelerator

User's Manual

Rev. 103

12MD-NX72G1D-103R



* The WEEE marking on the product indicates this product must not be disposed of with user's other household waste and must be handed over to a designated collection point for the recycling of waste electrical and electronic equipment!!
— * The WEEE marking applies only in European Union's member states.

Copyright

©2007 GIGABYTE TECHNOLOGY CO., LTD

Copyright by **GIGA-BYTE TECHNOLOGY CO., LTD.** ("GBT"). No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of GBT.

Trademarks

Third-party brands and names are the property of their respective owners.

Notice

Please do not remove any labels on VGA card, this may void the warranty of this VGA card

Due to rapid change in technology, some of the specifications might be out of date before publication of this booklet.

The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein.

Macrovision corporation product notice:

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

Table of Contents

1. Introduction	3
1.1. Features	3
1.2. Minimum System Requirement	3
2. Hardware Installation	4
2.1. Board Layout	4
2.2. Hardware Installation	7
3. Software Installation	11
3.1. Windows® XP Driver and Utilities Installation	11
3.1.1. Operating System Requirement	11
3.1.2. DirectX Installation	12
3.1.3. Driver Installation	13
3.1.4. Utilities on Driver CD	15
3.1.5. Taskbar Icon	18
3.1.6. Display Properties Pages	21
3.1.7. nView Properties Pages	26
3.2. Windows® 2000 Driver Installation	31
4. Troubleshooting Tips	32
5. Appendix	33
5.1. How to Reflash the BIOS	33
5.2. Connecting to a HDTV	34
5.3. Resolutions and Color Depth Table (In Windows® XP)	35

1. Introduction

1.1. Features

- The graphics card supports NVIDIA TurboCache technology, which enhances graphics card performance by allowing the graphics processing unit (GPU) to dynamically share the available system memory. The total effective VGA memory differs depending on system memory. See the following tables for details:

Available Graphics Memory Calculation for the GV-NX72G128D/GV-NX72G512P1

System Memory	256 MB	512 MB	1 GB or above
Onboard Graphics Memory (a)	128 MB	128 MB	128 MB
Allocated System Memory (b)	0 MB	128 MB	384 MB
Total Effective Graphics Memory (a)+(b)	128 MB	256 MB	512 MB

Available Graphics Memory Calculation for the GV-NX72G512P2

System Memory	256 MB	512 MB	1 GB or above
Onboard Graphics Memory (a)	256 MB	256 MB	256 MB
Allocated System Memory (b)	0 MB	0 MB	256MB
Total Effective Graphics Memory (a)+(b)	256 MB	256 MB	512 MB

- Powered by **NVIDIA® GeForce™ 7200 GS** Graphics Processing Unit (GPU)
- Supports the newest PCI Express x16
- Integrated with 128 MB DDRII memory (For GV-NX72G128D/GV-NX72G512P1 only)
- Integrated with 256 MB DDRII memory (For GV-NX72G512P2 only)
- Supports DirectX 9.0c
- Supports NVIDIA® SLI™ (Scalable Link Interface) technology via the PCI Express bus^(Note)
- Supports AV / S-Video and HDTV output
- Provides D-Sub and DVI-I connectors

1.2. Minimum System Requirement


- Intel® Pentium® 4 or AMD Athlon™ or higher
- One PCI Express x16 slot
- Operating Systems Windows® 2000 / Windows® XP/ Windows® Vista
- 512 MB of system memory
- 200 MB of available disk space for full installation
- CD-ROM or DVD-ROM drive

(Note): SLI technology requires a PCI Express motherboard with two x16 physical connectors. Graphics cards working in an SLI configuration must be of the same model and from the same vendor.



2. Hardware Installation

2.1. Board Layout

1. GV-NX72G128D/GV-NX72G512P2



2. GV-NX72G512P1





CAUTION

Expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

1. Turn off your computer and unplug power supply.
2. Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
3. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.

The card contains sensitive electric components, which can be easily damaged by static electricity, so the card should be left in its original packing until it is installed.

Unpacking and installation should be done on a grounded anti-static mat. The operator should be wearing an anti-static wristband, grounded at the same point as the anti-static mat.

Inspect the card carton for obvious damage. Shipping and handling may cause damage to your card. Be sure there are no shipping and handling damages on the card before proceeding.

*** DO NOT APPLY POWER TO YOUR SYSTEM IF IT HAS BEEN DAMAGED ON THE CARD.**

*** In order to ensure your graphics card working correctly, please use official Gigabyte BIOS only. Use none official Gigabyte BIOS might cause problem on the graphics card.**

2.2. Hardware Installation

Installing Your graphics card.

Now that you have prepared your computer, you are ready to install your graphics accelerator card.

To remove the existing graphics card:


1. Power off the computer and monitor, then disconnect the display cable from the back of your computer.



2. Remove the computer cover. If necessary, consult your computer's manual for help in removing the cover.




3. Remove any existing graphics card from your computer.



To install your new graphics card:

1. Locate the PCI Express x16 slot. If necessary, remove the metal cover from this slot; then align your graphics card with the PCI Express x16 slot, and press it in firmly until the card is fully seated.
- * Please make sure that the gold edge connectors of the graphics card is securely inserted.
2. Replace the screw to fasten the card in place, and replace the computer cover.



3. Plug the display cable into your card; then turn on the computer and monitor. If your graphics card came with a DVI-I connector, you can connect a flat panel display to the appropriate connector, as shown below...



To D-Sub Monitor



To TV / VCR



To Flat Panel Display



To avoid system instability, do not touch the graphics card when it is running.

You are now ready to proceed with the installation of the graphics card driver. Please refer to next chapter for detailed instructions.

How to enable NVIDIA® SLI™ (Scalable Link Interface) technology:

After installing two SLI-ready graphics cards of the same model on an SLI motherboard (example: GV-NX72G128D)(Figure 1), users can enable SLI mode simply through the graphics card driver^(Note).



Figure 1

Step 1: After installing the graphics card driver, right-click on Desktop and select **Properties**. When **Display Properties** dialog box appears, select the **Settings** tab. In **Settings**, click the **Advanced** button.

Step 2: Click the **GeForce 7300 SE/7200 GS** tab when advanced properties dialog box appears. Select **SLI multi-GPU** from the side menu and select the **Enable SLI multi-GPU** check box (Figure 2) and click **Apply**.





Figure 2

Step 3: Restart your system when prompted.

(Note): Only Windows® XP operating system supports SLI mode. Please do not enable **SLI multi-GPU** in Windows® 2000.

GIGABYTE Video Adapter for Nvidia Graphics Cards



(1) Connecting HDTV

Connect your HDTV cables to the video adapter according to the corresponding color.
(Y= Green, Pr= Red, Pb= Blue)



(2) Connecting S-Video

If your TV has an S-Video connection, connect the S-Video cable from your TV to the S-Video Out port on the adapter.



(3) Connecting AV Output

If your TV has Composite video connection, you can connect the RCA cable from your TV to the AV Out port on the adapter.



3. Software Installation

In this manual, we assume that your CD-ROM Drive letter to be Drive D:

The installation of Windows® 2000 / Windows® XP drivers is very simple. When you insert the driver CD into your CD-ROM drive, you can see the AUTORUN window (if it does not show up, run "D:\setup.exe"). Then you can follow the guides to setup your graphics card driver. (Please follow the subsection 3.1.3 "Driver installation" to install the driver for your graphics accelerator.)

3.1. Windows® XP Driver and Utilities Installation

3.1.1. Operating System Requirement

- When loading the graphics card drivers for the system, please make sure your system has installed DirectX 9.0c or later version.
- If you install the graphics card drivers for the motherboard, which consist of SIS or VIA chipsets, please install the appropriate driver program for that motherboard. Or please contact your motherboard nearest dealer for motherboard driver.

3.1.2. DirectX Installation

Install Microsoft DirectX to enable 3D hardware acceleration support for Windows® 2000 or Windows® XP to achieve better 3D performance.


 Note: For software MPEG support in Windows® 2000 or Windows® XP, you must install DirectX first. Users who run Windows XP with Service Pack 2 or above do not need to install DirectX separately.




Step 1. When autorun window show up, click the **Install DirectX 9** item.



Step 2. Choose **I accept the agreement** and click the **Next** button.



Step 3. Click the **Next** button.



Installing the components.



Step 4. Click **Finish** to restart computer.
Then the DirectX 9 installation is completed.

3.1.3. Driver Installation

A. New hardware found

After the graphics card is inserted into your computer at the first time, the windows will automatically detect a new hardware in the system and pop out a "New Hardware Found" message. The following is the step-by-step installation guide.

Step 1: Found new hardware wizard: Video controller (VGA Compatible)



Click the **Next** button to install the driver. (There is a driver CD disk that came with your graphics accelerator, please insert it now.)

Or click the **Cancel** button to install the driver from AUTORUN window.


Step 2: Found new hardware wizard: Searching and installing

The wizard will search for the driver and install it automatically.



Step 3: Found new hardware wizard: Finish

Click the "Finish" button to finish the installation.



B. Driver installation (Autorun Window)


Insert the driver CD disk into your CD-ROM, and then you can see the AUTORUN window. If it does not show up, please run "D:\setup.exe".



Step 1. When autorun window show up, click **Install Display Driver** item.



Step 2. Click "Next" button.



Windows installings the components.



Step 3. Click "Finish" button to restart computer.
Then the driver installation is completed.

3.1.4. Utilities on Driver CD

Insert the driver CD disk into your CD-ROM, and then you can see the AUTORUN window. If it does not show up, please run "D:\setup.exe".


- Install GIGABYTE utilities:



Step 1. When autorun window show up, please click the **GIGABYTE Utility** item.




Step 2. Click the **Next** button.




Step 3. Click the **Install** button.




- Step 4. Click the **Finish** button.
- Step 5. Click the **Next** button.






Step 6. Click the **Next** button.



Step 7. Click the **Next** button.




Step 8. Click the **Install** button.



Step 9. Click the **Finish** button to restart computer.
Then the utilities installation is completed.

V-Tuner 3

V-Tuner 3 lets you adjust the working frequency of the graphic engine and video memory (Core Clock and Memory Clock).



Button	Function
DEFAULT	You may click this button to restore to the default setting
SAVE	You may click this button to save the frequency you wanted
LOAD	After saving the specific value, you may click this button to load the frequency you saved last time
Auto-Optimized	The V-Tuner3 clock configuration utility will determine the recommended GPU and memory clock setting your system. If the utility should hang, restart your system and then enter "Auto-Optimized" mode
Fixed Clock	The V-Tuner3 clock configuration utility will lock the GPU and memory clock you choose, whether you restart your system or not. To recharge clock, uncheck the "Fixed Clock" mode and then adjust
Hardware Monitor	If your card have Hardware Monitor function, you will see the extend window. The window will display the GPU temperature and show the thermal curve. Besides, you can move the slider to adjust the frequency-time temperature of GPU, and you will see the change of thermal curve from now on.
HELP	Opens Help page


3.1.5. Taskbar Icon

After installation of the display drivers, you will find a GIGABYTE icon  on the taskbar's status area. Right-clicking this icon opens the GIGABYTE control panel, showing a menu composed of shortcut of the graphics card's enhanced and other functions.

You may click the **Display Properties** item, and then click **Settings**. Click **Advanced** after clicking **Settings**. Click the appropriate tab to change your display settings.



Right click the icon.



Click the **Color Correction** and **VGA Information** items into the "Color Adjust" and "VGA Info" tabs.

You can link to GIGABYTE website for updated information about the graphics accelerator, latest drivers, and other information.


Color Adjust

Color Adjust allows you to make color adjustments, such as brightness, contrast and gamma values for each or all of RGB colors.



VGA Information

VGA Info lists the relevant information about your card.



After installation of the display drivers, you will find a NVIDIA icon  on the taskbar's status area. Click this icon to open the control panel.




3.1.6. Display Properties Pages

To access Display Properties pages, right-click the GBT icon on the taskbar and select **Display Properties** or right-click on Desktop and then select **Properties**. The **Display Properties** dialog box shows the information of display adapter, color, the range of display area, and the refresh rate.

Settings (Resolutions and Color depth for Windows)


You may adjust the screen resolution and color quality settings in this dialog box.



To access more advanced options, click the **Advanced** button.

GeForce 7200 GS properties

After pressing the **Advanced** button in **Settings**, you'll see **Plug and Play Monitor** and **NVIDIA GeForce 7300 SE/7200 GS** dialog box. Click the **GeForce 7300 SE/7200 GS** tab. (You can also click the Nvidia icon in the system tray and select **Nvidia Display** to access the GeForce 7300 SE/7200 GS properties page.)



You can select other properties from the pop-out menu.

- This page shows the Adapter, System and Driver versions information.

nView Display Settings properties *



- nView allows you to connect separate displays to single graphics card.
- nView Display mode: select your preferred nView display modes here.
Options: Single display/ Clone/ Dual View
- Primary/Secondary display: select a single display or display pair. The selected display combination will appear in the graphical representation below.
- Make this the primary display: Specifies that the display corresponding to the icon you selected above is the primary display.
- Click **Apply** to apply settings or click **OK** to save settings.
- If TV is chosen as the display, you will need to select the proper TV format. To do this, click **Device Settings** followed by **Select TV format**. Select the format for your television and then click **Apply** followed by **OK**.

Display Matrix	Model	GV-NX72G128D/512P1/512P2
CRT+TV	Yes	
CRT+DVI	Yes	
DVI+TV	Yes	

Dual-Monitor Setup:

You can set the display to output from two monitors on the nView Display Settings page. This graphics card supports the following modes:

(1) Clone Mode:

Clone mode indicates that both displays in the display pair show images of the same desktop. Select **Clone** from the nView Display Mode list and click **Apply**.



Clone Mode

(2) Dual View Mode:

Dualview mode indicates that both displays in the display pair function as one virtual desktop. Unlike Horizontal Span or Vertical Span mode, Dualview treats each display as a separate device. This means that the taskbar will not be stretched across displays and 3D applications are not accelerated as efficiently as when the application spans displays.


Select **DualView** from the nView Display Mode list and click **Apply**.



Dual View Mode

*** Only Single display mode is available when SLI mode is enabled.

Performance and Quality Settings properties



- The sliders lets to decide whether your application should use quality or high performance texture.
- Application profiles:** Select the application profile from the list of profiles.
- Global driver settings:** Select the Settings item and move the slider below to set the degree of antialiasing to used in Direct3D and OpenGL applications.
- Antialiasing settings value:** allows to set the degree of the Global Driver Settings.


SLI multi-GPU *



- To enable SLI mode, select the **Enable SLI multi-GPU** check box and click **Apply** after installation of two GV-NX72G128D/GV-NX72G512P1/GV-NX72G512P2 graphics cards on an SLI-capable motherboard. Then restart your system when prompted.

*** Only Windows® XP operating system supports the SLI mode. Please do not enable SLI multi-GPU in Windows® 2000.

Color Correction properties




- The Color Correction Properties** is used to compensate for variations in luminance between a source image and its output on a display device. Adjust the color correction settings to provide more accurate color reproduction of images (such as photographs) on your display device. Also, many 3D-accelerated games may appear too dark to play. Increasing the brightness and/or the gamma value equally across all channels makes these games appear brighter and more playable.

Video Overlay Settings properties



- The **Video Overlay Settings Properties** can adjust Overlay zoom controls and Overlay color controls. There is only one video overlay, which is only available on the **Primary** display. The video overlay controls are automatically activated during playback of any video file type that supports overlay adjustments. The "Adjust Colors" button will access "Color Correction" properties page.

Tools properties



- The NVIDIA settings toolbar utility lets you conveniently access various features and presets you've configured in the Display Properties directly from the Windows toolbar.

- Shortcut tools**

The Desktop Manager provides enhanced nView multi-display functionality and helps you organize your applications for use with multiple displays and desktops.


- Display optimization**

Run the Display Optimization Wizard to adjust your display(s) for optimal viewing and representation of colors.

- Troubleshooting**

This option can be used to force detection of an attached TV set which does not report its presence to the graphics card.


NV Rotate properties



- The **NV Rotate Properties** is used to rotate the screen. If your monitor is capable of operating in either Landscape or Portrait mode, you can adjust the screen by this properties.


- Landscape (0 degree rotation)
- Portrait (90 degree rotation)
- Inverted landscape (180 degree rotation)
- Inverted portrait (270 degree rotation)

Temperature Settings properties




- The **Temperature Settings Properties** can auto detected the GPU Core temperature. You can select the **Notify when GPU core temperature exceeds threshold** check box.

Screen Resolutions & Refresh Rates properties



- The **Screen Resolutions & Refresh Rates Properties** allows you to adjust the screen resolution, color quality and monitor settings (screen refresh rates). Or you can customize resolutions and refresh rates.

Menu Editing properties



- The **Menu Editing Properties** can remove infrequently used screens by dragging them from the screen menu to the list below. Restore screens to the menu by dragging them individually, or click **Restore Defaults**.

To begin, select the **Enable menu editing** check box. To return to normal navigation mode, do not select the check box.

3.1.7. nView properties Pages

nView is a set of desktop tools designed to help you be more productive when using your graphics card. With **nView** you can set up multiple desktops to work with your applications. Multiple desktops give you extra desktop areas on which to run your applications so you won't have to crowd several open application windows on one desktop.

Enable the nView Desktop Manager features:

Right-click on desktop and choose Properties\Settings\Advanced\GeForce 7300 SE/7200 GS\Desktop Management




Click Enable button to turn on all the nView Desktop Manager features.

Access nView properties page:


To access the **nView** properties page, you can click the NVIDIA icon  on the taskbar and select **nView Properties** under **nView Desktop Manager** (Method A). Or right-click on Desktop, select Properties\Settings\Advanced\GeForce 7300 SE/7200 GS. Double-click **Desktop Management** item on the pop-up menu (Method B).

Method A:



Click the item to start nView Properties.

Method B:



Double-click Desktop Management to see more nView properties.

nView Desktop Management properties




- This tab contains information about the nView Desktop Manager. The setup wizard can also be accessed from this tab.

nView Profiles properties



- This tab contains a record all nView display settings for easy software setup.

nView Windows properties



- This tab allows you to control window and dialog box placement when using multiple monitors.

nView Applications properties




- This tab allows you to control nView settings depending different applications.

nView Desktops properties




- This tab allows you to create up to 32 unique desktops.

nView User Interface properties




- This tab allows for customization of the nView user interface.

nView Effects properties



- This tab provides special windows effects that you can apply to your applications.

nView Zoom properties



- This tab provides dynamic zoom functionality on the desktop. Also enables full screen video playback via the video mirroring control button.

nView Hot Keys properties



- This tab lets you perform various actions with shortcut keys or key combinations.

nView Mouse properties



- This tab can modify and extend mouse behavior with kinematic actions.

nView Tools properties



- This tab can improve nView functionality for mobile and desktop users.

3.2. Windows® 2000 Driver Installation

With Windows running on your computer, you need to install the graphics card driver to take advantage of the higher performance, resolutions, and special graphics features of the graphics card. To ensure you install the latest driver, insert the Installation CD that shipped with your graphics card.

To install the graphics card driver for Windows® 2000, please insert the Installation CD. Then the AUTORUN window will show up. Click **Install Display Driver** item, and follow the wizard to install the driver.

If Windows® does not show the CD automatically, please run following steps:

1. Click the Start button on the control bar.
2. Select Run.
3. Type the following: D:\SETUP.exe
(If D is not your CD-ROM drive, substitute D with the correct drive letter.)
4. Click "OK".
5. Click on "Install Display Drivers" to begin the Installation Wizard.
6. Click "Next".
7. Click "Yes" to the license agreement.
8. Follow the Wizard's on-screen instructions to complete the installation.



Please make sure the Windows® 2000 have installed Windows® 2000 Service Pack (or later) before installing the graphics card driver.

4. Troubleshooting Tips

The following troubleshooting tips may help if you experience problems. Contact your dealer or GIGABYTE for more advanced troubleshooting information.

- Check that the card is seated properly in the PCI Express x16 slot.
- Ensure that the display cable is securely fastened to the card's display connector.
- Make sure that the monitor and computer are plugged in and receiving power.
- If necessary, disable any built-in graphics capabilities on your motherboard. For more information, consult your computer's manual or manufacturer.

(NOTE: Some manufacturers do not allow the built-in graphics to be disabled or to become the secondary display.)

- Make sure you selected the appropriate display device and graphics card when you installed the graphics driver.

- Restart your computer.

Press the F8 key on your keyboard after system starts up. When the Windows Advanced Options Menu appears, select Safe Mode and press Enter.
After getting into Safe Mode, in Device Manager check whether the driver for the graphics card is correct.

- For more assistance, use the Troubleshooting Guide located in the Windows® Help or contact your computer manufacturer.



If necessary, adjust your monitor's setting by monitor's adjust panel to make the screen looks focused, crisp, and sharp. (Please refer to the monitor's manual.)

5. Appendix

5.1. How to Reflash the BIOS

Reflash BIOS in MS-DOS Mode

1. Extract the downloaded Zip file to your hard disk(s) or floppy disk. This procedure assumes drive A.
2. Restart the computer in MS-DOS mode. (For Windows® 2000/XP, you need a startup disk to restart the computer in MS-DOS mode.)
3. Change the command prompt to A:>.
4. To back up the current BIOS, at the A:> prompt, type [BIOS flash utility name] -s [BIOS file name] (**example: gvf19 -s NX72G1D.f1**) and press **Enter**.
5. To flash BIOS, at the A:> prompt, type [BIOS flash utility name] -p [BIOS file name] (**example: gvf19 -p NX72G1D.f2**) and press **Enter**.
6. Wait until it's done, then restart your computer.

5.2. Connecting to a HDTV

Use the included component video adapter to connect a HDTV to the graphics card.

Step 1:

Connect the HDTV component cable to the adapter according to the corresponding color. (Y= Green, Pr= Red, Pb= Blue). Connect the TV Out cable from the adapter to the TV Out port on your graphics card.




Step 2:

After installation of the graphics card driver, right-click on Desktop and select **Properties**. When **Display Properties** dialog box appears, select the **Settings** tab. In **Settings**, click the **Advanced** button.




Step 3:

Click the **GeForce 7300 SE/7200 GS** tab when advanced properties dialog box appears. Select **nViewe** **Display Settings** from the side menu and select **HDTV** from the **Current display** list. Then click **Apply**.



Step 4:

Right-click on the HDTV icon and select TV format depending on your HDTV. Then click **Apply** to complete the settings.



5.3. Resolutions and Color Depth Table (In Windows® XP)

GeForce 7200 GS Single Display Standard Modes

Display Resolution	Refresh Rate (Hz)	Color Depth (bpp)	Standard mode	High mode	True mode
320 x 200	60~75	8bpp(256 color)	✓	✓	✓
320 x 240	60~75	8bpp(256 color)	✓	✓	✓
400 x 300	60~75	8bpp(256 color)	✓	✓	✓
480 x 360	60~75	8bpp(256 color)	✓	✓	✓
512 x 384	60~75	8bpp(256 color)	✓	✓	✓
640 x 400	60~75	8bpp(256 color)	✓	✓	✓
640 x 480	60~240	8bpp(256 color)	✓	✓	✓
720 x 480	60	8bpp(256 color)	✓	✓	✓
720 x 576	60	8bpp(256 color)	✓	✓	✓
800 x 600	60~240	8bpp(256 color)	✓	✓	✓
848 x 480	60~240	8bpp(256 color)	✓	✓	✓
960 x 600	60~240	8bpp(256 color)	✓	✓	✓
1024 x 768	60~200	8bpp(256 color)	✓	✓	✓
	240	8bpp(256 color)	✓	✓	X
1088 x 612	60~200	8bpp(256 color)	✓	✓	✓
	240	8bpp(256 color)	✓	✓	X
1152 x 864	60~170	8bpp(256 color)	✓	✓	✓
	200	8bpp(256 color)	✓	✓	X
1280 x 720	60~150	8bpp(256 color)	✓	✓	✓
	170	8bpp(256 color)	✓	✓	X
1280 x 768	60~150	8bpp(256 color)	✓	✓	✓
	170	8bpp(256 color)	✓	✓	X
1280 x 960	60~150	8bpp(256 color)	✓	✓	✓
	170	8bpp(256 color)	✓	✓	X
1280 x 1024	60~150	8bpp(256 color)	✓	✓	✓
	170	8bpp(256 color)	✓	✓	X
1360 x 768	60~150	8bpp(256 color)	✓	✓	✓
	170	8bpp(256 color)	✓	✓	X
1600 x 900	60~120	8bpp(256 color)	✓	✓	✓
	140~150	8bpp(256 color)	✓	✓	X
1600 x 1024	60~100	8bpp(256 color)	✓	✓	✓
	120	8bpp(256 color)	✓	✓	X

To be continued...

Display	Refresh	Color Depth (bpp)		
Screen	Rate	8bpp(256 color)	16bpp (65K color)	32bpp (16.7M)
Resolution	(Hz)	Standard mode	High mode	True mode
1600 x 1200	60~100	✓	✓	✓
	120	✓	✓	X
1920 x 1080 (16:9)	60~85	✓	✓	✓
	100	✓	✓	X
1920 x 1200 (16:10)	60~85	✓	✓	✓
	100	✓	✓	X
1920 x 1440	60~85	✓	✓	✓
2048 x 1536	60~85	✓	✓	✓
2560 x 1600 (Dual-Link)	60	✓	✓	✓

* This table is for reference only. The actual resolutions supported depend on the monitor you use.