

Cando® Touch Software for Windows®

Welcome to Cando Touch Software for Windows Readme, which contains a multi touch application.

System Requirements

Cando® Touch Software for Windows® requires the following:

- Microsoft Windows operation system (2000/XP/2003/Vista/2008/7*).
- Touch Panel which is made in Cando.

*In Windows 7 Home Premium version or above, you don't need to install this software.

Standard Features


- Single touch and can control the mouse cursor move.*
- Multi touch to do some gestures as following:
 - Press and tap: As mouse right button.
 - Press and hold: As mouse right button, but the menu will show after finger leaving.*
 - Zoom
 - Rotation
 - Flickers
 - Panning: As mouse wheel.

* 2000/XP/2003 only. These functions have been supported in Vista and above.


Installation

1. Click install.exe  to install the software.


2. In the Cando Touch setup dialog box, click Next.




3. Select which folder you want to install into, and then click Next.




4. Select which Start Menu folder you want to install into, and then click Next.



5. Check if you want to create a desktop icon, and then click Next.



6. Confirm your setting, and then click Install.



7. Check if you want to launch Cando Touch right now, and then click Finish.




Uninstallation

1. Launch the Control Panel and from it select Add or Remove Programs.
2. From the list of applications that appears, highlight Cando Touch and press the Change/Remove button.
3. The Cando Touch Application Maintenance dialog appears. Press the Yes button to remove Cando Touch.


How to use Cando Touch

After launch Cando Touch, all Standard Features are available. There is an icon in the system tray. You can set some configurations in this application. After left or right click the icon in system tray, Cando Touch is opened.



A. Calibration (2000/XP/2003 only)


Cando Touch has a simple calibration. After click Calibration you can do calibration by pressing the cross and waiting. The next cross will appear after time bar finished. After 5 crosses, the calibration is completed.



If you want to give up during calibration, you can press “Esc” key.


B. Test

The stings shown on the frame are coordinate of point 1 and point 2, the file name and the caption of the focus process window, respectively.



If you click Test, you can do line painting test. The color of finger 1 is red, and the


color of finger 2 is blue.



You can press “Esc” key to exit line painting test.

C. Configure

The default applications supported for multi touch by Cando Touch are Internet Explorer, Windows Picture and Fax Viewer (or Windows Photo Viewer in Windows 7) (English and Traditional Chinese only), and Adobe Acrobat Reader. If you want to add another application to support multi touch, you can set the configuration by pressing Setup.




a. Add a new application setting

1. Key in file name or key words of title alternatively (you can find them in Test frame).
2. Choose the gesture and set the shortcuts. (You can find the shortcuts in the application which you want to set). You can also use default setting (click

- DEFAULT) to reduce setting time, but the default setting is always in-correct.
3. Click SAVE.
 4. Click OK or APPLY to make your new setting activate.

b. Modify an old application setting



1. Select the file name or key words of title.
2. Modify gesture and shortcuts setting.
3. Click SAVE.
4. Click OK or APPLY to make your new setting activate.

Otherwise, you can also click DELETE to delete old setting.

Attention:

If you still want to install in Windows 7 Home Premium version or above, suggest you delete all default setting and create new setting. Please avoid doing the same gesture and shortcuts setting with Windows 7 (ex: zoom in -> Ctrl + mouse wheel up), or some error will happen.

Copyright

The copyright belongs to Cando Corporation. You can copy and distribute the software, but to crack or to de-assemble are forbidden.

Windows is a registered Trademark of Microsoft Corporation.