

# GA-8I915GV-MF/ GA-8I915GVM

Intel® Pentium® 4 LGA775 Processor Motherboard

## User's Manual

Rev. 1202

12ME-I915GVMF-1202



\* The WEEE marking on the product indicates this product must not be disposed of with user's other household waste and must be handed over to a designated collection point for the recycling of waste electrical and electronic equipment!!!

\* The WEEE marking applies only in European Union's member states.

## Declaration of Conformity

(for access)

G.B.T. Technology, Inc. d/b/a **Goldberg GmbH**  
**Ausschleiger Weg 41, 4F 20327 Hamburg, Germany**

(description of the apparatus, system, installation to which it refers)  
declare that the product

**Motherboard**

GA-81915GV-MF (GA-81915GVM)

is in conformity with conformity is declared)  
(reference to the specification with which conformity is declared)  
in accordance with 90/338 EEC EMC Directive

☐ EN 55011

Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) high frequency equipment

☒ EN 61000-3-2  
☒ EN 61000-3-3

Limits and methods of measurement of radio disturbance characteristics of information technology equipment

☒ EN 55024

☐ EN 55014-1

Limits and methods of measurement of radio disturbance characteristics of household electrical appliances, portable tools and similar electrical apparatus

☐ EN 50082-1  
☐ EN 50082-2

Generic immunity standard Part 1: Radiated, electromagnetic and gsm vicinity

Disturbances in supply systems caused by household appliances and similar electrical equipment "Voltage fluctuations" Information Technology equipment immunity requirements - Limits and methods of measurement

☐ EN 55015

Limits and methods of measurement of radio disturbance characteristics of fluorescent lamps and luminaires

☐ EN 55014-2

☐ EN 55020

Immunity from radio interference of household appliances and associated equipment

☐ EN 50091-2

Immunity requirements for household appliances tools and similar apparatus

EMC requirements for uninterruptible power systems (UPS)

☒ EN 55022

Limits and methods of measurement of radio disturbance characteristics of information technology equipment

☐ DIN VDE 0855  
☐ Part 1  
☐ Part 12

Cabled distribution systems: Equipment for data transmission from sound and television signals

☒ CE marking



(EC conformity marking)

The manufacturer also declares the conformity of above mentioned product with the actual required safety standards in accordance with LVD 7323 EEC

☐ EN 60065

Safety requirements for mains operated household and similar general use

☐ EN 60950

Safety for information technology equipment including electrical business equipment

☐ EN 60335

Safety of household and similar electrical appliances

☐ EN 50091-1

General and Safety requirements for uninterruptible power systems (UPS)

Manufacturer/Importer

Signature: Jimmy Huang

(Stamp)

Date: Nov. 24, 2004

Name: Timmy Huang

## DECLARATION OF CONFORMITY

Per FCC Part 2, Section 2.1077(a)



Responsible Party Name: G.B.T. INC. (U.S.A.)

Address: 17358 Railroad Street

City of Industry, CA 91748

Phone/Fax No: (818) 854-9338/ (818) 854-9339

hereby declares that the product

**Product Name: Motherboard**

**Model Number: GA-81915GV-MF/**  
**GA-81915GVM**

Conforms to the following specifications:

FCC Part 15, Subpart B, Section 15.107(a) and Section 15.109

(a), Class B Digital Device

### Supplementary Information:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful and (2) this device must accept any interference received, including that may cause undesired operation.

Representative Person's Name: ERIC LU

Signature: Eric Lu

Date: Nov. 24, 2004

## **Copyright**

© 2004 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved.

The trademarks mentioned in the manual are legally registered to their respective companies.

## **Notice**

The written content provided with this product is the property of Gigabyte.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without Gigabyte's prior written permission. Specifications and features are subject to change without prior notice.

## **Product Manual Classification**

In order to assist in the use of this product, Gigabyte has categorized the user manual in the following:

- For detailed product information and specifications, please carefully read the "Product User Manual".
- For detailed information related to Gigabyte's unique features, please go to "Technology Guide" section on Gigabyte's website to read or download the information you need.


For more product details, please click onto Gigabyte's website at [www.gigabyte.com.tw](http://www.gigabyte.com.tw)

# Table of Content

|  |        |
|--|--------|
| GA-8I915GV-MF/GA-8I915GVM Motherboard Layout ..... | 6      |
| Block Diagram .....                                | 7      |
| <br>Chapter 1 Hardware Installation .....          | <br>9  |
| 1-1    Considerations Prior to Installation .....  | 9      |
| 1-2    Feature Summary .....                       | 10     |
| 1-3    Installation of the CPU and Heatsink .....  | 12     |
| 1-3-1    Installation of the CPU .....             | 12     |
| 1-3-2    Installation of the Heatsink .....        | 13     |
| 1-4    Installation of Memory .....                | 14     |
| 1-5    Install expansion cards .....               | 16     |
| 1-6    I/O Back Panel Introduction .....           | 17     |
| 1-7    Connectors Introduction .....               | 18     |
| <br>Chapter 2 BIOS Setup .....                     | <br>29 |
| The Main Menu (For example: BIOS Ver. : E2) .....  | 30     |
| 2-1    Standard CMOS Features .....                | 32     |
| 2-2    Advanced BIOS Features .....                | 34     |
| 2-3    Integrated Peripherals .....                | 36     |
| 2-4    Power Management Setup .....                | 39     |
| 2-5    PnP/PCI Configurations .....                | 41     |
| 2-6    PC Health Status .....                      | 42     |
| 2-7    MB Intelligent Tweaker(M.I.T.) .....        | 43     |
| 2-8    Load Fail-Safe Defaults .....               | 44     |
| 2-9    Load Optimized Defaults .....               | 44     |
| 2-10    Set Supervisor/User Password .....         | 45     |
| 2-11    Save & Exit Setup .....                    | 46     |
| 2-12    Exit Without Saving .....                  | 46     |

|           |   |    |
|-----------|---|----|
| Chapter 3 | Install Drivers .....                                       | 47 |
| 3-1       | Install Chipset Drivers .....                               | 47 |
| 3-2       | Software Applications .....                                 | 48 |
| 3-3       | Driver CD Information .....                                 | 48 |
| 3-4       | Hardware Information .....                                  | 49 |
| 3-5       | Contact Us .....  | 49 |
| Chapter 4 | Appendix .....  | 51 |
| 4-1       | Unique Software Utilities .....                             | 51 |
| 4-1-1     | EasyTune 5 Introduction .....                               | 52 |
| 4-1-2     | Xpress Recovery Introduction .....                          | 53 |
| 4-1-3     | Flash BIOS Method Introduction .....                        | 56 |
| 4-1-4     | 2- / 4- / 6- / 8- Channel Audio Function Introduction ..... | 65 |
| 4-2       | Troubleshooting .....                                       | 69 |


# GA-8I915GV-MF/GA-8I915GVM Motherboard Layout



① Only for GA-8I915GV-MF.

② Only for GA-8I915GVM.

## Block Diagram



- ① Only for GA-8I915GV-MF.  
② Only for GA-8I915GVM.

[illegible]



# Chapter 1 Hardware Installation

## 1-1 Considerations Prior to Installation

### Preparing Your Computer

The motherboard contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Thus, prior to installation, please follow the instructions below:

1. Please turn off the computer and unplug its power cord.
2. When handling the motherboard, avoid touching any metal leads or connectors.
3. It is best to wear an electrostatic discharge (ESD) cuff when handling electronic components (CPU, RAM).
4. Prior to installing the electronic components, please have these items on top of an antistatic pad or within a electrostatic shielding container.
5. Please verify that you the power supply is switched off before unplugging the power supply connector from the motherboard.

### Installation Notices

1. Prior to installation, please do not remove the stickers on the motherboard. These stickers are required for warranty validation.
2. Prior to the installation of the motherboard or any hardware, please first carefully read the information in the provided manual.
3. Before using the product, please verify that all cables and power connectors are connected.
4. To prevent damage to the motherboard, please do not allow screws to come in contact with the motherboard circuit or its components.
5. Please make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
6. Please do not place the computer system on an uneven surface.
7. Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
8. If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.

### Instances of Non-Warranty

1. Damage due to natural disaster, accident or human cause.
2. Damage as a result of violating the conditions recommended in the user manual.
3. Damage due to improper installation.
4. Damage due to use of uncertified components.
5. Damage due to use exceeding the permitted parameters.
6. Product determined to be an unofficial Gigabyte product.

## 1-2 Feature Summary

|                 |  |
|-----------------|--|
| CPU             | <ul style="list-style-type: none"> <li>• Supports the latest Intel® Pentium® 4 LGA775 CPU</li> <li>• Supports 800/533MHz FSB</li> <li>• L2 cache varies with CPU</li> </ul>  |
| Chipset         | <ul style="list-style-type: none"> <li>• Northbridge: Intel® 915GV Express chipset</li> <li>• Southbridge: Intel® ICH6</li> </ul>  |
| Memory          | <ul style="list-style-type: none"> <li>• 4 DDR DIMM memory slots (supports up to 4GB memory) <sup>(Note 1)</sup></li> <li>• Supports dual channel DDR400/333/266 DIMM</li> <li>• Supports 2.5V DDR DIMM</li> </ul>   |
| Slots           | <ul style="list-style-type: none"> <li>• 1 PCI Express x 1 slot</li> <li>• 2 PCI slots</li> </ul>  |
| IDE Connections | <ul style="list-style-type: none"> <li>• 1 IDE connection (UDMA 33/ATA 66/ATA 100), allows connection of 2 IIDE devices</li> </ul>   |
| FDD Connections | <ul style="list-style-type: none"> <li>• 1 FDD connection, allows connection of 2 FDD devices</li> </ul>   |
| Onboard SATA    | <ul style="list-style-type: none"> <li>• 4 Serial ATA connections</li> </ul>   |
| Peripherals     | <ul style="list-style-type: none"> <li>• 1 parallel port supporting Normal/EPP/ECP mode</li> <li>• 1 VGA port, onboard COMA/COMB connection</li> <li>• 8 USB 2.0/1.1 ports (rear x 4, front x 4 via cable)</li> <li>• 3 IEEE1394 ports (requires cable) ①</li> <li>• 1 front audio connector</li> <li>• 1 IR connector</li> <li>• 1 PS/2 keyboard port</li> <li>• 1 PS/2 mouse port</li> </ul> |
| Onboard LAN     | <ul style="list-style-type: none"> <li>• Onboard Realtek 8110S chip (10/100/1000 Mbit)②</li> <li>• Onboard Realtek 8100C chip (10/100 Mbit)②</li> <li>• 1 RJ 45 port</li> </ul>  |
| Onboard Audio   | <ul style="list-style-type: none"> <li>• ALC880 CODEC</li> <li>• High Definition Audio</li> <li>• Supports 2 / 4 / 6 / 8 channel audio</li> <li>• Supports Line In ; Line Out (Front Speaker Out) ; MIC ; Surround Speaker Out (Rear Speaker Out) ; Center/Subwoofer Speaker Out ; Side Speaker Out connection</li> <li>• Supports SPDIF In/Out connection</li> <li>• CD In</li> </ul>         |

(Note 1) Due to standard PC architecture, a certain amount of memory is reserved for system usage and therefore the actual memory size is less than the stated amount.

For example, 4 GB of memory size will instead be shown as 3.xxGB memory during system startup.

① Only for GA-8I915GV-MF.

② Only for GA-8I915GVM.

|                     |   |
|---------------------|---|
| I/O Control         | ♦ IT8712  |
| Hardware Monitor    | ♦ System voltage detection<br>♦ CPU temperature detection<br>♦ CPU / System fan speed detection<br>♦ CPU warning temperature<br>♦ CPU / System fan failure warning<br>♦ CPU smart fan control |
| BIOS                | ♦ Use of licensed AWARD BIOS<br>♦ Supports Q-Flash  |
| Additional Features | ♦ Supports @BIOS<br>♦ Supports EasyTune 5 (only supports Hardware Monitor function)   |
| Overclocking        | ♦ Over Clock via BIOS (DDR)   |
| Form Factor         | ♦ Micro ATX form factor; 24.4 cm x 24.4 cm  |

## 1-3 Installation of the CPU and Heatsink



Before installing the CPU, please comply with the following conditions:

1. Please make sure that the motherboard supports the CPU.
2. Please take note of the one indented corner of the CPU. If you install the CPU in the wrong direction, the CPU will not insert properly. If this occurs, please change the insert direction of the CPU.
3. Please add an even layer of heat sink paste between the CPU and heatsink.
4. Please make sure the heatsink is installed on the CPU prior to system use, otherwise overheating and permanent damage of the CPU may occur.
5. Please set the CPU host frequency in accordance with the processor specifications. It is not recommended that the system bus frequency be set beyond hardware specifications since it does not meet the required standards for the peripherals. If you wish to set the frequency beyond the proper specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc.



### HT functionality requirement content :

Enabling the functionality of Hyper-Threading Technology for your computer system requires all of the following platform components:

- CPU: An Intel® Pentium 4 Processor with HT Technology
- Chipset: An Intel® Chipset that supports HT Technology
- BIOS: A BIOS that supports HT Technology and has it enabled
- OS: An operation system that has optimizations for HT Technology

### 1-3-1 Installation of the CPU




Fig. 1  
Gently lift the metal lever located on the CPU socket to the upright position.




Fig. 2  
Remove the plastic covering on the CPU socket.




Fig. 3  
Notice the small gold colored triangle located on the edge of the CPU socket. Align the indented corner of the

CPU with the triangle and gently insert the CPU into position. (Grasping the CPU firmly between your thumb and forefinger, carefully place it into the socket in a straight and downwards motion. Avoid twisting or bending motions that might cause damage to the CPU during installation.)




Fig. 4  
Once the CPU is properly inserted, please replace the load plate and push the metal lever back into its original position.

### 1-3-2 Installation of the Heatsink



Fig. 1

Please apply an even layer of heatsink paste on the surface of the installed CPU.




Fig. 3

Place the heatsink atop the CPU and make sure the push pins aim to the pin hole on the motherboard. Pressing down the push pins diagonally.




Fig. 5

Please check the back of motherboard after installing. If the push pin is inserted as the picture, the installation is complete.



NOTE

The heatsink may adhere to the CPU as a result of hardening of the heatsink paste. To prevent such an occurrence, it is suggested that either thermal tape rather than heat sink paste be used for heat dissipation or using extreme care when removing the heatsink.




Fig. 2

(Turning the push pin along the direction of arrow is to remove the heatsink, on the contrary, is to install.) Please note the direction of arrow sign on the male push pin doesn't face inwards before installation. (This instruction is only for Intel boxed fan)




Fig. 4

Please make sure the Male and Female push pin are joined closely. (for detailed installation instructions, please refer to the heatsink installation section of the user manual)




Fig. 6

Finally, please attach the power connector of the heatsink to the CPU fan header located on the motherboard.


## 1-4 Installation of Memory




Before installing the memory modules, please comply with the following conditions:

1. Please make sure that the memory used is supported by the motherboard. It is recommended that memory of similar capacity, specifications and brand be used.
2. Before installing or removing memory modules, please make sure that the computer power is switched off to prevent hardware damage.
3. Memory modules have a foolproof insertion design. A memory module can be installed in only one direction. If you are unable to insert the module, please switch the direction.

The motherboard supports DDR memory modules, whereby BIOS will automatically detect memory capacity and specifications. Memory modules are designed so that they can be inserted only in one direction. The memory capacity used can differ with each slot.



1. The DIMM slot has a notch, so the DIMM memory module can only fit in one direction.



2. Insert the DIMM memory module vertically into the DIMM slot. Then push it down.



3. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module. Reverse the installation steps when you wish to remove the DIMM module.



GA-8I915GV-MF/GA-8I915GVM supports the Dual Channel Technology. After operating the Dual Channel Technology, the bandwidth of Memory Bus will double.

GA-8I915GV-MF/GA-8I915GVM includes 4 DIMM sockets, and each Channel has two DIMM sockets as following:

‣ Channel A : DDR 1, DDR 2

‣ Channel B : DDR 3, DDR 4

If you want to operate the Dual Channel Technology, please note the following explanations due to the limitation of Intel chipset specifications.

1. One/three DDR memory module is installed: The Dual Channel Technology can't operate when only one DDR memory module is installed.
2. Two DDR memory modules are installed (the same memory size and type): The Dual Channel Technology will operate when two memory modules are inserted individually into Channel A and B. If you install two memory modules in the same channel, the Dual Channel Technology will not operate.
3. Four DDR memory modules are installed: If you install four memory modules at the same time, the Dual Channel Technology will operate only when those modules have the same memory size and type.

We'll strongly recommend our user to slot two DDR memory modules into the DIMMs with the same color in order for Dual Channel Technology to work.

The following table is for Dual Channel Technology combination: (DS: Double Side, SS: Single Side)


|                  | DDR1  | DDR 2 | DDR3  | DDR4  |
|------------------|-------|-------|-------|-------|
| 2 memory modules | DS/SS | X     | DS/SS | X     |
|                  | X     | DS/SS | X     | DS/SS |
| 4 memory modules | DS/SS | DS/SS | DS/SS | DS/SS |

## 1-5 Install expansion cards

You can install your expansion card by following the steps outlined below:


1. Read the related expansion card's instruction document before install the expansion card into the computer.
2. Remove your computer's chassis cover, screws and slot bracket from the computer.
3. Press the expansion card firmly into expansion slot in motherboard.
4. Be sure the metal contacts on the card are indeed seated in the slot.
5. Replace the screw to secure the slot bracket of the expansion card.
6. Replace your computer's chassis cover.
7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
8. Install related driver from the operating system.

Installing a PCI expansion card:





## 1-6 I/O Back Panel Introduction



### ❶ PS/2 Keyboard and PS/2 Mouse Connector

To install a PS/2 port keyboard and mouse, plug the mouse to the upper port (green) and the keyboard to the lower port (purple).

### ❷ Parallel Port

The parallel port allows connection of a printer, scanner and other peripheral devices.

### ❸ SPDIF\_O (SPDIF Out)

The SPDIF output is capable of providing digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder.

### ❹ SPDIF\_I (SPDIF In)

Use SPDIF In feature only when your device has digital output function.

### ❺ VGA Port

Monitor can be connected to VGA port.

### ❻ USB port

Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker...etc. have a standard USB interface.

Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

### ❼ LAN Port

The provided Internet connection is Gigabit Ethernet, providing data transfer speeds of 10/100/1000Mbps. ①

The provided Internet connection is fast Ethernet, providing data transfer speeds of 10/100Mbps. ②

### ❽ Line In

Devices like CD-ROM, walkman etc. can be connected to Line In jack.

### ❾ Line Out (Front Speaker Out)

Connect the stereo speakers, earphone or front surround speakers to this connector.

### ❿ MIC In

Microphone can be connected to MIC In jack.

① Only for GA-8I915GV-MF.

② Only for GA-8I915GVM.

### ⑧ Rear Speaker Out

Connect the rear surround speakers to this connector.

### ⑨ Center/Subwoofer Speaker Out

Connect the Center/Subwoofer speakers to this connector.


### ⑩ Side Speaker Out

Connect the side surround speakers to this connector.



You can use audio software to configure 2-/4-/6-/8-channel audio functioning.

## 1-7 Connectors Introduction



|                                  |                         |
|----------------------------------|-------------------------|
| 1) ATX_12V                       | 10) AZALIA_FP           |
| 2) ATX (Power Connector)         | 11) CD_IN               |
| 3) CPU_FAN                       | 12) F_USB1 / F_USB2     |
| 4) SYS_FAN                       | 13) F1_1394 / F2_1394 ① |
| 5) FDD                           | 14) IR                  |
| 6) IDE                           | 15) COMA / COMB         |
| 7) SATA0 / SATA1 / SATA2 / SATA3 | 16) CLR_CMOS            |
| 8) F_PANEL                       | 17) BAT                 |
| 9) PWR_LED                       |                         |

① Only for GA-8I915GV-MF.

## 1/2) ATX\_12V/ATX (Power Connector)



With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard. Before connecting the power connector, please make sure that all components and devices are properly installed. Align the power connector with its proper location on the motherboard and connect tightly.

The ATX\_12V power connector mainly supplies power to the CPU. If the ATX\_12V power connector is not connected, the system will not start.


Caution!

Please use a power supply that is able to handle the system voltage requirements. It is recommended that a power supply that can withstand high power consumption be used (300W or greater). If a power supply is used that does not provide the required power, the result can lead to an unstable system or a system that is unable to start.

If you use a 24-pin ATX power supply, please remove the small cover on the power connector on the motherboard before plugging in the power cord ; Otherwise, please do not remove it.



| Pin No. | Definition |
|---------|------------|
| 1       | GND        |
| 2       | GND        |
| 3       | +12V       |
| 4       | +12V       |



| Pin No. | Definition                |
|---------|---------------------------|
| 1       | 3.3V                      |
| 2       | 3.3V                      |
| 3       | GND                       |
| 4       | VCC                       |
| 5       | GND                       |
| 6       | VCC                       |
| 7       | GND                       |
| 8       | Power Good                |
| 9       | 5V SB(stand by +5V)       |
| 10      | +12V                      |
| 11      | +12V                      |
| 12      | 3.3V(Only for 24pins ATX) |
| 13      | 3.3V                      |
| 14      | -12V                      |
| 15      | GND                       |
| 16      | PS_ON(soft On/Off)        |
| 17      | GND                       |
| 18      | GND                       |
| 19      | GND                       |
| 20      | -5V                       |
| 21      | VCC                       |
| 22      | VCC                       |
| 23      | VCC                       |
| 24      | GND                       |

### 3/4) CPU\_FAN / SYS\_FAN (Cooler Fan Power Connector)


The cooler fan power connector supplies a +12V power voltage via a 3-pin/4-pin (only for CPU\_FAN) power connector and possesses a foolproof connection design.

Most coolers are designed with color-coded power connector wires. A red power connector wire indicates a positive connection and requires a +12V power voltage. The black connector wire is the ground wire (GND).

Please remember to connect the power to the cooler to prevent system overheating and failure.

Caution!


Please remember to connect the power to the CPU fan to prevent CPU overheating and failure.



### 5) FDD (Floppy Connector)



The FDD connector is used to connect the FDD cable while the other end of the cable connects to the FDD drive. The types of FDD drives supported are: 360KB, 720KB, 1.2MB, 1.44MB and 2.88MB.

Please connect the red power connector wire to the pin1 position.




## 6) IDE (IDE Connector)

An IDE device connects to the computer via an IDE connector. One IDE connector can connect to one IDE cable, and the single IDE cable can then connect to two IDE devices (hard drive or optical drive). If you wish to connect two IDE devices, please set the jumper on one IDE device as Master and the other as Slave (for information on settings, please refer to the instructions located on the IDE device).



## 7) SATA0/SATA1/SATA2/SATA3 (Serial ATA Connector, Controlled by ICH6)


Serial ATA can provide 150MB/s transfer rate. Please refer to the BIOS setting for the Serial ATA and install the proper driver in order to work properly.



| Pin No. | Definition |
|---------|------------|
| 1       | GND        |
| 2       | TXP        |
| 3       | TXN        |
| 4       | GND        |
| 5       | RXN        |
| 6       | RXP        |
| 7       | GND        |

## 8) F\_PANEL (Front Panel Jumper)


Please connect the power LED, PC speaker, reset switch and power switch etc of your chassis front panel to the F\_PANEL connector according to the pin assignment below.



|                                  |  |
|----------------------------------|--|
| HD (IDE Hard Disk Active LED)    | Pin 1: LED anode(+)<br>Pin 2: LED cathode(-)           |
| SPEAK (Speaker Connector)        | Pin 1: VCC(+)<br>Pin 2- Pin 3: NC<br>Pin 4: Data(-)    |
| RES (Reset Switch)               | Open: Normal Operation<br>Close: Reset Hardware System |
| PW (Power Switch)                | Open: Normal Operation<br>Close: Power On/Off          |
| MSG(Message LED/Power/Sleep LED) | Pin 1: LED anode(+)<br>Pin 2: LED cathode(-)           |
| NC                               | NC   |

## 9) PWR\_LED

PWR\_LED is connect with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode.




1

| Pin No. | Definition |
|---------|------------|
| 1       | MPD+       |
| 2       | MPD-       |
| 3       | MPD-       |

## 10) AZALIA\_FP(Front Audio Panel Connector)

This connector is supported to connect HD(High Definition) Audio and AC'97 Audio. Check the pin assignment carefully while you connect the audio panel cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional audio panel cable, please contact your local dealer.



10 9  
2 1

HD Audio:

| Pin No. | Definition |
|---------|------------|
| 1       | MIC2_L     |
| 2       | GND        |
| 3       | MIC2_R     |
| 4       | -ACZ_DET   |
| 5       | Line2_R    |
| 6       | FSENSE1    |
| 7       | FAUOIO_JD  |
| 8       | No Pin     |
| 9       | LINE2_L    |
| 10      | FSENSE2    |

AC'97 Audio:

| Pin No. | Definition   |
|---------|--------------|
| 1       | MIC          |
| 2       | GND          |
| 3       | MIC Power    |
| 4       | N/A          |
| 5       | Line Out (R) |
| 6       | N/A          |
| 7       | N/A          |
| 8       | No Pin       |
| 9       | Line Out (L) |
| 10      | N/A          |




NOTE

HD Audio is the default setting for this connector. To enable AC'97 Audio, from BIOS settings, set **Front Panel Type** under **Integrated Peripherals** to **AC97**.

## 11) CD\_IN (CD IN)


Connect CD-ROM or DVD-ROM audio out to the connector.



| Pin No. | Definition |
|---------|------------|
| 1       | CD-L       |
| 2       | GND        |
| 3       | GND        |
| 4       | CD-R       |

## 12) F\_USB1 / F\_USB2 (Front USB Connector)

Be careful with the polarity of the front USB connector. Check the pin assignment carefully while you connect the front USB cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional front USB cable, please contact your local dealer. The "USB Device Wake up From S3" is only supported by rear USB ports.





| Pin No. | Definition |
|---------|------------|
| 1       | Power      |
| 2       | Power      |
| 3       | USB DX-    |
| 4       | USB Dy-    |
| 5       | USB DX+    |
| 6       | USB Dy+    |
| 7       | GND        |
| 8       | GND        |
| 9       | No Pin     |
| 10      | NC         |




### 13) F1\_1394/F2\_1394 (IEEE 1394 Connector) ①

Serial interface standard set by Institute of Electrical and Electronics Engineers, which has features like high speed, high bandwidth and hot plug.

Be careful with the polarity of the IEEE1394 connector. Check the pin assignment carefully while you connect the IEEE1394 cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional IEEE1394 cable, please contact your local dealer.



F2\_1394




F1\_1394

| Pin No. | Definition |
|---------|------------|
| 1       | TPA2+      |
| 2       | TPA2-      |
| 3       | GND        |
| 4       | GND        |
| 5       | TPB2+      |
| 6       | TPB2-      |
| 7       | No Pin     |
| 8       | Power      |
| 9       | Power      |
| 10      | GND        |

| Pin No. | Definition |
|---------|------------|
| 1       | Power      |
| 2       | Power      |
| 3       | TPA0+      |
| 4       | TPA0-      |
| 5       | GND        |
| 6       | GND        |
| 7       | TPB0+      |
| 8       | TPB0-      |
| 9       | Power      |
| 10      | Power      |
| 11      | TPA1+      |
| 12      | TPA1-      |
| 13      | GND        |
| 14      | No Pin     |
| 15      | TPB1+      |
| 16      | TPB1-      |

### 14) IR

Be careful with the polarity of the IR connector while you connect the IR. Please contact your nearest dealer for optional IR device.




| Pin No. | Definition |
|---------|------------|
| 1       | VCC        |
| 2       | No Pin     |
| 3       | IRRX       |
| 4       | GND        |
| 5       | IRTX       |

① Only for GA-8I915GV-MF.

## 15) COMA/COMB (Serial Port Connector)


Be careful with the polarity of the COM connector. Check the pin assignment carefully while you connect the COM cable, incorrect connection between the cable and connector will make the device unable to work or even damage it. For optional COM cable, please contact your local dealer.



| Pin No. | Definition |
|---------|------------|
| 1       | NDCCA/B-   |
| 2       | NSINA/B    |
| 3       | NSOUT A/B  |
| 4       | NDTRA/B-   |
| 5       | GND        |
| 6       | NDSRA/B-   |
| 7       | NRTS A/B-  |
| 8       | NCTS A/B-  |
| 9       | NRIA/B-    |
| 10      | No Pin     |

## 16) CLR\_CMOS (Clear CMOS)



You may clear the CMOS data to its default values by this jumper. To clear CMOS, temporarily short 1-2 pin. Default doesn't include the "Shunter" to prevent from improper use this jumper.



1 Open: Normal

1 Short: Clear CMOS

## 17) BAT(Battery)



- ❖ Danger of explosion if battery is incorrectly replaced.
- ❖ Replace only with the same or equivalent type recommended by the manufacturer.
- ❖ Dispose of used batteries according to the manufacturer's instructions.

If you want to erase CMOS...

1. Turn OFF the computer and unplug the power cord.
2. Remove the battery, wait for 30 second.
3. Re-install the battery.
4. Plug the power cord and turn ON the computer.



## Chapter 2 BIOS Setup

BIOS (Basic Input and Output System) includes a CMOS SETUP utility which allows user to configure required settings or to activate certain system features.

The CMOS SETUP saves the configuration in the CMOS SRAM of the motherboard.

When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS SRAM.

When the power is turned on, pushing the <Del> button during the BIOS POST (Power-On Self Test) will take you to the CMOS SETUP screen. You can enter the BIOS setup screen by pressing "Ctrl + F1".

When setting up BIOS for the first time, it is recommended that you save the current BIOS to a disk in the event that BIOS needs to be reset to its original settings. If you wish to upgrade to a new BIOS, either Gigabyte's Q-Flash or @BIOS utility can be used.

Q-Flash allows the user to quickly and easily update or backup BIOS without entering the operating system. @BIOS is a Windows-based utility that does not require users to boot to DOS before upgrading BIOS but directly download and update BIOS from the Internet.

### CONTROL KEYS

|              |   |
|--------------|---|
| <↑><↓><←><→> | Move to select item   |
| <Enter>      | Select Item   |
| <Esc>        | Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu |
| <Page Up>    | Increase the numeric value or make changes  |
| <Page Down>  | Decrease the numeric value or make changes  |
| <F1>         | General help, only for Status Page Setup Menu and Option Page Setup Menu  |
| <F2>         | Item Help   |
| <F5>         | Restore the previous CMOS value from CMOS, only for Option Page Setup Menu  |
| <F6>         | Load the file-safe default CMOS value from BIOS default table   |
| <F7>         | Load the Optimized Defaults   |
| <F8>         | Q-Flash utility   |
| <F9>         | System Information  |
| <F10>        | Save all the CMOS changes, only for Main Menu   |

### Main Menu


The on-line description of the highlighted setup function is displayed at the bottom of the screen.

### Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

## The Main Menu (For example: BIOS Ver. : E2)

Once you enter Award BIOS CMOS Setup Utility, the Main Menu (as figure below) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.



NOTE

If you can't find the setting you want, please press "Ctrl+F1" to search the advanced option hidden.

Please Load Optimized Defaults in the BIOS when somehow the system works not stable as usual. This action makes the system reset to the default for stability.

### ■ Standard CMOS Features

This setup page includes all the items in standard compatible BIOS.

### ■ Advanced BIOS Features

This setup page includes all the items of Award special enhanced features.

### ■ Integrated Peripherals

This setup page includes all onboard peripherals.

### ■ Power Management Setup

This setup page includes all the items of Green function features.

### ■ PnP/PCI Configuration

This setup page includes all the configurations of PCI & PnP ISA resources.

### ■ PC Health Status

This setup page is the System auto detect Temperature, voltage, fan, speed.

### ■ MB Intelligent Tweaker(M.I.T.)

This setup page is control CPU clock and frequency ratio.

### ■ Load Fail-Safe Defaults

Fail-Safe Defaults indicates the value of the system parameters which the system would be in safe configuration.

### ■ Load Optimized Defaults

Optimized Defaults indicates the value of the system parameters which the system would be in best performance configuration.

### ■ Set Supervisor Password

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

- **Set User Password**

Change, set, or disable password. It allows you to limit access to the system.

- **Save & Exit Setup**

Save CMOS value settings to CMOS and exit setup.

- **Exit Without Saving**

Abandon all CMOS value changes and exit setup.

## 2-1 Standard CMOS Features

| CMOS Setup Utility-Copyright (C) 1984-2004 Award Software   |                     |   |
|---|---------------------|---|
| Standard CMOS Features  |                     |   |
| Date (mm:dd:yy)   | Thu, Apr 29 2004    | Item Help                                 |
| Time (hh:mm:ss)   | 22:31:24            | Menu Level▶                               |
| ▶ IDE Channel 0 Master  | [None]              | Change the day, month, year               |
| ▶ IDE Channel 0 Slave   | [None]              |   |
| ▶ IDE Channel 2 Master  | [None]              | <Week>                                    |
| ▶ IDE Channel 2 Slave   | [None]              | Sun. to Sat.                              |
| ▶ IDE Channel 3 Master  | [None]              | <Month>                                   |
| ▶ IDE Channel 3 Slave   | [None]              | Jan. to Dec.                              |
| Drive A   | [1.44M, 3.5"]       | <Day>                                     |
| Drive B   | [None]              | 1 to 31 (or maximum allowed in the month) |
| Floppy 3 Mode Suport  | [Disabled]          | <Year>                                    |
| Halt On   | [All, But Keyboard] | 1999 to 2098                              |
| Base Memory   | 640K                |   |
| Extended Memory   | 127M                |   |
| Total Memory  | 128M                |   |
| ↑↓→←: Move    Enter: Select    +/-/PU/PD: Value    F10: Save    ESC: Exit    F1: General Help<br>F5: Previous Values    F6: Fail-Safe Default    F7: Optimized Defaults |                     |   |

### 🔑 Date

The date format is <week>, <month>, <day>, <year>.

- ▶ Week      The week, from Sun to Sat, determined by the BIOS and is display only
- ▶ Month     The month, Jan. Through Dec.
- ▶ Day        The day, from 1 to 31 (or the maximum allowed in the month)
- ▶ Year        The year, from 1999 through 2098

### 🔑 Time

The times format in <hour> <minute> <second>. The time is calculated base on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.

### 🔑 IDE Channel 0/2/3 Master, Slave

- ▶ IDE HDD Auto-Detection Press "Enter" to select this option for automatic device detection.
- ▶ IDE Channel 0/2/3 Master(Slave) IDE Device Setup. You can use one of three methods:
  - Auto      Allows BIOS to automatically detect IDE devices during POST(default)
  - None      Select this if no IDE devices are used and the system will skip the automatic detection step and allow for faster system start up.
  - Manual    User can manually input the correct settings
- ▶ Access Mode Use this to set the access mode for the hard drive. The four options are: CHS/LBA/Large/Auto(default:Auto)

Hard drive information should be labeled on the outside drive casing. Enter the appropriate option based on this information.

- ▶ Cylinder    Number of cylinders
- ▶ Head        Number of heads
- ▶ Precomp    Write precomp
- ▶ Landing Zone Landing zone
- ▶ Sector      Number of sectors

If a hard disk has not been installed, select NONE and press <Enter>.



## ☞ Drive A / Drive B

The category identifies the types of floppy disk drive A or drive B that has been installed in the computer.

- » None No floppy drive installed
- » 360K, 5.25" 5.25 inch PC-type standard drive; 360K byte capacity.
- » 1.2M, 5.25" 5.25 inch AT-type high-density drive; 1.2M byte capacity (3.5 inch when 3 Mode is Enabled).
- » 720K, 3.5" 3.5 inch double-sided drive; 720K byte capacity
- » 1.44M, 3.5" 3.5 inch double-sided drive; 1.44M byte capacity.
- » 2.88M, 3.5" 3.5 inch double-sided drive; 2.88M byte capacity.

## ☞ Floppy 3 Mode Support (for Japan Area)

- » Disabled Normal Floppy Drive. (Default value)
- » Drive A Drive A is 3 mode Floppy Drive.
- » Drive B Drive B is 3 mode Floppy Drive.
- » Both Drive A & B are 3 mode Floppy Drives.

## ☞ Halt on

The category determines whether the computer will stop if an error is detected during power up.

- » No Errors The system boot will not stop for any error that may be detected and you will be prompted.
- » All Errors Whenever the BIOS detects a non-fatal error the system will be stopped.
- » All, But Keyboard The system boot will not stop for a keyboard error; it will stop for all other errors. (Default value)
- » All, But Diskette The system boot will not stop for a disk error; it will stop for all other errors.
- » All, But Disk/Key The system boot will not stop for a keyboard or disk error; it will stop for all other errors.

## ☞ Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

### » Base Memory

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.


The value of the base memory is typically 512K for systems with 512K memory installed on the motherboard, or 640K for systems with 640K or more memory installed on the motherboard.

### » Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1 MB in the CPU's memory address map.

## 2-2 Advanced BIOS Features



" # " System will detect automatically and show up when you install the Intel® Pentium® 4 processor with HT Technology.



### Hard Disk Boot Priority

Select boot sequence for onboard(or add-on cards) SCSI, RAID, etc.

Use <↑> or <↓> to select a device, then press<+> to move it up, or <-> to move it down the list. Press <ESC> to exit this menu.



### First / Second / Third Boot Device

- ▶ Floppy                      Select your boot device priority by Floppy.
- ▶ LS120                     Select your boot device priority by LS120.
- ▶ Hard Disk                Select your boot device priority by Hard Disk.
- ▶ CDROM                    Select your boot device priority by CDROM.
- ▶ ZIP                        Select your boot device priority by ZIP.
- ▶ USB-FDD                 Select your boot device priority by USB-FDD.
- ▶ USB-ZIP                  Select your boot device priority by USB-ZIP.
- ▶ USB-CDROM             Select your boot device priority by USB-CDROM.
- ▶ USB-HDD                Select your boot device priority by USB-HDD.
- ▶ LAN                        Select your boot device priority by LAN.
- ▶ Disabled                 Select your boot device priority by Disabled.

(Note) This item will show up when you install a processor which supports this function.

### **Password Check**

- » Setup      The system will boot but will not access to Setup page if the correct password is not entered at the prompt. (Default value)
- » System    The system will not boot and will not access to Setup page if the correct password is not entered at the prompt.

### **CPU Hyper-Threading**

- » Enabled    Enables CPU Hyper Threading Feature. Please note that this feature is only working for operating system with multi processors mode supported. (Default value)
- » Disabled   Disables CPU Hyper Threading.

### **Limit CPUID Max. to 3**

- » Enabled    Limit CPUID Maximum value to 3 when use older OS like NT4. (Default value)
- » Disabled   Disables CPUID Limit for windows XP.

### **No-Execute Memory Protect** <sup>(Note)</sup>

- » Enabled    Enables No-Execute Memory Protect function.
- » Disabled   Disables No-Execute Memory Protect function. (Default value)

### **CPU Enhanced Halt (C1E)** <sup>(Note)</sup>

- » Enabled    Enables CPU Enhanced Halt (C1E) function.
- » Disabled   Disables CPU Enhanced Halt (C1E) function. (Default value)

### **CPU Thermal Monitor 2 (TM2)** <sup>(Note)</sup>

- » Enabled    Enable CPU Thermal Monitor 2 (TM2) function.
- » Disabled   Disable CPU Thermal Monitor 2 (TM2) function. (Default value)

### **On-Chip Frame Buffer Size**

- » 1MB        Set On-chip frame buffer size to 1MB.
- » 4MB        Set On-chip frame buffer size to 4MB.
- » 8MB        Set On-chip frame buffer size to 8MB. (Default value)
- » 16MB       Set On-chip frame buffer size to 16MB.
- » 32MB       Set On-chip frame buffer size to 32MB.

(Note) This item will show up when you install a processor which supports this function.

## 2-3 Integrated Peripherals

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software  
Integrated Peripherals

|                         |                   |             |
|-------------------------|-------------------|-------------|
| On-Chip Primary PCI IDE | [Enabled]         | Item Help   |
| On-Chip SATA Mode       | [Auto]            | Menu Level▶ |
| x PATA IDE Set to       | Ch.1 Master/Slave |             |
| SATA Port 0/2 Set to    | Ch.2 Master/Slave |             |
| SATA Port 1/3 Set to    | Ch.3 Master/Slave |             |
| USB Controller          | [Enabled]         |             |
| USB 2.0 Controller      | [Enabled]         |             |
| USB Keyboard Support    | [Disabled]        |             |
| USB Mouse Support       | [Disabled]        |             |
| Azalia Codec            | [Auto]            |             |
| Front Panel Type        | [HD Audio]        |             |
| Onboard H/W 1394 ①      | [Enabled]         |             |
| Onboard H/W LAN         | [Enabled]         |             |
| Onboard LAN Boot ROM    | [Disabled]        |             |
| Onboard Serial Port 1   | [3F8/IRQ4]        |             |
| Onboard Serial Port 2   | [2F8/IRQ3]        |             |
| UART Mode Select        | [Normal]          |             |
| x UR2 Duplex Mode       | [Half]            |             |
| Onboard Parallel Port   | [378/IRQ7]        |             |

↑↓→←: Move    Enter: Select    +/-/PU/PD: Value    F10: Save    ESC: Exit    F1: General Help  
F5: Previous Values    F6: Fail-Safe Default    F7: Optimized Defaults

CMOS Setup Utility-Copyright (C) 1984-2004 Award Software  
Integrated Peripherals

|                    |       |             |
|--------------------|-------|-------------|
| Parallel Port Mode | [SPP] | Item Help   |
| x ECP Mode Use DMA | 3     | Menu Level▶ |

↑↓→←: Move    Enter: Select    +/-/PU/PD: Value    F10: Save    ESC: Exit    F1: General Help  
F5: Previous Values    F6: Fail-Safe Default    F7: Optimized Defaults

### ⌘ On-Chip Primary PCI IDE

- ▶▶ Enabled      Enable onboard 1st channel IDE port. (Default value)
- ▶▶ Disabled     Disable onboard 1st channel IDE port.

① Only for GA-8I915GV-MF.

### ☞ On-Chip SATA Mode

- » Disabled                      Disable this function.
- » Auto                          BIOS will auto detect. (Default value)
- » Combined                    Set On-Chip SATA mode to Combined, you can use up to 4 HDDs on the motherboard; 2 for SATA and the other for PATA IDE.
- » Enhanced                    Set On-Chip SATA mode to Enhanced, the motherboard allows up to 6 HDDs to use.
- » Non-Combined              Set On-Chip SATA mode to Non-Combined, SATA will be simulated to PATA mode.

### ☞ PATA IDE Set to

- » Ch.1 Master/Slave        Set PATA IDE to Ch. 1 Master/Slave. (Default value)
- » Ch.0 Master/Slave        Set PATA IDE to Ch. 0 Master/Slave.

### ☞ SATA Port 0/2 Set to

- » This value will auto make by the setting "On-Chip SATA Mode" and "PATA IDE Set to".  
If PATA IDE were set to Ch. 1 Master/Slave, this function will auto set to Ch. 0 Master/Slave.

### ☞ SATA Port 1/3 Set to

- » This value will auto make by the setting "On-Chip SATA Mode" and "PATA IDE Set to".  
If PATA IDE were set to Ch. 0 Master/Slave, this function will auto set to Ch. 1 Master/Slave.

### ☞ USB Controller

- » Enabled                      Enable USB Controller. (Default value)
- » Disabled                    Disable USB Controller.

### ☞ USB 2.0 Controller

Disable this function if you are not using onboard USB 2.0 feature.

- » Enabled                      Enable USB 2.0 Controller. (Default value)
- » Disabled                    Disable USB 2.0 Controller.

### ☞ USB Keyboard Support

- » Enabled                      Enable USB Keyboard Support.
- » Disabled                    Disable USB Keyboard Support. (Default value)

### ☞ USB Mouse Support

- » Enabled                      Enable USB Mouse Support.
- » Disabled                    Disable USB Mouse Support. (Default value)

### ☞ Azalia Codec

- » Auto                          Auto detect Azalia audio function. (Default value)
- » Disabled                    Disable Azalia audio function.

### ☞ Front Panel Type

If you connect HD Audio Panel to the AZALIA\_FP connector, set this item to **HD Audio**. If you connect AC97 Audio Panel to the AZALIA\_FP connector, set this item to **AC97**.

- » AC97                          Set front audio panel type to AC97.
- » HD Audio                    Set front audio panel type to HD Audio. (Default value)

### ☞ Onboard H/W 1394 ①

- » Enabled Enable onboard IEEE 1394 function.(Default value)
- » Disabled Disable this function.

### ☞ Onboard H/W LAN

- » Enabled Enable Onboard H/W LAN function. (Default value)
- » Disabled Disable this function.

### ☞ Onboard LAN Boot ROM

This function decide whether to invoke the boot ROM of the onboard LAN chip.

- » Enabled Enable this function.
- » Disabled Disable this function. (Default value)

### ☞ Onboard Serial Port 1

- » Auto BIOS will automatically setup the port 1 address.
- » 3F8/IRQ4 Enable onboard Serial port 1 and address is 3F8. (Default value)
- » 2F8/IRQ3 Enable onboard Serial port 1 and address is 2F8.
- » 3E8/IRQ4 Enable onboard Serial port 1 and address is 3E8.
- » 2E8/IRQ3 Enable onboard Serial port 1 and address is 2E8.
- » Disabled Disable onboard Serial port 1.

### ☞ Onboard Serial Port 2

- » Auto BIOS will automatically setup the port 2 address.
- » 3F8/IRQ4 Enable onboard Serial port 2 and address is 3F8.
- » 2F8/IRQ3 Enable onboard Serial port 2 and address is 2F8. (Default value)
- » 3E8/IRQ4 Enable onboard Serial port 2 and address is 3E8.
- » 2E8/IRQ3 Enable onboard Serial port 2 and address is 2E8.
- » Disabled Disable onboard Serial port 2.

### ☞ UART Mode Select

This item allows you to determine which Infra Red(IR) function of Onboard I/O chip.

- » Normal Set onboard I/O chip UART to Normal Mode. (Default Value)
- » ASKIR Set onboard I/O chip UART to ASKIR Mode.
- » IrDA Set onboard I/O chip UART to IrDA Mode.

### ☞ UR2 Duplex Mode

This feature allows you to select IR mode.

This function will available when "UART Mode Select" doesn't set at Normal.

- » Half IR Function Duplex Half. (Default value)
- » Full IR Function Duplex Full.

### ☞ Onboard Parallel port

- » Disabled Disable onboard LPT port.
- » 378/IRQ7 Enable onboard LPT port and address is 378/IRQ7. (Default value)
- » 278/IRQ5 Enable onboard LPT port and address is 278/IRQ5.
- » 3BC/IRQ7 Enable onboard LPT port and address is 3BC/IRQ7.

① Only for GA-8I915GV-MF.

### Parallel Port Mode

- » SPP Using Parallel port as Standard Parallel Port. (Default value)
- » EPP Using Parallel port as Enhanced Parallel Port.
- » ECP Using Parallel port as Extended Capabilities Port.
- » ECP+EPP Using Parallel port as ECP & EPP mode.

### ECP Mode Use DMA

- » 3 Set ECP Mode Use DMA to 3. (Default value)
- » 1 Set ECP Mode Use DMA to 1.

## 2-4 Power Management Setup

| CMOS Setup Utility-Copyright (C) 1984-2004 Award Software |               |             |
|---|---------------|-------------|
| Power Management Setup                                    |               |             |
| ACPI Suspend Type   | [S1(POS)]     | Item Help   |
| Soft-Off by PWR-BTTN                                      | [Instant-off] | Menu Level▶ |
| PME Event Wake Up   | [Enabled]     |             |
| Power On by Ring  | [Enabled]     |             |
| Resume by Alarm   | [Disabled]    |             |
| x Date (of Month) Alarm                                   | Everyday      |             |
| x Time (hh:mm:ss) Alarm                                   | 0 : 0 : 0     |             |
| Power On By Mouse   | [Disabled]    |             |
| Power On By Keyboard                                      | [Disabled]    |             |
| x KB Power ON Password                                    | Enter         |             |
| AC Back Function  | [Soft-Off]    |             |

|                     |                       |                  |           |                        |                  |
|---------------------|-----------------------|------------------|-----------|------------------------|------------------|
| ↑↓→←: Move          | Enter: Select         | +/-/PU/PD: Value | F10: Save | ESC: Exit              | F1: General Help |
| F5: Previous Values | F6: Fail-Safe Default |                  |           | F7: Optimized Defaults |                  |

### ACPI Suspend Type

- » S1(POS) Set ACPI suspend type to S1/POS(Power On Suspend). (Default value)
- » S3(STR) Set ACPI suspend type to S3/STR(Suspend To RAM).

### Soft-off by PWR-BTTN

- » Instant-off Press power button then Power off instantly. (Default value)
- » Delay 4 Sec. Press power button 4 sec. to Power off. Enter suspend if button is pressed less than 4 sec.

### PME Event Wake Up

- » Disabled Disable this function.
- » Enabled Enable PME Event Wake up. (Default value)

### Power On by Ring

- » Disabled Disable Power on by Ring function.
- » Enabled Enable Power on by Ring function. (Default value)

### **Resume by Alarm**

You can set "Resume by Alarm" item to enabled and key in Date/time to power on system.

- » Disabled      Disable this function. (Default value)
- » Enabled      Enable alarm function to POWER ON system.

If RTC Alarm Lead To Power On is Enabled.

- » Date (of Month) Alarm :      Everyday, 1~31
- » Time (hh: mm: ss) Alarm :    (0~23) : (0~59) : (0~59)

### **Power On By Mouse**

- » Disabled      Disable this function. (Default value)
- » Double Click      Double click on PS/2 mouse left button to power on the system.

### **Power On By Keyboard**

- » Password      Enter from 1 to 5 characters to set the Keyboard Power On Password.
- » Disabled      Disabled this function. (Default value)
- » Keyboard 98      If your keyboard have "POWER Key" button, you can press the key to power on the system.

### **KB Power ON Password**

When "Power On by Keyboard" set at Password, you can set the password here.

- » Enter      Input password (from 1 to 5 characters) and press Enter to set the Keyboard Power On password.

### **AC Back Function**

- » Soft-Off      When AC-power back to the system, the system will be in "Off" state. (Default value)
- » Full-On      When AC-power back to the system, the system always in "On" state.
- » Memory      When AC-power back to the system, the system will return to the Last state before AC-power off.



## 2-5 PnP/PCI Configurations

| CMOS Setup Utility-Copyright (C) 1984-2004 Award Software  |        |
|--|--------|
| PnP/PCI Configurations   |        |
| PCI 1 IRQ Assignment   | [Auto] |
| PCI 2 IRQ Assignment   | [Auto] |
| <div>Item Help</div> <div>Menu Level▶</div>  |        |
| <div> ↑↓→←: Move    Enter: Select    +/-/PU/PD: Value    F10: Save    ESC: Exit    F1: General Help<br/> F5: Previous Values    F6: Fail-Safe Default    F7: Optimized Defaults </div> |        |

### PCI 1 IRQ Assignment

- ▶ Auto      Auto assign IRQ to PCI 1. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15      Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 1.

### PCI 2 IRQ Assignment

- ▶ Auto      Auto assign IRQ to PCI 2. (Default value)
- ▶ 3,4,5,7,9,10,11,12,14,15      Set IRQ 3,4,5,7,9,10,11,12,14,15 to PCI 2.

## 2-6 PC Health Status

| CMOS Setup Utility-Copyright (C) 1984-2004 Award Software |            |                          |  |
|---|------------|--------------------------|--|
| PC Health Status  |            |                          |  |
| Vcore   | OK         | Item Help<br>Menu Level▶ |  |
| DDR25V  | OK         |                          |  |
| +3.3V   | OK         |                          |  |
| +12V  | OK         |                          |  |
| Current CPU Temperature                                   | 33°C       |                          |  |
| Current CPU FAN Speed                                     | 4687 RPM   |                          |  |
| Current SYSTEM FAN Speed                                  | 0 RPM      |                          |  |
| CPU Warning Temperature                                   | [Disabled] |                          |  |
| CPU FAN Fail Warning                                      | [Disabled] |                          |  |
| SYSTEM FAN Fail Warning                                   | [Disabled] |                          |  |
| CPU Smart FAN Control                                     | [Enabled]  |                          |  |
| CPU Smart FAN Mode  | [Auto]     |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |
|   |            |                          |  |

### ☞ **Current Voltage(V) Vcore / DDR25V / +3.3V / +12V**

» Detect system's voltage status automatically.

### ☞ **Current CPU Temperature**

» Detect CPU temperature automatically.

### ☞ **Current CPU/SYSTEM FAN Speed (RPM)**

» Detect CPU/SYSTEM Fan speed status automatically.

### ☞ **CPU Warning Temperature**

- » 60°C / 140°F      Monitor CPU temperature at 60°C / 140°F.
- » 70°C / 158°F      Monitor CPU temperature at 70°C / 158°F.
- » 80°C / 176°F      Monitor CPU temperature at 80°C / 176°F.
- » 90°C / 194°F      Monitor CPU temperature at 90°C / 194°F.
- » Disabled          Disable this function. (Default value)

### ☞ **CPU/SYSTEM FAN Fail Warning**

- » Disabled          Fan warning function disable. (Default value)
- » Enabled          Fan warning function enable.

### ☞ **CPU Smart FAN Control**

- » Disabled          Disable this function.
- » Enabled          Enable CPU Smart Fan control function. (Default value)
  - a. When the CPU temperature is higher than 65 degrees Celsius, CPU fan will run at full speed.
  - b. The speed of CPU fan will increase linearly depend on the temperature if the temperature is more than 41 degree and less than 65 degree.
  - c. When the CPU temperature is lower than 40 degrees Celsius, CPU fan willbe disable.


## CPU Smart FAN Mode

This option is available only when CPU Smart FAN Control is enabled.

- » Auto BIOS autodetects the type of CPU fan you installed and sets the optimal CPU Smart FAN control mode for it. (Default Value)
- » Voltage Set to Voltage when you use a CPU fan with a 3-pin fan power cable.
- » PWM Set to PWM when you use a CPU fan with a 4-pin fan power cable.

Note: In fact, the Voltage option can be used for CPU fans with 3-pin or 4-pin power cables. However, some 4-pin CPU fan power cables are not designed following Intel 4-Wire fans PWM control specifications. With such CPU fans, selecting PWM will not effectively reduce the fan speed.

## 2-7 MB Intelligent Tweaker(M.I.T.)



CAUTION

Incorrect using these features may cause your system broken. For power end-user use only.

## CPU Clock Ratio

This setup option will automatically assign by CPU detection.

The option will display "Locked" and read only if the CPU ratio is not changeable.

## Memory Frequency For

Wrong frequency may make system can't boot, clear CMOS to overcome wrong frequency issue. for FSB(Front Side Bus) frequency=533MHz,

- » 3.0 Memory Frequency = Host clock X 3.0.
- » 4.0 Memory Frequency = Host clock X 4.0.
- » Auto Set Memory frequency by DRAM SPD data. (Default value)


for FSB(Front Side Bus) frequency=800MHz,

- » 2.0 Memory Frequency = Host clock X 2.0.
- » 2.66 Memory Frequency = Host clock X 2.66.
- » Auto Set Memory frequency by DRAM SPD data. (Default value)

## Memory Frequency (Mhz)


The values depend on "Memory Frequency For" item.

## 2-8 Load Fail-Safe Defaults




Fail-Safe defaults contain the most appropriate values of the system parameters that allow minimum system performance.

## 2-9 Load Optimized Defaults



Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

## 2-10 Set Supervisor/User Password



Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password, up to eight characters, and press <Enter>. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.


The BIOS Setup program allows you to specify two separate passwords:

SUPERVISOR PASSWORD and a USER PASSWORD. When disabled, anyone may access all BIOS Setup program function. When enabled, the Supervisor password is required for entering the BIOS Setup program and having full configuration fields, the User password is required to access only basic items.

If you select "System" at "Password Check" in Advance BIOS Features Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu.

If you select "Setup" at "Password Check" in Advance BIOS Features Menu, you will be prompted only when you try to enter Setup.


## 2-11 Save & Exit Setup



Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.

Type "N" will return to Setup Utility.

## 2-12 Exit Without Saving



Type "Y" will quit the Setup Utility without saving to RTC CMOS.

Type "N" will return to Setup Utility.

## Chapter 3 Install Drivers




Pictures below are shown in Windows XP.

Insert the driver CD-title that came with your motherboard into your CD-ROM drive, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the Run.exe.

### 3-1 Install Chipset Drivers

"Xpress Install " is now analyzing your computer...99%

After insert the driver CD, "Xpress Install" will scan automatically the system and then list all the drivers that recommended to install. Please pick the item that you want and press "install" followed the item; or you can press "Xpress Install" to install all items defaulted.




Some device drivers will restart your system automatically. After restarting your system the "Xpress Install" will continue to install other drivers. System will reboot automatically after install the drivers, afterward you can install others application.



For USB2.0 driver support under Windows XP operating system, please use Windows Service Pack. After install Windows Service Pack, it will show a question mark "?" in "Universal Serial Bus controller" under "Device Manager". Please remove the question mark and restart the system (System will auto-detect the right USB2.0 driver).


## 3-2 Software Applications

This page displays all the tools that Gigabyte developed and some free software, you can choose anyone you want and press "install" to install them.



## 3-3 Driver CD Information


This page lists the contents of software and drivers in this CD-title.





### 3-4 Hardware Information

This page lists all device you have for this motherboard.



### 3-5 Contact Us

Please see the last page for details.





## Chapter 4 Appendix

### 4-1 Unique Software Utilities

(Not all model support these Unique Software Utilities, please check your MB features.)



#### U-PLUS D.P.S. (Universal Plus Dual Power System)

The U-Plus Dual Power System (U-Plus DPS) is a revolutionary eight-phase power circuit built for ultimate system protection. Designed to withstand varying current levels and changes, the U-Plus D.P.S. provides an immensely durable and stable power circuit to the CPU for solid system stability. These characteristics make it the ideal companion with the latest LGA775 Intel® Pentium® 4 Processor as well as future Intel® processors. As well, 4 blue LED's are mounted on the U-Plus D.P.S. for intelligent indication of system loading.



#### M.I.T. (Motherboard Intelligent Tweaker)

Motherboard Intelligent Tweaker (M.I.T.) allows user to access and change BIOS feature settings with relative speed and ease. Through GIGABYTE M.I.T. feature the user is no longer required to switch into different modes within BIOS setup in order to change system settings such as the CPU system bus, memory timings or to enabled Gigabyte's unique C.I.A. 2 and M.I.B. 2 features. M.I.T.'s integration of all platform performance settings into a single mode now gives any user the ability to control and enhance their computer system to the desired level.



#### C.I.A.2 (CPU Intelligent Accelerator 2)

GIGABYTE CPU Intelligent Accelerator 2 (C.I.A. 2) is designed to automatically adjust CPU computing power to maximize system performance. When enabled, the program detects the current CPU loading and automatically accelerates the CPU computing performance to allow for a faster and smoother execution of programs. When the function is disabled, the CPU is returned to its initial status.



#### M.I.B.2 (Memory Intelligent Booster 2)

Built on the original M.I.B., the new Memory Intelligent Booster 2 (M.I.B. 2) is designed especially to maximize memory performance and boost memory bandwidth up to 10%. With added branded memory module information, users are able to optimize memory performance by selecting from a recommended memory module list.



#### S.O.S. (System Overclock Saver)

System Overclock Saver (S.O.S.) is a unique feature that eliminates system boot-up errors resulting from system over-enhancement by the user. With GIGABYTE's proprietary S.O.S. feature, users no longer need to open up the PC chassis and short-circuit the "Clear CMOS" pins or the battery on the motherboard to reset the system back to factory default settings. Instead, S.O.S. automatically resets the overclocked system settings back to their factory defaults to provide a more user-friendly and reliable platform for users.



#### Download Center

Download Center allows users to quickly download and update their BIOS as well as the latest drivers for their system. Download Center automatically runs a system check of the user PC and provides the user with the current system information as well as displaying a detailed list of all new drivers with the option for download.



#### C.O.M. (Corporate Online Management)

A web-based system management tool that allows system hardware information such as CPU, memory, graphics card, etc. to be monitored and controlled via the Internet. C.O.M. allows corporate MIS engineers to easily maintain corporate computers such as providing the most up-to-date drivers and BIOS.

## 4-1-1 EasyTune 5 Introduction

EasyTune 5 presents the most convenient Windows based system performance enhancement and manageability utility. Featuring several powerful yet easy to use tools such as 1) Overclocking for enhancing system performance, 2) C.I.A. and M.I.B. for special enhancement for CPU and Memory, 3) Smart-Fan control for managing fan speed control of both CPU cooling fan and North-Bridge Chipset cooling fan, 4) PC health for monitoring system status.<sup>(Note)</sup>

### User Interface Overview



|     | Button / Display                  | Description                                   |
|-----|-----------------------------------|---|
| 1.  | Overclocking                      | Enters the Overclocking setting page          |
| 2.  | C.I.A./C.I.A.2 and M.I.B./M.I.B.2 | Enters the C.I.A./2 and M.I.B./2 setting page |
| 3.  | Smart-Fan                         | Enters the Smart-Fan setting page             |
| 4.  | PC Health                         | Enters the PC Health setting page             |
| 5.  | GO                                | Confirmation and Execution button             |
| 6.  | "Easy Mode" & "Advance Mode"      | Toggles between Easy and Advance Mode         |
| 7.  | Display screen                    | Display panel of CPU frequency                |
| 8.  | Function display LEDs             | Shows the current functions status            |
| 9.  | GIGABYTE Logo                     | Log on to GIGABYTE website                    |
| 10. | Help button                       | Display EasyTune™ 5 Help file                 |
| 11. | Exit or Minimize button           | Quit or Minimize EasyTune™ 5 software         |

(Note) EasyTune 5 functions may vary depending on different motherboards.

## 4-1-2 Xpress Recovery Introduction



### What is Xpress Recovery ?

Xpress Recovery is a utility used to back up and restore an OS partition. If the hard drive is not working properly, the user can restore the drive to its original state.



1. Supports FAT16, FAT32, and NTFS formats
2. Must be connected to the IDE1 Master
3. Allows installation of only one OS
4. Must be used with an IDE hard disk supporting HPA
5. The first partition must be set as the boot partition. When the boot partition is backed up, please do not alter its size.
6. Xpress Recovery is recommended when using Ghost to return boot manager to NTFS format.

### How to use the Xpress Recovery


1. Boot from CD-ROM (BMP Mode)

Enter the BIOS menu, select "Advanced BIOS Feature" and set to boot from CD-ROM. Insert the provided driver CD into your CD drive, then save and exit the BIOS menu. Once the computer has restarted, the phrase "Boot from CD:" will appear at the bottom left-hand corner of the screen. When "Boot from CD:" appears, press any key to enter Xpress Recovery.


Once you have completed this step, subsequent access to Xpress Recovery can also function by pressing the F9 key during computer power on.




**Boot from CD:**



2. Press F9 during powering on the computer. (Text Mode)  
Press F9 during powering on the computer .



**F9 For Xpress Recovery**



1. If you have already entered Xpress Recovery by booting from the CD-ROM, you can enter Xpress Recovery in the future by pressing the F9 key.
2. System storage capacity as well as drive reading/writing speed will affect backup speed.
3. It is recommended that Xpress Recovery be immediately installed after OS and all required driver and software installations are complete.

### 1. Execute Backup Utility:

#### **Press B to Backup your System or Esc to Exit**

The backup utility will automatically scan your system and back up data as a backup image in your hard drive.



Not all systems support access to Xpress Recovery by pressing the F9 key during computer power on. If this is the case, please use the boot from CD-ROM method to enter Xpress Recovery.

### 2. Execute Restore Utility:

#### **This program will recover your system to factory default.**

**Press R to restore your system back to factory default or press Esc to exit**

Restores backup image to original state.

### 3. Remove Backup Image:

#### **Remove backup image. Are you sure? (Y/N)**

Remove the backup image.

### 4. Set Password:

#### **Please input a 4-16 character long password (a-z or 0-9) or press Esc to exit**

You can set a password to enter Xpress Recovery to protect your hard disk data. Once this is done, password input will be required to enter Xpress Recovery during the next as well as subsequent system restarts. If you wish to remove the need for password entry, please select "Set Password" and under "New Password/Confirm Password", make sure there is no entry and then press "Enter" to remove password requirement.

### 5. Exit and Restart:

Exit and restart your computer.

### 4-1-3 Flash BIOS Method Introduction



#### Method 1 : Q-Flash™ Utility

Q-Flash™ is a BIOS flash utility embedded in Flash ROM. With this utility, users only have to stay in the BIOS menu when they want to update BIOS. Q-Flash™ allows users to flash BIOS without any utility in DOS or Windows. Using Q-Flash™ indicating no more fooling around with any complicated instructions and operating system since it is in the BIOS menu.



Please note that because updating BIOS has potential risk, please do it with caution!! We are sorry that Gigabyte Technology Co., Ltd is not responsible for damages of system because of incorrect manipulation of updating BIOS to avoid any claims from end-users.

#### Before You Begin:

Before you start updating BIOS with the Q-Flash™ utility, please follow the steps below first.

1. Download the latest BIOS for your motherboard from Gigabyte's website.
2. Extract the BIOS file downloaded and save the BIOS file (the one with model name.Fxx. For example, 8KNXP.U.Fba) to a floppy disk.
3. Reboot your PC and press **Del** to enter BIOS menu.

The BIOS upgrading guides below are separated into two parts.

If your motherboard has dual-BIOS, please refer to **Part One**.

If your motherboard has single-BIOS, please refer to **Part Two**.


#### Part One:

##### Updating BIOS with Q-Flash™ Utility on Dual BIOS Motherboards.

Some of Gigabyte motherboards are equipped with dual BIOS. In the BIOS menu of the motherboards supporting Q-Flash and Dual BIOS, the Q-Flash utility and Dual BIOS utility are combined in the same screen. This section only deals with how to use Q-Flash utility.

In the following sections, we take GA-8KNXP Ultra as the example to guide you how to flash BIOS from an older version to the latest version. For example, from Fa3 to Fba.


The BIOS file is Fa3  
before updating





## Entering the Q-Flash™ utility:


Step1: To use Q-Flash utility, you must press **Del** in the boot screen to enter BIOS menu.



Step 2: Press **F8** button on your keyboard and then **Y** button to enter the Dual BIOS/Q-Flash utility.

## Exploring the Q-Flash™ / Dual BIOS utility screen

The Q-Flash / Dual BIOS utility screen consists of the following key components.



### Task menu for Dual BIOS utility:

Contains the names of eight tasks and two item showing information about the BIOS ROM type. Blocking a task and pressing Enter key on your keyboard to enable execution of the task.

### Task menu for Q-Flash utility:

Contains the names of four tasks. Blocking a task and pressing Enter key on your keyboard to enable execution of the task.

### Action bar:

Contains the names of four actions needed to operate the Q-Flash/Dual BIOS utility. Pressing the buttons mentioned on your keyboards to perform these actions.

### Using the Q-Flash™ utility:

This section tells you how to update BIOS using the Q-Flash utility. As described in the "Before you begin" section above, you must prepare a floppy disk having the BIOS file for your motherboard and insert it to your computer. If you have already put the floppy disk into your system and have entered the Q-Flash utility, please follow the steps below to flash BIOS.

### Steps:

1. Press arrow buttons on your keyboard to move the light bar to "Load Main BIOS from Floppy" item in the Q-Flash menu and press Enter button.

Later, you will see a box pop up showing the BIOS files you previously downloaded to the floppy disk.



If you want to save the current BIOS for backup purpose, you can begin Step 1 with "Save Main BIOS to Floppy" item.

2. Move to the BIOS file you want to flash and press **Enter**.

In this example, we only download one BIOS file to the floppy disk so only one BIOS file, 8KNXPU.Fba, is listed.



Please confirm again you have the correct BIOS file for your motherboard.

|                                |         |                     |               |
|--------------------------------|---------|---------------------|---------------|
| Dual BIOS Utility              |         |                     |               |
| Boot From.....                 |         | Main Bios           |               |
| Main ROM Type/Size.....        |         | SST 49LF003A        | 512K          |
| Backup ROM Type/Size.....      |         | SST 49LF003A        | 512K          |
| Wide Range Protection Disabled |         |                     |               |
| 8KNXPULFba                     |         | 1 file(s) found     | 512K          |
| Total size : 1.39M             |         | Free size : 911.50K |               |
| F5 : Refresh                   |         | DEL : Delete        |               |
| Save Settings to CMOS          |         |                     |               |
| Q-Flash Utility                |         |                     |               |
| Load Main BIOS from Floppy     |         |                     |               |
| Load Backup BIOS from Floppy   |         |                     |               |
| Save Main BIOS to Floppy       |         |                     |               |
| Save Backup BIOS to Floppy     |         |                     |               |
| Enter : Run                    | ↑↓:Move | ESC:Reset           | F10:Power Off |

- BIOS file in the floppy disk

After pressing **Enter**, you'll then see the progress of reading the BIOS file from the floppy disk.

|  |              |           |               |
|--|--------------|-----------|---------------|
| <b>Dual BIOS Utility</b>                                 |              |           |               |
| Boot From.....   | Main Bios    |           |               |
| Main ROM Type/Size.....                                  | SST 49LF003A | 512K      |               |
| Backup ROM Type/Size.....                                | SST 49LF003A | 512K      |               |
| <b>Wide Range Protection    Disable</b>                  |              |           |               |
| Reading BIOS file from floppy ...<br>>>>>>>>>>>>>> ..... |              |           |               |
| Don't Turn Off Power or Reset System                     |              |           |               |
| <b>Save Settings to CMOS</b>                             |              |           |               |
| <b>Q-Flash Utility</b>                                   |              |           |               |
| Load Main BIOS from Floppy                               |              |           |               |
| Load Backup BIOS from Floppy                             |              |           |               |
| Save Main BIOS to Floppy                                 |              |           |               |
| Save Backup BIOS to Floppy                               |              |           |               |
| Enter : Run  | ↑↓:Move      | ESC:Reset | F10:Power Off |



- Do not turn off power or reset your system at this stage!!

After BIOS file is read, you'll see a confirmation dialog box asking you "Are you sure to update BIOS?"

3. Press Y button on your keyboard after you are sure to update BIOS.

Then it will begin to update BIOS. The progress of updating BIOS will be displayed.



Please do not take out the floppy disk when it begins flashing BIOS.

4. Press any keys to return to the Q-Flash menu when the BIOS updating procedure is completed.

| Dual BIOS Utility  |              |                            |
|--|--------------|----------------------------|
| Boot From.....   | Main Bios    |                            |
| Main ROM Type/Size.....  | SST 49LF003A | 512K                       |
| Backup ROM Type/Size.....  | SST 49LF003A | 512K                       |
| Wide Range Protection    Disable   |              |                            |
| <b>!! Copy BIOS completed - Pass !!</b><br><b>Please press any key to continue</b> |              |                            |
| Save Settings to CMOS  |              |                            |
| Q-Flash Utility  |              |                            |
| Load Main BIOS from Floppy   |              |                            |
| Load Backup BIOS from Floppy   |              |                            |
| Save Main BIOS to Floppy   |              |                            |
| Save Backup BIOS to Floppy   |              |                            |
| Enter : Run  | ↑↓:Move      | ESC:Reset    F10:Power Off |



You can repeat Step 1 to 4 to flash the backup BIOS, too.

5. Press Esc and then Y button to exit the Q-Flash utility. The computer will restart automatically after you exit Q-Flash.


| Dual BIOS Utility   |              |                            |
|---|--------------|----------------------------|
| Boot From.....  | Main Bios    |                            |
| Main ROM Type/Size.....   | SST 49LF003A | 512K                       |
| Backup ROM Type/Size.....   | SST 49LF003A | 512K                       |
| Wide Range Protection    Disable  |              |                            |
| <b>Are you sure to RESET ?</b><br><b>[Enter] to continue or [Esc] to abort...</b> |              |                            |
| Save Settings to CMOS   |              |                            |
| Q-Flash Utility   |              |                            |
| Load Main BIOS from Floppy  |              |                            |
| Load Backup BIOS from Floppy  |              |                            |
| Save Main BIOS to Floppy  |              |                            |
| Save Backup BIOS to Floppy  |              |                            |
| Enter : Run   | ↑↓:Move      | ESC:Reset    F10:Power Off |

After system reboots, you may find the BIOS version on your boot screen becomes the one you flashed.

The BIOS file becomes Fab after updating.


|   |  |      |
|---|--|------|
| Award Modular BIOS v6.00PG, An Energy Star Ally<br>Copyright (C) 1984-2003, Award Software, Inc.  |  | <br> |
| Intel i875P AGPset BIOS for 8KNXP Ultra Fba<br>Check System Health OK, VCase = 1.525V<br>Main Processor : Intel Pentium(R) 4 1.6GHz (133x12)<br><CPUID> 0F27 Patch ID = 0027<br>Memory Testing : 131072K OK<br><br>Memory Frequency 266 MHz in Single Channel<br>Primary Master : FUJITSU MPE3170AT ED-03-08<br>Primary Slave : None<br>Secondary Master : CREATIVE DVD-RM DVD1242E BC101<br>Secondary Slave : None |  |      |
| Press DEL to enter SETUP / Dual BIOS / Q-Flash / F9 For Xpress Recovery<br>09/23/2003-i875P-6A79BG03C-00  |  |      |

6. Press **Del** to enter BIOS menu after system reboots. When you are in BIOS menu, move to **Load Fail-Safe Defaults** item and press **Enter** to load BIOS Fail-Safe Defaults. Normally the system redetects all devices after BIOS has been upgraded. Therefore, we highly recommend reloading the BIOS defaults after BIOS has been upgraded.



Press **Y** on your keyboard to load defaults.

7. Select **Save & Exit Setup** item to save the settings to CMOS and exit the BIOS menu. System will reboot after you exit the BIOS menu. The procedure is completed.




Press **Y** on your keyboard to save and exit.

## Part Two:


### Updating BIOS with Q-Flash™ Utility on Single-BIOS Motherboards.

This part guides users of single-BIOS motherboards how to update BIOS using the Q-Flash™ utility.



## Exploring the Q-Flash™ utility screen

The Q-FlashBIOS utility screen consists of the following key components.



### Task menu for Q-Flash utility:

Contains the names of three tasks. Blocking a task and pressing Enter key on your keyboard to enable execution of the task.

### Action bar:

Contains the names of four actions needed to operate the Q-Flash utility. Pressing the buttons mentioned on your keyboards to perform these actions.

### Using the Q-Flash™ utility:

This section tells you how to update BIOS using the Q-Flash utility. As described in the "Before you begin" section above, you must prepare a floppy disk having the BIOS file for your motherboard and insert it to your computer. If you have already put the floppy disk into your system and have entered the Q-Flash utility, please follow the steps below to flash BIOS.

### Steps:

1. Press arrow buttons on your keyboard to move the light bar to "Update BIOS from Floppy" item in the Q-Flash menu and press Enter button.

Later, you will see a box pop up showing the BIOS files you previously downloaded to the floppy disk.



NOTE

If you want to save the current BIOS for backup purpose, you can begin Step 1 with "Save BIOS to Floppy" item.


2. Move to the BIOS file you want to flash and press Enter.

**In this example, we only download one BIOS file to the floppy disk so only one BIOS file, 8GE800.F4, is listed.**



CAUTION

Please confirm again you have the correct BIOS file for your motherboard.




After BIOS file is read, you'll see a confirmation dialog box asking you "Are you sure to update BIOS?"




CAUTION

Please do not take out the floppy disk when it begins flashing BIOS.




- Do not turn off power or reset your system at this stage!!

4. Press any keys to return to the Q-Flash menu when the BIOS updating procedure is completed.




5. Press Esc and then Y button to exit the Q-Flash utility. The computer will restart automatically after you exit Q-Flash.



After system reboots, you may find the BIOS version on your boot screen becomes the one you flashed.

The BIOS file becomes F4 after updating



6. Press Del to enter BIOS menu after system reboots and "Load BIOS Fail-Safe Defaults". See how to Load BIOS Fail-Safe Defaults, please kindly refer to Step 6 to 7 in **Part One**.

**Congratulation!! You have updated BIOS successfully!!**

## Method 2 : @BIOS™ Utility

If you do not have a DOS startup disk, we recommend that you use the new @BIOS utility. @BIOS allows users to update their BIOS under Windows. Just select the desired @BIOS server to download the latest version of BIOS.

Fig 1. Installing the @BIOS utility




Fig 2. Installation Complete and Run @BIOS




Fig 3. The @BIOS Utility





Fig 4. Select the desired @BIOS server



## 1. Methods and steps:

### I. Update BIOS through Internet

- Click "Internet Update" icon
- Click "Update New BIOS" icon
- Select @BIOS™ sever
- Select the exact model name on your motherboard
- System will automatically download and update the BIOS.

### II. Update BIOS NOT through Internet:

- Do not click "Internet Update" icon
- Click "Update New BIOS"
- Please select "All Files" in dialog box while opening the old file.
- Please search for BIOS unzip file, downloading from internet or any other methods (such as: 8I915GV-MF.E2).
- Complete update process following the instruction.

### III. Save BIOS

In the very beginning, there is "Save Current BIOS" icon shown in dialog box. It means to save the current BIOS version.

### IV. Check out supported motherboard and Flash ROM:

In the very beginning, there is "About this program" icon shown in dialog box. It can help you check out which kind of motherboard and which brand of Flash ROM are supported.

## 2. Note:

- I. In method I, if it shows two or more motherboard's model names to be selected, please make sure your motherboard's model name again. Selecting wrong model name will cause the system unbooted.
- II. In method II, be sure that motherboard's model name in BIOS unzip file are the same as your motherboard's. Otherwise, your system won't boot.
- III. In method I, if the BIOS file you need cannot be found in @BIOS™ server, please go onto Gigabyte's web site for downloading and updating it according to method II.
- IV. Please note that any interruption during updating will cause system unbooted





## 4-1-4 2-/4-/6-/8- Channel Audio Function Introduction

This motherboard provide 6 audio connector. You are able to use 2-/4-/6-/8-channels audio feature by audio software selection.

### Introduction of audio connectors:

You may connect CD-ROM/DVD-ROM, walkman or others audio input to Line In.

The front channels or earphone can be connected to Line Out (Front Speaker Out).

Connect microphone to Mic In.

Connect the rear channels to Rear Speaker Out.

Connect the Center/Subwoofer channels to Center/Subwoofer Speaker Out.

Connect the side channels to Side Speaker Out.

The installation of audio software for Windows 2000/ XP is very simple. Please follow the steps to install the function.(Following pictures are in Windows XP)




If you set the **Front Panel Type** option to **HD Audio** in BIOS, make sure to connect your audio front panel cable(optional for different models) connector to the motherboard before system start-up or you'll not be able to see the front panel options from the **Sound Effect** application.

### Stereo Speakers Connection and Settings:


We recommend that you use the speaker with amplifier to acquire the best sound effect if the stereo output is applied.

#### STEP 1:

Connect the stereo speakers or earphone to "Line Out".



#### STEP 2 :

Following installation of the audio driver, you find a Sound Effect  icon on the lower right hand taskbar. Click the icon to select the function.




**STEP 3:**


Click "Speaker Configuration" then click on the left selection bar and select "2CH Speaker" to complete 2 channel audio configuration.

**4 Channel Audio Setup****STEP 1 :**

Connect the front channels to "Front Speaker Out", the rear channels to "Rear Speaker Out".

**STEP 2 :**

Following installation of the audio driver, you find a Sound Effect icon on the lower right hand taskbar. Click the icon to select the function.

**STEP 3:**


Click "Speaker Configuration" then click on the left selection bar and select "4CH Speaker" to complete 4 channel audio configuration.



## 6 Channel Audio Setup

### STEP 1 :

Connect the front channels to "Front Speaker Out", the rear channels to "Rear Speaker Out", and the Center/Subwoofer channels to "Center/Subwoofer Speaker Out".





### STEP 2 :

Following installation of the audio driver, you find a Sound Effect icon on the lower right hand taskbar. Click the icon to select the function.



### STEP 3:


Click "Speaker Configuration" then click on the left selection bar and select "6CH Speaker" to complete 6 channel audio configuration.



## 8 Channel Audio Setup

### STEP 1 :

Connect the front channels to "Front Speaker Out", the rear channels to "Rear Speaker Out", the Center/Subwoofer channels to "Center/Subwoofer Speaker Out", and the side channels to "Side Speaker Out".





### STEP 2 :

Following installation of the audio driver, you find a Sound Effect icon on the lower right hand taskbar. Click the icon to select the function.




### STEP 3:

Click "Speaker Configuration" then click on the left selection bar and select "6CH Speaker" to complete 6 channel audio configuration.



### Sound Effect Configuration:

At the sound effect menu, users can adjust sound option settings as desired.



## 4-2 Troubleshooting

Below is a collection of general asked questions. To check general asked questions based on a specific motherboard model, please log on to <http://tw.giga-byte.com/faq/faq.htm>

Question 1: I cannot see some options that were included in previous BIOS after updating BIOS. Why?

Answer: Some advanced options are hidden in new BIOS version. Please press Ctrl and F1 keys after entering BIOS menu and you will be able to see these options.

Questions 2: Why is the light of my keyboard/optical mouse still on after computer shuts down?

Answer: In some boards, a small amount of electricity is kept on standby after computer shuts down and that's why the light is still on.

Question 3: How do I clear CMOS?

Answer: If your board has a Clear CMOS jumper, please refer to the Clear CMOS steps in the manual. If your board doesn't have such jumper, you can take off the on-board battery to leak voltage to clear CMOS. Please refer to the steps below:

Steps:

1. Turn off power.
2. Disconnect the power cord from MB.
3. Take out the battery gently and put it aside for about 10 minutes (Or you can use a metal object to connect the positive and negative pins in the battery holder to makethem short for one minute).
4. Re-insert the battery to the battery holder.
5. Connect power cord to MB again and turn on power.
6. Press Del to enter BIOS and load Fail-Safe Defaults.
7. Save changes and reboot the system.

Question 4: Why does system seem unstable after updating BIOS?

Answer: Please remember to load Fail-Safe Defaults (Or Load BIOS Defaults) after flashing BIOS. However, if the system instability still remains, please clear CMOS to solve the problem.

Question 5: Why do I still get a weak sound after turning up the speaker to the maximum volume?

Answer: Please make sure the speaker you are using is equipped with an internal amplifier. If not, please change another speaker with power/amplifier and try again later.

Question 6: How do I disable onboard VGA card in order to add an external VGA card?

Answer: Gigabyte motherboards will auto-detect the external VGA card after it is plugged in, so you don't need to change any setting manually to disable the onboard VGA.

Question 7: Why cannot I use the IDE 2?

Answer: Please refer to the user manual and check whether you have connected any cable that is not provided with the motherboard package to the USB Over Current pin in the Front USB Panel. If the cable is your own cable, please remove it from this pin and do not connect any of your own cables to it.

Question 8: Sometimes I hear different continuous beeps from computer after system boots up. What do these beeps usually stand for?

Answer: The beep codes below may help you identify the possible computer problems. However, they are only for reference purposes. The situations might differ from case to case.

→ AMI BIOS Beep Codes

\*Computer gives 1 short beep when system boots successfully.

\*Except for beep code 8, these codes are always fatal.

- 1 beep Refresh failure
- 2 beeps Parity error
- 3 beeps Base 64K memory failure
- 4 beeps Timer not operational
- 5 beeps Processor error
- 6 beeps 8042 - gate A20 failure
- 7 beeps Processor exception interrupt error
- 8 beeps Display memory read/write failure
- 9 beeps ROM checksum error
- 10 beeps CMOS shutdown register read/write error
- 11 beeps Cache memory bad

→ AWARD BIOS Beep Codes

- 1 short: System boots successfully
- 2 short: CMOS setting error
- 1 long 1 short: DRAM or M/B error
- 1 long 2 short: Monitor or display card error
- 1 long 3 short: Keyboard error
- 1 long 9 short: BIOS ROM error
- Continuous long beeps: DRAM error
- Continuous short beeps: Power error

[illegible]





[illegible]



[illegible]



[illegible]





## Contact Us

---

### • Taiwan (Headquarters)

GIGA-BYTE TECHNOLOGY CO., LTD.

Address: No.6, Bau Chiang Road, Hsin-Tien, Taipei Hsien, Taiwan

TEL: +886 (2) 8912-4888

FAX: +886 (2) 8912-4003

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address (English): <http://www.gigabyte.com.tw>

WEB address (Chinese): <http://chinese.giga-byte.com>

---

### • U.S.A.

G.B.T. INC.

Address: 17358 Railroad St, City of Industry, CA 91748.

TEL: +1 (626) 854-9338

FAX: +1 (626) 854-9339

Tech. Support :

<http://www.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.com>

---

### • Germany

G.B.T. TECHNOLOGY TRADING GMBH

Address: Friedrich-Ebert-Damm 112 22047 Hamburg

TEL: +49-40-2533040 (Sales)

+49-1803-428468 (Tech.)

FAX: +49-40-25492343 (Sales)

+49-1803-428329 (Tech.)

Tech. Support :

<http://de.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.de>

---

---

### • Japan

NIPPON GIGA-BYTE CORPORATION

WEB address : <http://www.gigabyte.co.jp>

---

### • Singapore

GIGA-BYTE SINGAPORE PTE. LTD.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

---

### • U.K.

G.B.T. TECH. CO., LTD.

Tech. Support :

<http://uk.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://uk.giga-byte.com>

---

### • The Netherlands

GIGA-BYTE TECHNOLOGY B.V.

TEL: +31 40 290 2088

NL Tech.Support: 0900-GIGABYTE (0900-44422983)

BE Tech.Support: 0900-84034

FAX: +31 40 290 2089

Tech. Support :

<http://nz.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.nl>

---

---

**• China**

NINGBO G.B.T. TECH. TRADING CO., LTD.

Tech. Support :

<http://cn.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.com.cn>

**Shanghai**

TEL: +86-021-63410999

FAX: +86-021-63410100

**Beijing**

TEL: +86-010-82886651

FAX: +86-010-82888013

**Wuhan**

TEL: +86-027-87851061

FAX: +86-027-87851330

**GuangZhou**

TEL: +86-020-87586074

FAX: +86-020-85517843

**Chengdu**

TEL: +86-028-85236930

FAX: +86-028-85256822

**Xian**

TEL: +86-029-85531943

FAX: +86-029-85539821

**Shenyang**

TEL: +86-024-23960918

FAX: +86-024-23960918-809

---



---

**• Australia**

GIGABYTE TECHNOLOGY PTY. LTD.

Tech. Support :

<http://www.giga-byte.com.au/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.giga-byte.com.au>

---

**• France**

GIGABYTE TECHNOLOGY FRANCES S.A.R.L.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.fr>

---

**• Russia**

Moscow Representative Office Of Giga-Byte Technology Co., Ltd.

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.ru>

---

**• Poland**

Representative Office Of Giga-Byte Technology Co., Ltd.

POLAND

Tech. Support :

<http://tw.giga-byte.com/TechSupport/ServiceCenter.htm>

Non-Tech. Support(Sales/Marketing) :

<http://ggts.gigabyte.com.tw/nontech.asp>

WEB address : <http://www.gigabyte.pl>

---