

#### FCC Compliance Statement:

This equipment has been tested and found to comply with limits for a Class B digital device . pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable against harmful interference in protection This residential installations. equipment generates. uses. and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna

-Move the equipment away from the receiver

-Plug the equipment into an outlet on a circuit different from that to which the receiver is connected

-Consult the dealer or an experienced radio/television technician for additional suggestions

You are cautioned that any change or modifications to the equipment not expressly approve by the party responsible for compliance could void Your authority to operate such equipment.

This device complies with Part 15 of the FCC Rules. Operation is subjected to the following two conditions 1) this device may not cause harmful interference and 2) this device must accept any interference received, including interference that may cause undesired operation.

Declaration of Conformity

We, Manufacturer/Importer

(full address)

#### G.B.T. Technology Träding GMbH Ausschlager Weg 41, 1F, 20537 Hamburg, Germany

declare that the product (description of the apparatus, system, installation to which it refers)

#### Mother Board GA-6VM7-4I

#### is in conformity with (reference to the specification under which conformity is declared) in accordance with 89/336 EEC-EMC Directive

☐ EN 55011	Limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM high frequency equipment		EN 61000-3-2* EN60555-2	Disturbances in supply systems caused by household appliances and similar electrical equipment "Harmonics"
D EN55013	Limits and methods of measurement of radio disturbance characteristics of broadcast receivers and associated equipment		EN61000-3-3* EN60555-3	Disturbances in supply systems caused by household appliances and similar electrical equipment "Voltage fluctuations"
□EN 55014	Limits and methods of measurement of radio disturbance characteristics of	×	EN 50081-1	Generic emission standard Part 1: Residual, commercial and light industry
	portable tools and similar electrical apparatus	×	EN 50082-1	Generic immunity standard Part 1: Residual, commercial and light industry
EN 55015	Limits and methods of measurement of radio disturbance characteristics of fluorescent lamps and luminaries		EN 55081-2	Generic emission standard Part 2: Industrial environment
EN 55020	Immunity from radio interference of broadcast receivers and associated equipment		EN 55082-2	Generic immunity standard Part 2: Industrial environment
I EN 55022	Limits and methods of measurement of radio disturbance characteristics of information technology equipment		ENV 55104	Immunity requirements for household appliances tools and similar apparatus
DIN VDE 0855	Cabled distribution systems; Equipmer for receiving and/or <b>distribution</b> from sound and television signals	nt 🗆	EN 50091- 2	EMC requirements for uninterruptible power systems (UPS)
CE marking			(EC conformity	marking)
	The manufacturer also decla with the actual required safe	ares the c ety standa	onformity of above me ards in accordance wit	entioned product th LVD 73/23 EEC
🔲 EN 60065	Safety requirements for mains operate electronic and related apparatus for household and similar general use	d 🗆	EN 60950	Safety for information technology equipment including electrical business equipment
EN 60335	Safety of household and similar electrical appliances		EN 50091-1	General and Safety requirements for uninterruptible power systems (UPS)
	M	lanufactu	rer/Importer	
				Signature Rex Lin
	(Stamp)	Date :	Feb. 9, 2001	Name : Rex Lin

# 6VM7-4I Socket 370 Processor Motherboard

# **USER'S MANUAL**

Socket 370 Processor Motherboard REV. 5.1 Second Edition R-51-02-010628 12ME-6VM74I-5102

## How This Manual Is Organized

This manual is divided into the following sections:

1) Revision History	Manual revision information
2) Item Checklist	Product item list
3) Features	Product information & specification
4) Installation Guide	Instructions on CPU & Memory Installation
5) Performance & Block Diagram	Product performance & block diagram
6) Suspend to RAM	Instructions STR installation
7) @BIOS ™ & EasyTuneIII ™	@BIOS <sup>™</sup> & EasyTuneIII <sup>™</sup> introduction
8) BIOS Setup	Instructions on setting up the BIOS software
9) Technical Support /RMA Sheet	Document equipment used for after sales service
10) Appendix	General reference

## Table Of Content

Revision History	P.1
Item Checklist	P.2
Feature Summary	P.3
6VM7-4I Motherboard Layout	P.5
Installation Guide	P.6
Page Index for Connectors / Panel and Jumper Definition	P.13
Performance List	P.30
Block Diagram	P.30
Suspend to RAM Installation	P.32
@BIOS <sup>™</sup> Introduction (Optional)	P.38
EasyTuneIII <sup>™</sup> Introduction (Optional)	P.39
Page Index for BIOS Setup	P.40
Technical Support /RMA Sheet	P.70
Appendix	P.71

Revision History			
Revision	Revision Note	Date	
5.1	Initial release of the 6VM7-4I motherboard user's manual.	Jun.2001	
5.1	Second release of the 6VM7-4I motherboard user's manual.	Jun.2001	

The author assumes no responsibility for any errors or omissions that may appear in this document nor does the author make a commitment to update the information contained herein. Third-party brands and names are the property of their respective owners.

Jun. 28, 2001 Taipei, Taiwan, R.O.C

Item Checklist

## Item Checklist

☑ The 6VM7-4I motherboard
 ☑ Cable for IDE / floppy device
 ☑ Diskettes or CD (TUCD) for motherboard driver & utility
 ☑ 6VM7-4I user's manual

Features Summ	ary
Form Factor	• 24.3 cm x 21.0 cm micro ATX size form factor, 4 layers PCB.
CPU	Socket 370 processor
	Intel Pentium <sup>®</sup> !!! 100/133MHz FSB, FC-PGA
	Intel Celeron <sup>TM</sup> 66MHz FSB, FC-PGA
	VIA Cyrix <sup>®</sup> III 100 MHz FSB, CPGA
	<ul> <li>2nd cache in CPU(Depend on CPU)</li> </ul>
Chipset	VT82C694X (VIA Apollo Pro 133A)
1	• VT82C686B
Clock Generator	• ICS 9248DF-39
	66/100/133 MHz system bus speeds (PCI 33MHz)
	• 75/83/112/124/140/150 MHz system bus speeds
	(PCI 44MHz) (reserved)
Memory	2 168-pin DIMM sockets.
	Supports PC-100 / PC-133 SDRAM and VCM SDRAM
	Supports up to 1.0GB DRAM
	Supports only 3.3V SDRAM DIMM
VO O salast	Supports 72bit ECC type DRAM integrity mode.
I/U Control	VI82C686B
SIOIS	I AGP SIOI SUPPORTS 4X mode & AGP 2.0 compliant
	<ul> <li>2 PCI SIOL SUPPORTS SSIVITZ &amp; PCI 2.2 COMPITATIC</li> <li>1 AMD(Audio Modom Disor) stat</li> </ul>
	1 ISA slot
On-Board IDF	2 IDE bus master (DMA 33/ ATA 66/ ATA 100 )IDE
on board ib E	ports for up to 4 ATAPI devices
	• Supports PIO mode 3, 4 (UDMA 33/ATA 66/ATA100)
	IDE & ATAPI CD-ROM
On-Board	• 1 floppy port supports 2 FDD with 360K, 720K,1.2M,
Peripherals	1.44M and 2.88M bytes
	1 parallel ports supports Normal/EPP/ECP mode
	2 serial ports (COM A & COM B)
	4 USB ports
Hardware Monitor	CPU/System fan revolution detect
	CPU /System temperature detect     System voltage detect (/care v3 2)/v 5)/v 12)/0
	System voltage detect (vcore,+3.3v,+5v,+12v)     CDL everbeet ebutdeure detect
	CPU overneal snuldown delect

To be continued...

PS/2 Connector	•	PS/2 <sup>®</sup> Keyboard interface and PS/2 <sup>®</sup> Mouse interface
BIOS	•	Licensed AMI BIOS, 2M bit flash ROM
On-Board Sound	•	Build in VIA 82C686B
Additional Features	•	Includes 3 fan power connectors.
	•	Poly fuse for keyboard over-current protection
	•	Support USB KB Wake up from S3~S5
	•	Support STR (Suspend-To-RAM) function
	•	Support Wake-on-LAN (WOL)
	•	Support Internal / External modem wake up
	•	Support @BIOS <sup>™</sup> and EasyTuneIII <sup>™</sup>

## 6VM7-4I Motherboard Layout



## Installation Guide

### Getting Started



#### WARNING!

Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- 5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

#### Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

To set up your computer, you must complete the following steps:

- Step 1 Set system jumpers
   Step 2- Install the Central Processing Unit (CPU)
   Step 3-Install memory modules
- Step 4-Install expansion cards
- Step 5-Connect ribbon cables, cabinet wires, and power supply
- Step 6-Set up BIOS software
- Step 7-Install supporting software tools



#### **CPU Speed Setup**

The system bus speed is selectable at 66,100,133MHz and Auto. The user can select the system bus speed (SW1) and change the DIP switch (SW2) selection to set up the CPU speed for 500MHz - 1GHz and above processor.

### Set System Bus Speed

CPU (MHz)	PCI(MHz)	1	2	3	4	5	6
Auto	33.3	Х	Х	Х	Х	0	0
66	33.3	0	0	Х	Х	Х	Х
75	37.5	0	0	0	Х	Х	Х
83	41.6	0	0	Х	0	Х	Х
100	33.3	0	Х	Х	Х	Х	Х
112	37.3	0	Х	0	Х	Х	Х
124	31	Х	Х	Х	0	Х	X
133	33.3	Х	Х	Х	Х	Х	X
140	35	Х	Х	0	0	Х	Х
150	37.5	Х	Х	0	Х	Х	Х

The CPU speed must match with the frequency ratio. It will cause system hanging up if the frequency ratio is higher than that of CPU. SW2:

	DIP SWITCH					
TREQ. RAHO	1	2	3	4		
X 3	0	Х	0	0		
X 3.5	Х	Х	0	0		
X 4	0	0	Х	0		
X 4.5	Х	0	Х	0		
X 5	0	Х	Х	0		
X 5.5	Х	Х	Х	0		
X 6	0	0	0	Х		
X 6.5	Х	0	0	Х		
X 7	0	Х	0	Х		
X 7.5	Х	Х	0	Х		
X 8	0	0	Х	Х		
X 8.5	0	Х	0	0		
Х 9	Х	Х	0	0		
X 9.5	Х	0	0	0		
X 10	Х	0	Х	Х		
X 10.5	0	0	Х	0		
X11	0	Х	Х	Х		

6VM7-41	Motherboard
---------	-------------

X11.5	Х	0	Х	0
X12	0	Х	Х	0
X13	Х	Х	Х	0
X14	0	0	0	Х
X15	Х	0	0	Х
X16	0	Х	0	Х

Intel Processor all have locked Frequency Multiple, so you can not change the CPU Frequency Multiple.

**For Auto Jumper Setting:** 



★Note:

- 1. If you use 66/100/133 MHz CPU, We recommend you to setup your system speed to "Auto" value.
- 2. We don't recommend you to set up your system speed to 75, 83, 112, 124, 140, 150 MHz because these frequencies are not the standard specifications for CPU, Chipset and most of the peripherals. Whether your system can run under 75, 83, 112, 124, 140, 150 MHz properly will depend on your hardware configurations: CPU, SDRAM, Cards, etc.
- 1. Celeron<sup>™</sup> 533/ 66 MHz FSB



#### **CPU Installation**

Please make sure the CPU type and speed is supported by your motherboard.



CPU Top View



**CPU Bottom View** 



1.Pull the lever out and lift it up.



2. The notched corner should point toward the end of the lever. The CPU will only fit in the orientation as shown.

### CPU Heat Sink Installation:

Beware: Please check that the heat sink is in good contact with the CPU before you turn on your system. The poor contact will cause over heat, and might cause damage to your processor!



3. Align CPU and insert it

(Please refer to your heatsink installation manual for application of thermal grease to provide better heat conduction between your CPU and heatsink.)



4.Use compliant fan approved by Intel.



- 5. Hook one end of the cooler bracket to the CPU socket.
- 6. Hook the other end of the cooler bracket to the CPU socket.
- Please refer to the cooler's installation manual for detailed installation steps)

#### **Memory Installation**

The motherboard has 2 dual inline memory module (DIMM) sockets support 4 banks. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM Slot . The DIMM module can only fit in one direction due to the two notch. Memory size can vary between sockets.





1. The DIMM slot has two notch, so the DIMM 2. Insert the DIMM memory module vertically memory module can only fit in one direction.



into the DIMM slot. Then push it down.

- 3. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module.
- Reverse the installation steps when you wish to remove the DIMM module.

← Page Index for Connectors / Panel and Jumper Definition	Page
Connectors	P.14
Game & Audio Port	P.14
ATX Power	P.18
COM A / COM B / LPT Port	P.14
Floppy Port	P.18
F_AUDIO (Front Audio)	P.23
IDE 1(Primary)/ IDE 2(Secondary) Port	P.19
J1 (Wake On LAN)	P.21
J3 (Ring Power On)	P.20
J8 (CD Audio Line In)	P.19
J13 (IR)	P.20
JP2 (System Fan)	P.17
JP3 (Audio Out) [Optional]	P.21
JP5 / LED1/LED2 [Optional](STR LED Connector & DIMM LED)	P.22
JP15 (Power Fan)	P.17
JP16 (CPU Fan)	P.16
JP26 (CD_IN) [Optional]	P.22
PS/2 Keyboard & PS/2 Mouse Connector	P.15
USB 1 Connector	P.15
USB 2 Connector	P.16
Panel and Jumper Definition	P.24
BAT1 (Battery)	P.29
FMIC_EN (Front MIC)	P.29
J2 (2x11 Pins Jumper)	P.24
J12 (2x7 Pins Jumper)	P.25
JP1 (Clear CMOS Function)	P.26
JP7/JP8/JP18 (Onboard AC97& AMR Select)	P.27
JP9 (USB Device Wake Up Selection)	P.27
JP11 (STR Function Enabled)	P.28
JP22 (BIOS Write Protection)	P.28
JP23 (Case Open)	P.26

## Connectors

Game & Audio Port







Please note:

This motherboard supports standard audio port and game port. After install onboard audio driver. you may connector speaker to line out jack, micro phone to MIC in jack Device like CD-ROM , walkman etc can be connected to line-in jack

## COM A / COM B / LPT Port







#### Please note:

This mainboard supports 2 standard COM ports and 1 LPT port. Device like printer can be connected to LPT port; mouse and modem etc can be connected to COM ports.

### **USB 1 Connector**



#### Please note:

Before you connect your device(s) into USB connector(s), please make sure your device(s) has a standard USB interface like, USB keyboard, mouse, scanner, zip, speaker... Also make sure your OS supports USB controller (Win 95 w/ USB supperment, Win98, Windows 2000, Windows ME, Win NT w/ SP 6). If your OS does not support USB controller, please contact OS vander for passible patch or driver upgrade. For more information please contact your OS or device(s) vanders.

### PS/2 Keyboard & PS/2 Mouse Connector





#### Please note:

This mainboard supports standard  $\mathsf{PS/2}$  keyboard and  $\mathsf{PS/2}$  mouse interface connector.

### USB 2 Connector





#### Please note:

Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.

JP16 : CPU Fan



	1 •
Pin No.	Definition
1	GND

+12V

SENSE



#### Please note:

A proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating.

2

3

## JP15 : Power Fan





Pin No.	Definition
1	GND
2	+12V
3	NC

## JP2 : System Fan





Pin No.	Definition
1	GND
2	+12V
3	SENSE

## ATX Power



20			11
10			1

Pin No.	Definition
3,5,7,13, 15-17	GND
1,2,11	3.3V
4,6,19,20	VCC
10	+12V
12	-12V
18	-5V
8	Power Good
9	5V SB stand by+5V
14	PS-ON(Soft On/Off)



#### Please note:

AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

## Floppy Port



Red Line



## IDE1(Primary), IDE2(Secondary) Port





### J8 : CD Audio Line In



1		]
		L
		I
	٦	

Pin No.	Definition
1	CD-L
2	GND
3	GND
4	CD-R

## J13 : IR





Please note: Be careful with the polarity of the IR connector while you connect the IR. Please contact you nearest dealer for optional IR device.

J3 : Ring Power On (Internal Modem Card Wake Up)



1	_	
<u>ا</u> י		
	_	1

Pin No.	Definition
1	Signal
2	GND

## J1 : Wake On LAN



Pin No.	Definition	
1	+5VSB	
2	GND	
3	Signal	

## JP3 : Audio Out (Optional)



	Pin No.	Definition
2	1	Line Out (R)
	2	Line Out (L)
	3.4	Analog GND
1	5.6	Digital GND
	7	+12V
	8	NC

JP26 : CD\_IN (Optional)



JP5 / LED1 / LED2(Optional) : STR LED Connector & DIMM LED





Please note, Do not remove memory modules while DIMM LED is on. It might cause short or other unexpected damages due to the 3.3V stand by voltage. Remove memory modules only when STR function is disabled by jumper and AC Power cord is disconnected.

## F\_AUDIO : Front Audio



15			16
	-		
	_		
		-	-
1	-	-	2

Definition
Incase speaker (R)
Incase speaker (L)
GND
+12V
NC
MIC
Front Audio (R)
Front Audio (L)
Rear Audio (R)
Rear Audio (L)



## Please Note : If you want to use "Front Audio" connector, you must move 11-12,13-14 Jumper.

In order to utilize the front audio header, your chassis must have front audio connector. Also please make sure the pin assignment on the cable is the same as the pin assignment on the MB header. To find out if the chassis you are buying support front audio connector, please contact your dealer.

## Panel and Jumper Definition

J2: 2x11 Pins Jumper





GN (Green Switch)	Open: Normal Operation
	Close: Entering Green Mode
GD (Green LED)	Pin 1: LED anode(+)
	Pin 2: LED cathode(–)
HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+)
	Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+)
	Pin 2- Pin 3: NC
	Pin 4: Data(-)
RE (Reset Switch)	Open: Normal Operation
	Close: Reset Hardware System
P+P–P–(Power LED)	Pin 1: LED anode(+)
	Pin 2: LED cathode(–)
	Pin 3: LED cathode(-)
PW (Soft Power Connector)	Open: Normal Operation
	Close: Power On/Off



**Please Note:** Please connect the power LED, PC speaker, reset switch and power switch etc of your chassis front panel to the front panel jumper according to the pin assignment above.

## J12 : 2x7 Pins Jumper (Optional)



HD (IDE Hard Disk Active LED)	Pin 1: LED anode(+)
	Pin 2: LED cathode(-)
SPK (Speaker Connector)	Pin 1: VCC(+)
	Pin 2- Pin 3: NC
	Pin 4: Data(–)
RE (Reset Switch)	Open: Normal Operation
	Close: Reset Hardware System
P+P–P–(Power LED)	Pin 1: LED cathode(+)
	Pin 2: Green LED cathode(-)
	Pin 3: Yellow LED cathode(–)
PW (Soft Power Connector)	Open: Normal Operation
	Close: Power On/Off

## JP1 : Clear CMOS Function



<b>1</b>	<b>1</b>

Normal (Default)

Clear	CMOS

Pin No.	Definition
1-2 Close	Normal (Default)
2-3 Close	Clear CMOS



**Please note:** You may clear the CMOS data to its default values by this jumper.

## JP23 : Case Open



1	

Pin No.	Definition
1	Signal
2	GND

JP7/JP8/JP18 : Onboard AC97& AMR (Primary or Secondary ) Select (AMR-> Audio Modem Riser)





**Please note:** This MB supports AMR slot, you can look up the table above to choose the appropriate AMR card for your board.

### JP9 : USB Device Wake up Selection



1	
Pin No.	Definition
1-2 Close	Normal (Default)
2-3 Close	USB Device
	Wake up



Please note: (If you want to use "USB KB Wakeup from S3~S5" function, you have to set the BIOS setting "USB KB Wakeup from S3~S5" enabled, and the jumper "JP9"& "JP11" enabled).

\*(Power on the computer and as soon as memory counting starts, press <Del: You will enter BIOS Setup. Select the item "POWER MANAGEMENT SETUP then select "USB KB Wakeup from S3~S5: Enabled". Remember to save th setting by pressing "ESC" and choose the "SAVE & EXIT SETUP" option.)

## JP22 : BIOS Write Protection



1 <b>Normal</b> (Default)	1 BIOS write protection
Pin No.	Definition
1-2Close	BIOS Write Protection
2-3Close	Normal (Default)



**Please note:** To flash/upgrade BIOS on this M/B "JP22" jumper must be "2-3 close". We recommend "JP22" jumper to be set to"1-2 close", whenever user is not try to flash/upgrade the BIOS.

## JP11 : STR Function Enabled



1	1	
-		

Disabled (Default)

Enabled

Pin No.	Definition
1-2 close	STR Enabled
2-3 close	STR Disabled (Default)

## FMIC\_EN : Front MIC





Enabled (Default) Disabled

Pin No.	Definition
1-2 close	Disabled
2-3 close	Enabled (Default)

### BAT1 : Battery





#### CAUTION

- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.
# **Performance List**

The following performance data list is the testing results of some popular benchmark testing programs.

These data are just referred by users, and there is no responsibility for different testing data values gotten by users. (The different Hardware & Software configuration will result in different benchmark testing results.)

- CPU Intel Pentium<sup>®</sup> *III* Socket 370 Processor
- DRAM (128 x 2) MB SDRAM (LGS GM72V66841ET75 9931 AA5)
- CACHE SIZE 256 KB included in CPU
- DISPLAY GA-GF2000 (32MB SDRAM)
- STORAGE Onboard IDE (IBM DTLA-307045)
- O.S. Windows NT<sup>™</sup> 4.0 (SP6)
- DRIVER Display Driver at 1024 x 768 x 64K x 75Hz VIA 4 in 1 Driver Ver.4.23A

Processor	Intel Pentium <sup>®</sup> ///Socket 370		
	933MHz(133x8)		
Winbench99			
CPU mark99	85.2		
FPU Winmark 99	4940		
Business Disk Winmark 99	8560		
Hi-End Disk Winmark 99	23100		
Business Graphics Winmark 99	461		
Hi-End Graphics Winmark 99	890		
Winstone99			
Business Winstone99	49.8		
Hi-End Winstone99	59.4		

€<sup>∞</sup>If you wish to maximize the performance of your system, please refer to the detail on P.50.

# Block Diagram



# Suspend To RAM Installation

A.1 Introduce STR function:

Suspend-to-RAM (STR) is a Windows 98/ME/2000 ACPI sleep mode function. When recovering from STR (S3) sleep mode, the system is able, in just a few seconds, to retrieve the last "state" of the system before it went to sleep and recover to that state. The "state" is stored in memory (RAM) before the system goes to sleep. During STR sleep mode, your system uses only enough energy to maintain critical information and system functions, primarily the system state and the ability to recognize various "wake up" triggers or signals, respectively.

#### A.2 STR function Installation

Please use the following steps to complete the STR function installation.

#### Step-By-Step Setup

#### Step 1:

To utilize the STR function, the system must be in Windows 98/ME/2000 ACPI mode.

Putting Windows 98/ME/2000 into ACPI mode is fairly easy.

#### Setup with Windows Installation CD-title:

- A. Insert the Windows ME (98/2000) into your CD-ROM drive, select Start, and then Run.
- B. Type (without quotes) "D:\setup" in the window provided. Hit the enter key or click OK.
- C. After setup completes, remove the CD, and reboot your system

(This manual assumes that your CD-ROM device drive letter is D:).

#### Step 2:

(If you want to use STR Function, please set jumper "JP11" Pin1-2 (Closed.)



1	1 🔳 🔳	

Disabled Enabled (Default)

Pin No.	Definition
1-2 close	STR Enabled
2-3 close	STR Disabled (Default)

#### Step 3:

Power on the computer and as soon as memory counting starts, press <Del>. You will enter BIOS Setup. Select the item "POWER MANAGEMENT SETUP", then select "ACPI Sleep Type : S3 /STR". Remember to save the settings by pressing "ESC" and choose the "SAVE & EXIT SETUP" option.

Congratulation! You have completed the installation and now can use the STR function.

### A.3 How to put your system into STR mode? (For example : Windows ME)

There are two ways to accomplish this:

- 1. Choose the "Stand by" item in the "Shut Down Windows" area.
  - A. Press the "Start" button and then select "Shut Down"



B. Choose the "Stand by" item and press "OK"

	What do you way	nt the computer to r	102
y	Shut down		•
	Shut down Restart Stand by		
	OK	Cancel	<u>H</u> elp

- 2. Define the system "power on" button to initiate STR sleep mode:
  - A. Double click "My Computer" and then "Control Panel"

Be Bill San Be Tyrutes Bills	1
* · * · * · * × · · · · · · · · · · · ·	
	1
Ny Computer	
Cantool Pased Eviden Valler	
Use the extinct in Control Panel for performing repr	
standig and standing and standi	5

B. Double click the "Power Management" item.

Control Parel								<u></u>
its its yes then be	a: 1948							10
Gelland + + + (24) @ Brand	Shier .	Other 1	6 S X #	122-				
Agenere and Control Famil								+ pto
Control Panel	Access dollars Column	*	Additioned	Salara Antoniak Antoniak	Data Tata	Data	Disc Detector	
Power-Options Configured analog-contrap entropy for your computer.	3	Callin Dation	(all Freeh	3	Cathorn	(internet)	۲	
technicalitazoot	C	12	Witte.	A	ų.		() Hepord	
	-	-	10.000 (12.00)	-	Eunig	ver inergi te	ing ratings for	our computer.
	50	33	48	-	1.	20	22	
	Segment and Canavas	Scheduled Tasks	Sounds and Multimode	System	Taskbar-and Shattifiketu	Tolghow	Usen	
Emilgent anerge-sering retring its your	computer						A Corpo	w.

C. Select the "Advanced" tab and "Standby" mode in Power Buttons.

Power Options Properties	? ×
Power Schemer Advanced Hibemate	
Select the behaviors you want.	
Optiona	- 1
Always show jcon on the taskbar.	
Frompt for paraword when computer goes of i standby and hibernal	8.
Power buttons	
When I press the power button on my computer.	
Stand By	
When I press the sleep button on my computer	
Stand By	
OK. Cancel 607	9

D. Restart your computer to complete setup.

Now when you want to enter STR sleep mode, just momentarily press the "Power on" button..

### A.4 How to recover from the STR sleep mode?

There are five ways to "wake up" the system:

- 1. Press the "Power On" button.
- 2. Use the "Resume by Alarm" function.
- 3. Use the "Modem Ring On" function.
- 4. Use the "Wake On LAN" function.
- 5. Use the "USB Device Wake Up" function.

#### A.5 Notices :

- 1. In order for STR to function properly, several hardware and software requirements must be satisfied:
  - A. Your ATX power supply must comply with the ATX 2.01 specification (provide more than 720 mA 5V Stand-By current).
  - B. Your SDRAM must be PC-100 compliant.
- Jumper "JP5" is provided to connect to the STR LED in your system chassis. [Some chassis may not provide this feature.] The STR LED will be illuminated when your system is in STR sleep mode.



STR LED Connector External.





**Please note**, Do not remove memory modules while DIMM LED is on. It might cause short or other unexpected damages due to the 3.3V stand by voltage. Remove memory modules only when STR function is disabled by jumper and AC Power cord is disconnected.

# @ BIOS Introduction

### Gigabyte announces @ **BIOS** Windows BIOS live update utility



Have you ever updated BIOS by yourself? Or like many other people, you just know what BIOS is, but always hesitate to update it? Because you think updating newest BIOS is

unnecessary and actually you don't know how to update it.

Maybe not like others, you are very experienced in BIOS updating and spend quite a lot of time to do it. But of course you don't like to do it too much. First, download different BIOS from website and then switch the operating system to DOS mode. Secondly, use different flash utility to update BIOS. The above process is not a interesting job. Besides, always be carefully to store the BIOS source code correctly in your disks as if you update the wrong BIOS, it will be a nightmare.

Certainly, you wonder why motherboard vendors could not just do something right to save your time and effort and save you from the lousy BIOS updating work? Here it comes! Now Gigabyte announces @BIOS--the first Windows BIOS live update utility. This is a smart BIOS update software. It could help you to download the BIOS from internet and update it. Not like the other BIOS update software, it's a Windows utility. With the help of "@BIOS', BIOS updating is no more than a click.

Besides, no matter which mainboard you are using, if it's a Gigabyte's product\*, @BIOS help you to maintain the BIOS. This utility could detect your correct mainboard model and help you to choose the BIOS accordingly. It then downloads the BIOS from the nearest Gigabyte ftp site automatically. There are several different choices; you could use "Internet Update" to download and update your BIOS directly. Or you may want to keep a backup for your current BIOS, just choose "Save Current BIOS" to save it first. You make a wise choice to use Gigabyte, and @BIOS update your BIOS smartly. You are now worry free from updating wrong BIOS, and capable to maintain and manage your BIOS easily. Again, Gigabyte's innovative product erects a milestone in mainboard industries.

For such a wonderful software, how much it costs? Impossible! It's free! Now, if you buy a Gigabyte's motherboard, you could find this amazing software in the attached driver CD. But please remember, connected to internet at first, then you could have a internet BIOS update from your Gigabyte @BIOS.

# Easy TuneIII<sup>™</sup> Introduction

# Gigabyte announces *EasyTunelll* Windows overdrive utility



"Overdrive" might be one of the most common issues in computer field. But have many users ever tried it? The answer is probably "no". Because "overdrive" is thought to be very difficult and includes a lot of technical know-how, sometimes "overdrive" is

even considered as special skills found only in some enthusiasts.

But as to the experts in "overdrive", what's the truth? They may spend quite a lot of time and money to study, try and use many different hardware and software tools to do "overdrive". And even with these technologies, they still learn that it's quite a risk because the safety and stability of an "overdrive" system is unknown.

Now everything is different because of a Windows overdrive utility EasyTuneIII--announced by Gigabyte. This utility has totally changed the gaming rule of "overdrive". This is the first overdrive utility suitable for both normal and power users. Users can choose either "Easy Mode" or "Advanced Mode" to run "overdrive" at their convenience. For users who choose "Easy Mode", they just need to click "Auto Optimize" to have auto and immediate CPU overclocking. This software will then overdrive CPU speed automatically with the result being shown in the control panel. If someone prefers to "overdrive" by oneself, there is also another choice. Click "Advanced Mode" to enjoy "sport drive" class overclocking. In "Advanced Mode", one can change the system bus speed in small increments to get ultimate system performance. And no matter which mainboard is used, if it's a Gigabyte's product\*, EasyTuneIII helps to perform the best of system.

Besides, different from other traditional over-clocking methods, EasyTuneIII doesn't require users to change neither BIOS nor hardware switch/ jumper setting; on the other hand, they can do "overdrive" at only one click. Therefore, this is a safer way for "overdrive" as nothing is changed on software or hardware. If user runs EasyTuneIII over system's limitation, the biggest lost is only to restart the computer again and the side effect is then well controlled. Moreover, if one well-performed system speed been tested in EasyTuneIII, user can "Save" this bus speed and "Load" it in next time. Obviously, Gigabyte EasyTuneIII has already turned the "overdrive" technology toward to a newer generation.

This wonderful software is now free bundled in Gigabyte motherboard attached driver CD. Users may make a test drive of "EasyTuneIII<sup> $M_n$ </sup>" to find out more amazing features by themselves.

For further technical information, please link to: http://www.gigabyte.com.tw

\* Note: For the latest version of EasyTuneIII™, please visit our website.

G√ Page Index for BIOS Setup	Page
The Main Menu	P.43
Standard CMOS Setup	P.45
BIOS Features Setup	P.48
Chipset Features Setup	P.50
Power Management Setup	P.53
PNP/ PCI Configuration	P.56
Load BIOS Defaults	P.58
Load Setup Defaults	P.59
Integrated Peripherals	P.60
Hardware Monitor Setup	P.64
Supervisor Password / User Password	P.66
IDE HDD Auto Detection	P.67
Save to CMOS and Exit	P.68
Exit Without Saving	P.69

# **BIOS Setup**

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

### ENTERING SETUP

Power ON the computer and press <Del> immediately will allow you to enter Setup. If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" bottom on the system case. You may also restart by simultaneously press <Ctrl> - <Alt> - <Del> keys.

#### **CONTROL KEYS**

<^>	Move to previous item
<↓>	Move to next item
<>	Move to the item in the left hand
$\langle \rightarrow \rangle$	Move to the item in the right hand
<esc></esc>	Main Menu - Quit and not save changes into CMOS
	Status Page Setup Menu and Option Page Setup Menu - Exit current page
	and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<f1></f1>	General help, only for Status Page Setup Menu and Option Page Setup
	Menu
<f2></f2>	Reserved
<f3></f3>	Reserved
<f4></f4>	Reserved
<f5></f5>	Restore the previous CMOS value from CMOS, only for Option Page
	Setup Menu
<f6></f6>	Load the default CMOS value from BIOS default table, only for Option
	Page Setup Menu
<f7></f7>	Load the Setup Defaults.
<f8></f8>	Reserved
<f9></f9>	Reserved
<f10></f10>	Save all the CMOS changes, only for Main Menu

#### **GETTING HELP**

#### Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

#### Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

#### The Main Menu (For example BIOS version: F5)

Once you enter AMI BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. The Main Menu allows you to select from nine setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

AMIBIOS SIMPLE SETUP UTILITY-VERSION 1.24d (C) 1999 American Megatrends, Inc. All Rights Reserved		
STANDARD CMOS SETUP	INTEGRATED PERIPHERALS	
BIOS FEATURES SETUP	HARDWARE MONITOR SETUP	
CHIPSET FEATURES SETUP	SUPERVISOR PASSWORD	
POWER MANAGEMENT SETUP	USER PASSWORD	
PNP/PCI CONFIGURATION	IDE HDD AUTO DETECTION	
LOAD BIOS DEFAULTS	SAVE & EXIT SETUP	
LOAD SETUP DEFAULTS	EXIT WITHOUT SAVING	
$\begin{array}{llllllllllllllllllllllllllllllllllll$		
Time. Date. Hard Disk Type		

Figure 1: Main Menu

#### • Standard CMOS Setup

This setup page includes all the items in standard compatible BIOS.

#### BIOS Features Setup

This setup page includes all the items of AMI special enhanced features.

#### • Chipset Features Setup

This setup page includes all the items of chipset special features.

#### • Power Management Setup

This setup page includes all the items of Green function features.

#### • PnP/PCI Configurations

This setup page includes all the configurations of PCI & PnP ISA resources.

#### • Load BIOS Defaults

Bios Defaults indicates the value of the system parameter which the system would be in the safe configuration.

#### Load Setup Defaults

Setup Defaults indicates the value of the system parameter which the system would be in the most appropriate configuration.

#### • Integrated Peripherals

This setup page includes all onboard peripherals.

#### • Hardware Monitor Setup

This setup page is auto detect fan and temperature status.

#### • Supervisor password

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

#### • User password

Change, set, or disable password. It allows you to limit access to the system.

#### IDE HDD auto detection

Automatically configure hard disk parameters.

#### • Save & Exit Setup

Save CMOS value settings to CMOS and exit setup.

#### • Exit Without Saving

Abandon all CMOS value changes and exit setup.

### Standard CMOS Setup

The items in Standard CMOS Features Menu (Figure 2) are divided into 9 categories. Each category includes no, one or more than one setup items. Use the arrows to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

AMIBIOS SETUP – STANDAR ( C ) 1999 American Megatrends, In	D CMOS SETUP ic. All Rights Reserved
Date (mm/dd/yyyy) : Tue Jan 25, 2000 Time (hh/mm/ss) : 10:36:24 TYPE SIZE CYLS HEAD PF	RECOMP LANDZ SECTOR MODE
Pri Master : Auto Pri Slave : Auto Sec Master : Auto Sec Slave : Auto	
Floppy Drive A: 1.44 MB 3 ½ Floppy Drive B: Not Installed Boot Sector Virus Protection : Disabled	Base Memory : 640 Kb Other Memory: 384 Kb Extended Memory: 30Mb Total Memory: 31Mb
Month: Jan – Dec Day: 01 – 31 Year : 1990– 2099	ESC : Exit ↑↓ : Select Item PU/PD/+/– : Modify (Shift)F2 : Color



#### Date

The date format is <Week>, <Month>, <Day>, <Year>.

Week	The week, from Sun to Sat, determined by the BIOS and is display-only
Month	The month, Jan. Through Dec.
Day	The day, from 1 to 31 (or the maximum allowed in the month)
Year	The year, from 1990 through 2099

### • Time

The times format in <hour> <minute> <second>. The time is calculated base on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.

### • IDE Primary Master, Slave / Secondary Master, Slave

The category identifies the types of hard disk from drive C to F that has been installed in the computer. There are two types: auto type, and user definable type. User type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

CYLS.	Number of cylinders
HEADS	number of heads
PRECOMP	write precomp
LANDZONE	Landing zone
SECTORS	number of sectors

If a hard disk has not been installed select NONE and press <Enter>.

#### • Drive A type / Drive B type

The category identifies the types of floppy disk drive A or drive B that has been installed in the computer.

None	No floppy drive installed
360K, 5.25 in.	5.25 inch PC-type standard drive; 360K byte capacity.
1.2M, 5.25 in.	5.25 inch AT-type high-density drive; 1.2M byte capacity (3.5 inch
	when 3 Mode is Enabled).
720K, 3.5 in.	3.5 inch double-sided drive; 720K byte capacity
1.44M, 3.5 in.	3.5 inch double-sided drive; 1.44M byte capacity.
2.88M, 3.5 in.	3.5 inch double-sided drive; 2.88M byte capacity.

### • Boot Sector Virus Protection

If it is set to enable, the category will flash on the screen when there is any attempt to write to the boot sector or partition table of the hard disk drive. The system will halt and the following error message will appear in the mean time. You can run anti-virus program to locate the problem.

Enabled	Activate automatically when the system boots up causing a warning
	message to appear when anything attempts to access the boot sector or
	hard disk partition table
Disabled	No warning message to appear when anything attempts to access the
	boot sector or hard disk partition table. (Default Value)

#### Memory

The category is display-only which is determined by POST (Power On Self Test) of the BIOS.

#### **Base Memory**

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

The value of the base memory is typically 512 K for systems with 512 K memory installed on the motherboard, or 640 K for systems with 640 K or more memory installed on the motherboard.

#### Extended Memory

The BIOS determines how much extended memory is present during the POST.

This is the amount of memory located above 1 MB in the CPU's memory address map.

#### Other Memory

This refers to the memory located in the 640 K to 1024 K address space. This is memory that can be used for different applications.

DOS uses this area to load device drivers to keep as much base memory free for application programs. Most use for this area is Shadow RAM

### **BIOS Features Setup**

AMIBIOS ( C ) 1999 A	SETUP – BIOS merican Megatr	S FEATURES CMOS SETUP rends, Inc. All Rights Reserved
1st Boot Device 2nd Boot Device 3rd Boot Device S.M.A.R.T for Hard Disks BootUp Num-Lock Floppy Drive Seek Password Check Processor Serial Number	:Floppy :IDE-0 :CDROM :Disabled :On :Disabled :Setup :Disabled	
		ESC : Quit $\uparrow \downarrow \leftarrow \rightarrow$ : Select ItemF1: HelpPU/PD/+/- : ModifyF5: Old Values(Shift)F2 :ColorF6: Load BIOS DefaultsF7: Load Setup Defaults

Figure 3: BIOS Features Setup

### • 1st / 2nd / 3rd Boot Device

The default value is Floppy or LS-120 / ZIP A: or ATAPI ZIP C: or CDROM or SCSI or NET WORK / I20 or IDE-0~IDE-3 or Disabled.

Floppy	Boot Device by Floppy.
LS-120 / ZIP A:	Boot Device by LS-120 / ZIP A:.
CDROM	Boot Device by CDROM.
SCSI	Boot Device by SCSI.
NETWORK	Boot Device by NETWORK.
IDE-0~IDE-3	Boot Device by IDE-0~IDE-3.
Disabled	Boot Device by Disabled.
ATAPI ZIP C:	Boot Device by ATAPI ZIP C:.

### • S.M.A.R.T. for Hard Disks

Enable	Enable S.M.A.R.T. Hard for Disks.
Disable	Disable S.M.A.R.T. Hard for Disks. (Default Value)

#### Boot Up Num-Lock

On	Keypad is number keys. (Default Value)
Off	Keypad is arrow keys.

#### • Floppy Drive Seek

During POST, BIOS will determine if the floppy disk drive installed is 40 or 80 tracks. 360 type is 40 tracks while 720 , 1.2 and 1.44 are all 80 tracks.

Enabled	BIOS searches for floppy disk drive to determine if it is 40 or 80 tracks.
	Note that BIOS can not tell from 720, 1.2 or 1.44 drive type as they are
	all 80 tracks.
Disabled	BIOS will not search for the type of floppy disk drive by track number.
	Note that there will not be any warning message if the drive installed is
	360. (Default Value)

#### Password Check

Setup	Set Password Check to Setup. (Default Value)
Always	Set Password Check to Always.

### • **Processor Serial Number** (Only Support Pentium<sup>®</sup> *!!!* Processor)

Disabled	Disabled CPU Serial Number. (Default Value)
Enabled	Enabled CPU Serial Number.

## **Chipset Features Setup**

AMIBIOS S ( C ) 1999 A	ETUP –CHIPSET F merican Megatrends	FEATURE CMOS SETUP Is, Inc. All Rights Reserved
*** DRAM Timing *** Top Performance SDRAM Timing by SPD SDRAM CAS# Latency DRAM Frequency C2P Concurrency & Master DRAM Integrity Mode AGP Mode AGP Comp. Driving Manual AGP Comp. Driving AGP Aperture Size CIKGen Spread Spectrum South Bridge Subsystem ID USB Controller	:Disabled :Disabled :3 :Auto :Enabled :Disabled :4X :Auto :CB :64MB :Center ± 0.25% :Disabled :All USB Port	
USB Legacy Support	:Disabled	$\begin{array}{c c c c c c c c c c c c c c c c c c c $

Figure 4: Chipset Features Setup

### • Top Performance

If you wish to maximize the performance of your system, set "Top Performance" as "Enabled".

Disabled	Set Top Performance is disabled. (Default Value)
Enabled	Set Top Performance is enabled.

### • SDRAM Timing by SPD

Disabled	SDRAM Timing by SPD Function Disabled. (Default Value)
Enabled	SDRAM Timing by SPD Function Enabled.

### • SDRAM CAS# Latency

3	For Slower SDRAM DIMM module. (Default Value)
2	For Fastest SDRAM DIMM module.

### DRAM Frequency

Auto	Set DRAM Frequency automation. (Default Value)
100MHz	Set DRAM Frequency is 100MHz.
66MHz	Set DRAM Frequency is 66MHz.
133MHz	Set DRAM Frequency is 133MHz.

### • C2P Concurrency & Master

Enabled	Enabled C2P Concurrency & Master. (Default Value)
Disabled	Disabled C2P Concurrency & Master.

### DRAM Integrity Mode

ECC	For 72 bit ECC type DIMM Modle.
Disabled	Normal Setting. (Default Value)

### AGP Mode

4X	Set AGP Mode is 4X. (Default Value)
1X	Set AGP Mode is 1X.
2X	Set AGP Mode is 2X.

### AGP Comp. Driving

Auto	Set AGP Comp. Driving is Auto. (Default Value)
Manual	Set AGP Comp. Driving is Manual.

If AGP Comp. Driving is Manual.

Manual AGP Comp. Driving : 00~FF

### AGP Aperture Size

4MB	Set AGP Aperture Size to 4MB.
8MB	Set AGP Aperture Size to 8 MB.
16MB	Set AGP Aperture Size to 16 MB.
32MB	Set AGP Aperture Size to 32 MB.
64MB	Set AGP Aperture Size to 64 MB. (Default Value)
128MB	Set AGP Aperture Size to 128 MB.
256MB	Set AGP Aperture Size to 256 MB.

### • CIKGen Spread Spectrum

Disabled	Spread Spectrum Disabled.
Center ± 0.25%	Set Spread Spectrum 0. 25% (Center Spread). (Default Value)
Center ± 0.5%	Set Spread Spectrum 0. 5% (Center Spread).

# • South Bridge Subsystem ID

Disabled	Disable it if you have to install VIA 4 in 1 SP4.22 or before. (Default Value)
Enabled	Enable south bridge subsystem ID function.

### USB Controller

All USB Port	Set USB Controller Function used all USB Port. (Default Value)
USB Port 0&1	Set USB Controller Function used USB Port 0&1.
USB Port 2&3	Set USB Controller Function used USB Port 2&3.
Disabled	USB Controller Function Disabled.

### USB Legacy Support

Keyboard	Set USB Legacy Support Keyboard.
Keyb+Mouse	Set USB Legacy Support Keyboard +Mouse.
Disabled	Disabled USB Legacy Support Function. (Default Value)

### **Power Management Setup**

AMIBIOS SETUP – POWER MANAGEMENT SETUP			
(C) 1999 All	iencan wegau	enus, inc. All Rights Reser	veu
ACPI Sleep Type	:S1/POS	PME Event Wake up	:Enabled
USB KB Wakeup From S3-S5	:Disabled	RTC Alarm Power On	:Disabled
Video Power Down Mode	:Stand By	RTC Alarm Date	:15
Hard Disk Power Down Mode	:Stand by	RTC Alarm Hour	:12
Suspend Time Out (Minute)	:Disabled	RTC Alarm Minute	:30
Display Activity	:Ignore	RTC Alarm Second	:30
IRQ3	:Monitor		
IRQ 4	:Monitor		
IRQ 5	:Ignore		
IRQ 7	:Monitor		
IRQ 9	:Ignore		
IRQ 10	:Ignore		
IRQ 11	:Ignore		
IRQ 13	:Ignore		
IRQ 14	:Monitor		
IRQ 15	:Ignore	ESC : Quit	$\uparrow\downarrow \leftarrow \rightarrow$ : Select Item
Soft-off by Power Button	Instant off	F1 : Help	PU/PD/+/- : Modify
AC Back Function	:Soft Off	F5 : Old Values (S	Shift)F2 :Color
Modem Use IRQ	:4	F6 : Load BIOS Defa	ults
Modem Ring On/Wake On Lan	:Enabled	F7 : Load Setup Defa	aults

Figure 5: Power Management Setup

### • ACPI Sleep Type

S1/POS	Set ACPI sleep type is S1. (Default Value)
S3/STR	Set ACPI sleep type is S3.

### • USB KB Wakeup From S3-S5

Disabled	Disabled USB KB Wakeup From S3-S5 function. (Default Value)
Enabled	Enabled USB KB Wakeup From S3-S5 function.

### • Video Power Down Mode

Disabled	Disabled Video Power Down Mode Function.
Suspend	Set Video Power Down Mode to Suspend.
Stand By	Set Video Power Down Mode to Stand By. (Default Value)

### • Hard Disk Power Down Mode

Disabled	Disabled Hard Disk Power Down Mode Function.
Suspend	Set Hard Disk Power Down Mode to Suspend.
Stand By	Set Hard Disk Power Down Mode to Stand By. (Default Value)

### • Suspend Time Out (Minute.)

Disabled	Disabled Suspend Time Out Function. (Default Value)
1	Enabled Suspend Time Out after 1min.
2	Enabled Suspend Time Out after 2min.
4	Enabled Suspend Time Out after 4min.
8	Enabled Suspend Time Out after 8min.
10	Enabled Suspend Time Out after 10min.
20	Enabled Suspend Time Out after 20min.
30	Enabled Suspend Time Out after 30min.
40	Enabled Suspend Time Out after 40min.
50	Enabled Suspend Time Out after 50min.
60	Enabled Suspend Time Out after 60min.

### Display Activity

Ignore	Ignore Display Activity. (Default Value)
Monitor	Monitor Display Activity.

### IRQ 3~IRQ15

Ignore	Ignore IRQ3 ~IRQ15.
Monitor	Monitor IRQ3~IRQ15.

### • Soft-off by Power Button

Instant-off	If the user press the power button once, he can turn off the system. <b>(Default Value)</b>
Delay 4 sec	The user needs to press the power button at least 4 sec, then he can turn off the system.

### AC Back Function

Memory	When AC-power back to the system, the system will return to the state
_	before AC-power off.
Soft Off	When AC-power back to the system, the system will be in "Soft-Off" state.
	(Default Value)
Full On	When AC-power back to the system, the system will be in "Full-On" state.

### Modem Use IRQ

NA	Set Modem Use IRQ to NA.
3	Set Modem Use IRQ to 3.
4	Set Modem Use IRQ to 4. (Default Value)
5	Set Modem Use IRQ to 5.
7	Set Modem Use IRQ to 7.

### • Modem Ring On / Wake On Lan

Disabled	Disabled Modem Ring On / Wake On Lan function.
Enabled	Enabled Modem Ring On / Wake On Lan function. (Default Value)

### PME Event Wake up

Disabled	Disabled PME Event Wake up function.
Enabled	Enabled PME Event Wake up function. (Default Value)

### • RTC Alarm Power On

You can set "RTC Alarm Power On" item to enabled and key in Data/time to power on

system.

Disabled	Disable this function. (Default Value)
Enabled	Enable alarm function to POWER ON system.

If RTC Alarm Lead To Power On is Enabled.

RTC Alarm Date :	Every Day,1~31
RTC Alarm Hour:	0~23
RTC Alarm Minute :	0~59
RTC Alarm Second :	0~59

# **PnP/PCI** Configurations

AMIBIOS SETUP –PNP/PCI CONFIGURATION SETUP (C) 1999 American Megatrends, Inc. All Rights Reserved			
Plug and Play Aware O/S Reset Configuration Data VGA Boot From PCI VGA Palette Snoop DMA Channel 0 DMA Channel 1 DMA Channel 3 DMA Channel 5 DMA Channel 6 DMA Channel 7 IRQ 3	:No :No :AGP :Disabled :PnP :PnP :PnP :PnP :PnP :PnP :PnP :Pn		
IRQ 4 IRQ 5 IRQ 7	:PCI/PnP :PCI/PnP :PCI/PnP		
IRQ 9 IRQ 10 IRQ 11 IRQ 14 IRQ 15	:PCI/PnP :PCI/PnP :PCI/PnP :PCI/PnP :PCI/PnP	ESC : Quit $\uparrow \downarrow \leftarrow \rightarrow$ : Select Item   F1 : Help $PU/PD/+/-$ : Modify   F5 : Old Values (Shift)F2 :Color   F6 : Load BIOS Defaults   F7 : Load Setup Defaults	

Figure 6: PnP/PCI Configuration

### • Plug and Play Aware O/S

Yes	Enable Plug and Play Aware O/S function.
No	Disable Plug and Play Aware O/S function (Default Value)

### • Reset Configuration Data

Yes	Reset configuration data.	
No	Disabled this function. (Default Value)	

### VGA Boot From

AGP	Set VGA Boot From AGP. (Default Value)
PCI	Set VGA Boot From PCI.

### PCI VGA Palette Snoop

Enabled	For having Video Card on ISA Bus and VGA Card on PCI Bus.
Disabled	For VGA Card only. (Default Value)

### • DMA Channel (0,1,3,5,6,7)

PnP	The resource is used by PnP device.
ISA/EISA	The resource is used by ISA / EISA device (PCI or ISA).

### • IRQ (3,4,5,7, 9,10,11,14,15)

PCI/PnP	The resource is used by PCI/PnP device.
ISA/EISA	The resource is used by ISA / EISA device (PCI or ISA).

### **Load BIOS Defaults**



Figure 7: Load BIOS Defaults

### Load BIOS Defaults

BIOS defaults contain the most appropriate values of the system parameters that allow minimum system performance.

### **Load Setup Defaults**



Figure 8: Load Setup Defaults

### Load Setup Defaults

Selecting this field loads the factory defaults for BIOS and Chipset Features which the system automatically detects.

# **Integrated Peripherals**

AMIBIOS SETUP –INTEGRATED PERIPHERAL ( C ) 1999 American Megatrends, Inc. All Rights Reserved			
OnBoard IDE OnBoard FDC OnBoard Serial Port 1 OnBoard Serial Port 2 Serial Port 2 Mode Duplex Mode OnBoard Parallel Port Parallel Port Mode Parallel Port DMA Parallel Port IRQ OnBoard AC'97 Audio OnBoard MC'97 Modem OnBoard Legacy Audio Sound Blaster SB I/O Base Address	:Both :Auto :Auto :Auto :Normal :N/A :Auto :ECP :Auto :Auto :Auto :Auto :Enabled :Disabled :220h-22Fh	Game Port (200h-207h) :Enabled	
SB IRQ Select SB DMA Select MPU-401 MPU-401 I/O Address	:IRQ 5 :DMA 1 :Disabled :330h-333h	ESC : Quit ↑↓←→: Select Item   F1 : Help PU/PD/+/- : Modify   F5 : Old Values (Shift)F2 :Color   F6 : Load BIOS Defaults	
FM Port (388h-38Bh)	:Disabled	F7 : Load Setup Defaults	

Figure 9: Integrated Peripherals

### OnBoard IDE

Disabled	Disabled onboard IDE
Both	Set onboard IDE is Both (Default Value).
Primary	Set onboard IDE is Primary
Secondary	Set onboard IDE is Secondary

### • OnBoard FDC

Auto	Set onboard FDC is Auto (Default Value).
Disabled	Disabled onboard FDC
Enabled	Enabled onboard FDC

### OnBoard Serial Port 1

Auto	BIOS will automatically setup the port 1 address (Default Value).
3F8/COM1	Enable onboard Serial port 1 and address is 3F8.
2F8/COM2	Enable onboard Serial port 1 and address is 2F8.
3E8/COM3	Enable onboard Serial port 1 and address is 3E8.
2E8/COM4	Enable onboard Serial port 1 and address is 2E8.
Disabled	Disable onboard Serial port 1.

### • OnBoard Serial Port 2

Auto	BIOS will automatically setup the port 2 address (Default Value).
3F8/COM1	Enable onboard Serial port 2 and address is 3F8.
2F8/COM2	Enable onboard Serial port 2 and address is 2F8.
3E8/COM3	Enable onboard Serial port 2 and address is 3E8.
2E8/COM4	Enable onboard Serial port 2 and address is 2E8.
Disabled	Disable onboard Serial port 2.

### • Serial Port 2 Mode

ASKIR	Set onboard I/O chip Serial Port 2 to ASKIR Mode.
IrDA	Set onboard I/O chip Serial Port 2 to IrDA Mode.
Normal	Set onboard I/O chip Serial Port 2 to Normal Mode. (Default Value)

### • Duplex Mode

Half Duplex	IR Function Duplex Half.
N/A	Disabled this function. (Default Value)
Full Duplex	IR Function Duplex Full.

### OnBoard Parallel port

378	Enable onboard LPT port and address is 378.
278	Enable onboard LPT port and address is 278.
3BC	Enable onboard LPT port and address is 3BC.
Auto	Set onboard LPT port is Auto. (Default Value).
Disabled	Disable onboard LPT port.

### Parallel Port Mode

EPP	Using Parallel port as Enhanced Parallel Port.
ECP	Using Parallel port as Extended Capabilities Port. (Default Value)
Normal	Normal Operation.

### Parallel Port DMA

Auto	Set Auto to parallel port mode DMA Channel. (Default Value)
N/A	Disabled this function.
3	Set Parallel Port DMA is 3.
1	Set Parallel Port DMA is 1.
0	Set Parallel Port DMA is 0.

### Parallel Port IRQ

Auto	Set Auto to parallel Port IRQ DMA Channel. (Default Value).
N/A	Disabled this function.
5	Set Parallel Port IRQ is 5.
7	Set Parallel Port IRQ is 7.

### • OnBoard AC'97 Audio

Auto	Set AC'97 Audio to Auto (Default Value).
Disabled	Disabled AC'97 Audio.

### • OnBorard MC'97 Modem

Auto	Set MC'97 Modem to Auto (Default Value).
Disabled	Disabled MC'97 Modem.

### • OnBorard Legacy Audio

Enabled	Enabled onboard Legacy Audio. (Default Value)
Disabled	Disabled onboard Legacy Audio.

### Sound Blaster

Enabled	Enabled Sound Blaster.
Disabled	Disabled Sound Blaster. (Default Value)

### SB I/O Base Address

220h-22Fh	Set SB I/O Base Address is 220h-22Fh. (Default Value).
280h-28Fh	Set SB I/O Base Address is 280h-28Fh.
260h-26Fh	Set SB I/O Base Address is 260h-26Fh.
240h-24Fh	Set SB I/O Base Address is 240h-24Fh.

### SB IRQ Select

IRQ 9 / 5 / 7/ 10(Default Value: 5).

### SB DMA Select

DMA 0 / 1 / 2/ 3(Default Value: 1).

#### • MPU-401

Enabled	Enabled MPU-401.
Disabled	Disabled MPU-401. (Default Value)

### MUP-401 I/O Address

330h-333h	Set MUP-401 I/O Address is 330h-333h. (Default Value).
300h-303h	Set MUP-401 I/O Address is 300h-303h.
310h-313h	Set MUP-401 I/O Address is 310h-313h.
320h-323h	Set MUP-401 I/O Address is 320h-323h.

### • FM Port (388h-38Bh)

Disabled	Disabled FM Port (388h-38Bh). (Default Value)
Enabled	Enabled FM Port (388h-38Bh).

### • Game Port (200h-207h)

Disabled	Disabled Game Port (200h-207h).
Enabled	Enabled Game Port (200h-207h). (Default Value)

### **Hardware Monitor**

AMIBIOS SETUP –HARDWARE MONITOR ( C ) 1999 American Megatrends, Inc. All Rights Reserved			
ACPI Shut Down Temp. Current CPU Temp. Current System Temp. Case Status Current CPU Fan Speed Current System Fan Speed Vcore +3.300V +5.000V +12.000V	:Disabled :36°C/96°F :28°C/82°F :Closed :5487 RPM :0 RPM :1.634V :3.590V :5.119V :11.926V		
		ESC : Quit ↑↓←→: Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 :Color F6 : Load BIOS Defaults F7 : Load Setup Defaults	

Figure 10: Hardware Monitor

### • ACPI Shutdown Temp. (°C / °F)

(This function will be effective only for the operating systems that support ACPI Function.)

Disabled	Normal Operation. (Default value)
60°C / 140°F	Monitor CPU Temp. at 60°C / 140°F, if Temp. > 60°C / 140°F
	system will automatically power off.
70°C / 158°F	Monitor CPU Temp. at 70°C / 158°F, if Temp. > 70°C / 158°F
	system will automatically power off.
80°C / 176°F	Monitor CPU Temp. at 80°C / 176°F, if Temp. > 80°C / 176°F
	system will automatically power off.
90°C / 194°F	Monitor CPU Temp. at 90°C / 194°F, if Temp. > 90°C / 194°F
	system will automatically power off.

### • Current CPU Temp. (°C / °F)

Detect CPU Temperature automatically.

### • Current System Temp. (°C / °F)

Detect System Temperature automatically.

#### Case Status

If the case is closed, "Case Status" will show "Closed". If the case have been opened, "Case Opened" will show "Open".

### • Current CPU FAN Speed

Detect CPU Fan speed status automatically .

### • Current System FAN Speed

Detect System Fan speed status automatically .

### • Current Voltage (V) Vcore / +3.3V / +5V / +12V

Detect system's voltage status automatically.
## Set Supervisor / User Password

When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

AMIBIOS SIMPLE SETUP UTILITY-VERSION 1.24d (C) 1999 American Megatrends, Inc. All Rights Reserved				
STANDARD CMOS SETUP		INTEGRATED PERIPHERALS		
BIOS FEATURES SETUP		HARDWARE MONITOR SETUP		
CHIPSET FEATURES SETUP		SUPERVISOR PASSWORD		
POWER MANAGEMENT SETUP		USER PASSWORD		
PNP/PCI CONFIGURATION		IDE HDD AUTO DETECTION		
LOAD BIOS DEFAULTS	Enter new supervisor password:			
LOAD SETUP DEFAULTS		EXIT WITHOUT SAVING		
ESC : Quit ↑↓→← : Select Item (Shift) F2 : Change Color F5 : Old Values   F6 : Load BIOS Defaults F7: Load Setup Defaults F10: Save & Exit				
Chang /Set /Disabled Password				

#### Figure 11: Password Setting

Type the password, up to eight characters, and press <Enter>. The password typed now will clear the previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message "PASSWORD DISABLED" will appear to confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

If you select "Always" at "Password Check" in BIOS Features Setup Menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup Menu. If you select "Setup" at "Password Check" in BIOS Features Setup Menu, you will be prompted only when you try to enter Setup.

# **IDE HDD AUTO Detection**

AMIBIOS SETUP – STANDARD CMOS SETUP ( C ) 1999 American Megatrends, Inc. All Rights Reserved			
Date (mm/dd/yyyy) : Tue Jan 25, 2000 Time (hh/mm/ss) : 10:36:24 TYPE SIZE CYLS HEAD PRE	COMP LANDZ SECTOR MODE		
Pri Master : Not Installed Pri Slave : Not Installed Sec Master : Not Installed Sec Slave : Not Installed			
Floppy Drive A: 1.44 MB 3 ½ Floppy Drive B: Not Installed Boot Sector Virus Protection : Disabled	Base Memory : 640 Kb Other Memory : 384 Kb Extended Memory: 31Mb Total Memory : 32Mb		
Month: Jan – Dec Day: 01 – 31 Year: 1990– 2099	ESC : Exit ↑↓ : Select Item PU/PD/+/- : Modify (Shift)F2 : Color		

Figure 12: IDE HDD Auto Detection

Type "Y" will accept the H.D.D. parameter reported by BIOS.

Type "N" will keep the old H.D.D. parameter setup. If the hard disk cylinder number is over 1024, then the user can select LBA mode or LARGER mode for DOS partition larger than 528 MB.

## Save & Exit Setup



Figure	13:	Save	&	Exit	Setup
--------	-----	------	---	------	-------

Type "Y" will quit the Setup Utility and save the user setup value to RTC CMOS.

Type "N" will return to Setup Utility.

# **Exit Without Saving**



Figure 14: Exit Without Saving

Type "Y" will quit the Setup Utility without saving to RTC CMOS.

Type "N" will return to Setup Utility.

Customer/Country: Compa Contact Person:		any:		Phone No.:	
		E-mail Add. :			
Model name/L	_ot Num	ber:		PC	CB revision:
BIOS version:			0.S./A.S.:		
Hardware Configuration	Mfs.	Model name	Size:		Driver/Utility:
CPU					
Memory Brand					
Video Card					
Audio Card					
HDD					
CD-ROM / DVD-ROM					
Modem					
Network					
AMR / CNR					
Keyboard					
Mouse					
Power supply					
Other Device					

Problem Description:

····· × ···

×

# Appendix [Picture below are shown in Windows ME (TUCD version 1.71)]

# Appendix A: VIA Chipsets Driver Installation

## A.VIA 4 in 1 Service Pack Utility

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.



## Appendix B: VIA AC'97 Audio Driver

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.



## Appendix C: BIOS Flash Procedure

BIOS update procedure:

If your OS is Win9X, we recommend that you used Gigabyte @BIOS Program to flash BIOS.



Methods and steps:

- I. Update BIOS through Internet
  - a. Click "Internet Update" icon
  - b. Click "Update New BIOS" icon
  - c. Select @BIOS sever ( "Gigabyte @BIOS sever 1 in Taiwan" and "Gigabyte @BIOS sever 2 in Taiwan" are available for now, the others will be completed soon)
  - d. Select the exact model name on your motherboard
  - e. System will automatically download and update the BIOS.

- II. Update BIOS NOT through Internet:
  - a. Do not click "Internet Update" icon
  - b. Click "Update New BIOS"
  - c. Please select "All Files" in dialog box while opening the old file.
  - d. Please search for BIOS unzip file, downloading from internet or any other methods (such as: 6VM7-4I.F1).
  - e. Complete update process following the instruction.

#### III. Save BIOS

In the very beginning, there is "Save Current BIOS" icon shown in dialog box. It means to save the current BIOS version.

IV. Check out supported motherboard and Flash ROM:

In the very beginning, there is "About this program" icon shown in dialog box. It can help you check out which kind of motherboard and which brand of Flash ROM are supported.

#### Note:

- a. In method I, if it shows two or more motherboard's model names to be selected, please make sure your motherboard's model name again. Selecting wrong model name will cause the system unbooted.
- b. In method II, be sure that motherboard's model name in BIOS unzip file are the same as your motherboard's. Otherwise, your system won't boot.
- c. In method I, if the BIOS file you need cannot be found in @BIOS server, please go onto Gigabyte's web site for downloading and updating it according to method II.
- d. Please note that any interruption during updating will cause system unbooted

Or else you can select flash BIOS in DOS mode.

- Please check your BIOS vendor (AMI or AWARD), your motherboard name and PCB version on the motherboard.
  - 1. Format a bootable system floppy diskette by the command "format a:/s" in command mode.
  - 2. Visit the Gigabyte website at http://www.gigabyte.com.tw, Select the BIOS file you need and download it to your bootable floppy diskette.
  - 3. Insert the bootable diskette containing the BIOS file into the floppy diskette driver.
  - 4. Assuming that the floppy diskette driver is A, reboot the system by using the A: driver. At the A: > prompt, run the BIOS upgraded file by executing the Flash BIOS utility and the BIOS file with its appropriate extension.

Example: (AMI tool) (Where 6VM7-4I is name of the BIOS file name)

A:>flashxxx.exe 6VM7-4I ←

Example: (Award tool) (Where 6VM7-4I is name of the BIOS file name)

A:>Awdflash.exe 6VM7-4I ←

- Upon pressing the <Enter> key, a flash memory writer menu will appear on screen. Enter the new BIOS file name with its extension filename into the text box after file name to program.
- 6. If you want to save the old BIOS file(perform as soon as system is operational, this is recommended), select Y to DO YOU WANT TO SAVE BIOS, then type the old BIOS filename and the extension after filename to save: This option allows you to copy the contents of the flash memory chip onto a diskette, giving you a backup copy of the original motherboard BIOS in case you need to re-install it. Select N to DO YOU WANT TO SAVE BIOS, if you don't want to save the old BIOS file.
- After the decision to save the old BIOS file or not is made, select Y to ARE YOU SURE TO PROGRAM when the next menu appear; wait until a message showing Power Off or Reset the system appears. Then turn off your system.
- 8. Remove the diskette and restart your system.
- Hold down <Delete> key to enter BIOS setup. You must select "Load Fail-Safe Default" to activate the new BIOS, then you may set other item from the main menu.

## Appendix D: EasyTuneIII Utilities Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.





# Appendix E: Acronyms

Acronyms	Meaning
ACPI	Advanced Configuration and Power Interface
APM	Advanced Power Management
AGP	Accelerated Graphics Port
AMR	Audio Modem Riser
ACR	Audio Communication Riser
BIOS	Basic Input / Output System
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRM	Dual Retention Mechanism
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCD	Extended System Configuration Data
ECC	Error Checking and Correcting
EMC	Electromagnetic Compatibility
EPP	Enhanced Parallel Port
ESD	Electrostatic Discharge
FDD	Floppy Disk Device
HDD	Hard Disk Device
IDE	Integrated Dual Channel Enhanced
IRQ	Interrupt Request
I/O	Input / Output
IOAPIC	Input Output Advanced Programmable Input Controller
ISA	Industry Standard Architecture
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Interface Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System

To be continued...

Acronyms	Meaning
OFM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory
SMP	Symmetric Multi-Processing
SMI	System Management Interrupt
USB	Universal Serial Bus
VID	Voltage ID