

GA-8ICXT  
Pentium Prescott 800 Motherboard

# USER'S MANUAL

Pentium® Prescott Processor Motherboard  
Rev. 1002

## Table of Content

Revision History .....	4
Item Checklist .....	4
WARNING! .....	4
Chapter 1 Introduction .....	5
Features Summary .....	5
GA-8ICXT Motherboard Layout .....	7
Chapter 2 Hardware Installation Process .....	9
Step 1: Installing Processor and CPU Heat Sink .....	10
Step 1-1: Installing CPU .....	10
Step 1-2: Installing Heat Sink .....	11
Step 2: Install memory modules .....	12
Step 3: Install expansion cards .....	14
Step 4: Connect ribbon cables, cabinet wires, and power supply .....	15
Step 4-1 : I/O Back Panel Introduction .....	15
Step 4-2 : Connectors & Jumper Setting Introduction .....	17
Chapter 3 BIOS Setup .....	27
Main .....	29
Advanced .....	32
Memory Configuration .....	33
PCI Configuration .....	35
I/O Device Configuration .....	37
Advanced Chipset Control .....	41
Security .....	44
Server .....	46
System Management .....	47
Console Redirection .....	48
Boot .....	51
Exit .....	52

Chapter 4 Technical Reference .....	55
Block Diagram .....	55
Chapter 5 Driver Installation .....	56
A.Intel Chipset Software Installation Utilities .....	56
B.Intel Network Driver Installation .....	58
C.Intel VGA Driver Installation .....	59
D.Adaptec RAID Driver Installation .....	60
E.DirectX 9.0 Driver Installation .....	61
Chapter 6 Appendix .....	62
Acronyms .....	62

## Revision History

Revision	Revision Note	Date
1.0	Initial release of the GA-8ICXT motherboard user's manual.	Dec. 2004

## Item Checklist

- |   |  |
|---|--|
| <input checked="" type="checkbox"/> The GA-8ICXT motherboard                  | <input checked="" type="checkbox"/> Serial ATA cable x 4         |
| <input checked="" type="checkbox"/> IDE (ATA100) cable x 1 / Floppy cable x 1 | <input checked="" type="checkbox"/> COM2 cable x 1               |
| <input checked="" type="checkbox"/> CD for motherboard driver & utility       | <input checked="" type="checkbox"/> I/O Shield                   |
| <input checked="" type="checkbox"/> GA-8ICXT user's manual                    | <input checked="" type="checkbox"/> GA-8ICXT Quick Install Label |



### WARNING!

Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

1. Unplug your computer when working on the inside.
2. Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
3. Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
5. Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

### Installing the motherboard to the chassis...

If the motherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

## Chapter 1 Introduction

### Features Summary


Form Factor	<ul style="list-style-type: none"> <li>• 30.6cm x 24.4cm ATX size form factor, 6 layers PCB.</li> </ul>
CPU	<ul style="list-style-type: none"> <li>• Supports Intel® Pentium Prescott LGA 775 processor</li> <li>• Intel® Prescott LGA 775 supports 800MHz FSB</li> <li>• L2 cache on-die per processor from 1M</li> </ul>
Chipset	<ul style="list-style-type: none"> <li>• Intel® MCH E7221 Chipset</li> <li>• Intel® 6702 PXH-V</li> <li>• Intel® ICH6R</li> </ul>
Memory	<ul style="list-style-type: none"> <li>• 4 x DDR socket up to 4 GB</li> <li>• Supports Dual Channel Un-buffered DDR 333/400</li> <li>• Support 256MB, 512MB, and 1GB memory</li> <li>• Single-bit Errors Correction, Multiple-bit Errors Detection</li> </ul>
I/O Control	<ul style="list-style-type: none"> <li>• ITE IT8712F-A Super I/O</li> </ul>
Expansion Slots	<ul style="list-style-type: none"> <li>• Supports 3 PCI slots 32-Bit/33MHz (5V)</li> <li>• Supports 2 PCI-X slots 64/100MHz (3.3V)</li> <li>• Supports 1 PCI-Express X4 slot</li> </ul>
On-Board RAID	<ul style="list-style-type: none"> <li>• ICH6R</li> <li>• Supports SATA RAID 0,1</li> </ul>
On-Board Peripherals	<ul style="list-style-type: none"> <li>• 1 Floppy port supports 2 FDD with 360K, 720K, 1.2M, 1.44M and 2.88M bytes.</li> <li>• 1 Parallel port supports Normal/EPP/ECP mode</li> <li>• 1 Serial port (COM)</li> <li>• 2 x USB 2.0</li> <li>• 1 VGA Connector</li> <li>• 2 x LAN RJ45</li> </ul>
Hardware Monitor	<ul style="list-style-type: none"> <li>• CPU/Power/System Fan Revolution Detect</li> <li>• CPU shutdown when overheat</li> <li>• System Voltage Detect</li> </ul>
On-Board Video Function	<ul style="list-style-type: none"> <li>• Build in Intel MCH E7221 Chipset</li> </ul>
On-Board LAN	<ul style="list-style-type: none"> <li>• Dual Intel 82541PI Gigabit Ethernet</li> </ul>
On-Board USB 2.0	<ul style="list-style-type: none"> <li>• Built in ICH6R Chipset</li> </ul>
PS/2 Connector	<ul style="list-style-type: none"> <li>• PS/2 Keyboard interface and PS/2 Mouse interace</li> </ul>
BIOS	<ul style="list-style-type: none"> <li>• Phoenix BIOS on 8Mb flash RAM</li> </ul>

## GA-8ICXT Motherboard

---

- |                     |   |
|---------------------|---|
| Additional Features | <ul style="list-style-type: none"><li data-bbox="613 390 1143 426">• PS/2 Mouse power on under Windows Operating System</li><li data-bbox="613 426 1143 462">• External Modem wake up</li><li data-bbox="613 462 1143 497">• Supports S1, S4, S5 under Windows Operating System</li><li data-bbox="613 497 1143 533">• Wake on LAN (WOL)</li><li data-bbox="613 533 1143 569">• AC Recovery</li><li data-bbox="613 569 1143 611">• Supports Console Redirection</li></ul> |
|---------------------|---|
-

# GA-8ICXT Motherboard Layout




A.	CPU	S.	FAN2
B.	Intel E7221	T.	FAN3
C.	Intel E6702 PXH-V	U.	FAN4
D.	ICH6R	V	FAN5
E.	FDD	W.	ATX1
F.	IDE	X	ATX12V
G.	SATA1	Y.	Intel 82541PI
H.	SATA2	Z.	Intel 82541PI
I.	SATA3	1.	PCI-E
J.	SATA4	2.	PCI-X 1
K.	F_Panel	3.	PCI-X 2
L.	IPMB1	4.	PCI 1
M.	IPMB2	5.	PCI 2
N.	USB2	6.	PCI 3
O.	COM2	7.	DDR1
P.	WOR (Wake on Ring)	8.	DDR2
Q.	WOL (Wake On LAN)	9.	DDR3
R.	CPU_FAN (CPU Fan)	10.	DDR4



# Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following steps:

- Step 1- Install the Central Processing Unit (CPU)
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect ribbon cables, cabinet wires, and power supply
- Step 5- Setup BIOS software



## Step 1: Installing Processor and CPU Heat Sink

Before installing the processor and cooling fan, adhere to the following cautions:



1. The processor will overheat without the heatsink and/or fan, resulting in permanent irreparable damage.
2. Never force the processor into the socket.
3. Apply thermal grease on the processor before placing cooling fan.
4. Please make sure the CPU type is supported by the motherboard.
5. If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.

### Step1-1: Installing CPU

- Step 1 Gently lift the metal lever located on the CPU socket to the upper-right position.
- Step 2 Remove the plastic covering on the CPU socket.
- Step 3 Align the indented corner of the CPU with the triangle and gently insert the CPU into position. (Grasping the CPU firmly between your thumb and forefinger, carefully place it into the socket in a straight and downwards motion. Avoid twisting or bending motions that might cause damage to the CPU during installation.)
- Step 4 Once the CPU is properly inserted, please replace the plastic covering and push the metal lever back into its original position.
- Step 5 Close the lever, reverse step 1 & 2.



### Step1-2: Installing Heat Sink



Fig.1  
Please apply heatsink paste on the surface of the installed CPU.




Fig. 2  
( to remove the heatsink, turning the push pin along the direction of arrow; and reverse the previous step to install the heat sink.)  
Please note the direction of arrow sign on the male push pin doesn't face inwards before installation. (This instruction is only for Intel boxed fan)




Fig. 3  
Place the heatsink on top the CPU and make sure the push pins align to the pin hole on the motherboard. Push down the push pins diagonally.



Fig. 4  
Please make sure the Male and Female push pin are brought together. (for detailed installation instructions, please refer to the heatsink installation section of the user manual)



Fig. 5  
Please check the back side of teh motherboard. Make sure the push pin is seated firmly as the picture shown. Installation completed.



Fig. 6  
Attach the power connector of the heatsink to the CPU fan header located on the motherboard.


## Step 2: Install memory modules



**CAUTION** Before installing the processor and heatsink, adhere to the following warning:  
When DIMM LED is ON, do not install/remove DIMM from socket.


Please note that the DIMM module can only fit in one direction due to the one notches. Wrong orientation will cause improper installation. Please change the insert orientation.

GA-8ICXT has 4 dual inline memory module (DIMM) sockets. It supports the Dual Channel Technology. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM socket. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.



**Installation Step:**

1. The DIMM slot has a notch, so the DIMM memory module can only fit in one direction.
2. Insert the DIMM memory module vertically into the DIMM slot. Then push it down.
3. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module.
4. When installing the DIMM into the DIMM module, we recommend to populate one DIMM in Channel A module and one in Channel B module for best performance.  
Please note that each logical DIMM must be made of two identical DIMMs having the same device size on each and the same DIMM size.
5. Reverse the installation steps when you wish to remove the DIMM module.



**DDR DIMM Supported Configuration**

Technology	Configuration	# of Row Address Bits	# of Column Address Bits	# of Bank Address Bits	Page Size	Rank Size
256Mbit	16M x 16	13	9	2	4K	128MB
256Mbit	32M x 8	13	10	2	8K	256MB
512Mbit	32M x 8	13	10	2	8K	256MB
512Mbit	64M x 8	13	11	2	16K	512MB
512Mbit	64M x 8	14	10	2	8K	512MB
1Gbit	64M x 16	14	10	2	8K	512MB
1Gbit	128M x 8	14	11	2	16K	1GB
1Gbit	64M x 16	13	10	3	8K	512MB
1Gbit	128M x 8	14	10	3	8K	1GB

### Step 3: Install expansion cards

1. Read the related expansion card's instruction document before install the expansion card into the computer.
2. Remove your server's chassis cover, necessary screws and slot bracket from the computer.
3. Press the expansion card firmly into expansion slot in motherboard.
4. Be sure the metal contacts on the card are indeed seated in the slot.
5. Replace the screw to secure the slot bracket of the expansion card.
6. Replace your computer's chassis cover.
7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
8. Install related driver from the operating system.




CAUTION

Please carefully pull out the small white-drawable bar at the end of the PCI Express x 4 slot when you try to install/Uninstall the VGA card. Please align the VGA card to the onboard PCI Express x 4 slot and fully seated. Make sure your VGA card is locked by the small white-drawable bar.

# Step 4: Connect ribbon cables, cabinet wires, and power supply

## Step 4-1 : I/O Back Panel Introduction



**❶ PS/2 Keyboard and PS/2 Mouse Connector**

To install a PS/2 port keyboard and mouse, plug the mouse to the upper port (green) and the keyboard to the lower port (purple).

**❷ USB port**

Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker...etc. have a standard USB interface.

Also make sure your OS supports USB controller. If your OS does not support USB controller, please contact OS vendor for possible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

**❸/❹/❺ Parallel Port / Serial Port / VGA Port**

This connector supports 1 standard COM port and 1 Parallel port. Device like printer can be connected to Parallel port ; mouse and modem etc can be connected to Serial port.

**❻ LAN1/2 Port**


The provided Internet connection is Gigabit Ethernet, providing data transfer speeds of 10/100/1000Mbps.

**LAN1/LAN2 LED Description**

Name	Color	Condition	Description
LAN Link/Activity	Green	ON	LAN Link / no Access
	Green	BLINK	LAN Access
	-	OFF	Idle
10/100 LAN Speed	Green	ON	100Mbps connection
	-	OFF	10Mbps connection
GbE LAN Speed	Yellow	ON	1Gbps connection
	Yellow	BLINK	Port identification with 1Gbps connection
	Green	ON	100Mbps connection
	Green	BLINK	Port identification with 10 or 100Mbps connection
	-	OFF	10Mbps connection




Step 4-2 :Connectors & Jumper Setting Introduction



A) ATX1	M) WOR1
B) ATX 12V	N) WOL1
C) IDE1	O) CPU_FAN1
D) FDD1	P) FAN2
E) SATA_1	Q) FAN3
F) SATA_2	R) FAN4
G) SATA_3	S) FAN5
H) SATA_4	T) BAT1 (Battery)
I) IPMB1	U) F_Panel
J) IPMB2	V) CLR_CMOS1(CMOS Clear Jumper)
K) USB2	W) CI1 (Case Open)
L) COM2	


A) ATX (ATX Power Connector)




PIN No.	Definition
1	+3.3V
2	+3.3V
3	GND
4	+5V
5	GND
6	+5V
7	GND
8	PSON
9	5VSB
10	+12V
11	+12V
12	+3.3V
13	+3.3V
14	-12V
15	GND
16	PSON
17	GND
18	GND
19	GND
20	-5V
21	+5V
22	+5V
23	+5V
24	GND

- AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

B) ATX 12V( +12V Power Connector)





- This connector (ATX +12V) is used only for CPU1 Core Voltage.



Pin No.	Definition
1	GND
2	GND
3	GND
4	GND
5	P12V_CPU1
6	P12V_CPU1
7	P12V_CPU0
8	P12V_CPU0



### C) IDE1 Connector

Please connect first harddisk to IDE1. The red stripe of the ribbon cable must be the same side with the Pin1.




### D) FDD1 (Floppy Connector)

Please connect the floppy drive ribbon cables to FDD. It supports 360K,720K,1.2M,1.44M and 2.88Mbytes floppy disk types. The red stripe of the ribbon cable must be the same side with the Pin1.




**E / F / G / H) S\_ATA1/ 2/ 3/ 4 (Serial ATA Connectors)**


You can connect the Serial ATA device to this connector, it provides you high speed transfer rates (150MB/sec).



**I) IPMB1 (IPMB1 Connector)**





J ) IPMB2 (IPMB1 Connector)



Pin No.	Definition
1	IPMB_SDA
2	GND
3	IPMB_SCL
4	NC



K ) USB2 (Front USB Connector)

Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.




Pin No.	Definition
1	PWR1
2	GND
3	P0-
4	NC
5	P0+
6	P1+
7	NC
8	P1-
9	GND
10	PWR2

L) COM2



Pin No.	Definition
1	NDCDA2-
2	NDSRA2-
3	NSINA2
4	NRTS42-
5	NSOUTA2-
6	NCTSA2-
7	NDTRA2-
8	NRIA2-
9	NRIB-
10	NC


M) WOR1 (Wake on Ring)



Pin No.	Definition
1	Signal
2	GND

**N) WOL1 (Wake on LAN)**


This connector allows the remote servers to manage the system that installed this mainboard via your network adapter which also supports WOL.



Pin No.	Definition
1	+5V SB
2	GND
3	Signal

**O) CPU\_FAN (CPU Fan Connector)**


Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 1A .




Pin No.	Definition
1	GND
2	12V
3	Sense
4	Control

**P / Q / R / S ) FAN1/2/3/4/5 (System Fan Connectors)**

This connector allows you to link with the cooling fan on the system case to lower the system temperature.



**T ) BAT1 (Battery)**



**CAUTION**


- ❖ Danger of explosion if battery is incorrectly replaced.
- ❖ Replace only with the same or equivalent type recommended by the manufacturer.
- ❖ Dispose of used batteries according to the manufacturer's instructions.

- If you want to erase CMOS...
1. Turn OFF the computer and unplug the power cord.
  2. Remove the battery, wait for 30 second.
  3. Re-install the battery.
  4. Plug the power cord and turn ON the computer.



### U) F\_Panel1 (2X9 Pins Front Panel connector)


Please connect the power LED, PC speaker, reset switch and power switch of your chassis front panel to the F\_PANEL connector according to the pin assignment above.





Pin No	Signal Name	Description
1	HD+	Hard Disk LED anode (+)
2	HD-	Hard Disk LEDcathode(-)
3	PDY-	Power LED Signal cathode(-)
4	SPK-	Speaker connector
5	PDG-	Power LED Signal cathode(-)
6	N C	No Connect
7	PD+	Power LED anode (+)
8	N C	No Connect
9	PW-	Soft power connector cathode(-)
10	SPK+	Speaker connector anode (+)
11	PW+	Soft power connector anode (+)
12	RST+	Front Panel Reset Switch anode (+)
13	Pin Removed	N C
14	RST-	Front Panel Reset Switch cathode(-)
15	GD+	Green LED anode (+)
16	GD-	Green LED cathode(-)
17	GN+	Green Switch anode (+)
18	GN-	Green Switch cathode(-)


### V) CLR\_CMOS ( (Clear CMOS Function)

You may clear the CMOS data to its default values by this jumper.  
Default value doesn't include the "Shunter" to prevent from improper use this jumper.  
To clear CMOS, temporarily short 1-2 pin.



- 1  1-2 close: Clear CMOS
- 1  2-3 close: Normal

### W) C11 (Case Open)



1 

Pin No.	Definition
1	Signal
2	GND

---

## Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

### ENTERING SETUP

Power ON the computer and press <F2> immediately will allow you to enter Setup.

### CONTROL KEYS

<↑>	Move to previous item
<↓>	Move to next item
<←>	Move to the item in the left hand
<→>	Move to the item in the right hand
<Esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu - Exit current page and return to Main Menu
<+/PgUp>	Increase the numeric value or make changes
<-/PgDn>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F2>	Reserved
<F3>	Reserved
<F4>	Reserved
<F6>	Reserved
<F7>	Reserved
<F8>	Reserved
<F9>	Load the Optimized Defaults
<F10>	Save all the CMOS changes, only for Main Menu

## **GETTINGHELP**

### **Main Menu**

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

### **Status Page Setup Menu / Option Page Setup Menu**

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

- **Main**  
This setup page includes all the items in standard compatible BIOS.
- **Advanced**  
This setup page includes all the items of AMI special enhanced features.  
(ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)
- **Security**  
Change, set, or disable password. It allows you to limit access the system and setup.
- **Server**  
Server additional features enabled/disabled setup menus.
- **Boot**  
This setup page include all the items of first boot function features.
- **Exit**  
There are five options in this selection: Exit Saving Changes, Exit Discarding Changes, Load Optimal Defaults, Load Failsafe Defaults, and Discard Changes.

## Main

Once you enter Phoenix BIOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.




Figure 1: Main

### System Time

The time is calculated based on the 24-hour military time clock. Set the System Time (HH:MM:SS)

### System Date

Set the System Date. Note that the "Day" automatically changed after you set the date.  
(Weekend: DD: MM: YY) (YY: 1099-2099)

### ☞ Legacy Diskette A

This category identifies the type of floppy disk drive A that has been installed in the computer.

- ▶ Disabled                    Disable this device.
- ▶ 360KB, 5<sup>1</sup>/<sub>4</sub> in.            3<sup>1</sup>/<sub>2</sub> inch AT-type high-density drive; 360K byte capacity
- ▶ 1.2MB, 3<sup>1</sup>/<sub>2</sub> in.            3<sup>1</sup>/<sub>2</sub> inch AT-type high-density drive; 1.2M byte capacity
- ▶ 720K, 3<sup>1</sup>/<sub>2</sub> in.            3<sup>1</sup>/<sub>2</sub> inch double-sided drive; 720K byte capacity
- ▶ 1.44M, 3<sup>1</sup>/<sub>2</sub> in.            3<sup>1</sup>/<sub>2</sub> inch double-sided drive; 1.44M byte capacity.
- ▶ 2.88M, 3<sup>1</sup>/<sub>2</sub> in.            3<sup>1</sup>/<sub>2</sub> inch double-sided drive; 2.88M byte capacity.

☞ **Note:** The 1.25MB,3<sup>1</sup>/<sub>2</sub> reference a 1024 byte/sector Japanese media format. The 1.25MB,3<sup>1</sup>/<sub>2</sub> diskette requires 3-Mode floppy-disk drive.

### ☞ Hard Disk Pre-Delay

This item provides function for user to add a delay before the first access of a hard disk by BIOS. Some hard disks hang if accessed before they have initialized themselves. The delay ensures the hard disk initialized after powering up, prior to being accessed.

- ▶ Options                    Disabled, 3 Seconds, 6 Seconds, 9 Seconds, 12 Seconds, 21 Seconds, 30Seconds. Default vaule is **Disabled**.

### ☞ IDE Primary Master, Slave / Secondary Master, Slave, Parallel ATA

The category identifies the types of hard disk from drive C to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

**» TYPE**

1-39: Predefined types.

Users: Set parameters by User.

Auto: Set parameters automatically. (Default Vaules)

CD-ROM: Use for ATAPI CD-ROM drives or double click [Auto] to set all HDD parameters automatically.

ATAPI Removable: Removable disk drive is installed here.

**» Multi-Sector Transfer**

This field displays the information of Multi-Sector Transfer Mode.

Disabled: The data transfer from and to the device occurs one sector at a time.

Auto: The data transfer from and to the device occurs multiple sectors at a time if the device supports it.

- » LBA Mode**            This field shows if the device type in the specific IDE channel support LBA Mode.
- » 32-Bit I/O**            Enable this function to max imize the IDE data transfer rate.
- » Transfer Mode**        This field shows the information of Teansfer Mode.
- » Ultra DMA Mode**      This filed displays the DMA mode of the device in the specific IDE channel.

**☞ Advanced Processor Option**

This category includes the information of CPU Speed, Processor ID, Processor L2 Cache.

**☞ Hyper Threading Technology**

- » Enabled**                Enables Hyper-Threading Technology Feature when using Windows XP and Linux 2.4x operating systems that are optimized for Hyper-Threading technology. (Default value)
- » Disabled**              Disables Hyper-Threading Technology when using other operating systems.

## Advanced

### About This Section: Advanced

With this section, allowing user to configure your system for basic operation. User can change the processor options, chipset configuration, PCI configuration and chipset control.




Figure 2: Advanced



## Memory Configuration

PhoenixBIOS Setup Utility		
Advanced		
Memory Configuration		Item Specific Help
System Memory	624KB	
Extended Memory	251904KB	
DIMM Group #1 Status	256MB	
DIMM Group #2 Status	Not Installed	
DIMM Group #3 Status	Not Installed	
DIMM Group #4 Status	Not Installed	
Clear Mem. ECC Error Info.	[No]	
Extend RAM Step:	[Disabled]	
F1: Help	↑↓: Select Item	+ -: Change Values
Esc: Exit	←→: Select Menu	Enter: Select ▶ Sub-Menu
		F5: Setup Defaults
		F10: Save&Exit

Figure 2-1: Memory Configuration

### ☞ **System Memory/Extended Memory/DIMM Group 1,2,3,4 Status**

These category is display-only which is determined by POST (Power On Self Test) of the BIOS.

### ☞ **Clear Mem. ECC Error Info**

- ▶▶ Yes                      Select 'Yes', system will clear the memory error status.
- ▶▶ No                        Disable this function. (Default value)

### ☞ **Extend RAM Step**

- ▶▶ Enabled                 Enable test extended memroy process.
- ▶▶ Disabled                Disable this function. (Default value)

## PCI Configuration




Figure 2-2: PCI Configuration

### Embedded Video Controller

#### ▶ Onboard VGA Control

- ▶ Enabled            Enable onboard VGA device. (Default value)
- ▶ Disabled            Disable this function.

#### ▶ Pre-Allocated Memory Size

Select the amount of pre-allocated graphics memory for use by the Internal Graphics Device.

- ▶ Options            1MB, 8MB. Default value is 8MB.

### ☞ **EmbeddedNIC#1**

#### ▶ **Onboard LAN1/ Control**

- ▶▶ Enabled                    Enable onboard LAN1 device. (Default value)
- ▶▶ Disabled                    Disable this function.

#### ▶ **Option ROM Scan**

- ▶▶ Enabled                    Enableing this item to initialize device expansion ROM.
- ▶▶ Disabled                    Disable this function. (Default value)

### ☞ **EmbeddedNIC#2**

#### ▶ **Onboard LAN2/ Control**

- ▶▶ Enabled                    Enable onboard LAN2 device. (Default value)
- ▶▶ Disabled                    Disable this function.

#### ▶ **Option ROM Scan**

- ▶▶ Enabled                    Enableing this item to initialize device expansion ROM.
- ▶▶ Disabled                    Disable this function. (Default value)

### ☞ **PCI Slot 1/2/3/4/5 Option ROM**

- ▶▶ Enabled                    Enableing this item to initialize device expansion ROM.  
(Default value)
- ▶▶ Disabled                    Disable this function.

## I/O Device Configuration

PhoenixBIOS Setup Utility		
Advanced		
I/O Device Configuration		Item Specific Help
Serial port A:	[Disabled]	Configure serial port A using options:
Serial port B:	[Disabled]	[Disabled]
Parallel port:	[Disabled]	No configuration
PS/2 Mouse	[Enabled]	[Enabled]
		User configuration
USB Controller:	[Enabled]	
USB 2.0 Controller	[Enabled]	
Legacy USB Support:	[Enabled]	
Serial ATA:	[Enabled]	
Native Mode Operation:	[Auto]	
SATA Controller Mode Option:	[Compatible]	

F1	Help	↑/↓	Select Item	-/+	Change Values	F9	Setup Defaults
Esc	Exit	<	Select Menu	Enter	Select > Sub-Menu	F10	Save and Exit

Figure 2-3: I/O Device Configuration

### Serial Port A

This allows users to configure serial port A by using this option.

- ▶▶ Disabled      Disable the configuration.
- ▶▶ Enabled      Enable the configuration (Default value)

### Serial Port B

This allows users to configure serial port B by using this option.

- ▶▶ Disabled      Disable the configuration.
- ▶▶ Enabled      Enable the configuration (Default value)

### Parallel Port

This allows users to configure parallel port by using this option.

- ▶▶ Disabled      Disable the configuration.
- ▶▶ Enabled      Enable the configuration. (Default value)

### PS/2 Mouse

Set this option 'Enabled' to allow BIOS support for a PS/2 - type mouse.

- ▶▶ Enabled      'Enabled' forces the PS/2 mouse port to be enabled regardless if a mouse is present. (Default value)
- ▶▶ Disabled      'Disabled' prevents any installed PS/2 mouse from functioning, but frees up IRQ12.

### USB Controller

This item allows users to enable or disable the USB device by setting item to the desired value.

- ▶▶ Enabled      Enable USB controller. (Default value)
- ▶▶ Options      Disable this function.

---

### ☞ USB 2.0 Controller

This item allows users to enable or disable the USB 2.0 device by setting item to the desired value.

- ▶▶ Enabled            Enable USB 2.0 controller. (Default value)
- ▶▶ Options            Disbale this function.

### ☞ Legacy USB Support

This option allows user to function support for legacy USB.

- ▶▶ Enabled            Enables support for legacy USB (Default Value)
- ▶▶ Disabled           Disables support for legacy USB

### ☞ Serial ATA

- ▶▶ Enabled            Enables on-board serial ATA function. (Default Value)
- ▶▶ Disabled           Disables on-board serial ATA function.

#### ▶ Native Mode Operation

This option allows user to set the native mode for Serial ATA function.

- ▶▶ Auto                Auto detected. (Default value)
- ▶▶ Serial ATA        Set Native mode to Serial ATA.

#### ▶ SATA Controller Mode Option

- ▶▶ Compatible Mode            SATA and PATA drives are auto-detected and placed in Legacy mode. (Default value)
- ▶▶ Enhanced (non-AHCI) Mode    SATA and PATA drives are auto-detected and placed in Native mode.

**Note:** Pre-Win2000 operating system do not work in Enhanced mode.

▶ **SATA AHCI Enable**

▶▶ Enabled      Set this item to enable SATA AHCI function for WinXP-SP1+IAA driver supports AHCI mode.

▶▶ Disabled      Disabled this function.

▶ **SATA RAID Enable**

▶▶ Enabled      Enabled SATA RAID function.

▶▶ Disabled      Disable this function.



## Advanced Chipset Control




Figure 2-4: Advanced Chipset Control

### ☞ Wake On LAN / PME

This option allow user to determine the action of the system when a LAN/PME wake up event occurs.

- ▶▶ Enabled Enable Wake On LAN/PME. (Default value)
- ▶▶ Disabled Disable this function.

**Note:** This item must enabled if you're running under Windows operating system.

### ☞ **Wake On Ring**

This option allow user to determine the action of the system power is off and the modem is ringing.

- ▶▶ Enabled            Enable Wake On Ring. (Default value)
- ▶▶ Disabled            Disable this function.

**Note:** This item must enabled if you're running under Windows operating system.

### ☞ **Wake On RTC Alarm**

You can set "RTC Alarm Resume" item to enabled and key in Data/time to power on system.

- ▶▶ Enabled            Enable alarm function to POWER ON system. (Default value)
- ▶▶ Disabled            Disable this function.

**Note:** This item must enabled if you're running under Windows operating system.

### ☞ **Reset Configuration Data**

- ▶▶ Yes            Reset all configuration data.
- ▶▶ No            Do not make any changes. (Default value)

### ☞ **NumLock**

This option allows user to select power-on state for NumLock.

- ▶▶ On            Enable NumLock.
- ▶▶ Off            Disable this function.

**Memory Processor Error**

When Boot is selected, the system will attempt to boot after a memory or processor error occurred.

- ▶▶ Boot            System attempts to boot if a memory or processor error occurred. (Default)
- ▶▶ Halt            System will stop if an error is detected during power up.

**Multiprocessor Specification**

This option allows user to configure the multiprocessor(MP) specification revision level. Some operating system will require 1.1 for compatibility reasons.

- ▶▶ 1.4            Support MPS Version 1.4 . (Default)
- ▶▶ 1.1            Support MPS Version 1.1.

**Note:** Please Select 1.1 if your install NT4.0 with Prescott CPU.

## Security




Figure 3: Security

### 🔑 About This Section: Security

In this section, user can set either supervisor or user passwords, or both for different level of password securities. In addition, user also can set the virus protection for boot sector.

#### 🔑 Set Supervisor Password

You can install and change this options for the setup menus. Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password or press <Enter> key to disable this option.

**☞ Set User Password**

You can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password.

**☞ Password on boot**

Password entering will be required when system on boot.

- ▶▶ Enabled      Requires entering password when system on boot.
- ▶▶ Disabled     Disable this function. (Default value)

**☞ Fixed disk boot sector**

- ▶▶ Write Protect   Write protects boot sector on harddisk to protect against virus.
- ▶▶ Normal          Set the fixed disk boot sector at Normal state. (Default value)

**☞ Diskette access**

Control access to diskette drives.

- ▶▶ User            Requires user's password to access floppy drives.
- ▶▶ Supervisor    Requires supervisor's password to access floppy drives. (Default value)

## Server




Figure 4: Server

## System Management




Figure 4-1: System Management

### Server Management

This category allows user to view the server management features. Including information of **BIOS Version**. All items in this menu cannot be modified in user's mode. If any items require changes, please consult your system supervisor.

## Console Redirection




Figure 4-2: Console Redirection

### ☞ BIOS Redirection Port

If this option is set to enabled, it will use a port on the motherboard.

- ▶▶ On-board COMA    Use COMA as the COM port address.
- ▶▶ Disabled    Disable this function. (Default value)

### ☞ Baud Rate

This option allows user to set the specified baud rate.

- ▶▶ Options    300, 1200, 2400, 9600, 19.2K, 38.4K, 57.6K, 115.2K.



---

**☞ Terminal Type**

This option allows user to select the specified terminal type. This is defined by IEEE.

- ▶▶ Options                      VT100, VT100 8bit, PC-ANSI 7bit, VT100+, VT-UTF8

**☞ Flow Control**

This option provide user to enable the flow control function.

- ▶▶ None                          Not supported.
- ▶▶ XON/OFF                      Software control.
- ▶▶ CTS/RTS                      Hardware control. (Default value)

**☞ Console Connect**

This field indicates whether the console is connected directly to the system or a modem is used to connect.

- ▶▶ Direct                          Console is connected directly to the system. (Default)
- ▶▶ Disabled                      Console is connected via the modem.

**☞ Continue C.R. after POST**

This option allows user to enable console redirection after O.S has loaded.

- ▶▶ On                              Enable console redirection after O.S has loaded.
- ▶▶ Off                              Disable this function. (Default value)

#### **Assert NMI on SERR**

If this option is set to enabled, PCI bus system error (SERR) is enabled and is routed to NMI.

- ▶▶ Enabled            Enable Assert NMI on SERR. (Default value)
- ▶▶ Disabled            Disable this function.

#### **Post Error Pause**

If this item is set to enabled, the system will wait for user intervention on critical POST errors. If this item is disabled, the system will boot with no intervention if possible.

- ▶▶ Enabled            Enable Post Error Pause. (Default value)
- ▶▶ Disabled            Disable this function.

#### **AC-LINK**

This option provides user to set the mode of operation if an AC / power loss occurs.

- ▶▶ Power On        System power state when AC cord is re-plugged.
- ▶▶ Stay Off        Do not power on system when AC power is back.
- ▶▶ Last State        Set system to the last state when AC power is removed. Do not power on system when AC power is back. (Default value)

## Boot




Figure 5: Boot

### 🔔 About This Section: Boot

The “Boot” menu allows user to select among four possible types of boot devices listed using the up and down arrow keys. By applying <+> and <Space> key, you can promote devices and by using the <-> key, you can demote devices. Promotion or demotion of devices alerts the priority that the system uses to search for boot device on system power on.

### 🔗 Boot Device Priority

#### ▶ Removable Device / Hard Drive / CD-ROM Drive/

These three fields determines which type of device the system attempt to boot from after **PhoenixBIOS Post** completed. Specifies the boot sequence from the available devices. If the first device is not a bootable device, the system will seek for next available device.

## Exit




Figure 6: Exit

### ⚡ About This Section: Exit

Once you have changed all of the set values in the BIOS setup, you should save your changes and exit BIOS setup program. Select "Exit" from the menu bar, to display the following sub-menu.

- ☛ Exit Saving Changes
- ☛ Exit Discarding Changes
- ☛ Load Setup Default
- ☛ Discard Change
- ☛ Save Changes


**Exit Saving Changes**

This option allows user to exit system setup with saving the changes.

Press <Enter> on this item to ask for the following confirmation message:

Pressing 'Y' to store all the present setting values the user made in this time into CMOS.


Therefore, when you boot up your computer next time, the BIOS will re-configure your system according to data in CMOS.

**Exit Discarding Changes**

This option allows user to exit system setup without changing any previous settings values in CMOS. The previous selection remains in effect.


This will exit the Setup Utility and restart your computer when selecting this option.

Press <Enter> on this item to ask for confirmation message.

**Load Setup Default**

This option allows user to load default values for all setup items.


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



**☞ Discard Changes**

This option allows user to load previous values from CMOS for all setup item.


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



**☞ Save Changes**

This option allows user to save setup data to CMOS.


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:



Press [Yes] to save setup data to CMOS.

# Chapter 4 Technical Reference

## Block Diagram



## Chapter 5 Driver Installation

### A. Intel Chipset Software Installation Utilities

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

Installation Procedures:


1. The CD auto run program starts, **Double click** on "Intel Chipset Software Installation Utilities" to start the installation.
2. Then, a series of installation wizards appear. Follow up the wizards to install the drivers.
3. Setup completed, click "Finish" to restart your computer.

#### Auto Run windows




(1)

#### Setup Wizard




(2)

#### License Agreement



(3)


#### Readme Information



(4)



Installation Completed



(5)

## B. Intel Network Driver Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

### Installation Procedures:

1. The CD auto run program starts, **Double click** on "Intel Network Driver" to start the installation.
2. **RK\_EM64T** folder contains LAN driver for Windows 64 Bit operating system, **RK2\_Gold** folder contains other available operating systems.
3. Follow up a series of installation wizards to install the drivers.

### Auto Run windows



(1)

### Intel Network Drivers




(2)

### C. Intel VGA Driver Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

#### Installation Procedures:

1. The CD auto run program starts, **Double click** on "Intel VGA Driver" to start the installation.
2. Then, a series of installation wizards appear. Follow up the wizards to install the drivers.
3. Setup completed, click "Finish" to restart your computer.

 **Please note: The driver does not support Windows XP operating system.**

Auto Run windows




(1)

Intel E7221 Graphic Installer Software




(2)

License Agreement



(3)

Installation Completed



(4)

## D. Adaptec RAID Driver Installation

### Installation Procedures:


1. The CD auto run program starts, Double click on "Adaptec RAID Driver" to start the installation.
2. Double click "Driver" folder.
3. Refer to your operating system, select the desired folder to install the RAID driver.
4. Copy the folder to a floppy diskette. When installing, insert the diskette into floppy drive.

Note: User must enable "SATA RAID" function in the BIOS setup menu before installing Adaptec RAID driver.

### Auto Run windows



(1)



(2)

### RAID Driver Operating System Selection



(3)

## E. DirectX 9.0 Driver Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

### Installation Procedures:

1. The CD auto run program starts, **Double** click on "Directx9.0" to start the installation.
2. Then, a series of installation wizards appear. Follow up the wizards to install the drivers.
3. Setup completed, click "Finish" to restart your computer.

#### Auto Run windows




(1)

#### License Agreement




(2)

#### Starting Installaiton



(3)

#### Installaiton Wizard completed



(4)

## Chapter 6 Appendix

### Acronyms

Acronyms	Meaning
ACPI	Advanced Configuration and Power Interface
APM	Advanced Power Management
AGP	Accelerated Graphics Port
AMR	Audio Modem Riser
ACR	Advanced Communications Riser
BBS	BIOS Boot Specification
BIOS	Basic Input / Output System
CPU	Central Processing Unit
CMOS	Complementary Metal Oxide Semiconductor
CRIMM	Continuity RIMM
CNR	Communication and Networking Riser
DMA	Direct Memory Access
DMI	Desktop Management Interface
DIMM	Dual Inline Memory Module
DRM	Dual Retention Mechanism
DRAM	Dynamic Random Access Memory
DDR	Double Data Rate
ECP	Extended Capabilities Port
ESCD	Extended System Configuration Data
ECC	Error Checking and Correcting
EMC	Electromagnetic Compatibility
EPP	Enhanced Parallel Port
ESD	Electrostatic Discharge
FDD	Floppy Disk Device
FSB	Front Side Bus
HDD	Hard Disk Device
IDE	Integrated Dual Channel Enhanced
IRQ	Interrupt Request

---

Acronyms	Meaning
I/O	Input / Output
IOAPIC	Input Output Advanced Programmable Input Controller
ISA	Industry Standard Architecture
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Instrument Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System
OEM	Original Equipment Manufacturer
PAC	PCI A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory
SMP	Symmetric Multi-Processing
SMI	System Management Interrupt
USB	Universal Serial Bus
VID	Voltage ID

---